

GE Fanuc Automation

Computer Numerical Control Products

Series 21i / 210i – Model A for Machining Center

Operator's Manual

GFZ-63094EN/01 April 1997

Warnings, Cautions, and Notes as Used in this Publication

Warning

Warning notices are used in this publication to emphasize that hazardous voltages, currents, temperatures, or other conditions that could cause personal injury exist in this equipment or may be associated with its use.

In situations where inattention could cause either personal injury or damage to equipment, a Warning notice is used.

Caution

Caution notices are used where equipment might be damaged if care is not taken.

Note

Notes merely call attention to information that is especially significant to understanding and operating the equipment.

This document is based on information available at the time of its publication. While efforts have been made to be accurate, the information contained herein does not purport to cover all details or variations in hardware or software, nor to provide for every possible contingency in connection with installation, operation, or maintenance. Features may be described herein which are not present in all hardware and software systems. GE Fanuc Automation assumes no obligation of notice to holders of this document with respect to changes subsequently made.

GE Fanuc Automation makes no representation or warranty, expressed, implied, or statutory with respect to, and assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of the information contained herein. No warranties of merchantability or fitness for purpose shall apply.

SAFETY PRECAUTIONS

This section describes the safety precautions related to the use of CNC units. It is essential that these precautions be observed by users to ensure the safe operation of machines equipped with a CNC unit (all descriptions in this section assume this configuration). Note that some precautions are related only to specific functions, and thus may not be applicable to certain CNC units.

Users must also observe the safety precautions related to the machine, as described in the relevant manual supplied by the machine tool builder. Before attempting to operate the machine or create a program to control the operation of the machine, the operator must become fully familiar with the contents of this manual and relevant manual supplied by the machine tool builder.

Contents

1.	DEFINITION OF WARNING, CAUTION, AND NOTE	s-2
2.	GENERAL WARNINGS AND CAUTIONS	s–3
3.	WARNINGS AND CAUTIONS RELATED TO PROGRAMMING	s-5
4.	WARNINGS AND CAUTIONS RELATED TO HANDLING	s-7
5.	WARNINGS RELATED TO DAILY MAINTENANCE	s-9

1

DEFINITION OF WARNING, CAUTION, AND NOTE

This manual includes safety precautions for protecting the user and preventing damage to the machine. Precautions are classified into Warning and Caution according to their bearing on safety. Also, supplementary information is described as a Note. Read the Warning, Caution, and Note thoroughly before attempting to use the machine.

WARNING

Applied when there is a danger of the user being injured or when there is a damage of both the user being injured and the equipment being damaged if the approved procedure is not observed.

CAUTION

Applied when there is a danger of the equipment being damaged, if the approved procedure is not observed.

NOTE

The Note is used to indicate supplementary information other than Warning and Caution.

• Read this manual carefully, and store it in a safe place.

2

GENERAL WARNINGS AND CAUTIONS

WARNING

- 1. Never attempt to machine a workpiece without first checking the operation of the machine. Before starting a production run, ensure that the machine is operating correctly by performing a trial run using, for example, the single block, feedrate override, or machine lock function or by operating the machine with neither a tool nor workpiece mounted. Failure to confirm the correct operation of the machine may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **2.** Before operating the machine, thoroughly check the entered data. Operating the machine with incorrectly specified data may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **3.** Ensure that the specified feedrate is appropriate for the intended operation. Generally, for each machine, there is a maximum allowable feedrate. The appropriate feedrate varies with the intended operation. Refer to the manual provided with the machine to determine the maximum allowable feedrate. If a machine is run at other than the correct speed, it may behave unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **4.** When using a tool compensation function, thoroughly check the direction and amount of compensation.
 - Operating the machine with incorrectly specified data may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- **5.** The parameters for the CNC and PMC are factory—set. Usually, there is not need to change them. When, however, there is not alternative other than to change a parameter, ensure that you fully understand the function of the parameter before making any change. Failure to set a parameter correctly may result in the machine behaving unexpectedly, possibly causing damage to the workpiece and/or machine itself, or injury to the user.
- 6. Immediately after switching on the power, do not touch any of the keys on the MDI panel until the position display or alarm screen appears on the CNC unit.
 Some of the keys on the MDI panel are dedicated to maintenance or other special operations.
 Pressing any of these keys may place the CNC unit in other than its normal state. Starting the machine in this state may cause it to behave unexpectedly.
- 7. The operator's manual and programming manual supplied with a CNC unit provide an overall description of the machine's functions, including any optional functions. Note that the optional functions will vary from one machine model to another. Therefore, some functions described in the manuals may not actually be available for a particular model. Check the specification of the machine if in doubt.

WARNING

8. Some functions may have been implemented at the request of the machine—tool builder. When using such functions, refer to the manual supplied by the machine—tool builder for details of their use and any related cautions.

NOTE

Programs, parameters, and macro variables are stored in nonvolatile memory in the CNC unit. Usually, they are retained even if the power is turned off. Such data may be deleted inadvertently, however, or it may prove necessary to delete all data from nonvolatile memory as part of error recovery.

To guard against the occurrence of the above, and assure quick restoration of deleted data, backup all vital data, and keep the backup copy in a safe place.

3

WARNINGS AND CAUTIONS RELATED TO PROGRAMMING

This section covers the major safety precautions related to programming. Before attempting to perform programming, read the supplied operator's manual and programming manual carefully such that you are fully familiar with their contents.

WARNING

1. Coordinate system setting

If a coordinate system is established incorrectly, the machine may behave unexpectedly as a result of the program issuing an otherwise valid move command.

Such an unexpected operation may damage the tool, the machine itself, the workpiece, or cause injury to the user.

2. Positioning by nonlinear interpolation

When performing positioning by nonlinear interpolation (positioning by nonlinear movement between the start and end points), the tool path must be carefully confirmed before performing programming.

Positioning involves rapid traverse. If the tool collides with the workpiece, it may damage the tool, the machine itself, the workpiece, or cause injury to the user.

3. Function involving a rotation axis

When programming polar coordinate interpolation or normal—direction (perpendicular) control, pay careful attention to the speed of the rotation axis. Incorrect programming may result in the rotation axis speed becoming excessively high, such that centrifugal force causes the chuck to lose its grip on the workpiece if the latter is not mounted securely.

Such mishap is likely to damage the tool, the machine itself, the workpiece, or cause injury to the user.

4. Inch/metric conversion

Switching between inch and metric inputs does not convert the measurement units of data such as the workpiece origin offset, parameter, and current position. Before starting the machine, therefore, determine which measurement units are being used. Attempting to perform an operation with invalid data specified may damage the tool, the machine itself, the workpiece, or cause injury to the user.

5. Constant surface speed control

When an axis subject to constant surface speed control approaches the origin of the workpiece coordinate system, the spindle speed may become excessively high. Therefore, it is necessary to specify a maximum allowable speed. Specifying the maximum allowable speed incorrectly may damage the tool, the machine itself, the workpiece, or cause injury to the user.

WARNING

6. Stroke check

After switching on the power, perform a manual reference position return as required. Stroke check is not possible before manual reference position return is performed. Note that when stroke check is disabled, an alarm is not issued even if a stroke limit is exceeded, possibly damaging the tool, the machine itself, the workpiece, or causing injury to the user.

7. Tool post interference check

A tool post interference check is performed based on the tool data specified during automatic operation. If the tool specification does not match the tool actually being used, the interference check cannot be made correctly, possibly damaging the tool or the machine itself, or causing injury to the user.

After switching on the power, or after selecting a tool post manually, always start automatic operation and specify the tool number of the tool to be used.

8. Absolute/incremental mode

If a program created with absolute values is run in incremental mode, or vice versa, the machine may behave unexpectedly.

9. Plane selection

If an incorrect plane is specified for circular interpolation, helical interpolation, or a canned cycle, the machine may behave unexpectedly. Refer to the descriptions of the respective functions for details.

10. Torque limit skip

Before attempting a torque limit skip, apply the torque limit. If a torque limit skip is specified without the torque limit actually being applied, a move command will be executed without performing a skip.

11. Programmable mirror image

Note that programmed operations vary considerably when a programmable mirror image is enabled.

12. Compensation function

If a command based on the machine coordinate system or a reference position return command is issued in compensation function mode, compensation is temporarily canceled, resulting in the unexpected behavior of the machine.

Before issuing any of the above commands, therefore, always cancel compensation function mode.



WARNINGS AND CAUTIONS RELATED TO HANDLING

This section presents safety precautions related to the handling of machine tools. Before attempting to operate your machine, read the supplied operator's manual and programming manual carefully, such that you are fully familiar with their contents.

WARNING

1. Manual operation

When operating the machine manually, determine the current position of the tool and workpiece, and ensure that the movement axis, direction, and feedrate have been specified correctly. Incorrect operation of the machine may damage the tool, the machine itself, the workpiece, or cause injury to the operator.

2. Manual reference position return

After switching on the power, perform manual reference position return as required. If the machine is operated without first performing manual reference position return, it may behave unexpectedly. Stroke check is not possible before manual reference position return is performed. An unexpected operation of the machine may damage the tool, the machine itself, the workpiece, or cause injury to the user.

3. Manual numeric command

When issuing a manual numeric command, determine the current position of the tool and workpiece, and ensure that the movement axis, direction, and command have been specified correctly, and that the entered values are valid.

Attempting to operate the machine with an invalid command specified may damage the tool, the machine itself, the workpiece, or cause injury to the operator.

4. Manual handle feed

In manual handle feed, rotating the handle with a large scale factor, such as 100, applied causes the tool and table to move rapidly. Careless handling may damage the tool and/or machine, or cause injury to the user.

5. Disabled override

If override is disabled (according to the specification in a macro variable) during threading, rigid tapping, or other tapping, the speed cannot be predicted, possibly damaging the tool, the machine itself, the workpiece, or causing injury to the operator.

6. Origin/preset operation

Basically, never attempt an origin/preset operation when the machine is operating under the control of a program. Otherwise, the machine may behave unexpectedly, possibly damaging the tool, the machine itself, the tool, or causing injury to the user.

WARNING

7. Workpiece coordinate system shift

Manual intervention, machine lock, or mirror imaging may shift the workpiece coordinate system. Before attempting to operate the machine under the control of a program, confirm the coordinate system carefully.

If the machine is operated under the control of a program without making allowances for any shift in the workpiece coordinate system, the machine may behave unexpectedly, possibly damaging the tool, the machine itself, the workpiece, or causing injury to the operator.

8. Software operator's panel and menu switches

Using the software operator's panel and menu switches, in combination with the MDI panel, it is possible to specify operations not supported by the machine operator's panel, such as mode change, override value change, and jog feed commands.

Note, however, that if the MDI panel keys are operated inadvertently, the machine may behave unexpectedly, possibly damaging the tool, the machine itself, the workpiece, or causing injury to the user.

9. Manual intervention

If manual intervention is performed during programmed operation of the machine, the tool path may vary when the machine is restarted. Before restarting the machine after manual intervention, therefore, confirm the settings of the manual absolute switches, parameters, and absolute/incremental command mode.

10. Feed hold, override, and single block

The feed hold, feedrate override, and single block functions can be disabled using custom macro system variable #3004. Be careful when operating the machine in this case.

11. Dry run

Usually, a dry run is used to confirm the operation of the machine. During a dry run, the machine operates at dry run speed, which differs from the corresponding programmed feedrate. Note that the dry run speed may sometimes be higher than the programmed feed rate.

12. Cutter and tool nose radius compensation in MDI mode

Pay careful attention to a tool path specified by a command in MDI mode, because cutter or tool nose radius compensation is not applied. When a command is entered from the MDI to interrupt in automatic operation in cutter or tool nose radius compensation mode, pay particular attention to the tool path when automatic operation is subsequently resumed. Refer to the descriptions of the corresponding functions for details.

13. Program editing

If the machine is stopped, after which the machining program is edited (modification, insertion, or deletion), the machine may behave unexpectedly if machining is resumed under the control of that program. Basically, do not modify, insert, or delete commands from a machining program while it is in use.

5

WARNINGS RELATED TO DAILY MAINTENANCE

WARNING

1. Memory backup battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) turned on, and apply an emergency stop to the machine. Because this work is performed with the power on and the cabinet open, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing the batteries, be careful not to touch the high–voltage circuits (marked \(\begin{align*} \lambda \) and fitted with an insulating cover).

Touching the uncovered high-voltage circuits presents an extremely dangerous electric shock hazard.

NOTE

The CNC uses batteries to preserve the contents of its memory, because it must retain data such as programs, offsets, and parameters even while external power is not applied.

If the battery voltage drops, a low battery voltage alarm is displayed on the machine operator's panel or screen

When a low battery voltage alarm is displayed, replace the batteries within a week. Otherwise, the contents of the CNC's memory will be lost.

Refer to the maintenance section of the operator's manual or programming manual for details of the battery replacement procedure.

WARNING

2. Absolute pulse coder battery replacement

When replacing the memory backup batteries, keep the power to the machine (CNC) turned on, and apply an emergency stop to the machine. Because this work is performed with the power on and the cabinet open, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing the batteries, be careful not to touch the high–voltage circuits (marked \(\triangle \) and fitted with an insulating cover).

Touching the uncovered high-voltage circuits presents an extremely dangerous electric shock hazard.

NOTE

The absolute pulse coder uses batteries to preserve its absolute position.

If the battery voltage drops, a low battery voltage alarm is displayed on the machine operator's panel or screen.

When a low battery voltage alarm is displayed, replace the batteries within a week. Otherwise, the absolute position data held by the pulse coder will be lost.

Refer to the maintenance section of the operator's manual or programming manual for details of the battery replacement procedure.

WARNING

3. Fuse replacement

For some units, the chapter covering daily maintenance in the operator's manual or programming manual describes the fuse replacement procedure.

Before replacing a blown fuse, however, it is necessary to locate and remove the cause of the blown fuse.

For this reason, only those personnel who have received approved safety and maintenance training may perform this work.

When replacing a fuse with the cabinet open, be careful not to touch the high-voltage circuits (marked \triangle and fitted with an insulating cover).

Touching an uncovered high-voltage circuit presents an extremely dangerous electric shock hazard.

Table of Contents

SA	FETY PR	ECAUTIONS	S–1
ı.	GENER	AL	
1. (GENERAL		3
		GENERAL FLOW OF OPERATION OF CNC MACHINE TOOL	
		NOTES ON READING THIS MANUAL	
II.	PROGE	RAMMING	
1. (GENERAL		. 11
	1.1	TOOL MOVEMENT ALONG WORKPIECE PARTS FIGURE-INTERPOLATION	12
		FEED-FEED FUNCTION	
		PART DRAWING AND TOOL MOVEMENT	
	1.3.		
	1.3.2	_	
	1.3.3		
	1.4	Incremental Commands	
		CUTTING SPEED – SPINDLE SPEED FUNCTION	
		SELECTION OF TOOL USED FOR VARIOUS MACHINING – TOOL FUNCTION COMMAND FOR MACHINE OPERATIONS – MISCELLANEOUS FUNCTION	
		PROGRAM CONFIGURATION	
		TOOL FIGURE AND TOOL MOTION BY PROGRAM	
		TOOL MOVEMENT RANGE – STROKE	
2. (CONTROL	LED AXES	. 28
		CONTROLLED AXES	
		AXIS NAME	
		INCREMENT SYSTEM	
		MAXIMUM STROKE	
3. F	PREPARA	TORY FUNCTION (G FUNCTION)	. 31
4. I	NIERPOI	LATION FUNCTIONS	. 36
	4.1	POSITIONING (G00)	37
		SINGLE DIRECTION POSITIONING (G60)	
		LINEAR INTERPOLATION (G01)	
		CIRCULAR INTERPOLATION (G02,G03)	
		HELICAL INTERPOLATION (G02,G03)	
		CYLINDRICAL INTERPOLATION (G07.1)	
		THREAD CUTTING (G33)	
		SKIP FUNCTION (G31)	
	49	HIGH SPEED SKIP SIGNAL (G31)	55

5. FEED	FUNCTIONS	56
5.1	GENERAL	57
5.2	RAPID TRAVERSE	59
5.3		
5.4		
	5.4.1 Exact Stop (G09, G61) Cutting Mode (G64) Tapping Mode (G63)	
	5.4.2 Automatic Corner Override	
	5.4.2.1 Automatic override for inner corners (G62)	
5.5	5.4.2.2 Internal circular cutting feedrate change	
3.3	DWELL (G04)	09
6. REFE	RENCE POSITION	70
6.1	REFERENCE POSITION RETURN	71
7. COOR	DINATE SYSTEM	75
7.1	MACHINE COORDINATE SYSTEM	76
7.2	WORKPIECE COORDINATE SYSTEM	77
	7.2.1 Setting a Workpiece Coordinate System	77
	7.2.2 Selecting a Workpiece Coordinate System	
	7.2.3 Changing Workpiece Coordinate System	
	7.2.4 Workpiece Coordinate System Preset (G92.1)	
	7.2.5 Adding Workpiece Coordinate Systems (G54.1 or G54)	
7.3		
7.4		
8. COOR	DINATE VALUE AND DIMENSION	89
8.1	ABSOLUTE AND INCREMENTAL PROGRAMMING (G90, G91)	90
8.2	POLAR COORDINATE COMMAND (G15, G16)	91
8.3		
8.4	DECIMAL POINT PROGRAMMING	95
9. SPIND	LE SPEED FUNCTION (S FUNCTION)	96
9.1	SPECIFYING THE SPINDLE SPEED WITH A CODE	97
9.2		
9.3		
10. TOOL	L FUNCTION (T FUNCTION)	101
10.		
10. 10.		
10.	10.2.1 Tool Life Management Data	
	10.2.2 Register, Change and Delete of Tool Life Management Data	
	10.2.3 Tool Life Management Command in a Machining Program	
	10.2.4 Tool Life	
11. AUXI	LIARY FUNCTION	112
11.	1 AUXILIARY FUNCTION (M FUNCTION)	113
11.		
11		

12.	PROGR	ΑM	CONFIGURATION	116
	12.1		OGRAM COMPONENTS OTHER THAN PROGRAM SECTIONS	
	12.2		OGRAM SECTION CONFIGURATION	
	12.3	SUI	BPROGRAM (M98, M99)	127
13.	FUNCTI	ONS	S TO SIMPLIFY PROGRAMMING	131
	13.1	CA	NNED CYCLE	132
	13.	1.1	High–speed Peck Drilling Cycle (G73)	136
	13.	1.2	Left–handed Tapping Cycle (G74)	138
	13.	1.3	Fine Boring Cycle (G76)	140
	13.	1.4	Drilling Cycle, Spot Drilling (G81)	142
	13.	1.5	Drilling Cycle Counter Boring Cycle (G82)	144
	13.	1.6	Peck Drilling Cycle (G83)	146
	13.	1.7	Small-hole Peck Drilling Cycle (G83)	148
	13.	1.8	Tapping Cycle (G84)	152
	13.	1.9	Boring Cycle (G85)	154
	13.	1.10	Boring Cycle (G86)	156
	13.	1.11	Boring Cycle Back Boring Cycle (G87)	
	13.	1.12	Boring Cycle (G88)	
	13.	1.13	Boring Cycle (G89)	162
	13.	1.14	Canned Cycle Cancel (G80)	
	13.2		ID TAPPING	
	13.	2.1	Rigid Tapping (G84)	
		2.2	Left–handed Rigid Tapping Cycle (G74)	
	13.	2.3	Peck Rigid Tapping Cycle (G84 or G74)	
	13.	2.4	Canned Cycle Cancel (G80)	
	13.3		TIONAL ANGLE CHAMFERING AND CORNER ROUNDING	
	13.4		FERNAL MOTION FUNCTION (G81)	
	13.5		DEX TABLE INDEXING FUNCTION	
14	COMPE	NS/	ATION FUNCTION	184
	14.1		OL LENGTH OFFSET (G43,G44,G49)	
		1.1	General	
		1.2	G53, G28, G30, and G30.1 Commands in Tool Length Offset Mode	
	14.2		TOMATIC TOOL LENGTH MEASUREMENT (G37)	
	14.3		OL OFFSET (G45–G48)	
	14.4		ERVIEW OF CUTTER COMPENSATION C (G40 – G42)	
	14.5		TAILS OF CUTTER COMPENSATION C	
		5.1	General	
		5.2	Tool Movement in Start–up	
		5.3	Tool Movement in Offset Mode	
		5.4	Tool Movement in Offset Mode Cancel	
		5.5	Interference Check	
		5.6	Overcutting by Cutter Compensation	
		5.7	Input Command from MDI	
		5.8	G53,G28,G30,G30.1 and G29 Commands in Cutter Compensation C Mode	
	14.	5.9	Corner Circular Interpolation (G39)	261

	14.6	TOOL COMPENSATION VALUES, NUMBER OF COMPENSATION VALUES, AND ENTERING VALUES FROM THE PROGRAM (G10)	263
	14.7	SCALING (G50,G51)	
	14.8	COORDINATE SYSTEM ROTATION (G68, G69)	
	14.9	NORMAL DIRECTION CONTROL (G40.1, G41.1, G42.1 OR G150, G151, G152)	
	14.10	PROGRAMMABLE MIRROR IMAGE (G50.1, G51.1)	
15. C	USTOI	M MACRO	283
	15.1	VARIABLES	284
	15.2	SYSTEM VARIABLES	
	15.3	ARITHMETIC AND LOGIC OPERATION	296
	15.4	MACRO STATEMENTS AND NC STATEMENTS	301
	15.5	BRANCH AND REPETITION	302
	15.	5.1 Unconditional Branch (GOTO Statement)	302
	15.	5.2 Conditional Branch (IF Statement)	303
	15.	5.3 Repetition (While Statement)	304
	15.6	MACRO CALL	307
	15.	6.1 Simple Call (G65)	308
	15.	6.2 Modal Call (G66)	312
	15.	6.3 Macro Call Using G Code	314
	15.	6.4 Macro Call Using an M Code	315
	15.		
	15.		
		6.7 Sample Program	
	15.7	PROCESSING MACRO STATEMENTS	
	15.8	REGISTERING CUSTOM MACRO PROGRAMS	
	15.9	LIMITATIONS	
	15.10	EXTERNAL OUTPUT COMMANDS	
	15.11	INTERRUPTION TYPE CUSTOM MACRO	
		11.1 Specification Method	
	15.	11.2 Details of Functions	330
16. P	ATTER	N DATA INPUT FUNCTION	338
	16.1	DISPLAYING THE PATTERN MENU	339
	16.2	PATTERN DATA DISPLAY	343
	16.3	CHARACTERS AND CODES TO BE USED FOR THE PATTERN DATA INPUT FUNCTION	347
17. P	ROGR	AMMABLE PARAMETER ENTRY (G10)	349
18. M	EMOR	Y OPERATION USING FS10/11 TAPE FORMAT	351
19. H	IGH SI	PEED CUTTING FUNCTIONS	352
	19.1	FEEDRATE CLAMPING BY ARC RADIUS	353
	19.2	LOOK-AHEAD CONTROL (G08)	
	19.3	HIGH–SPEED REMOTE BUFFER	

	19.3.1	High–speed Remote Buffer A (G05)	356
	19.3.2	High–speed Remote Buffer B (G05)	359
20	AVIC CON	TOOL FUNCTIONS	200
20. <i>F</i>		TROL FUNCTIONS	
		MPLE SYNCHRONOUS CONTROL	
	20.2 RC	OTARY AXIS ROLL-OVER	364
III.	OPERA	TION	
1. G	ENERAL .		367
	1.1 MA	ANUAL OPERATION	368
		OOL MOVEMENT BY PROGRAMMING – AUTOMATIC OPERATION	
		JTOMATIC OPERATION	
	1.4 TE	SSTING A PROGRAM	373
	1.4.1	Check by Running the Machine	373
	1.4.2	How to View the Position Display Change without Running the Machine	374
	1.5 ED	DITING A PART PROGRAM	375
	1.6 DI	SPLAYING AND SETTING DATA	376
	1.7 DI	SPLAY	379
	1.7.1	Program Display	379
	1.7.2	Current Position Display	380
	1.7.3	Alarm Display	380
	1.7.4	Parts Count Display, Run Time Display	
	1.7.5	Graphic Display	381
	1.8 DA	ATA INPUT/OUTPUT	382
2. O	PERATION	IAL DEVICES	383
	2.1 SE	TTING AND DISPLAY UNITS	384
	2.1.1	CNC Control Unit with 7.2"/8.4" LCD	385
	2.1.2	CNC Control Unit with 9.5"/10.4" LCD	385
	2.1.3	Separate-Type Small MDI Unit	386
	2.1.4	Separate-Type Standard MDI Unit (Horizontal Type)	387
	2.1.5	Separate-Type Standard MDI Unit (Vertical Type)	388
	2.1.6	Separate-Type Standard MDI Unit (Vertical Type) (for 210i)	389
	2.2 EX	XPLANATION OF THE KEYBOARD	390
	2.3 FU	UNCTION KEYS AND SOFT KEYS	392
	2.3.1	General Screen Operations	392
	2.3.2	Function Keys	393
	2.3.3	Soft Keys	
	2.3.4	Key Input and Input Buffer	
	2.3.5	Warning Messages	
	2.3.6	Soft Key Configuration	
		TERNAL I/O DEVICES	
	2.4.1	FANUC Handy File	
	2.4.2	FANUC Floppy Cassette	415

	2.4.3 FANUC FA Card	416
	2.4.4 FANUC PPR	416
	2.4.5 Portable Tape Reader	417
2.5	POWER ON/OFF	418
	2.5.1 Turning on the Power	418
	2.5.2 Screen Displayed at Power–on	419
	2.5.3 Power Disconnection	
3. MANU	AL OPERATION	421
3.1		
3.2		
3.3		
3.4		
3.5	MANUAL ABSOLUTE ON AND OFF	429
4. AUTON	MATIC OPERATION	434
4.1	MEMORY OPERATION	
4.2		
4.3		
4.4		
4.5		
4.6		
4.7		
4.8		
4.9	MANUAL INTERVENTION AND RETURN	
5. TEST C	OPERATION	466
5.1		
5.2	FEEDRATE OVERRIDE	469
5.3		
5.4		
5.5	SINGLE BLOCK	472
6. SAFET	TY FUNCTIONS	474
6.1		
6.2	OVERTRAVEL	476
6.3	STROKE CHECK	477
7. ALARN	M AND SELF-DIAGNOSIS FUNCTIONS	481
7.1	ALARM DISPLAY	482
7.2	ALARM HISTORY DISPLAY	484
7.3	CHECKING BY SELF-DIAGNOSTIC SCREEN	
8. DATA I	INPUT/OUTPUT	488
8.1	FILES	489

	8.2 FIL	LE SEARCH	491
	8.3 FIL	LE DELETION	493
	8.4 PR	OGRAM INPUT/OUTPUT	494
	8.4.1	Inputting a Program	494
	8.4.2	Outputting a Program	497
	8.5 OF	FSET DATA INPUT AND OUTPUT	499
	8.5.1	Inputting Offset Data	499
	8.5.2	Outputting Offset Data	500
		PUTTING AND OUTPUTTING PARAMETERS AND ICH ERROR COMPENSATION DATA	501
	8.6.1	Inputting Parameters	501
	8.6.2	Outputting Parameters	502
	8.6.3	Inputting Pitch Error Compensation Data	503
	8.6.4	Outputting Pitch Error Compensation Data	504
	8.7 INI	PUTTING/OUTPUTTING CUSTOM MACRO COMMON VARIABLES	505
	8.7.1	Inputting Custom Macro Common Variables	505
	8.7.2	Outputting Custom Macro Common Variable	506
	8.8 DIS	SPLAYING DIRECTORY OF FLOPPY CASSETTE	507
	8.8.1	Displaying the Directory	508
	8.8.2	Reading Files	511
	8.8.3	Outputting Programs	512
	8.8.4	Deleting Files	513
	8.9 OU	TPUTTING A PROGRAM LIST FOR A SPECIFIED GROUP	515
	8.10 DA	TA INPUT/OUTPUT ON THE ALL IO SCREEN	516
	8.10.1	Setting Input/Output–Related Parameters	517
	8.10.2	Inputting and Outputting Programs	518
	8.10.3	Inputting and Outputting Parameters	523
	8.10.4	Inputting and Outputting Offset Data	525
	8.10.5	Outputting Custom Macro Common Variables	527
	8.10.6	Inputting and Outputting Floppy Files	528
	8.10.7	Memory Card Input/Output	533
	8.11 DA	TA INPUT/OUTPUT USING A MEMORY CARD	542
9. ED	ITING PR	OGRAMS	554
	9.1 INS	SERTING, ALTERING AND DELETING A WORD	555
	9.1.1	Word Search	556
	9.1.2	Heading a Program	558
	9.1.3	Inserting a Word	559
	9.1.4	Altering a Word	560
	9.1.5	Deleting a Word	561
	9.2 DE	LETING BLOCKS	562
	9.2.1	Deleting a Block	562
	9.2.2	Deleting Multiple Blocks	563
	9.3 PR	OGRAM NUMBER SEARCH	565
	9.4 SE	QUENCE NUMBER SEARCH	566
	9.5 DE	LETING PROGRAMS	568
	9.5.1	Deleting One Program	568
	9.5.2	Deleting All Programs	568
	9.5.3	Deleting More Than One Program by Specifying a Range	569

	9.6 EX	TENDED PART PROGRAM EDITING FUNCTION	570
	9.6.1	Copying an Entire Program	571
	9.6.2	Copying Part of a Program	572
	9.6.3	Moving Part of a Program	573
	9.6.4	Merging a Program	574
	9.6.5	Supplementary Explanation for Copying, Moving and Merging	575
	9.6.6	Replacement of Words and Addresses	577
	9.7 ED	ITING OF CUSTOM MACROS	579
	9.8 BA	CKGROUND EDITING	580
	9.9 PAS	SSWORD FUNCTION	581
10. (CREATING	PROGRAMS	583
	10.1 CR	EATING PROGRAMS USING THE MDI PANEL	584
		TOMATIC INSERTION OF SEQUENCE NUMBERS	
		EATING PROGRAMS IN TEACH IN MODE (PLAYBACK)	
11. \$	SETTING A	ND DISPLAYING DATA	590
	11.1 SCI	REENS DISPLAYED BY FUNCTION KEY POS	597
	11.1.1	Position Display in the Work Coordinate System	598
	11.1.2	Position Display in the Relative Coordinate System	
	11.1.2	Overall Position Display	
	11.1.4	Presetting the Workpiece Coordinate System	
	11.1.5	Actual Feedrate Display	
	11.1.6	Display of Run Time and Parts Count	
	11.1.7	Operating Monitor Display	
		REENS DISPLAYED BY FUNCTION KEY PROG	007
	•	MEMORY MODE OR MDI MODE)	
	11.2.1	Program Contents Display	
	11.2.2	Current Block Display Screen	
	11.2.3	Next Block Display Screen	
	11.2.4	Program Check Screen	
	11.2.5	Program Screen for MDI Operation	
	11.3 SCI	REENS DISPLAYED BY FUNCTION KEY PROG (IN THE EDIT MODE)	
	11.3.1	Displaying Memory Used and a List of Programs	
	11.3.2	Displaying a Program List for a Specified Group	619
	11.4 SCI	REENS DISPLAYED BY FUNCTION KEY OFFSET SETTING	622
	11.4.1	Setting and Displaying the Tool Offset Value	623
	11.4.2	Tool Length Measurement	
	11.4.3	Displaying and Entering Setting Data	628
	11.4.4	Sequence Number Comparison and Stop	630
	11.4.5	Displaying and Setting Run Time, Parts Count, and Time	632
	11.4.6	Displaying and Setting the Workpiece Origin Offset Value	634
	11.4.7	Direct Input of Measured Workpiece Origin Offsets	635
	11 4 8	Displaying and Setting Custom Macro Common Variables	637

	11.	4.9 Displaying Pattern Data and Pattern Menu	638
	11.	4.10 Displaying and Setting the Software Operator's Panel	640
	11.	4.11 Displaying and Setting Tool Life Management Data	642
	11.	4.12 Displaying and Setting Extended Tool Life Management	645
	11.5	SCREENS DISPLAYED BY FUNCTION KEY SYSTEM	650
	11.	5.1 Displaying and Setting Parameters	651
	11.		653
	11.6		655
	11.	1	
	11.	6.2 Displaying the Status and Warning for Data Setting or Input/Output Operation	656
	11.7		
	11.		
	11.8		
		* *	
	11.	8.2 Automatic Erase Screen Display	661
12. G	RAPH	ICS FUNCTION 6	62
	12.1	GRAPHICS DISPLAY	663
	12.2	DYNAMIC GRAPHIC DISPLAY	669
	12.	2.1 Path Drawing	669
13 H	IFI P FI	UNCTION	ing and Setting Tool Life Management Data
13.11			,,,
IV	MΔIN	TENANCE	
. V.		TENANOL	
1. ME	ETHOD	OF REPLACING BATTERY 6	85
	1.1	REPLACING THE ALKALINE DRY CELLS (SIZE D)	688
	1.3		
APF	11.4.11 Displaying and Setting Tool Life Management Data 11.4.12 Displaying and Setting Extended Tool Life Management 645		
A. TA	11.4.12 Displaying and Setting Extended Tool Life Management		
в п	11.4.10 Displaying and Setting the Software Operator's Panel 640 11.4.11 Displaying and Setting Tool Life Management Data 642 11.4.12 Displaying and Setting Extended Tool Life Management 645 11.5 SCREENS DISPLAYED BY FUNCTION KEY 650 11.5.1 Displaying and Setting Parameters 651 11.5.2 Displaying and Setting Pitch Error Compensation Data 653 11.5 Displaying and Setting Pitch Error Compensation Data 653 11.5 Displaying and Setting Pitch Error Compensation Data 653 11.6 Displaying the Program Number and Sequence Number 655 11.6 Displaying the Program Number and Sequence Number 655 11.6 Displaying the Program Number and Sequence Number 655 11.6 SCREENS DISPLAYED BY FUNCTION KEY 655 11.7 SCREENS DISPLAYED BY FUNCTION KEY 656 11.8 CLEARING THE SCREEN 660 11.8.1 Erase Screen Display 660 11.8.2 Automatic Erase Screen Display 660 11.8.1 Erase Screen Display 660 11.8.2 Automatic Erase Screen Display 661 2. GRAPHICS FUNCTION 662 2. GRAPHICS FUNCTION 662 2. GRAPHICS DISPLAY 669 12.2.1 Path Drawing 669 3. HELP FUNCTION 678 METHOD OF REPLACING BATTERY 685 3. BATTERY FOR SEPARATE ABSOLUTE PULSE CODERS 690 PPENDIX TAPE CODE LIST 693 LIST OF FUNCTIONS AND TAPE FORMAT 696 3. RANGE OF COMMAND VALUE 701 NOMOGRAPHS 704 D.1 INCORRECT THREADED LENGTH 705 D.2 SIMPLE CALCULATION OF INCORRECT THREAD LENGTH 705 D.2 SIMPLE CALCULATION OF INCORRECT THREAD LENGTH 705 D.2 SIMPLE CALCULATION OF INCORRECT THREAD LENGTH 705 D.3 TOOL PATH AT CORNER 709		
D. LI	11.4.10		
C. R	ANGE	OF COMMAND VALUE 7	'01
D. N	OMOGI	RAPHS 7	' 04
	D.1	INCORRECT THREADED LENGTH	705
	D.3		
	D.4	RADIUS DIRECTION ERROR AT CIRCLE CUTTING	712

TABLE OF CONTENTS
B-63094EN/01

E. STATUS WHEN TURNING POWER ON, WHEN CLEAR AND WHEN RESET	713
F. CHARACTER-TO-CODES CORRESPONDENCE TABLE	715
G. ALARM LIST	716
H. OPERATION OF PORTABLE TAPE READER	738

I. GENERAL

1

GENERAL

About this manual

This manual consists of the following parts:

I. GENERAL

Describes chapter organization, applicable models, related manuals, and notes for reading this manual.

II. PROGRAMMING

Describes each function: Format used to program functions in the NC language, characteristics, and restrictions. When a program is created through conversational automatic programming function, refer to the manual for the conversational automatic programming function (Table 1).

III. OPERATION

Describes the manual operation and automatic operation of a machine, procedures for inputting and outputting data, and procedures for editing a program.

IV. MAINTENANCE

Describes procedures for replacing batteries.

APPENDIX

Lists tape codes, valid data ranges, and error codes.

Some functions described in this manual may not be applied to some products. For detail, refer to the DESCRIPTIONS manual (B-63002EN).

This manual does not describe parameters in detail. For details on parameters mentioned in this manual, refer to the manual for parameters (B-63090EN).

This manual describes all optional functions. Look up the options incorporated into your system in the manual written by the machine tool builder.

The models covered by this manual, and their abbreviations are:

Product name	Abbro	eviations
FANUC Series 21i-MA	21 <i>i</i> –MA	Series 21i
FANUC Series 210i-MA	210 <i>i</i> –MA	Series 210i

Special symbols

This manual uses the following symbols:

 $\mathbb{P}_{_}$: Indicates a combination of axes such as $X_{_}Y_{_}Z$ (used in PROGRAMMING.).

indicates the end of a block. It actually corresponds to the ISO code LF or EIA code CR.

Related manuals

The table below lists manuals related to MODEL A of Series 21i and Series 210i. In the table, this manual is marked with an asterisk (*).


Table 1 Related Manuals

Manual name	Specification number	
DESCRIPTIONS	B-63002EN	
CONNECTION MANUAL (Hardware)	B-63083EN	
CONNECTION MANUAL (Function)	B-63003EN-1	
OPERATOR'S MANUAL for Lathe	B-63084EN	
OPERATOR'S MANUAL for Machining Center	B-63094EN	*
MAINTENANCE MANUAL	B-63085EN	
PARAMETER MANUAL	B-63090EN	
PROGRAMMING MANUAL (Macro Compiler / Macro Executer)	B-61803E-1	
FAPT MACRO COMPILER PROGRAMMING MANUAL	B-66102E	
FANUC Symbolic CAP T Basic module V1 OPERATOR'S MANUAL	B-62824EN	
FANUC Symbolic CAP T C/Y axis module V1 OPERATOR'S MANUAL	B-62824EN-1	
FANUC Symbolic CAP M Basic module V1 OPERATOR'S MANUAL	B-62984EN	

1.1 GENERAL FLOW OF OPERATION OF CNC MACHINE TOOL

When machining the part using the CNC machine tool, first prepare the program, then operate the CNC machine by using the program.

- 1) First, prepare the program from a part drawing to operate the CNC machine tool.
 - How to prepare the program is described in the Chapter II. PROGRAMMING.
- 2) The program is to be read into the CNC system. Then, mount the workpieces and tools on the machine, and operate the tools according to the programming. Finally, execute the machining actually. How to operate the CNC system is described in the Chapter III. OPERATION.




Before the actual programming, make the machining plan for how to machine the part.

Machining plan

- 1. Determination of workpieces machining range
- 2. Method of mounting workpieces on the machine tool
- 3. Machining sequence in every machining process
- 4. Machining tools and machining

Decide the machining method in every machining process.

Machining process	1	2	3
Machining procedure	Feed cutting	Side cutting	Hole machining
Machining method Rough Semi Finish			
Machining tools			
Machining conditions Feedrate Cutting depth			
4. Tool path			



Prepare the program of the tool path and machining condition according to the workpiece figure, for each machining.

1.2 NOTES ON READING THIS MANUAL

NOTE

- 1 The function of an CNC machine tool system depends not only on the CNC, but on the combination of the machine tool, its magnetic cabinet, the servo system, the CNC, the operator's panels, etc. It is too difficult to describe the function, programming, and operation relating to all combinations. This manual generally describes these from the stand-point of the CNC. So, for details on a particular CNC machine tool, refer to the manual issued by the machine tool builder, which should take precedence over this manual.
- 2 Headings are placed in the left margin so that the reader can easily access necessary information. When locating the necessary information, the reader can save time by searching though these headings.
- 3 Machining programs, parameters, variables, etc. are stored in the CNC unit internal non-volatile memory. In general, these contents are not lost by the switching ON/OFF of the power. However, it is possible that a state can occur where precious data stored in the non-volatile memory has to be deleted, because of deletions from a maloperation, or by a failure restoration. In order to restore rapidly when this kind of mishap occurs, it is recommended that you create a copy of the various kinds of data beforehand.
- 4 This manual describes as many reasonable variations in equipment usage as possible. It cannot address every combination of features, options and commands that should not be attempted.
 - If a particular combination of operations is not described, it should not be attempted.

II. PROGRAMMING



GENERAL

1.1 TOOL MOVEMENT ALONG WORKPIECE PARTS FIGURE– INTERPOLATION

The tool moves along straight lines and arcs constituting the workpiece parts figure (See II–4).

Explanations

 Tool movement along a straight line The function of moving the tool along straight lines and arcs is called the interpolation.




Fig. 1.1 (a) Tool movement along a straight line

Tool movement along an arc




Fig. 1.1 (b) Tool movement along an arc

Symbols of the programmed commands G01, G02, ... are called the preparatory function and specify the type of interpolation conducted in the control unit.




Fig. 1.1 (c) Interpolation function

NOTE

Some machines move tables instead of tools but this manual assumes that tools are moved against workpieces.

1.2 FEED-FEED FUNCTION

Movement of the tool at a specified speed for cutting a workpiece is called the feed.




Fig. 1.2 Feed function

Feedrates can be specified by using actual numerics. For example, to feed the tool at a rate of 150 mm/min, specify the following in the program: F150.0

The function of deciding the feed rate is called the feed function (See II–5).

1.3 PART DRAWING AND TOOL MOVEMENT

1.3.1 Reference Position (Machine–Specific Position)

A CNC machine tool is provided with a fixed position. Normally, tool change and programming of absolute zero point as described later are performed at this position. This position is called the reference position.




Fig. 1.3.1 Reference position

Explanations

The tool can be moved to the reference position in two ways:

- (1) Manual reference position return (See III–3.1) Reference position return is performed by manual button operation.
- (2) Automatic reference position return (See II–6)
 In general, manual reference position return is performed first after the power is turned on. In order to move the tool to the reference position for tool change thereafter, the function of automatic reference position return is used.

1.3.2 Coordinate System on Part Drawing and Coordinate System Specified by CNC – Coordinate System




Fig. 1.3.2 (a) Coordinate system

Explanations

Coordinate system

The following two coordinate systems are specified at different locations: (See II–7)

- (1) Coordinate system on part drawing

 The coordinate system is written on the part drawing. As the program data, the coordinate values on this coordinate system are used.
- (2) Coordinate system specified by the CNC

 The coordinate system is prepared on the actual machine tool table.

 This can be achieved by programming the distance from the current position of the tool to the zero point of the coordinate system to be set.




Fig. 1.3.2 (b) Coordinate system specified by the CNC

The positional relation between these two coordinate systems is determined when a workpiece is set on the table.




Fig. 1.3.2 (c) Coordinate system specified by CNC and coordinate systemon part drawing


The tool moves on the coordinate system specified by the CNC in accordance with the command program generated with respect to the coordinate system on the part drawing, and cuts a workpiece into a shape on the drawing.

Therefore, in order to correctly cut the workpiece as specified on the drawing, the two coordinate systems must be set at the same position.


To set the two coordinate systems at the same position, simple methods shall be used according to workpiece shape, the number of machinings.

(1) Using a standard plane and point of the workpiece.


 Methods of setting the two coordinate systems in the same position



(2) Mounting a workpiece directly against the jig



(3) Mounting a workpiece on a pallet, then mounting the workpiece and pallet on the jig



1.3.3


How to Indicate Command Dimensions for Moving the Tool – Absolute, Incremental Commands

Explanations

Absolute command


Command for moving the tool can be indicated by absolute command or incremental command (See II–8.1).

The tool moves to a point at "the distance from zero point of the coordinate system" that is to the position of the coordinate values.



Incremental command


Specify the distance from the previous tool position to the next tool position.



1.4 CUTTING SPEED – SPINDLE SPEED FUNCTION

The speed of the tool with respect to the workpiece when the workpiece is cut is called the cutting speed.

As for the CNC, the cutting speed can be specified by the spindle speed in rpm unit.



Examples


<When a workpiece should be machined with a tool 100 mm in diameter at a cutting speed of 80 m/min. >

The spindle speed is approximately 250 rpm, which is obtained from N=1000v/ π D. Hence the following command is required: S250;

Commands related to the spindle speed are called the spindle speed function (See II–9) .

1.5 SELECTION OF TOOL USED FOR VARIOUS MACHINING – TOOL FUNCTION

When drilling, tapping, boring, milling or the like, is performed, it is necessary to select a suitable tool. When a number is assigned to each tool and the number is specified in the program, the corresponding tool is selected.




Examples

<When No.01 is assigned to a drilling tool>

When the tool is stored at location 01 in the ATC magazine, the tool can be selected by specifying T01. This is called the tool function (See II–10).

1.6 COMMAND FOR MACHINE OPERATIONS – MISCELLANEOUS FUNCTION

When machining is actually started, it is necessary to rotate the spindle, and feed coolant. For this purpose, on–off operations of spindle motor and coolant valve should be controlled.



The function of specifying the on–off operations of the components of the machine is called the miscellaneous function. In general, the function is specified by an M code (See II–11).

For example, when M03 is specified, the spindle is rotated clockwise at the specified spindle speed.

1.7 PROGRAM CONFIGURATION

A group of commands given to the CNC for operating the machine is called the program. By specifying the commands, the tool is moved along a straight line or an arc, or the spindle motor is turned on and off. In the program, specify the commands in the sequence of actual tool movements.




Fig. 1.7 (a) Program configuration

A group of commands at each step of the sequence is called the block. The program consists of a group of blocks for a series of machining. The number for discriminating each block is called the sequence number, and the number for discriminating each program is called the program number (See II–12).

Explanations

Block

The block and the program have the following configurations.




Fig. 1.7 (b) Block configuration

A block starts with a sequence number to identify the block and ends with an end-of-block code.

This manual indicates the end–of–block code by ; (LF in the ISO code and CR in the EIA code).

Program






Fig. 1.7 (c) Program configuration

Normally, a program number is specified after the end–of–block (;) code at the beginning of the program, and a program end code (M02 or M30) is specified at the end of the program.

Main program and subprogram

When machining of the same pattern appears at many portions of a program, a program for the pattern is created. This is called the subprogram. On the other hand, the original program is called the main program. When a subprogram execution command appears during execution of the main program, commands of the subprogram are executed. When execution of the subprogram is finished, the sequence returns to the main program.






1.8 TOOL FIGURE AND TOOL MOTION BY PROGRAM


Explanations

 Machining using the end of cutter – Tool length compensation function (See II–14.1) Usually, several tools are used for machining one workpiece. The tools have different tool length. It is very troublesome to change the program in accordance with the tools.

Therefore, the length of each tool used should be measured in advance. By setting the difference between the length of the standard tool and the length of each tool in the CNC (data display and setting : see III–11), machining can be performed without altering the program even when the tool is changed. This function is called tool length compensation.




 Machining using the side of cutter – Cutter compensation function (See II–14.4,14.5,14.6) Because a cutter has a radius, the center of the cutter path goes around the workpiece with the cutter radius deviated.



If radius of cutters are stored in the CNC (Data Display and Setting : see III–11), the tool can be moved by cutter radius apart from the machining part figure. This function is called cutter compensation.

1.9 TOOL MOVEMENT RANGE – STROKE

Limit switches are installed at the ends of each axis on the machine to prevent tools from moving beyond the ends. The range in which tools can move is called the stroke.



Besides strokes defined with limit switches, the operator can define an area which the tool cannot enter using a program or data in memory. This function is called stroke check (see III–6.3).

2

CONTROLLED AXES

2.1 CONTROLLED AXES

ltem	21 <i>i</i> –MA 210 <i>i</i> –MA
No. of basic controlled axes	3 axes
Controlled axes expansion (total)	Max. 4 axes (included in Cs axis)
Basic simultaneously controlled axes	2 axes
Simultaneously controlled axes expansion (total)	Max. 4 axes

NOTE

The number of simultaneously controllable axes for manual operation jog feed, manual reference position return, or manual rapid traverse) is 1 or 3 (1 when bit 0 (JAX) of parameter 1002 is set to 0 and 3 when it is set to 1).

2.2 AXIS NAME

The names of three basic axes are always X, Y, and Z. The name of an additional axis can be set to A, B, C, U, V, or W by using parameter 1020. Parameter No. 1020 is used to determine the name of each axis.

When this parameter is set to 0 or a character other than the valid characters is specified, an axis name from 1 to 4 is assigned by default.

Limitations

Default axis name

Duplicate axis names

When a default axis name (1 to 4) is used, operation in the MEM mode and MDI mode is disabled.

If a duplicate axis name is specified in the parameter, operation is enabled only for the axis specified first.

2.3 INCREMENT SYSTEM

The increment system consists of the least input increment (for input) and least command increment (for output). The least input increment is the least increment for programming the travel distance. The least command increment is the least increment for moving the tool on the machine. Both increments are represented in mm, inches, or deg.

Name of in- crement sys- tem	Least input incre- ment	Least command increment	Maximum stroke
IS-B	0.001mm	0.001mm	99999.999mm
	0.0001inch	0.0001inch	9999.9999inch
	0.001deg	0.001deg	99999.999deg
Name of increment system	Least input incre- ment	Least command increment	Maximum stroke
IS-C	0.0001mm	0.0001mm	9999.9999mm
	0.00001inch	0.00001inch	999.99999inch
	0.0001deg	0.0001deg	9999.9999deg

The least command increment is either metric or inch depending on the machine tool. Set metric or inch to the parameter INM (No.100#0). For selection between metric and inch for the least input increment, G code (G20 or G21) or a setting parameter selects it.

Combined use of the inch system and the metric system is not allowed. There are functions that cannot be used between axes with different unit systems (circular interpolation, cutter compensation, etc.). For the increment system, see the machine tool builder's manual.

2.4 MAXIMUM STROKE

Maximum stroke = Least command increment × 99999999 See 2.3 Incremen System.

Table 2.4 Maximum strokes

Increment system		Maximum stroke
IS-B	Metric machine system	±99999.999 mm ±99999.999 deg
10-В	Inch machine system	±9999.9999 inch ±99999.999 deg
IS-C	Metric machine system	±9999.9999 mm ±9999.9999 deg
15–0	Inch machine system	±999.99999 inch ±9999.9999 deg

NOTE

- 1 A command exceeding the maximum stroke cannot be specified.
- 2 The actual stroke depends on the machine tool.



PREPARATORY FUNCTION (G FUNCTION)

A number following address G determines the meaning of the command for the concerned block.

G codes are divided into the following two types.

Туре	Meaning	
One-shot G code	The G code is effective only in the block in which it is specified.	
Modal G code	The G code is effective until another G code of the same group is specified.	

(Example)

G01 and G00 are modal G codes in group 01.

```
\left. \begin{array}{c} G01X-;\\ Z\cdot;\\ X\,;\\ G00Z-; \end{array} \right\} \ \mbox{G01 is effective in this range}.
```

Explanations

- 1. When the clear state (bit 6 (CLR) of parameter No. 3402) is set at power—up or reset, the modal G codes are placed in the states described below.
- (1) The modal G codes are placed in the states marked with as indicated in Table 3.
- (2) G20 and G21 remain unchanged when the clear state is set at power–up or reset.
- (3) Which status G22 or G23 at power on is set by parameter G23 (No. 3402#7). However, G22 and G23 remain unchanged when the clear state is set at reset.
- (4) The user can select G00 or G01 by setting bit 0 (G01) of parameter No. 3402.
- (5) The user can select G90 or G91 by setting bit 3 (G91) of parameter No. 3402.
- (6) The user can select G17, G18, or G19 by setting bit 1 (parameter G18) and bit 2 (parameter G19) of parameter No. 3402.
- 2.G codes other than G10 and G11 are one–shot G codes.
- 3. When a G code not listed in the G code list is specified, or a G code that has no corresponding option is specified, P/S alarm No. 010 is output.
- 4. Multiple G codes can be specified in the same block if each G code belongs to a different group. If multiple G codes that belong to the same group are specified in the same block, only the last G code specified is valid.
- 5.If a G code belonging to group 01 is specified in a canned cycle, the canned cycle is cancelled. This means that the same state set by specifying G80 is set. Note that the G codes in group 01 are not affected by a G code specifying a canned cycle.
- 6.G codes are indicated by group.
- 7. The group of G60 is switched according to the setting of the MDL bit (bit 0 of parameter 5431). (When the MDL bit is set to 0, the 00 group is selected.) When the MDL bit is set to 1, the 01 group is selected.)

Table 3 G code list (1/3)

G code	Group		Function		
G 00		Positioning			
G 01	01	Linear interpolation			
G02	7 0'	Circular interpolation/Helical interpolation CW			
G03		Circular interpolation/Heli	cal interpolation CCW		
G04		Dwell, Exact stop			
G05		High speed cycle machini	High speed cycle machining		
G07		Hypothetical axis interpolation			
G07.1 (G107)		Cylindrical interpolation			
G08	- 00	Look-ahead control			
G09		Exact stop			
G10		Programmable data input			
G11		Programmable data input	mode cancel		
G 15	17	Polar coordinates comma	nd cancel		
G16	17	Polar coordinates comma	nd		
G 17		XpYp plane selection	Xp: X axis or its parallel axis		
G 18	02	ZpXp plane selection	Yp: Y axis or its parallel axis		
G 19	7	YpZp plane selection	Zp: Z axis or its parallel axis		
G20	00	Input in inch			
G21	- 06	Input in mm			
G 22	04	Stored stroke check function on			
G23	- 04	Stored stroke check function off			
G 25	0.4	Spindle speed fluctuation	detection off		
G26	24	Spindle speed fluctuation detection on			
G27		Reference position return	check		
G28		Return to reference positi	on		
G29	00	Return from reference por	sition		
G30		2nd, 3rd and 4th reference	e position return		
G31		Skip function			
G33	01	Thread cutting			
G37	00	Automatic tool length mea	asurment		
G39	- 00	Corner offset circular inte	rpolation		
G 40		Cutter compensation can	cel/Three dimensional compensation cancel		
G41	07	Cutter compensation left/Three dimensional compensation			
G42	7	Cutter compensation right			
G40.1 (G150)		Normal direction control of	ancel mode		
G41.1 (G151)	19 Normal direction control left side on				
G42.1 (G152)		Normal direction control right side on			
G43	Tool length compensation + direction		+ direction		
G44	Tool length compensation – direction				

Table 3 G code list (2/3)

G code	Group	Function	
G45		Tool offset increase	
G46	1	Tool offset decrease	
G47	00	Tool offset double increase	
G48	1	Tool offset double decrease	
Ğ 49	08	Tool length compensation cancel	
€ 50		Scaling cancel	
G51	11	Scaling	
G 50.1		Programmable mirror image cancel	
G51.1	22	Programmable mirror image	
G52		Local coordinate system setting	
G53	- 00	Machine coordinate system selection	
G 54		Workpiece coordinate system 1 selection	
G54.1	1	Additional workpiece coordinate system selection	
G55	1	Workpiece coordinate system 2 selection	
G56	14	Workpiece coordinate system 3 selection	
G57	-	Workpiece coordinate system 4 selection	
G58	1	Workpiece coordinate system 5 selection	
G59	-	Workpiece coordinate system 6 selection	
G60	00	Single direction positioning	
G61		Exact stop mode	
G62	-	Automatic corner override	
G63	15	Tapping mode	
G 64	1	Cutting mode	
G65	00	Macro call	
G66		Macro modal call	
G 67	12	Macro modal call cancel	
G68		Coordinate rotation/Three dimensional coordinate conversion	
G 69	16	Coordinate rotation cancel/Three dimensional coordinate conversion cancel	
G73	00	Peck drilling cycle	
G74	- 09	Counter tapping cycle	
G76	09	Fine boring cycle	
Ğ80		Canned cycle cancel/external operation function cancel	
G81	1	Drilling cycle, spot boring cycle or external operation function	
G82	1	Drilling cycle or counter boring cycle	
G83	1	Peck drilling cycle	
G84	09	Tapping cycle	
G85	1	Boring cycle	
G86	1	Boring cycle	
G87	1	Back boring cycle	
G88	1	Boring cycle	
G89	1	Boring cycle	

Table 3 G code list (3/3)

G code	Group	Function
G 90	03	Absolute command
G91	03	Increment command
G92	00	Setting for work coordinate system or clamp at maximum spindle speed
G92.1] 00	Workpiece coordinate system preset
G94	05	Feed per minute
G95		Feed per rotation
G96	42	Constant surface speed control
G97	13	Constant surface speed control cancel
G98	10	Return to initial point in canned cycle
G99		Return to R point in canned cycle



INTERPOLATION FUNCTIONS

4.1 POSITIONING (G00)

The G00 command moves a tool to the position in the workpiece system specified with an absolute or an incremental command at a rapid traverse rate.

In the absolute command, coordinate value of the end point is programmed.

In the incremental command the distance the tool moves is programmed.

Format


G00 IP;

P: For an absolute command, the coordinates of an end position, and for an incremental commnad, the distance the tool moves.

Explanations

Either of the following tool paths can be selected according to bit 1 of parameter LRP No. 1401.

- Nonlinear interpolation positioning
 The tool is positioned with the rapid traverse rate for each axis separately. The tool path is normally straight.
- Linear interpolation positioning
 The tool path is the same as in linear interpolation (G01). The tool
 is positioned within the shortest possible time at a speed that is not
 more than the rapid traverse rate for each axis.



The rapid traverse rate in G00 command is set to the parameter No. 1420 for each axis independently by the machine tool builder. In the positioning mode actuated by G00, the tool is accelerated to a predetermined speed at the start of a block and is decelerated at the end of a block. Execution proceeds to the next block after confirming the in–position.

"In-position" means that the feed motor is within the specified range. This range is determined by the machine tool builder by setting to parameter (No. 1826).

In–position check for each block can be disabled by setting bit 5 (NCI) of parameter No.1601 accordingly.


Limitations

The rapid traverse rate cannot be specified in the address F. Even if linear interpolation positioning is specified, nonlinear interpolation positioning is used in the following cases. Therefore, be careful to ensure that the tool does not foul the workpiece.

- G28 specifying positioning between the reference and intermediate positions.
- G53

4.2 SINGLE DIRECTION POSITIONING (G60)

For accurate positioning without play of the machine (backlash), final positioning from one direction is available.



Format

G60IP_;

P: For an absolute command, the coordinates of an end position, and for an incremental commnad, the distance the tool moves.

Explanations

An overrun and a positioning direction are set by the parameter (No. 5440). Even when a commanded positioning direction coincides with that set by the parameter, the tool stops once before the end point. G60, which is an one–shot G–code, can be used as a modal G–code in group 01 by setting 1 to the parameter (No. 5431 bit 0 MDL). This setting can eliminate specifying a G60 command for every block. Other specifications are the same as those for an one–shot G60 command. When an one–shot G code is sepcified in the single direction positioning mode, the one–shot G command is effective like G codes in group 01.

Examples

When one-shot		When mod	al
G60 command	s are used.	G60 comm	and is used.
G90; G60 X0Y0; G60 X100; G60 Y100; G04 X10; G00 X0Y0;	Single direction positioning	G90G60; X0Y0; X100; Y100; G04X10; G00X0Y0;	Single direction positioning mode start Single direction positioning Dwell Single direction positioning mode cancel

Restrictions

- During canned cycle for drilling, no single direction positioning is effected in Z axis.
- No single direction positioning is effected in an axis for which no overrun has been set by the parameter.
- When the move distance 0 is commanded, the single direction positioning is not performed.
- The direction set to the parameter is not effected by mirror image.
- The single direction positioning does not apply to the shift motion in the canned cycles of G76 and G87.

4.3 LINEAR INTERPOLATION (G01)

Tools can move along a line

Format

G01 IP_F_;

IP: For an absolute command, the coordinates of an end point, and for an incremental command, the distance the tool moves.

F_:Speed of tool feed (Feedrate)

Explanations

A tools move along a line to the specified position at the feedrate specified in F.

The feedrate specified in F is effective until a new value is specified. It need not be specified for each block.

The feedrate commanded by the F code is measured along the tool path. If the F code is not commanded, the feedrate is regarded as zero.

The feedrate of each axis direction is as follows.

G01α $\underline{\alpha}$ β $\underline{\beta}$ γγζζ Ff;

Feed rate of α axis direction : $F\alpha = \frac{\alpha}{L} \times f$

Feed rate of β axis direction : $F_{\beta} = \frac{\beta}{L} \times f$

Feed rate of γ axis direction : $F\gamma = \frac{\gamma}{I} \times f$

Feed rate of ζ axis direction : $F_{\zeta} = \frac{\zeta}{L} \times f$

 $L = \sqrt{\alpha^2 + \beta^2 + \gamma^2 + \zeta^2}$

The feed rate of the rotary axis is commanded in the unit of deg/min (the unit is decimal point position).

When the straight line axis $\alpha(\text{such as } X, Y, \text{ or } Z)$ and the rotating axis β (such as A, B, or C) are linearly interpolated, the feed rate is that in which the tangential feed rate in the α and β cartesian coordinate system is commanded by $\Gamma(\text{mm/min})$.

 β -axis feedrate is obtained; at first, the time required for distribution is calculated by using the above fromula, then the β -axis feedrate unit is changed to deg 1min.

A calcula;tion example is as follows.

G91 G01 X20.0B40.0 F300.0;


This changes the unit of the C axis from 40.0 deg to 40mm with metric input. The time required for distribution is calculated as follows:

$$\frac{\sqrt{20^2 + 40^2}}{300} \doteq 0.14907 \text{ (min)}$$
The feed rate for the C axis is
$$\frac{40}{0.14907} \doteq 268.3 \text{ deg/min}$$


In simultaneous 3 axes control, the feed rate is calculated the same way as in 2 axes control.

Examples

• Linear interpolation



Feedrate for the rotation axis



4.4 CIRCULAR INTERPOLATION (G02,G03)

The command below will move a tool along a circular arc.

Format

Arc in the XpYp plane
$$G17 \left\{ \begin{array}{l} G02 \\ G03 \end{array} \right\} \quad Xp_Yp_ \quad \left\{ \begin{array}{l} I_J_ \\ R_ \end{array} \right\} \quad F_;$$
 Arc in the $ZpXp$ plane
$$G18 \left\{ \begin{array}{l} G02 \\ G03 \end{array} \right\} \quad Xp_p_ \quad \left\{ \begin{array}{l} I_K_ \\ R_ \end{array} \right\} \quad F_$$
 Arc in the $YpZp$ plane
$$G19 \left\{ \begin{array}{l} G02 \\ G03 \end{array} \right\} \quad Yp_Zp_ \quad \left\{ \begin{array}{l} J_K_ \\ R_ \end{array} \right\} \quad F_$$


Table 4.4 Description of the command format

Command	Description	
G17	Specification of arc on XpYp plane	
G18	Specification of arc on ZpXp plane	
G19	Specification of arc on YpZp plane	
G02	Circular Interpolation Clockwise direction (CW)	
G03	Circular Interpolation Counterclockwise direction (CCW)	
X _{p_}	Command values of X axis or its parallel axis (set by parameter No. 1022)	
Y _p _	Command values of Y axis or its parallel axis (set by parameter No. 1022)	
Z _p _	Command values of Z axis or its parallel axis (set by parameter No. 1022)	
I_	X _p axis distance from the start point to the center of an arc with sign	
J_	$\boldsymbol{Y}_{\!p}$ axis distance from the start point to the center of an arc with sign	
k_	$\boldsymbol{Z}_{\boldsymbol{p}}$ axis distance from the start point to the center of an arc with sign	
R_	Arc radius (with sign)	
F_	Feedrate along the arc	

Explanations

Direction of the circular interpolation

"Clockwise" (G02) and "counterclockwise" (G03) on the X_pY_p plane (Z_pX_p plane or Y_pZ_p plane) are defined when the X_pY_p plane is viewed in the positive–to–negative direction of the Z_p axis (Y_p axis or X_p axis, respectively) in the Cartesian coordinate system. See the figure below.




Distance moved on an arc

The end point of an arc is specified by address Xp, Yp or Zp, and is expressed as an absolute or incremental value according to G90 or G91. For the incremental value, the distance of the end point which is viewed from the start point of the arc is specified.

 Distance from the start point to the center of arc The arc center is specified by addresses I, J, and K for the Xp, Yp, and Zp axes, respectively. The numerical value following I, J, or K, however, is a vector component in which the arc center is seen from the start point, and is always specified as an incremental value irrespective of G90 and G91, as shown below.

I, J, and K must be signed according to the direction.



I0,J0, and K0 can be omitted. When X_p , Y_p , and Z_p are omitted (the end point is the same as the start point) and the center is specified with I, J, and K, a 360° arc (circle) is specified.


G021; Command for a circle

If the difference between the radius at the start point and that at the end point exceeds the permitted value in a parameter (No.3410), an P/S alarm (No.020) occurs.

Arc radius

The distance between an arc and the center of a circle that contains the arc can be specified using the radius, R, of the circle instead of I, J, and K. In this case, one arc is less than 180° , and the other is more than 180° are considered. When an arc exceeding 180° is commanded, the radius must be specified with a negative value. If Xp, Yp, and Zp are all omitted, if the end point is located at the same position as the start point and when R is used, an arc of 0° is programmed

G02R; (The cutter does not move.)



Feedrate

The feedrate in circular interpolation is equal to the feed rate specified by the F code, and the feedrate along the arc (the tangential feedrate of the arc) is controlled to be the specified feedrate.

The error between the specified feedrate and the actual tool feedrate is $\pm 2\%$ or less. However, this feed rate is measured along the arc after the cutter compensation is applied

Restrictions


If I, J, K, and R addresses are specified simultaneously, the arc specified by address R takes precedence and the other are ignored.

If an axis not comprising the specified plane is commanded, an alarm is displayed.

For example, if axis U is specified as a parallel axis to X axis when plane XY is specified, an P/S alarm (No.028)is displayed.

When an arc having a center angle approaching 180° is specified, the calculated center coordinates may contain an error. In such a case, specify the center of the arc with I, J, and K.

Examples



The above tool path can be programmed as follows;

(1) In absolute programming
G92X200.0 Y40.0 Z0;
G90 G03 X140.0 Y100.0R60.0 F300.;
G02 X120.0 Y60.0R50.0;
or
G92X200.0 Y40.0Z0;
G90 G03 X140.0 Y100.0I-60.0 F300.;
G02 X120.0 Y60.0I-50.0;
(2) In incremental programming
G91 G03 X-60.0 Y60.0 R60.0 F300.;
G02 X-20.0 Y-40.0 R50.0;
or

G91 G03 X-60.0 Y60.0 I-60.0 F300.;

G02 X-20.0 Y-40.0 I-50.0;

4.5 HELICAL INTERPOLATION (G02,G03)

Format

Helical interpolation which moved helically is enabled by specifying up to two other axes which move synchronously with the circular interpolation by circular commands.

Synchronously with arc of XpYp plane

$$\label{eq:G17} \text{G17} \left\{ \begin{array}{c} \text{G02} \\ \text{G03} \end{array} \right\} \ \ \text{χp_Y$p_} \quad \left\{ \begin{array}{c} \text{I_J_} \\ \text{R_} \end{array} \right\} \alpha_(\beta_) \text{F_};$$

Synchronously with arc of ZpXp plane

$$\text{G18} \left\{ \begin{array}{c} \text{G02} \\ \text{G03} \end{array} \right\} \ \, \text{Xp_Zp_} \quad \left\{ \begin{array}{c} \text{I_K_} \\ \text{R_} \end{array} \right\} \ \, \alpha_(\beta_)\text{F_};$$

Synchronously with arc of YpZp plane


$$\begin{array}{c} \textbf{G19} \, \left\{ \begin{array}{c} \textbf{G02} \\ \textbf{G03} \end{array} \right\} \, \, \, \textbf{Yp_Zp_} \quad \left\{ \begin{array}{c} \textbf{J_K_} \\ \textbf{R_} \end{array} \right\} \, \, \, \alpha_(\beta_)\textbf{F_;}$$

 α,β : Any one axis where circular interpolation is not applied. Up to two other axes can be specified.

Explanations

The command method is to simply or secondary add a move command axis which is not circular interpolation axes. An F command specifies a feed rate along a circular arc. Therefore, the feed rate of the linear axis is as follows:

Determine the feed rate so the linear axis feed rate does not exceed any of the various limit values. Bit 0 (HFC) of parameter No. 1404 can be used to prevent the linear axis feedrate from exceeding various limit values.



Restrictions

Cutter compensation is applied only for a circular arc.

Tool offset and tool length compensation cannot be used in a block in which a helical interpolation is commanded.

4.6 CYLINDRICAL INTERPOLATION (G07.1)

Format

The amount of travel of a rotary axis specified by an angle is once internally converted to a distance of a linear axis along the outer surface so that linear interpolation or circular interpolation can be performed with another axis. After interpolation, such a distance is converted back to the amount of travel of the rotary axis.

The cylindrical interpolation function allows the side of a cylinder to be developed for programming. So programs such as a program for cylindrical cam grooving can be created very easily.

G07.1 Pr; Starts the cylindrical interpolation mode (enables cylindrical interpolation).

G07.1 № 0 ; The cylindrical interpolation mode is cancelled.

IP: An address for the rotation axis r: The radius of the cylinder

Specify G07.1 IP r; and G07.1 IP 0; in separate blocks. G107 can be used instead of G07.1.

Explanations

 Plane selection (G17, G18, G19)

Feedrate

 Circular interpolation (G02,G03) Use parameter (No. 1022) to specify whether the rotation axis is the X–, Y–, or Z–axis, or an axis parallel to one of these axes. Specify the G code to select a plane for which the rotation axis is the specified linear axis. For example, when the rotation axis is an axis parallel to the X–axis, G17 must specify an Xp–Yp plane, which is a plane defined by the rotation axis and the Y–axis or an axis parallel to the Y–axis.

Only one rotation axis can be set for cylindrical interpolation.

A feedrate specified in the cylindrical interpolation mode is a speed on the developed cylindrical surface.

In the cylindrical interpolation mode, circular interpolation is possible with the rotation axis and another linear axis. Radius R is used in commands in the same way as described in II–4.4.

The unit for a radius is not degrees but millimeters (for metric input) or inches (for inch input).

< Example Circular interpolation between the Z axis and C axis > For the C axis of parameter (No.1022), 5 (axis parallel with the X axis) is to be set. In this case, the command for circular interpolation is

G18 Z__C_; G02 (G03) Z__C__R__;

For the C axis of parameter (No.1022), 6 (axis parallel with the Y axis) may be specified instead. In this case, however, the command for circular interpolation is

G19 C_Z_; G02 (G03) Z_C_R_;

Tool offset

Cylindrical interpolation accuracy

To perform tool offset in the cylindrical interpolation mode, cancel any ongoing cutter compensation mode before entering the cylindrical interpolation mode. Then, start and terminate tool offset within the cylindrical interpolation mode.

In the cylindrical interpolation mode, the amount of travel of a rotary axis specified by an angle is once internally converted to a distance of a linear axis on the outer surface so that linear interpolation or circular interpolation can be performed with another axis. After interpolation, such a distance is converted back to an angle. For this conversion, the amount of travel is rounded to a least input increment.

So when the radius of a cylinder is small, the actual amount of travel can differ from a specified amount of travel. Note, however, that such an error is not accumulative.

If manual operation is performed in the cylindrical interpolation mode with manual absolute on, an error can occur for the reason described above

The actual amount
$$=$$
 $\left\lceil \frac{\text{MOTION REV}}{2 \times 2\pi R} \right\rceil \times \text{Specified value} \times \frac{2 \times 2\pi R}{\text{MOTION REV}} \right\rceil$

MOTION REV: The amount of travel per rotation of the rotation axis (Setting value of parameter No. 1260)

R : Workpiece radius

:Rounded to the least input increment

Limitations

 Arc radius specification in the cylindrical interpolation mode

 Circular interpolation and cutter compensation

Positioning

- Coordinate system setting
- Cylindrical interpolation mode setting
- Tool offset
- Index table indexing function

In the cylindrical interpolation mode, an arc radius cannot be specified with word address I, J, or K.

If the cylindrical interpolation mode is started when cutter compensation is already applied, circular interpolation is not correctly performed in the cylindrical interpolation mode.

In the cylindrical interpolation mode, positioning operations (including those that produce rapid traverse cycles such as G28, G53, G73, G74, G76, G80 through G89) cannot be specified. Before positioning can be specified, the cylindrical interpolation mode must be cancelled. Cylindrical interpolation (G07.1) cannot be performed in the positioning mode (G00).


In the cylindrical interpolation mode, a workpiece coordinate system (G92, G54 through G59) or local coordinate system (G52) cannot be specified.

In the cylindrical interpolation mode, the cylindrical interpolation mode cannot be reset. The cylindrical interpolation mode must be cancelled before the cylindrical interpolation mode can be reset.

A tool offset must be specified before the cylindrical interpolation mode is set. No offset can be changed in the cylindrical interpolation mode.

Cylindrical interpolation cannot be specified when the index table index function is being used.


Examples



4.7 THREAD CUTTING (G33)

Format

Straight threads with a constant lead can be cut. The position coder mounted on the spindle reads the spindle speed in real—time. The read spindle speed is converted to the feedrate per minute to feed the tool.



Explanations

In general, thread cutting is repeated along the same tool path in rough cutting through finish cutting for a screw. Since thread cutting starts when the position coder mounted on the spindle outputs a 1–turn signal, threading is started at a fixed point and the tool path on the workpiece is unchanged for repeated thread cutting. Note that the spindle speed must remain constant from rough cutting through finish cutting. If not, incorrect thread lead will occur.

In general, the lag of the servo system, etc. will produce somewhat incorrect leads at the starting and ending points of a thread cut. To compensate for this, a thread cutting length somewhat longer than required should be specified.

Table 4.7 lists the ranges for specifying the thread lead.

Table. 4.7 Ranges of lead sizes that can be specified

	Least command increment	Command value range of the lead
	0.001 mm	F1 to F50000 (0.01 to 500.00mm)
mm input	0.0001 mm	F1 to F50000 (0.01 to 500.00mm)
la de insust	0.0001 inch	F1 to F99999 (0.0001 to 9.9999inch)
Inch input	0.00001 inch	F1 to F99999 (0.0001 to 9.9999inch)

NOTE

1 The spindle speed is limited as follows:

 $1 \le \text{ spindle speed} \le \frac{\text{Maximum feedrate}}{\text{Thread lead}}$

Spindle speed : rpm Thread lead : mm or inch

Maximum feedrate: mm/min or inch/min; maximum command-specified feedrate for feed-per-minute mode or maximum feedrate that is determined based on mechanical restrictions including those related to motors, whichever is smaller

- 2 Cutting feedrate override is not applied to the converted feedrate in all machining process from rough cutting to finish cutting. The feedrate is fixed at 100%
- 3 The converted feedrate is limited by the upper feedrate specified.
- 4 Feed hold is disabled during threading. Pressing the feed hold key during thread cutting causes the machine to stop at the end point of the next block after threading (that is, after the G33 mode is terminated)

Examples

Thread cutting at a pitch of 1.5mm G33 Z10. F1.5;

4.8 SKIP FUNCTION(G31)

Linear interpolation can be commanded by specifying axial move following the G31 command, like G01. If an external skip signal is input during the execution of this command, execution of the command is interrupted and the next block is executed.

The skip function is used when the end of machining is not programmed but specified with a signal from the machine, for example, in grinding. It is used also for measuring the dimensions of a workpiece.

Format

G31 IP_;

G31: One-shot G code (If is effective only in the block in which it is specified)

Explanations

The coordinate values when the skip signal is turned on can be used in a custom macro because they are stored in the custom macro system variable #5061 to #5064, as follows:

#5061 X axis coordinate value

#5062 Y axis coordinate value

#5063 Z axis coordinate value

#5064 4th axis coordinate value

WARNING

Disable feedrate override, dry run, and automatic acceleration/deceleration (however, these become available by setting the parameter SKF No.6200#7 to 1.) when the feedrate per minute is specified, allowing for an error in the position of the tool when a skip signal is input. These functions are enabled when the feedrate per rotation is specified.

NOTE

If G31 command is issued while cutter compensation C is applied, an P/S alarm of No.035 is displayed. Cancel the cutter compensation with the G40 command before the G31 command is specified.

Examples

 The next block to G31 is an incremental command




Fig. 4.8 (a) The next block is an incremental command

 The next block to G31 is an absolute command for 1 axis




Fig. 4.8 (b) The next block is an absolute command for 1 axis

 The next block to G31 is an absolute command for 2 axes




Fig. 4.8 (c) The next block is an absolute command for 2 axes

4.9 HIGH SPEED SKIP SIGNAL (G31)

The skip function operates based on a high–speed skip signal (connected directly to the NC; not via the PMC) instead of an ordinary skip signal. In this case, up to eight signals can be input.

Delay and error of skip signal input is 0-2 msec at the NC side (not considering those at the PMC side).

This high–speed skip signal input function keeps this value to 0.1 msec or less, thus allowing high precision measurement.

For details, refer to the appropriate manual supplied from the machine tool builder.

Format

G31 IP_;

G31: One–shot G code (If is effective only in the block in which it is specified)

5

FEED FUNCTIONS

5.1 GENERAL

Feed functions

- Override
- Automatic acceleration/ deceleration

The feed functions control the feedrate of the tool. The following two feed functions are available:

- 1. Rapid traverse
 When the positioning command (G00) is specified, the tool moves at a rapid traverse feedrate set in the CNC (parameter No. 1420).
- 2. Cutting feed
 The tool moves at a programmed cutting feedrate.

Override can be applied to a rapid traverse rate or cutting feedrate using the switch on the machine operator's panel.

To prevent a mechanical shock, acceleration/deceleration is automatically applied when the tool starts and ends its movement (Fig. 5.1 (a)).




Fig. 5.1 (a) Automatic acceleration/deceleration (example)

Tool path in a cutting feed

If the direction of movement changes between specified blocks during cutting feed, a rounded–corner path may result (Fig. 5.1 (b)).




Fig. 5.1 (b) Example of tool path between two blocks

In circular interpolation, a radial error occurs (Fig. 5.1(c)).




Fig. 5.1 (c) Example of radial error in circular interpolation

The rounded–corner path shown in Fig. 5.1(b) and the error shown in Fig. 5.1(c) depend on the feedrate. So, the feedrate needs to be controlled for the tool to move as programmed.

5.2 RAPID TRAVERSE

Format

G00 IP_;

G00: G code (group 01) for positioning (rapid traverse)

IP_; Dimension word for the end point

Explanations

The positioning command (G00) positions the tool by rapid traverse. In rapid traverse, the next block is executed after the specified feedrate becomes 0 and the servo motor reaches a certain range set by the machine tool builder (in–position check).

A rapid traverse rate is set for each axis by parameter No. 1420, so no rapid traverse feedrate need be programmed.

The following overrides can be applied to a rapid traverse rate with the switch on the machine operator's panel:F0, 25, 50, 100%

F0: Allows a fixed feedrate to be set for each axis by parameter No. 1421. For detailed information, refer to the appropriate manual of the machine tool builder.

5.3 CUTTING FEED

Feedrate of linear interpolation (G01), circular interpolation (G02, G03), etc. are commanded with numbers after the F code.

In cutting feed, the next block is executed so that the feedrate change from the previous block is minimized.

Four modes of specification are available:

- 1. Feed per minute (G94)
 After F, specify the amount of feed of the tool per minute.
- 2. Feed per revolution (G95)
 After F, specify the amount of feed of the tool per spindle revolution.
- 3. Inverse time feed (G93)
 Specify the inverse time (FRN) after F.
- 4. F1-digit feed Specify a desired one-digit number after F. Then, the feedrate set with the CNC for that number is set.

Format

Feed per minute

G94; G code (group 05) for feed per minute F_; Feedrate command (mm/min or inch/min)

Feed per revolution

G95; G code (group 05) for feed per revolution F_; Feedrate command (mm/rev or inch/rev)

Inverse time feed (G93)

G93; Inverse time feed command G code (05 group)

F_; Feedrate command (1/min)

F1-digit feed

FN;

N: Number from 1 to 9

Explanations

 Tangential speed constant control Cutting feed is controlled so that the tangential feedrate is always set at a specified feedrate.




Fig. 5.3 (a) Tangential feedrate (F)

• Feed per minute (G94)

After specifying G94 (in the feed per minute mode), the amount of feed of the tool per minute is to be directly specified by setting a number after F. G94 is a modal code. Once a G94 is specified, it is valid until G95 (feed per revolution) is specified. At power—on, the feed per minute mode is set.

An override from 0% to 254% (in 1% steps) can be applied to feed per minute with the switch on the machine operator's panel. For detailed information, see the appropriate manual of the machine tool builder.




Fig. 5.3 (b) Feed per minute

WARNING

No override can be used for some commands such as for threading.

Feed per revolution (G95)

After specifying G95 (in the feed per revolution mode), the amount of feed of the tool per spindle revolution is to be directly specified by setting a number after F. G95 is a modal code. Once a G95 is specified, it is valid until G94 (feed per minute) is specified.

An override from 0% to 254% (in 1% steps) can be applied to feed per revolution with the switch on the machine operator's panel. For detailed information, see the appropriate manual of the machine tool builder.




Fig. 5.3 (c) Feed per revolution

CAUTION

When the speed of the spindle is low, feedrate fluctuation may occur. The slower the spindle rotates, the more frequently feedrate fluctuation occurs.

One-digit F code feed

When a one-digit number from 1 to 9 is specified after F, the feedrate set for that number in a parameter (Nos. 1451 to 1459) is used. When F0 is specified, the rapid traverse rate is applied.

The feedrate corresponding to the number currently selected can be increased or decreased by turning on the switch for changing F1–digit feedrate on the machine operator's panel, then by rotating the manual pulse generator.

The increment/decrement, ΔF , in feedrate per scale of the manual pulse generator is as follows:

$$\Delta F = \frac{Fmax}{100X}$$

Fmax : feedrate upper limit for F1–F4 set by parameter (No.1460), or feedrate upper limit for F5–F9 set by parameter (No.1461)

X : any value of 1–127 set by parameter (No.1450)

The feedrate set or altered is kept even while the power is off. The current feed rate is displayed on the CRT screen.

Cutting feedrate clamp

A common upper limit can be set on the cutting feedrate along each axis with parameter No. 1422. If an actual cutting feedrate (with an override applied) exceeds a specified upper limit, it is clamped to the upper limit. Parameter No. 1430 can be used to specify the maximum cutting feedrate for each axis only for linear interpolation and circular interpolation. When the cutting feedrate along an axis exceeds the maximum feedrate for the axis as a result of interpolation, the cutting feedrate is clamped to the maximum feedrate.

NOTE

An upper limit is set in mm/min or inch/min. CNC calculation may involve a feedrate error of $\pm 2\%$ with respect to a specified value. However, this is not true for acceleration/deceleration. To be more specific, this error is calculated with respect to a measurement on the time the tool takes to move 500 mm or more during the steady state:

Reference

See Appendix C for range of feedrate command value.

5.4 CUTTING FEEDRATE CONTROL


Cutting feedrate can be controlled, as indicated in Table 5.4.

Table 5.4 Cutting Feedrate Control

	Function name	G code	Validity of G code	Description	
Exact stop		G09	This function is valid for specified blocks only.	The tool is decelerated at the end point of a block, then an in–position check is made. Then the next block is executed.	
Exact stop mode G61		G61	Once specified, this function is valid until G62, G63, or G64 is specified.	The tool is decelerated at the end point of a block, then an in–position check is made. Then the next block is executed.	
Cutting mode G6		G64	Once specified, this function is valid until G61, G62, or G63 is specified.	The tool is not decelerated at the end point of a block, but the next block is executed.	
Tapping mode		G63	Once specified, this function is valid until G61, G62, or G64 is specified.	The tool is not decelerated at the end point of a block, but the next block is executed. When G63 is specified, feedrate override and feed hold are invalid.	
Auto- matic	Automatic override for inner corners	G62	Once specified, this function is valid until G61, G63, or G64 is specified.	When the tool moves along an inner corner during cutter compensation, override is applied to the cutting feedrate to suppress the amount of cutting per unit of time so that a good surface finish can be produced.	
	Internal circular cutting feedrate change	_	This function is valid in the cutter compensation mode, regardless of the G code.	The internal circular cutting feedrate is changed.	

NOTE

- 1 The purpose of in–position check is to check that the servo motor has reached within a specified range (specified with a parameter by the machine tool builder). In–position check is not performed when bit 5 (NCI) of parameter No. 1601 is set to 1.
- 2 Inner corner angle θ : $2^{\circ} < \theta \le \alpha \le 178^{\circ}$ (α is a set value)



Format

Exact stop G09 IP; G61;

Cutting mode G64;

Tapping mode G63;

Automatic corner override G62;

5.4.1 Exact Stop (G09, G61) Cutting Mode (G64) Tapping Mode (G63)

Explanations

The inter-block paths followed by the tool in the exact stop mode, cutting mode, and tapping mode are different (Fig. 5.4.1).




Fig. 5.4.1 Example of tool paths from block (1) to block (2)

CAUTION

The cutting mode (G64 mode) is set at power–on or system clear.

5.4.2 Automatic Corner Override

When cutter compensation is performed, the movement of the tool is automatically decelerated at an inner corner and internal circular area. This reduces the load on the cutter and produces a smoothly machined surface.

5.4.2.1 Automatic Override for Inner Corners (G62)

Explanations

• Override condition

When G62 is specified, and the tool path with cutter compensation applied forms an inner corner, the feedrate is automatically overridden at both ends of the corner.

There are four types of inner corners (Fig. 5.4.2.1 (a)).

 $2, \le \theta \le \theta p \le 178$, in Fig. 5.4.2.1 (a)

 θp is a value set with parameter No. 1711. When θ is approximately equal to θp , the inner corner is determined with an error of 0.001, or less.





Fig. 5.4.2.1 (a) Inner corner

Override range

When a corner is determined to be an inner corner, the feedrate is overridden before and after the inner corner. The distances Ls and Le, where the feedrate is overridden, are distances from points on the cutter center path to the corner (Fig. 5.4.2.1 (b), Fig. 5.4.2.1 (c), Fig. 5.4.2.1 (d)). Ls and Le are set with parameter Nos. 1713 and 1714.



Flg. 5.4.2.1 (b) Override Range (Straight Line to Straight Line)

When a programmed path consists of two arcs, the feedrate is overridden if the start and end points are in the same quadrant or in adjacent quadrants (Fig. 5.4.2.1 (c)).




Fig. 5.4.2.1 (c) Override Range (Arc to Arc)

Regarding program (2) of an arc, the feedrate is overridden from point a to point b and from point c to point d (Fig. 5.4.2.1 (d)).




Fig. 5.4.2.1 (d) Override Range (Straight Line to Arc, Arc to Straight Line)

Override value

An override value is set with parameter No. 1712. An override value is valid even for dry run and F1–digit specification.

In the feed per minute mode, the actual feedrate is as follows:

F × (automatic override for inner corners) × (feedrate override)

Limitations

Acceleration/deceleration
 n before interpolation

Override for inner corners is disabled during acceleration/deceleration before interpolation.

Start-up/G41, G42

Override for inner corners is disabled if the corner is preceded by a start-up block or followed by a block including G41 or G42.

Offset

Override for inner corners is not performed if the offset is zero.

5.4.2.2

Internal Circular Cutting Feedrate Change

For internally offset circular cutting, the feedrate on a programmed path is set to a specified feedrate (F) by specifying the circular cutting feedrate with respect to F, as indicated below (Fig. 5.4.2.2). This function is valid in the cutter compensation mode, regardless of the G62 code.

$$F \times \frac{Rc}{Rp}$$

Rc : Cutter center path radius Rp : Programmed radius

It is also valid for the dry run and the one-digit F command.




Fig. 5.4.2.2 Internal circular cutting feedrate change

If Rc is much smaller than Rp, Rc/Rp \doteq 0; the tool stops. A minimum deceleration ratio (MDR) is to be specified with parameter No. 1710. When Rc/Rp \leq MDR, the feedrate of the tool is (F×MDR).

NOTE

When internal circular cutting must be performed together with override for inner corners, the feedrate of the tool is as follows:

$$F \times \frac{Rc}{Rn} \times$$
 (override for the inner corners)×(feedrate override)

5.5 DWELL (G04)

Format

Dwell G04 X_; or G04 P_;

X_: Specify a time (decimal point permitted)P_: Specify a time (decimal point not permitted)

Explanations

By specifying a dwell, the execution of the next block is delayed by the specified time. In addition, a dwell can be specified to make an exact check in the cutting mode (G64 mode).

When neither P nor X is specified, exact stop is performed.

Bit 1 (DWL) of parameter No. 3405 can specify dwell for each rotation in feed per rotation mode (G95).

Table 5.5 (a) Command value range of the dwell time (Command by X)

Increment system	Command value range	Dwell time unit
IS-B	0.001A99999.999	s
IS-C	0.0001A9999.9999	

Table 5.5 (b) Command value range of the dwell time (Command by P)

Increment system	Command value range	Dwell time unit	
IS-B	1A9999999	0.001 s	
IS-C	1A9999999	0.0001 s	



REFERENCE POSITION

A CNC machine tool has a special position where, generally, the tool is exchanged or the coordinate system is set, as described later. This position is referred to as a reference position.

6.1 REFERENCE POSITION RETURN

General

• Reference position

The reference position is a fixed position on a machine tool to which the tool can easily be moved by the reference position return function. For example, the reference position is used as a position at which tools are automatically changed. Up to four reference positions can be specified by setting coordinates in the machine coordinate system in parameters (No. 1240 to 1243).




Fig. 6.1 (a) Machine zero point and reference positions

 Reference position return and movement from the reference position Tools are automatically moved to the reference position via an intermediate position along a specified axis. Or, tools are automatically moved from the reference position to a specified position via an intermediate position along a specified axis. When reference position return is completed, the lamp for indicating the completion of return goes on.




Fig. 6.1 (b) Reference position return and return form the reference position

 Reference position return check The reference position return check (G27) is the function which checks whether the tool has correctly returned to the reference position as specified in the program. If the tool has correctly returned to the reference position along a specified axis, the lamp for the axis goes on.

Format

 Reference position return

G28 IP; Reference position return

G30 P2 IP_; 2nd reference position return

(P2 can be omitted.)

G30 P3 IP_; 3rd reference position return

G30 P4 IP; 4th reference position return

P: Command specifying the intermediate position (Absolute/incremental command)

 Return from reference position

G29IP_;

P: Command specifying the destination of return from reference position (Absolute/incremental command)

 Reference position return check

G27IP_;

Explanations

Reference position return (G28)

Positioning to the intermediate or reference positions are performed at the rapid traverse rate of each axis.

Therefore, for safety, the cutter compensation, and tool length compensation should be cancelled before executing this command.

The coordinates for the intermediate position are stored in the CNC only for the axes for which a value is specified in a G28 block. For the other axes, the previously specified coordinates are used.

Example N1 G28 X40.0 ; Intermediate position (X40.0) N2 G28 Y60.0 ; Intermediate position (X40.0, Y60.0)

 2nd, 3rd, and 4th reference position return (G30) In a system without an absolute–position detector, the first, third, and fourth reference position return functions can be used only after the reference position return (G28) or manual reference position return (see III–3.1) is made. The G30 command is generally used when the automatic tool changer (ATC) position differs from the reference position.

 Return from the reference position (G29) In general, it is commanded immediately following the G28 command or G30. For incremental programming, the command value specifies the incremental value from the intermediate point.

Positioning to the intermediate or reference points are performed at the rapid traverse rate of each axis.

When the workpiece coordinate system is changed after the tool reaches the reference position through the intermediate point by the G28 command, the intermediate point also shifts to a new coordinate system. If G29 is then commanded, the tool moves to to the commanded position through the intermediate point which has been shifted to the new coordinate system.

The same operations are performed also for G30 commands.

 Reference position return check (G27) G27 command positions the tool at rapid traverse rate. If the tool reaches the reference position, the reference position return lamp lights up. However, if the position reached by the tool is not the reference position, an alarm (No. 092) is displayed.

Restrictions

 Status the machine lock being turned on

The lamp for indicating the completion of return does not go on when the machine lock is turned on, even when the tool has automatically returned to the reference position. In this case, it is not checked whether the tool has returned to the reference position even when a G27 command is specified.

 First return to the reference position after the power has been turned on (without an absolute position detector) When the G28 command is specified when manual return to the reference position has not been performed after the power has been turned on, the movement from the intermediate point is the same as in manual return to the reference position.

In this case, the tool moves in the direction for reference position return specified in parameter ZMIx (bit 5 of No. 1006). Therefore the specified intermediate position must be a position to which reference position return is possible.

- Reference position return check in an offset mode
- Lighting the lamp when the programmed position does not coincide with the reference position

In an offset mode, the position to be reached by the tool with the G27 command is the position obtained by adding the offset value. Therefore, if the position with the offset value added is not the reference position, the lamp does not light up, but an alarm is displayed instead. Usually, cancel offsets before G27 is commanded.

When the machine tool system is an inch system with metric input, the reference position return lamp may also light up even if the programmed position is shifted from the reference position by the least setting increment. This is because the least setting increment of the machine tool system is smaller than its least command increment.

Reference

 Manual reference position return See III-3.1.

Examples

G28G90X1000.0Y500.0; (Programs movement from A to B) T1111; (Changing the tool at the reference position) G29X1300.0Y200.0; (Programs movement from B to C)




Fig. 6.1 (c) Reference position return and return from the reference position



COORDINATE SYSTEM

By teaching the CNC a desired tool position, the tool can be moved to the position. Such a tool position is represented by coordinates in a coordinate system. Coordinates are specified using program axes. When three program axes, the X-axis, Y-axis, and Z-axis, are used,

$X_Y_Z_$

This command is referred to as a dimension word.

coordinates are specified as follows:




Fig. 7 Tool position specified by X40.0Y50.0Z25.0

Coordinates are specified in one of following three coordinate systems:

- (1) Machine coordinate system
- (2) Workpiece coordinate system
- (3) Local coordinate system

The number of the axes of a coordinate system varies from one machine to another. So, in this manual, a dimension word is represented as IP_.

7.1 MACHINE COORDINATE SYSTEM

The point that is specific to a machine and serves as the reference of the machine is referred to as the machine zero point. A machine tool builder sets a machine zero point for each machine.

A coordinate system with a machine zero point set as its origin is referred to as a machine coordinate system.

A machine coordinate system is set by performing manual reference position return after power—on (see III—3.1). A machine coordinate system, once set, remains unchanged until the power is turned off.

Format

(G90)G53 IP_;

IP_; Absolute dimension word

Explanations

 Selecting a machine coordinate system (G53) When a command is specified the position on a machine coordinate system, the tool moves to the position by rapid traverse. G53, which is used to select a machine coordinate system, is a one–shot G code; that is, it is valid only in the block in which it is specified on a machine coordinate system. Specify an absolute command (G90) for G53. When an incremental command (G91) is specified, the G53 command is ignored. When the tool is to be moved to a machine–specific position such as a tool change position, program the movement in a machine coordinate system based on G53.

Restrictions


- Cancel of the compensation function
- G53 specification immediately after power–on

Reference

When the G53 command is specified, cancel the cutter compensation, tool length offset, and tool offset.

Since the machine coordinate system must be set before the G53 command is specified, at least one manual reference position return or automatic reference position return by the G28 command must be performed after the power is turned on. This is not necessary when an absolute–position detector is attached.

When manual reference position return is performed after power–on, a machine coordinate system is set so that the reference position is at the coordinate values of (α, β) set using parameter No.1240.



7.2 WORKPIECE COORDINATE SYSTEM

A coordinate system used for machining a workpiece is referred to as a workpiece coordinate system. A workpiece coordinate system is to be set with the CNC beforehand (setting a workpiece coordinate system).

A machining program sets a workpiece coordinate system (selecting a workpiece coordinate system).

A set workpiece coordinate system can be changed by shifting its origin (changing a workpiece coordinate system).

7.2.1

Setting a Workpiece Coordinate System

A workpiece coordinate system can be set using one of three methods:

(1) Method using G92

A workpiece coordinate system is set by specifying a value after G92 in the program.

(2) Automatic setting

If bit 0 of parameter SPR No. 1201 is set beforehand, a workpiece coordinate system is automatically set when manual reference position return is performed (see Part III–3.1.).

(3) Input using the CRT/MDI panel

Six workpiece coordinate systems can be set beforehand using the MDI panel (see Part III–11.4.6.).

When using an absolute command, establish the workpiece coordinate system in any of the above ways.

Format

 Setting a workpiece coordinate system by G92


(G90) G92 IP_

Explanations

A workpiece coordinate system is set so that a point on the tool, such as the tool tip, is at specified coordinates. If a coordinate system is set using G92 during tool length offset, a coordinate system in which the position before offset matches the position specified in G92 is set.


Cutter compensation is cancelled temporarily with G92.

Examples



Example 2

Setting the coordinate system by the G92X600.0Z1200.0; command (The base point on the tool holder is the start point for the program.)



If an absolute command is issued, the base point moves to the commanded position. In order to move the tool tip to the commanded position, the difference from the tool tip to the base point is compensated by tool length offset.

7.2.2 Selecting a Workpiece Coordinate System

The user can choose from set workpiece coordinate systems as described below. (For information about the methods of setting, see II–7.2.1.)

- (1) Once a workpiece coordinate system is selected by G92 or automatic workpiece coordinate system setting, absolute commands work with the workpiece coordinate system.
- (2) Choosing from six workpiece coordinate systems set using the CRT/MDI panel

By specifying a G code from G54 to G59, one of the workpiece coordinate systems 1 to 6 can be selected.

- G54 Workpiece coordinate system 1
- G55 Workpiece coordinate system 2
- G56 Workpiece coordinate system 3
- G57 Workpiece coordinate system 4
- G58 Workpiece coordinate system 5
- G59 Workpiece coordinate system 6

Workpiece coordinate system 1 to 6 are established after reference position return after the power is turned on. When the power is turned on, G54 coordinate system is selected.

Examples




Fig. 7.2.2

7.2.3 Changing Workpiece Coordinate System

The six workpiece coordinate systems specified with G54 to G59 can be changed by changing an external workpiece zero point offset value or workpiece zero point offset value.

Three methods are available to change an external workpiece zero point offset value or workpiece zero point offset value.

- (1) Inputting from the MDI panel (see III–11.4.6)
- (2) Programming by G10 or G92
- (3) Using the external data input function An external workpiece zero point offset value can be changed by input signal to CNC. Refer to machine tool builder's manual for details




Fig. 7.2.3 Changing an external workpiece zero point offset value or workpiece zero point offset value

Format

Changing by G10

G10 L2 Pp IP_;

p=0 : External workpiece zero point offset value

p=1 to 6: Workpiece zero point offset value correspond to workpiece

coordinate system 1 to 6

P: For an absolute command (G90), workpiece zero point offset for each axis.

For an incremental command (G91), value to be added to the set workpiece zero point offset for each axis (the result of addition becomes the new workpiece zero point offset).

Changing by G92

G92 IP_;

Explanations

- Changing by G10
- Changing by G92

With the G10 command, each workpiece coordinate system can be changed separately.


By specifying G92IP_;, a workpiece coordinate system (selected with a code from G54 to G59) is shifted to set a new workpiece coordinate system so that the current tool position matches the specified coordinates (\mathbb{P}_{-}).


Then, the amount of coordinate system shift is added to all the workpiece zero point offset values. This means that all the workpiece coordinate systems are shifted by the same amount.

WARNING

When a coordinate system is set with G92 after an external workpiece zero point offset value is set, the coordinate system is not affected by the external workpiece zero point offset value. When G92X100.0Z80.0; is specified, for example, the coordinate system having its current tool reference position at X = 100.0 and Z = 80.0 is set.

Examples





X' – Z' New workpiece coordinate system

X – Z - Original workpiece coordinate system

A: Offset value created by G92

B: Workpiece zero point offset value in the G54 C: Workpiece zero point offset value in the G55 Suppose that a G54 workpiece coordinate system is specified. Then, a G55 workpiece coordinate system where the black circle on the tool (figure at the left) is at (600.0,12000.0) can be set with the following command if the relative relationship between the G54 workpiece coordinate system and G55 workpiece coordinate system is set correctly:G92X600.0Z1200.0;Also, suppose that pallets are loaded at two different positions. If the relative relationship of the coordinate systems of the pallets at the two positions is correctly set by handling the coordinate systems as the G54 workpiece coordinate system and G55 workpiece coordinate system, a coordinate system shift with G92 in one pallet causes the same coordinate system shift in the other pallet. This means that workpieces on two pallets can be machined with the same program just by specifying G54 or G55.

7.2.4

Workpiece coordinate system preset (G92.1)

The workpiece coordinate system preset function presets a workpiece coordinate system shifted by manual intervention to the pre-shift workpiece coordinate system. The latter system is displaced from the machine zero point by a workpiece zero point offset value.

There are two methods for using the workpiece coordinate system preset function. One method uses a programmed command (G92.1). The other uses MDI operations on the absolute position display screen, relative position display screen, and overall position display screen (III–11.1.4).


Format

G92.1 IP 0;

P 0; Specifies axis addresses subject to the workpiece coordinate system preset operation. Axes that are not specified are not subject to the preset operation.

Explanations


When manual reference position return operation is performed in the reset state, a workpiece coordinate system is shifted by the workpiece zero point offset value from the machine coordinate system zero point. Suppose that the manual reference position return operation is performed when a workpiece coordinate system is selected with G54. In this case, a workpiece coordinate system is automatically set which has its zero point displaced from the machine zero point by the G54 workpiece zero point offset value; the distance from the zero point of the workpiece coordinate system to the reference position represents the current position in the workpiece coordinate system.



If an absolute position detector is provided, the workpiece coordinate system automatically set at power—up has its zero point displaced from the machine zero point by the G54 workpiece zero point offset value. The machine position at the time of power—up is read from the absolute position detector and the current position in the workpiece coordinate system is set by subtracting the G54 workpiece zero point offset value from this machine position. The workpiece coordinate system set by these operations is shifted from the machine coordinate system using the commands and operations listed next page.

- (a) Manual intervention performed when the manual absolute signal is off
- (b) Move command executed in the machine lock state
- (c) Movement by handle interrupt
- (d) Operation using the mirror image function
- (e) Setting the local coordinate system using G52, or shifting the workpiece coordinate system using G92

In the case of (a) above, the workpiece coordinate system is shifted by the amount of movement during manual intervention.



In the operation above, a workpiece coordinate system once shifted can be preset using G code specification or MDI operation to a workpiece coordinate system displaced by a workpiece zero point offset value from the machine zero point. This is the same as when manual reference position return operation is performed on a workpiece coordinate system that has been shifted. In this example, such G code specification or MDI operation has the effect of returning workpiece coordinate system zero point WZn to the original zero point WZo, and the distance from WZo to Pn is used to represent the current position in the workpiece coordinate system.

Bit 3 (PPD) of parameter No. 3104 specifies whether to preset relative coordinates (RELATIVE) as well as absolute coordinates.

When no workpiece coordinate system option (G54 to G59) is selected, the workpiece coordinate system is preset to the coordinate system set by automatic workpiece coordinate system setting. When automatic workpiece coordinate system setting is not selected, the workpiece coordinate system is preset with its zero point placed at the reference position.

Limitations

- Cutter compensation, tool length compensation, tool offset
- Program restart
- Prohibited modes

When using the workpiece coordinate system preset function, cancel compensation modes: cutter compensation, tool length compensation, and tool offset. If the function is executed without cancelling these modes, compensation vectors are temporarily cancelled.

The workpiece coordinate system preset function is not executed during program restart.

Do not use the workpiece coordinate system preset function when the scaling, coordinate system rotation, programmable image, or drawing copy mode is set.

7.2.5 Adding Workpiece Coordinate Systems (G54.1 or G54)

Besides the six workpiece coordinate systems (standard workpiece coordinate systems) selectable with G54 to G59, 48 additional workpiece coordinate systems (additional workpiece coordinate systems) can be used. Alternatively, up to 300 additional workpiece coordinate systems can be used.

Format

- Selecting the additional workpiece coordinate systems
- Setting the workpiece zero point offset value in the additional workpiece coordinate systems

G54.1Pn; or G54Pn;

Pn: Codes specifying the additional workpiece coordinate systems

n : 1 to 48

G10L20 Pn IP_;

Pn : Codes specifying the workpiece coordinate system for setting

the workpiece zero point offset value

n : 1 to 48

 ${\rm I\!P}_-$: Axis addresses and a value set as the workpiece zero point

offset

Explanations

 Selecting the additional workpiece coordinate systems When a P code is specified together with G54.1 (G54), the corresponding coordinate system is selected from the additional workpiece coordinate systems (1 to 48).

A workpiece coordinate system, once selected, is valid until another workpiece coordinate system is selected. Standard workpiece coordinate system 1 (selectable with G54) is selected at power–on.

G54.1 P1 Additional workpiece coordinate system 1 G54.1 P2 Additional workpiece coordinate system 2 G54.1 P48 Additional workpiece coordinate system 48

 Setting the workpiece zero point offset value in the additional workpiece coordinate systems When an absolute workpiece zero point offset value is specified, the specified value becomes a new offset value. When an incremental workpiece zero point offset value is specified, the specified value is added to the current offset value to produce a new offset value.

As with the standard workpiece coordinate systems, the following operations can be performed for a workpiece zero point offset in an additional workpiece coordinate system:

- (1) The OFFSET function key can be used to display and set a workpiece zero point offset value.
- (2) The G10 function enables a workpiece zero point offset value to be set by programming (refer to II–7.2.3).

- (3) A custom macro allows a workpiece zero point offset value to be handled as a system variable.
- (4) Workpiece zero point offset data can be entered or output as external data.
- (5) The PMC window function enables workpiece zero point offset data to be read as program command modal data.

Limitations

Specifying P codes

A P code must be specified after G54.1 (G54). If G54.1 is not followed by a P code in the same block, additional workpiece coordinate system 1 (G54.1P1) is assumed.

If a value not within the specifiable range is specified in a P code, an P/S alarm (No. 030) is issued.

P codes other than workpiece offset numbers cannot be specified in a G54.1 (G54) block.

Example) G54.1 (G54) G04 P1000;

7.3 LOCAL COORDINATE SYSTEM

When a program is created in a workpiece coordinate system, a child workpiece coordinate system can be set for easier programming. Such a child coordinate system is referred to as a local coordinate system.

Format

G52 IP _; Setting the local coordinate system

G52 IP0; Canceling of the local coordinate system

IP_: Origin of the local coordinate system

Explanations

By specifying G52 \mathbb{P}_{-} ;, a local coordinate system can be set in all the workpiece coordinate systems (G54 to G59). The origin of each local coordinate system is set at the position specified by \mathbb{P}_{-} in the workpiece coordinate system.

When a local coordinate system is set, the move commands in absolute mode (G90), which is subsequently commanded, are the coordinate values in the local coordinate system. The local coordinate system can be changed by specifying the G52 command with the zero point of a new local coordinate system in the workpiece coordinate system.

To cancel the local coordinate system and specify the coordinate value in the workpiece coordinate system, match the zero point of the local coordinate system with that of the workpiece coordinate system.




Fig. 7.3 Setting the local coordinate system

WARNING

B-63094EN/01

1 When an axis returns to the reference point by the manual reference point return function, the zero point of the local coordinate system of the axis matches that of the work coordinate system. The same is true when the following command is issued:

G52α0;

α:Axis which returns to the reference point

- 2 The local coordinate system setting does not change the workpiece and machine coordinate systems.
- 3 Whether the local coordinate system is canceled at reset depends on the parameter setting. The local coordinate system is canceled when either CLR, bit 6 of parameter No.3402 or RLC, bit 3 of parameter No.1202 is set to 1.
- 4 If coordinate values are not specified for all axes when setting a workpiece coordinate system with the G92 command, the local coordinate systems of axes for which coordinate values were not specified are not cancelled, but remain unchanged.
- 5 G52 cancels the offset temporarily in cutter compensation.
- 6 Command a move command immediately after the G52 block in the absolute mode.

7.4 PLANE SELECTION

Explanations

Select the planes for circular interpolation, cutter compensation, and drilling by G-code.

The following table lists G-codes and the planes selected by them.

Table 7.4 Plane selected by G code

G code	Selected plane	Хр	Yp	Zp
G17	Xp Yp plane	X-axis or an	Y-axis or an axis parallel to it	Z-axis or an axis parallel to it
G18	Zp Xp plane	axis parallel		
G19	Yp Zp plane	to it		

Xp, Yp, Zp are determined by the axis address appeared in the block in which G17, G18 or G19 is commanded.

When an axis address is omitted in G17, G18 or G19 block, it is assumed that the addresses of basic three axes are omitted.

Parameter No. 1022 is used to specify that an optional axis be parallel to the each axis of the X, Y-, and Z-axes as the basic three axes.

The plane is unchanged in the block in which G17, G18 or G19 is not commanded.

When the power is turned on or the CNC is reset, G17 (XY plane), G18 (ZX plane), or G19 (YZ plane) is selected by bits 1 (G18) and 2 (G19) of parameter 3402.

The movement instruction is irrelevant to the plane selection.

Examples

Plane selection when the X-axis is parallel with the U-axis.

G17X_Y_ XY plane,

G17U_Y_ UY plane

G18X_Z_ ZX plane

X_Y_ Plane is unchanged (ZX plane)

G17 XY plane

G18 ZX plane

G17 U_ UY plane

G18Y_; ZX plane, Y axis moves regardless without any relation to the plane.



COORDINATE VALUE AND DIMENSION

This chapter contains the following topics.

- 8.1 ABSOLUTE AND INCREMENTAL PROGRAMMING (G90, G91)
- 8.2 POLAR COORDINATE COMMAND (G15, G16)
- 8.3 INCH/METRIC CONVERSION (G20, G21)
- **8.4 DECIMAL POINT PROGRAMMING**


8.1 ABSOLUTE AND INCREMENTAL PROGRAMMING (G90, G91)

Format

There are two ways to command travels of the tool; the absolute command, and the incremental command. In the absolute command, coordinate value of the end position is programmed; in the incremental command, move distance of the position itself is programmed. G90 and G91 are used to command absolute or incremental command, respectively.

Absolute command G90 IP_;
Incremental command G91 IP_;

Examples



8.2 POLAR COORDINATE COMMAND (G15, G16)

Format


The end point coordinate value can be input in polar coordinates (radius and angle).

The plus direction of the angle is counterclockwise of the selected plane first axis + direction, and the minus direction is clockwise.


Both radius and angle can be commanded in either absolute or incremental command (G90, G91).

G G G	○ G16; Starting the polar coordinate command (polar coordinate mode)	
GOO IP	Polar coordinate command	
G15 ;	Canceling the polar coordinate command (polar coordinate mode)	
G16	Polar coordinate command	
G15	Polar coordinate command cancel	
G□□	Plane selection of the polar coordinate command (G17, G18 or G19)	
GOO	G90 specifies the zero point of the work coordinate system as the origin of the polar coordinate system, from which a radius is measured. G91 specifies the current position as the origin of the polar coordinate system, from which a radius is measured.	
IP_	Specifying the addresses of axes constituting the plane selected for the polar coordinate system, and their values First axis: radius of polar coordinate Second axis: radius of polar coordinate	

 Setting the zero point of the workpiece coordinate system as the origin of the polar coordinate system Specify the radius (the distance between the zero point and the point) to be programmed with an absolute command. The zero point of the work coordinate system is set as the origin of the polar coordinate system. When a local coordinate system (G52) is used, the origin of the local coordinate system becomes the center of the polar coordinates.




 Setting the current position as the origin of the polar coordinate system Specify the radius (the distance between the current position and the point) to be programmed with an incremental command. The current position is set as the origin of the polar coordinate system.



Examples

Bolt hole circle



 Specifying angles and a radius with absolute commands

N1 G17 G90 G16;

Specifying the polar coordinate command and selecting the XY plane Setting the zero point of the work coordinate system as the origin of the polar coordinate system

N2 G81 X100.0 Y30.0 Z-20.0 R-5.0 F200.0;

Specifying a distance of 100 mm and an angle of 30 degrees **N3 Y150.0**;

Specifying a distance of 100 mm and an angle of 150 degrees **N4 Y270.0**;

Specifying a distance of 100 mm and an angle of 270 degrees **N5 G15 G80**;

Canceling the polar coordinate command

 Specifying angles with incremental commands and a radius with absolute commands

N1 G17 G90 G16;

Specifying the polar coordinate command and selecting the XY plane Setting the zero point of the work coordinate system as the origin of the polar coordinate system

N2 G81 X100.0 Y30.0 Z-20.0 R-5.0 F200.0;

Specifying a distance of 100 mm and an angle of 30 degrees **N3 G91 Y120.0**;

Specifying a distance of 100 mm and an angle of +120 degrees **N4 Y120.0**;

Specifying a distance of 100 mm and an angle of +120 degrees

N5 G15 G80;

Canceling the polar coordinate command

Limitations

 Specifying a radius in the polar coordinate mode In the polar coordinate mode, specify a radius for circular interpolation or helical cutting (G02, G03) with R.

 Axes that are not considered part of a polar coordinate command in the polar coordinate mode Axes specified for the following commands are not considered part of the polar coordinate command:

- Dwell (G04)
- Programmable data input (G10)
- Setting the local coordinate system (G52)
- Converting the workpiece coordinate system (G92)
- Selecting the machine coordinate system (G53)
- Stored stroke check (G22)
- Coordinate system rotation (G68)
- Scaling (G51)

8.3 INCH/METRIC CONVERSION (G20,G21)

Either inch or metric input can be selected by G code.

Format

G20; Inch input
G21; mm input

This G code must be specified in an independent block before setting the coordinate system at the beginning of the program. After the G code for inch/metric conversion is specified, the unit of input data is switched to the least inch or metric input increment of increment system IS–B or IS–C (II–2.3). The unit of data input for degrees remains unchanged. The unit systems for the following values are changed after inch/metric conversion:

- Feedrate commanded by F code
- Positional command
- Work zero point offset value
- Tool compensation value
- Unit of scale for manual pulse generator
- Movement distance in incremental feed
- Some parameters

When the power is turned on, the G code is the same as that held before the power was turned off.

WARNING

- 1 G20 and G21 must not be switched during a program.
- 2 When switching inch input (G20) to metric input (G21) and vice versa, the tool compensation value must be re—set according to the least input increment.
 - However, when bit 0 (OIM) of parameter 5006 is 1, tool compensation values are automatically converted and need not be re–set.

CAUTION

For the first G28 command after switching inch input to metric input or vice versa, operation from the intermediate point is the same as that for manual reference position return. The tool moves from the intermediate point in the direction for reference position return, specified with bit 5 (ZMI) of parameter No. 1006.

NOTE

- 1 When the least input increment and the least command increment systems are different, the maximum error is half of the least command increment. This error is not accumulated.
- 2 The inch and metric input can also be switched using settings.

8.4 DECIMAL POINT PROGRAMMING

Numerical values can be entered with a decimal point. A decimal point can be used when entering a distance, time, or speed. Decimal points can be specified with the following addresses:

X, Y, Z, U, V, W, A, B, C, I, J, K, Q, R, and F.

Explanations

There are two types of decimal point notation: calculator—type notation and standard notation.

When calculator—type decimal notation is used, a value without decimal point is considered to be specified in millimeters inch,or deg. When standard decimal notation is used, such a value is considered to be specified in least input increments. Select either calculator—type or standard decimal notation by using the DPI bit (bit 0 of parameter 3401). Values can be specified both with and without decimal point in a single program.

Examples

Program command	Pocket calculator type decimal point programming	Standard type decimal point programming
X1000 Command value without decimal point	1000mm Unit : mm	1mm Unit : Least input increment (0.001 mm)
X1000.0 Command value with decimal point	1000mm Unit : mm	1000mm Unit : mm

WARNING

In a single block, specify a G code before entering a value. The position of decimal point may depend on the command.

Examples:

G20; Input in inches

X1.0 G04; X1.0 is considered to be a distance and processed as X10000. This command

is equivalent to G04 X10000. The tool dwells for 10 seconds.

G04 X1.0; Equivalent to G04 X1000. The tool dwells for one second.

NOTE

1 Fractions less than the least input increment are truncated.

Examples:

X1.23456; Truncated to X1.234 when the least input increment is 0.001 mm.

Processed as X1.2345 when the least input increment is 0.0001 inch.

2 When more than eight digits are specified, an alarm occurs. If a value is entered with a decimal point, the number of digits is also checked after the value is converted to an integer according to the least input increment.

Examples:

X1.23456789; P/S alarm 0.003 occurs because more than eight digits are specified.

X123456.7; If the least input increment is 0.001 mm, the value is converted to integer

123456700. Because the integer has more than eight digits, an alarm occurs.



SPINDLE SPEED FUNCTION (S FUNCTION)

The spindle speed can be controlled by specifying a value following address S.

This chapter contains the following topics.

- 9.1 SPECIFYING THE SPINDLE SPEED WITH A CODE
- 9.2 SPECIFYING THE SPINDLE SPEED VALUE DIRECTLY (S5-DIGIT COMMAND)
- 9.3 CONSTANT SURFACE SPEED CONTROL (G96, G97)

9.1 SPECIFYING THE SPINDLE SPEED WITH A CODE

When a value is specified after address S, the code signal and strobe signal are sent to the machine to control the spindle rotation speed.

A block can contain only one S code. Refer to the appropriate manual provided by the machine tool builder for details such as the number of digits in an S code or the execution order when a move command and an S code command are in the same block.

9.2 SPECIFYING THE SPINDLE SPEED VALUE DIRECTLY (S5-DIGIT COMMAND) The spindle speed can be specified directly by address S followed by a max.five—digit value (rpm). The unit for specifying the spindle speed may vary depending on the machine tool builder. Refer to the appropriate manual provided by the machine tool builder for details.

9.3 CONSTANT SURFACE SPEED CONTROL (G96, G97)

Specify the surface speed (relative speed between the tool and workpiece) following S. The spindle is rotated so that the surface speed is constant regardless of the position of the tool.

Format

Constant surface speed control command

G96 S<u>OOOOO</u>;

↑ Surface speed (m/min or feet/min)

Note: This surface speed unit may change according to machine tool builder's specification.

Constant surface speed control cancel command

G97 S<u>OOOO</u>;

↑ Spindle speed (rpm)

Note: This surface speed unit may change according to machine tool builder's specification.

Constant surface speed controlled axis command

G96 P α ; P0 : Axis set in the parameter (No. 3770)

P1 : X axis, P2 : Y axis, P3 : Z axis, P4 : 4th axis P5 : 5th axis, P6 : 6th axis, P7 : 7th axis, P8 : 8th axis

 Clamp of maximum spindle speed

G92 S_; The maximum spindle speed (rpm) follows S.

Explanations

 Constant surface speed control command (G96) G96 (constant surface speed control command) is a modal G code. After a G96 command is specified, the program enters the constant surface speed control mode (G96 mode) and specified S values are assumed as a surface speed. A G96 command must specify the axis along which constant surface speed control is applied. A G97 command cancels the G96 mode. When constant surface speed control is applied, a spindle speed higher than the value specified in G92S_; (maximum spindle speed) is clamped at the maximum spindle speed. When the power is turned on, the maximum spindle speed is not yet set and the speed is not clamped. S (surface speed) commands in the G96 mode are assumed as S = 0 (the surface speed is 0) until M03 (rotating the spindle in the positive direction) or M04 (rotating the spindle in the negative direction) appears in the program.




Fig. 9.3 (a) Relation between workpiece radius, spindle speed and surface speed

 Setting the workpiece coordinate system for constant surface speed control To execute the constant surface speed control, it is necessary to set the work coordinate system, and so the coordinate value at the center of the rotary axis, for example, Z axis, (axis to which the constant surface speed control applies) becomes zero.





Fig. 9.3 (b) Example of the workpiece coordinate system for constant surface speed control

Surface speed specified in the G96 mode



Restrictions

- Constant surface speed control for threading
- Constant surface speed control for rapid traverse (G00)

The constant surface speed control is also effective during threading. Accordingly, it is recommended that the constant surface speed control be invalidated with G97 command before starting the scroll threading and taper threading, because the response problem in the servo system may not be considered when the spindle speed changes.

In a rapid traverse block specified by G00, the constant surface speed control is not made by calculating the surface speed to a transient change of the tool position, but is made by calculating the surface speed based on the position at the end point of the rapid traverse block, on the condition that cutting is not executed at rapid traverse.

10

TOOL FUNCTION (T FUNCTION)

General

Two tool functions are available. One is the tool selection function, and the other is the tool life management function.

10.1 TOOL SELECTION FUNCTION

By specifying an up to 8–digit numerical value following address T, tools can be selected on the machine.

One T code can be commanded in a block. Refer to the machine tool builder's manual for the number of digits commandable with address T and the correspondence between the T codes and machine operations. When a move command and a T code are specified in the same block, the commands are executed in one of the following two ways:

- (i) Simultaneous execution of the move command and T function commands.
- (ii) Executing T function commands upon completion of move command execution.

The selection of either (i) or (ii) depends on the machine tool builder's specifications. Refer to the manual issued by the machine tool builder for details.

10.2 TOOL LIFE MANAGEMENT FUNCTION

Tools are classified into various groups, with the tool life (time or frequency of use) for each group being specified. The function of accumulating the tool life of each group in use and selecting and using the next tool previously sequenced in the same group, is called the tool life management function.




Fig. 10.2(a) Tool life management data (number of n tools)

By choosing a tool from a tool group specified by a machining program, the tool life can be managed.




Fig. 10.2(b) Tool Selection by machining program

For two-path control, tool life management is applied independently for each path. Tool life management data is also set for each path.

10.2.1

Tool Life Management Data

Tool life management data consists of tool group numbers, tool numbers, codes specifying tool compensation values, and tool life value.

Explanations

• Tool group number

The Max. number of groups and the number of tools per group that can be registered are set by parameter (GS1,GS2 No. 6800#0, #1) (Table 10.2.1 (a)).

Table 10.2.1 (a) The Max. number of groups and tools that can be registered

GS1 (No. 6800#0)	GS2 (No. 6800#1)	The Max. number of groups and tools without optional function of 512 tool pairs		and tools with o	ber of groups ptional function ool pairs
		Number of group	Number of tool	Number of group	Number of tool
0	0	16	16	64	32
0	1	32	8	128	16
1	0	64	4	256	8
1	1	128	2	512	4

WARNING

When bits 0 or 1 of parameter GS1,GS2 No.6800 is changed, re-register tool life management data with the G10L3 command (for registering and deleting data for all groups). Otherwise, new data pairs cannot be set.

Tool number

Specify a four-digit number after T.

Code specifying tool compensation value

Codes specifying tool offset values are classified into H codes (for tool length offset) and D codes (cutter compensation). The maximum number of the tool compensation value specification code which can be registered is 255 when there are 400 tool compensation values (even if the option for 512 tool life management sets is supported). The maximum number is 32, 64, 99, 200, 499, or 999 when there are 32, 64, 99, 200, 499, or 999 tool compensation values.

NOTE

When codes specifying tool offset values are not used, registration can be omitted.

Tool life value

Refer to II-10.2.2 and II-10.2.4.

10.2.2 Register, Change and Delete of Tool Life Management Data	In a program, tool life management data can be registered in the CNC unit, and registered tool life management data can be changed or deleted.
Explanations	A different program format is used for each of the four types of operations described below.
 Register with deleting all groups 	After all registered tool life management data is deleted, programmed tool life management data is registered.
 Addition and change of tool life management data 	Programmed tool life management data for a group can be added or changed.
Deletion of tool life management data	Programmed tool life management data for a group can be deleted.
 Register of tool life count type 	Count types (time or frequency can be registered for individual groups.
• Life value	Whether tool life is to be indicated by time (minutes) or by frequency, it is set by a parameter LTM (No. 6800 #2). Maximum value of tool life is as follows.

In case of minute:4300(minutes)
In case of frequency :9999(times)

Format

 Register with deleting all groups

Format	Meaning of command
G10L3; P·L-; T-H·D·; T-H·D·; T-H·D·; T-H·D·; T-H·D·; M02 (M30);	G10L3 :Register with deleting all groups P- :Group number L- :Life value T- :Tool number H- :Code specifying tool offset value

 Addition and change of tool life management data

Format		Meaning of command
G10L3P1; P·L-; T-H·D·; T-H·D·; T-H·D·; T-H·D·; G11; M02 (M30);	G10L3 P. L- T- H. D.	:Group number :Life value :Tool number :Code specifying tool offset value (H code) :Code specifying tool offset value (D code) :End of addition and change of group

 Deletion of tool life management data

Format	Meaning of command
G10L3P2; P-; P-; P-; P-;	G10L3P2 :Deletion of group P- :Group number G11 :End of deletion of group
G11 ; M02 (M30) ;	

 Setting a tool life cout type for groups

Format	Meaning of command
G10L3 or G10L3P1); P-L-Q ; T-H-D ; T-H-D ;	Q_: Life count type (1:Frequency, 2:Time)
P-L-Q.; T-H-D.; T-H-D.;	
G11 ; M02 (M30) ;	

CAUTION

When the Q command is omitted, the value set in bit 7 (LTM) of parameter No.6800 is used as the life count type.

10.2.3 Tool Life Management Command in a Machining Program

Explanations

Command

The following command is used for tool life management: $T\nabla\nabla\nabla\nabla$;—Specifies a tool group number.

The tool life management function selects, from a specified group, a tool whose life has not expired, and outputs its T code. In $\nabla\nabla\nabla\nabla$, specify a number calculated by adding the tool life management cancel number specified in parameter 6810 to a group number. For example, to set tool group 1 when the tool life management cancel number is 100, specify T101;

NOTE

When $\nabla\nabla\nabla\nabla$ is less than a tool life management cancel number, the T code is treated as an ordinary T code.

M06;——Terminates life management for the previously used tools, and begins counting the life of the new tools selected with the T code.

WARNING

When an option for speciofying multiple M codes is selected, specify this code by itself or as the first M code.

H99;——Selects the H code of tool life management data for the tool currently being used.

H00;——Cancels tool length offset

D99;——Selects the D code of tool life management data for the tool currently being used.

D00;——Cancels cutter compensation

WARNING

H99 or D99 must be specified after the M06 command. When a code other than H99 or D99 is specified after the M06 command, the H code and D code of tool life management data are not selected.

Types

For tool life management, the four tool change types indicated below are available. The type used varies from one machine to another. For details, refer to the appropriate manual of each machinde tool builder.

Table 10.2.3 Tool Change Type

Tool change type	А	В	С	D
Tool group number spe- cified in the same block as the tool change com- mand (M06)	Previously used tools	Tools to be use	ed next	
Tool life count timing		performed for a roup when M06		Life counting is performed when a tool in the tool group specified in the same block as M06 is specified.
Remarks		Normally, when number is spec- type B is used. alarm is raised tool group num fied by itself as	cified by itself, However, no even if the ber is speci-	When only M06 is speci- fied, P/S alarm No. 153 is issued.
Parameter	No. 6800#7 (M6T)=0 No.6801#7 (M6E)=0	No. 6800# No. 6801#	, ,	No.6801#7 (M6E)=1

NOTE

When a tool group number is specified and a new tool is selected, the new tool selection signal is output.

Examples

Tool change type A

Suppose that the tool life management cancel number is 100.

T101; A tool whose life has not expired is selected from group 1.

(Suppose that tool number 010 is selected.)

M06; Tool life counting is performed for the tool in group 1.

(The life of tool number 010 is counted.)

T102; A tool whose life has not expired is selected from group 2. (Suppose that tool number 100 is selected.)

M06T101; Tool life counting is performed for the tool in group 2.

(The life of tool number 100 is counted.)

The number of the tool currently used (in group 1) is output with a T code signal. (Tool number 010 is output.)

Tool change type B and C

Suppose that the tool life management ignore number is 100.

T101; A tool whose life has not expired is selected from group 1.

(Suppose that tool number 010 is selected.)

M06T102;Tool life counting is performed for the tool in group 1.

(The life of tool number 010 is counted.)

A tool whose life has not expired is selected from group 2.

(Suppose that toolnumber 100 is selected.

M06T103;Tool life counting is lperformed for the tool in group 2.

(The life of tool number 100 is counted.)

A tool whose life has not expired is selected from group 3.

(Suppose that tool number 200 is selected.)

Tool change type D

Suppose that the tool life management ignore number is 100.

T101M06;A tool whose life has not expired is selected from group 1.

(Suppose that tool number 010 is selected.)

Tool life counting is performed for the tool in group 1.

i

T102M06;A tool whose life has not expired is selected from group 2.

(Suppose that tool number 100 is selected.)

Tool life counting is performed for the tool in group 2.

(The life of tool number 100 is counted.)

10.2.4 Tool Life

The life of a tool is specified by a usage frequency (count) or usage time (in minutes).

Explanations

Usage count

The usage count is incremented by 1 for each tool used in a program. In other words, the usage count is incremented by 1 only when the first tool group number and tool change command are specified after the CNC unit enters the automatic operation state from the reset state.

CAUTION

Even if the same tool group number is specified more than once in a program, the usage count is only incremented by 1 and no new tools are selected.

Usage time

When a tool change is specified (M06), tool life management is started for the tools specified by the tool group number. In tool life management, the time during which a tool is used in the cutting mode is counted in four second increments., If the tool group is changed before the incremental time of four seconds elapses, the time is not counted. The time a tool is used for single block stop, feed hold, rapid traverse, dwell, machine lock, and interlock is not counted.

NOTE

- 1 When a tool is selected from available tools, tools are searched starting from the current tool towards the lasttool to find a tool whose life has not expired. When thelast tool is reached during this search, the search restartsfrom the first tool. When it has been determined that there are no tools whose life has not expired, the last tool is selected. When the tool currently being used is changed by tool skip signal, the next new tool is selected using the method described here.
- When tool life is counted by time, the life counting can be overridden using the tool life count override signal. An override from 0 to 99.9 can be applied. When 0 is specified, time is not counted. Before the override capability can be used, bit 2 of parameter LFV No.6801 must be set.
- 3 When tool life counting indicates that the life of the last tool in a group has expired, the tool change signal is output. When tool life is managed by time, the signal is output when the life of the last tool in the group has expired. When tool life is managed by usage frequency (count), the signal is output when the CNC unit is reset or the tool life count restart M code is specified.

11

AUXILIARY FUNCTION

General

There are two types of auxiliary functions; miscellaneous function (M code) for specifying spindle start, spindle stop program end, and so on, and secondary auxiliary function (B code) for specifying index table positioning.

When a move command and miscellaneous function are specified in the same block, the commands are executed in one of the following two ways:

- i) Simultaneous execution of the move command and miscellaneous function commands.
- ii) Executing miscellaneous function commands upon completion of move command execution.

The selection of either sequence depends on the machine tool builder's specification. Refer to the manual issued by the machine tool builder for details.

11.1 AUXILIARY FUNCTION (M FUNCTION)

When a numeral is specified following address M, code signal and a strobe signal are sent to the machine. The machine uses these signals to turn on or off its functions.

Usually, only one M code can be specified in one block. In some cases, however, up to three M codes can be specified for some types of machine tools.

Which M code corresponds to which machine function is determined by the machine tool builder.

The machine processes all operations specified by M codes except those specified by M98, M99,M198 or called subprogram(Parameter No.6071 to 6079), or called custom macro (Parameter No.6080 to 6089). Refer to the machine tool builder's instruction manual for details.

Explanations

• M02,M03 (End of program)

The following M codes have special meanings.

This indicates the end of the main program

Automatic operation is stopped and the CNC unit is reset.

This differs with the machine tool builder.

After a block specifying the end of the program is executed,

control returns to the start of the program.

Bit 5 of parameter 3404 (M02) or bit 4 of parameter 3404 (M30) can be used to disable M02, M30 from returning control to the start of the program.

M00 (Program stop) Automatic operation is stopped after a block containing M00 is executed. When the program is stopped, all existing modal information remains unchanged. The automatic operation can be restarted by actuating the cycle operation. This differs with the machine tool builder.

M01 (Optional stop) Similarly to M00, automatic operation is stopped after a block containing M01 is executed. This code is only effective when the Optional Stop switch on the machine operator's panel has been pressed.

 M98 (Calling of sub – program) This code is used to call a subprogram. The code and strobe signals are not sent. See the subprogram **II**–**12.3** for details.

M99 (End of subprogram) This code indicates the end of a subprogram.

M99 execution returns control to the main program. The code and strobe signals are not sent. See the subprogram section 12.3 for details.

M198 (Calling a subprogram)

This code is used to call a subprogram of a file in the external input/output function. See the description of the subprogram call function (III–4.7) for details.

NOTE

The block following M00, M01, M02, or M30 is not pre—read (buffered). Similarly, ten M codes which do not buffer can be set by parameters (Nos. 3411 to 3420). Refer to the machine tool builder's instruction manual for these M codes.

11.2 MULTIPLE M COMMANDS IN A SINGLE BLOCK

Explanations

In general, only one M code can be specified in a block. However, up to three M codes can be specified at once in a block by setting bit 7 (M3B) of parameter No. 3404 to 1. Up to three M codes specified in a block are simultaneously output to the machine. This means that compared with the conventional method of a single M command in a single block, a shorter cycle time can be realized in machining.

CNC allows up to three M codes to be specified in one block. However, some M codes cannot be specified at the same time due to mechanical operation restrictions. For detailed information about the mechanical operation restrictions on simultaneous specification of multiple M codes in one block, refer to the manual of each machine tool builder.

M00, M01, M02, M30, M98, M99, or M198 must not be specified together with another M code.

Some M codes other than M00, M01, M02, M30, M98, M99, and M198 cannot be specified together with other M codes; each of those M codes must be specified in a single block.

Such M codes include these which direct the CNC to perform internal operations in addition to sending the M codes themselves to the machine. To be specified, such M codes are M codes for calling program numbers 9001 to 9009 and M codes for disabling advance reading (buffering) of subsequent blocks. Meanwhile, multiple of M codes that direct the CNC only to send the M codes themselves (without performing internal operations) can be specified in a single block.

Examples

One M command in a single block	Multiple M commands in a single block
M40 ;	M40M50M60;
M50 ;	G28G91X0Y0Z0;
M60 ;	:
G28G91X0Y0Z0;	:
:	:
:	:
:	:

11.3 THE SECOND AUXILIARY FUNCTIONS (B CODES)

Indexing of the table is performed by address B and a following 8–digit number. The relationship between B codes and the corresponding indexing differs between machine tool builders.

Refer to the manual issued by the machine tool builder for details.

Explanations

- Valid data range
- Specification

0 to 99999999

1. To enable the use of a decimal point, set bit 0 (AUP) of parameter No.3450 to 1.

Command	Output value
B10.	10000
B10	10

2. Use bit 0 (DPI) of parameter No. 3401 to specify whether the magnification for B output will be $\times 1000$ or $\times 1$ when a decimal point is omitted.

	Command	Output value
DPI=1	B1	1000
DPI=0	B1	1

3. Use bit 0 (AUX) of parameter No. 3405 to specify whether the magnification for B output will be ×1000 or ×10000 when a decimal point is omitted for the inch Input system (only when DPI=1).

	Command	Output value
AUX=1	B1	10000
AUX=0	B1	1000

Restrictions

When this functions is used, the B address specifying an axis movement disabled.

12

PROGRAM CONFIGURATION

General

 Main program and subprogram There are two program types, main program and subprogram. Normally, the CNC operates according to the main program. However, when a command calling a subprogram is encountered in the main program, control is passed to the subprogram. When a command specifying a return to the main program is encountered in a subprogram, control is returned to the main program.




Fig. 12 (a) Main program and subprogram

The CNC memory can hold up to 400 main programs and subprograms (63 as standard). A main program can be selected from the stored main programs to operate the machine. See III–9.3 or III–10 in OPERATION for the methods of registering and selecting programs.

Program components

A program consists of the following components:

Table 12 Program components

Components	Descriptions
Tape start	Symbol indicating the start of a program file
Leader section	Used for the title of a program file, etc.
Program start	Symbol indicating the start of a program
Program section	Commands for machining
Comment section	Comments or directions for the operator
Tape end	Symbol indicating the end of a program file




Fig. 12(b) Program configuration

Program section configuration

A program section consists of several blocks. A program section starts with a program number and ends with a program end code.

Program section		
O0001 ;		
N1 G91 G00 X120.0 Y80.0;		
N2 G43 Z-32.0 H01;		
Nn Z0 ;		
M30 ;		

A block contains information necessary for machining, such as a move command or coolant on/off command. Specifying a slash (/) at the start of a block disables the execution of some blocks (see "optional block skip" in II–12.2).

12.1 PROGRAM COMPONENTS OTHER THAN PROGRAM SECTIONS

This section describes program components other than program sections. See II–12.2 for a program section.




Fig. 12.1(a) Program configuration

Explanations

Tape start

The tape start indicates the start of a file that contains NC programs. The mark is not required when programs are entered using SYSTEM P or ordinary personal computers. The mark is not displayed on the screen. However, if the file is output,the mark is automatically output at the start of the file.

Table 12.1(a) Code of a tape start

Name	ISO	EIA	Notation in this manu-
	code	code	al
Tape start	%	ER	%

Leader section

Data entered before the programs in a file constitutes a leader section.

When machining is started, the label skip state is usually set by turning on the power or resetting the system. In the label skip state, all information is ignored until the first end–of–block code is read. When a file is read into the CNC unit from an I/O device, leader sections are skipped by the label skip function.

A leader section generally contains information such as a file header. When a leader section is skipped, even a TV parity check is not made. So a leader section can contain any codes except the EOB code.

The program start code is to be entered immediately after a leader section, that is, immediately before a program section.

This code indicates the start of a program, and is always required to disable the label skip function.

With SYSTEM P or ordinary personal computers, this code can be entered by pressing the return key.

Table 12.1(b) Code of a program start

Name	ISO	EIA	Notation in this manu-
	code	code	al
Program start	LF	CR	;

Program start

NOTE

If one file contains multiple programs, the EOB code for label skip operation must not appear before a second or subsequent program number.

Comment section

Any information enclosed by the control-out and control-in codes is regarded as a comment.

The user can enter a header, comments, directions to the operator, etc. in a comment section.

Table 12.1(c) Codes of a control-in and a control-out

Name	ISO code	EIA code	Notation in this manual	Meaning
Control-out	(2-4-5	(Start of comment section
Control-in)	2-4-7)	End of comment section

When a program is read into memory for memory operation, comment sections, if any, are not ignored but are also read into memory. Note, however, that codes other than those listed in the code table in Appendix A are ignored, and thus are not read into memory.

When data in memory is output on external I/O device(See III-8), the comment sections are also output.

When a program is displayed on the screen, its comment sections are also displayed. However, those codes that were ignored when read into memory are not output or displayed.

During memory operation or DNC operation, all comment sections are ignored.

The TV check function can be used for a comment section by setting parameter CTV (bit 1 of No. 0100).

CAUTION

If a long comment section appears in the middle of a program section, a move along an axis may be suspended for a long time because of such a comment section. So a comment section should be placed where movement suspension may occur or no movement is involved.

NOTE

- 1 If only a control—in code is read with no matching control—out code, the read control—in code is ignored.
- 2 The EOB code cannot be used in a comment.

• Tape end

A tape end is to be placed at the end of a file containing NC programs. If programs are entered using the automatic programming system, the mark need not be entered.

The mark is not displayed on the screen. However, when a file is output, the mark is automatically output at the end of the file.

If an attempt is made to execute % when M02 or M03 is not placed at the end of the program, the P/S alarm (No. 5010) is occurred.

Table 12.1(d) Code of a tape end

Name	ISO	EIA	Notation in this
	code	code	manual
Tape end	%	ER	%

12.2 PROGRAM SECTION CONFIGURATION

This section describes elements of a program section. See II–12.1 for program components other than program sections.




Fig. 12.2(a) Program configuration

Program number

A program number consisting of address O followed by a four-digit number is assigned to each program at the beginning registered in memory to identify the program.

In ISO code, the colon (:) can be used instead of O.

When no program number is specified at the start of a program, the sequence number (N....) at the start of the program is regarded as its program number. If a five—digit sequence number is used, the lower four digits are registered as a program number. If the lower four digits are all 0, the program number registered immediately before added to 1 is registered as a program number. Note, however, that N0 cannot be used for a program number.

If there is no program number or sequence number at the start of a program, a program number must be specified using the MDI panel when the program is stored in memory (See III–8.4 or III–10.1)

NOTE

Program numbers 8000 to 9999 may be used by machine tool builders, and the user may not be able to use these numbers.

Sequence number and block

A program consists of several commands. One command unit is called a block. One block is separated from another with an EOB of end of block code.

Table 12.2(a) EOB code

Name	ISO	EIA	Notation in this
	code	code	manual
End of block (EOB)	LF	CR	•

At the head of a block, a sequence number consisting of address N followed by a number not longer than five digits (1 to 99999) can be placed. Sequence numbers can be specified in a random order, and any numbers can be skipped. Sequence numbers may be specified for all blocks or only for desired blocks of the program. In general, however, it is convenient to assign sequence numbers in ascending order in phase with the machining steps (for example, when a new tool is used by tool replacement, and machining proceeds to a new surface with table indexing.)

N300 X200.0 Z300.0; A sequence number is underlined.

Fig. 12.2 (b) Sequence number and block (example)

NOTE

NO must not be used for the reason of file compatibility with other CNC systems.

Program number 0 cannot be used. So 0 must not be used for a sequence number regarded as a program number.

 TV check (Vertical parity check along tape) A parity check is made for a block on input tape vertically. If the number of characters in one block (starting with the code immediately after an EOB and ending with the next EOB) is odd, an P/S alarm (No.002) is output. No TV check is made only for those parts that are skipped by the label skip function. Bit 1 (CTV) of parameter No. 0100 is used to specify whether comments enclosed in parentheses are counted as characters during TV check. The TV check function can be enabled or disabled by setting on the MDI unit (See III–11.4.3.).

Block configuration (word and address)

A block consists of one or more words. A word consists of an address followed by a number some digits long. (The plus sign (+) or minus sign (-) may be prefixed to a number.)

Word = Address + number (Example : X-1000)

For an address, one of the letters (A to Z) is used; an address defines the meaning of a number that follows the address. Table 12.2 (b) indicates the usable addresses and their meanings.

The same address may have different meanings, depending on the preparatory function specification.

Table 12.2(b) Major functions and addresses

Function	Address	Meaning
Program number	O ⁽¹⁾	Program number
Sequence number	N	Sequence number
Preparatory function	G	Specifies a motion mode (linear, arc, etc.)
Dimension word	X, Y, Z, U, V, W, A, B, C	Coordinate axis move command
	I, J, K	Coordinate of the arc center
	R	Arc radius
Feed function	F	Rate of feed per minute, Rate of feed per revolution
Spindle speed function	S	Spindle speed
Tool function	Т	Tool number
Auxiliary function	М	On/off control on the machine tool
	В	Table indexing, etc.
Offset number	D, H	Offset number
Dwell	P, X	Dwell time
Program number designation	Р	Subprogram number
Number of repetitions	Р	Number of subprogram repetitions
Parameter	P, Q	Canned cycle parameter

NOTE

In ISO code, the colon (:) can also be used as the address of a program number.

N_	G _ 2	(_ Y_	F_	S _	T _	M_ ;	
Sequence number	Preparatory function	Dimension word	Feed- function	Spindle speed function	Tool function	Miscellaneous function	

Fig. 12.2 (c) 1 block (example)

Major addresses and ranges of command values

Major addresses and the ranges of values specified for the addresses are shown below. Note that these figures represent limits on the CNC side, which are totally different from limits on the machine tool side. For example, the CNC allows a tool to traverse up to about 100 m (in millimeter input) along the X axis.

However, an actual stroke along the X axis may be limited to 2 m for a specific machine tool.

Similarly, the CNC may be able to control a cutting federate of up to 240 m/min, but the machine tool may not allow more than 3 m/min. When developing a program, the user should carefully read the manuals of the machine tool as well as this manual to be familiar with the restrictions on programming.

Table 12.2(c) Major addresses and ranges of command values

Function		Address	Input in mm	Input in inch
Program number		O (1)	1–9999	1–9999
Sequence	Sequence number		1–99999	1–99999
Preparato	ory function	G	0–99	0–99
Dimen- sion	Increment system IS-B	X, Y, Z, U, V, W,	±99999.999mm	±9999.9999inch
word	Increment system IS-C	A, B, C, I, J, K, R,	±9999.9999mm	±999.99999inch
Feed per	Increment system IS-B	F	1-240000mm/min	0.01–9600.00 inch/min
minute	Increment system IS-C		1–100000mm/min	0.01–4000.00 inch/min
Feed per revolution		F	0.001–500.00 mm/rev	0.0001-9.9999 inch/rev
Spindle speed function		S	0–20000	0–20000
Tool funct	tion	Т	0-99999999	0-99999999
Auxiliary	function	М	0-99999999	0-99999999
	В		0-99999999	0-99999999
Offset nu	mber	H, D	0-400	0–400
Dwell	Dwell Increment system IS-B		0-99999.999s	0-99999.999s
	Increment system IS-C		0-9999.9999s	0-9999.9999s
	Designation of a program number		1–9999	1–9999
Number of subprogram repetitions		Р	1–999	1–999

NOTE

In ISO code, the colon (:) can also be used as the address of a program number.

Optional block skip

When a slash followed by a number (/n (n=1 to 9)) is specified at the head of a block, and optional block skip switch n on the machine operator panel is set to on, the information contained in the block for which /n corresponding to switch number n is specified is ignored in DNC operation or memory operation.

When optional block skip switch n is set to off, the information contained in the block for which /n is specified is valid. This means that the operator can determine whether to skip the block containing /n.

Number 1 for /1 can be omitted. However, when two or more optional block skip switches are used for one block, number 1 for /1 cannot be omitted.

Example)

(Incorrect) (Correct)

//3 G00X10.0; /1/3 G00X10.0;

This function is ignored when programs are loaded into memory. Blocks containing /n are also stored in memory, regardless of how the optional block skip switch is set.

Programs held in memory can be output, regardless of how the optional block skip switches are set.

Optional block skip is effective even during sequence number search operation.

Depending on the machine tool, all optional block skip switches (1 to 9) may not be usable. Refer to manuals of the machine tool builder to find which switches are usable.

WARNING

1 Position of a slash

A slash (/) must be specified at the head of a block. If a slash is placed elsewhere, the information from the slash to immediately before the EOB code is ignored.

2 Disabling an optional block skip switch

Optional block skip operation is processed when blocks are read from memory or tape into a buffer. Even if a switch is set to on after blocks are read into a buffer, the blocks already read are not ignored.

NOTE

TV and TH check

When an optional block skip switch is on. TH and TV checks are made for the skipped portions in the same way as when the optional block skip switch is off.

Program end

The end of a program is indicated by programming one of the following codes at the end of the program:

Table 12.2(d) Code of a program end

Code	Meaning usage
M02	For main program
M30	
M99	For subprogram

If one of the program end codes is executed in program execution, the CNC terminates the execution of the program, and the reset state is set. When the subprogram end code is executed, control returns to the program that called the subprogram.

WARNING

A block containing an optional block skip code such as /M02 ; , /M30 ; , or /M99 ; is not regarded as the end of a program, if the optional block skip switch on the machine operator's panel is set to on.

(See "Optional block skip".)

12.3 SUBPROGRAM (M98, M99)


If a program contains a fixed sequence or frequently repeated pattern, such a sequence or pattern can be stored as a subprogram in memory to simplify the program.

A subprogram can be called from the main program.


A called subprogram can also call another subprogram.

Format

Subprogram configuration




Subprogram call



Explanations

When the main program calls a subprogram, it is regarded as a one-level subprogram call. Thus, subprogram calls can be nested up to four levels as shown below.



A single call command can repeatedly call a subprogram up to 999 times. For compatibility with automatic programming systems, in the first block, Nxxxx can be used instead of a subprogram number that follows O (or:). A sequence number after N is registered as a subprogram number.

Reference

See III–10 for the method of registering a subprogram.

NOTE

- 1 The M98 and M99 code signal and strobe signal are not output to the machine tool.
- 2 If the subprogram number specified by address P cannot be found, an alarm (No. 078) is output.

Examples


★ M98 P51002;

This command specifies "Call the subprogram (number 1002) five times in succession." A subprogram call command (M98P_) can be specified in the same block as a move command.

★ X1000.0 M98 P1200;

This example calls the subprogram (number 1200) after an X movement.

★ Execution sequence of subprograms called from a main program



A subprogram can call another subprogram in the same way as a main program calls a subprogram.

Special Usage

 Specifying the sequence number for the return destination in the main program If P is used to specify a sequence number when a subprogram is terminated, control does not return to the block after the calling block, but returns to the block with the sequence number specified by P. Note, however, that P is ignored if the main program is operating in a mode other than memory operation mode.

This method consumes a much longer time than the normal return method to return to the main program.

```
      Main program
      Subprogram

      N0010 ...;
      O0010 ...;

      N0020 ...;
      N1020 ...;

      N0030 M98 P1010;
      N1030 ...;

      N0040 ...;
      N1040 ...;

      N0050 ...;
      N1050 ...;

      N0060 ...;
      N1060 M99 P0060;
```

 Using M99 in the main program If M99 is executed in a main program, control returns to the start of the main program. For example, M99 can be executed by placing /M99; at an appropriate location of the main program and setting the optional block skip function to off when executing the main program. When M99 is executed, control returns to the start of the main program, then execution is repeated starting at the head of the main program.

Execution is repeated while the optional block skip function is set to off. If the optional block skip function is set to on, the /M99; block is skipped; control is passed to the next block for continued execution.

If/M99P \underline{n} ; is specified, control returns not to the start of the main program, but to sequence number n. In this case, a longer time is required to return to sequence number n.

```
N0010 ... ;
N0020 ... ;
N0030 ... ;
N0040 ... ;
N0050 ... ;
N0060 M99 P0030 ;
N0070 ... ;
N0080 M02 ;
```

• Using a subprogram only

A subprogram can be executed just like a main program by searching for the start of the subprogram with the MDI.

(See III–9.3 for information about search operation.)

In this case, if a block containing M99 is executed, control returns to the start of the subprogram for repeated execution. If a block containing M99Pn is executed, control returns to the block with sequence number n in the subprogram for repeated execution. To terminate this program, a block containing /M02; or /M30; must be placed at an appropriate location, and the optional block switch must be set to off; this switch is to be set to on first.

	N1010 ;		
-	N1020 ;		
	N1030 ;		Optional block skip
/	N1040 M02;		ON SIGNATURE
	N1050 M99 P1020;	◄	

13

FUNCTIONS TO SIMPLIFY PROGRAMMING

General

This chapter explains the following items:

- 13.1 CANNED CYCLE
- 13.2 RIGID TAPPING
- 13.3 OPTIONAL ANGLE CHAMFERING AND CORNER ROUNDING
- 13.4 EXTERNAL MOTION FUNCTION
- 13.5 INDEX TABLE INDEXING FUNCTION

13.1 CANNED CYCLE

Canned cycles make it easier for the programmer to create programs. With a canned cycle, a frequently—used machining operation can be specified in a single block with a G function; without canned cycles, normally more than one block is required. In addition, the use of canned cycles can shorten the program to save memory.

Table 13.1 (a) lists canned cycles.

Table 13.1 (a) Canned cycles

G code	Drilling(–Z direction)	Operation at the bottom of a hole	Retraction(+Z direction)	Application
G73	Intermittent feed	-	Rapid traverse	High-speed peck drilling cycle
G74	Feed	Dwell→Spindle CW	Feed	Left-hand tapping cycle
G76 Feed		Oriented spindle stop	Rapid traverse	Fine boring cycle
G80	_	-	-	Cancel
G81	Feed	-	Rapid traverse	Drilling cycle, spot drilling cycle
G82	Feed	Dwell	Rapid traverse	Drilling cycle, counter boring cycle
G83	Intermittent feed	_	Rapid traverse	Peck drilling cycle
G84	Feed	Dwell→Spindle CCW	Feed	Tapping cycle
G85	Feed	-	Feed	Boring cycle
G86	Feed	Spindle stop	Rapid traverse	Boring cycle
G87	Feed	Spindle CW	Rapid traverse	Back boring cycle
G88	Feed	Dwell→spindle stop	Manual	Boring cycle
G89	Feed	Dwell	Feed	Boring cycle

Explanations

A canned cycle consists of a sequence of six operations (Fig. 13.1 (a))

Operation 1 Positioning of axes X and Y

(including also another axis)

Operation 2 Rapid traverse up to point R level

Operation 3 Hole machining

Operation 4 Operation at the bottom of a hole

Operation 5 Retraction to point R level

Operation 6 Rapid traverse up to the initial point




Fig. 13.1 Canned cycle operation sequence

Positioning plane

Drilling axis

The positioning plane is determined by plane selection code G17, G18, or G19.

The positioning axis is an axis other than the drilling axis.

Although canned cycles include tapping and boring cycles as well as drilling cycles, in this chapter, only the term drilling will be used to refer to operations implemented with canned cycles.

The drilling axis is a basic axis (X, Y, or Z) not used to define the positioning plane, or any axis parallel to that basic axis.

The axis (basic axis or parallel axis) used as the drilling axis is determined according to the axis address for the drilling axis specified in the same block as G codes G73 to G89.

If no axis address is specified for the drilling axis, the basic axis is assumed to be the drilling axis.

Table13.1(b) Positioning plane and drilling axis

G code	Positioning plane	Drilling axis
G17	Xp-Yp plane	Zp
G18	Zp-Xp plane	Yp
G19	Yp-Zp plane	Хр

Xp: X axis or an axis parallel to the X axis Yp: Y axis or an axis parallel to the Y axis Zp: Z axis or an axis parallel to the Z axis

Examples

Assume that the U, V and W axes be parallel to the X, Y, and Z axes respectively. This condition is specified by parameter No. 1022.

G17	G81	Z:	The Z axis is used for drilling.
G17	G81	\dots :	The W axis is used for drilling.
G18	G81	Y:	The Y axis is used for drilling.
G18	G81	V:	The V axis is used for drilling.
G19	G81	X:	The X axis is used for drilling.
G19	G81	U :	The U axis is used for drilling.

G17 to G19 may be specified in a block in which any of G73 to G89 is not specified.

WARNING


Switch the drilling axis after canceling a canned cycle.

NOTE

A parameter FXY (No. 5101 #0) can be set to the Z axis always used as the drilling axis. When FXY=0, the Z axis is always the drilling axis.

Travel distance along the drilling axis G90/G91

The travel distance along the drilling axis varies for G90 and G91 as follows:



Drilling mode

G73, G74, G76, and G81 to G89 are modal G codes and remain in effect until canceled. When in effect, the current state is the drilling mode. Once drilling data is specified in the drilling mode, the data is retained until modified or canceled.

Specify all necessary drilling data at the beginning of canned cycles; when canned cycles are being performed, specify data modifications only.

Return point level G98/G99

When the tool reaches the bottom of a hole, the tool may be returned to point R or to the initial level. These operations are specified with G98 and G99. The following illustrates how the tool moves when G98 or G99 is specified. Generally, G99 is used for the first drilling operation and G98 is used for the last drilling operation.

The initial level does not change even when drilling is performed in the G99 mode.

G98(Return to initial level)	G99(Return to point R level)
Initial level	Point R level

Repeat

To repeat drilling for equally—spaced holes, specify the number of repeats in K_.

K is effective only within the block where it is specified.

Specify the first hole position in incremental mode (G91).

If it is specified in absolute mode (G90), drilling is repeated at the same position.

Number of repeats K The maximum command value = 9999

If K0 is specified, drilling data is stored, but drilling is not performed.

To cancel a canned cycle, use G80 or a group 01 G code.

Cancel

Group 01 G codes

G00 : Positioning (rapid traverse)

G01: Linear interpolation


G02: Circular interpolation or helical interpolation (CW)

G03 : Circular interpolation or helical interpolation (CCW)

G60: Single direction positioning (when the MDL bit (bit 0 of parameter 5431) is set to 1)

Symbols in figures

Subsequent sections explain the individual canned cycles. Figures in these explanations use the following symbols:



13.1.1 **High-speed Peck Drilling Cycle** (G73)

This cycle performs high-speed peck drilling. It performs intermittent cutting feed to the bottom of a hole while removing chips from the hole.


Format

G73 X_ Y_ Z_ R_ Q_ F_ K_ ;

 $\begin{array}{lll} X_-\,Y_-\colon \mbox{ Hole position data} \\ Z_-\,\colon \mbox{ The distance from point R to the bottom of the hole} \\ R_-\,\colon \mbox{ The distance from the initial level to point R level} \end{array}$

Q_ : Depth of cut for each cutting feed

F_ : Cutting feedrate K_ : Number of repeats



Explanations

The high–speed peck drilling cycle performs intermittent feeding along the Z–axis. When this cycle is used, chips can be removed from the hole easily, and a smaller value can be set for retraction. This allows, drilling to be performed efficiently. Set the clearance, d, in parameter 5114. The tool is retracted in rapid traverse.

Before specifying G73, rotate the spindle using a miscellaneous function (M code).

When the G73 code and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled.

Drilling

In a block that does not contain X, Y, Z, R, or any other axes, drilling is not performed.

Q/R

Specify Q and R in blocks that perform drilling. If they are specified in a block that does not perform drilling, they cannot be stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G73 in a single block. Otherwise, G73 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples

M3 S2000; Cause the spindle to start rotating. G90 G99 G73 X300. Y-250. Z-150. R-100. Q15. F120.;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.
Position, drill hole 6, then return to the initial


level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return **M5**; Cause the spindle to stop rotating.

13.1.2 Left-handed Tapping Cycle (G74)

This cycle performs left-handed tapping. In the left-handed tapping cycle, when the bottom of the hole has been reached, the spindle rotates clockwise.

Format



Explanations

Tapping is performed by turning the spindle counterclockwise. When the bottom of the hole has been reached, the spindle is rotated clockwise for retraction. This creates a reverse thread.

Feedrate overrides are ignored during left–handed tapping. A feed hold does not stop the machine until the return operation is completed.

Before specifying G74, use a miscellaneous function (M code) to rotate the spindle counterclockwise.

When the G74 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G74 in a single block.

Otherwise, G74 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M4 S100; Cause the spindle to start rotating.

G90 G99 G74 X300. Y-250. Z-150. R-120. F120.;

Position, tapping hole 1, then return to point R.
Y–550.;
Position, tapping hole 2, then return to point R.
Y–750.;
Position, tapping hole 3, then return to point R.
X1000.;
Position, tapping hole 4, then return to point R.
Y–550.;
Position, tapping hole 5, then return to point R.

G98 Y-750.; Position, tapping hole 6, then return to the

initial level.

G80 G28 G91 X0 Y0 Z0 ; Return to the reference position return **M5**; Cause the spindle to stop rotating.

13.1.3 Fine Boring Cycle (G76)

Format

The fine boring cycle bores a hole precisely. When the bottom of the hole has been reached, the spindle stops, and the tool is moved away from the machined surface of the workpiece and retracted.


G76 X_ Y_ Z_ R_ Q_ P_ F_ K_;


X_Y_: Hole position data

Z_: The distance from point R to the bottom of the hole
 R_: The distance from the initial level to point R level

Q_ : Shift amount at the bottom of a hole P_ : Dwell time at the bottom of a hole

F_ : Cutting feedrateK_ : Number of repeats





WARNING

Q (shift at the bottom of a hole) is a modal value retained within canned cycles. It must be specified carefully because it is also used as the depth of cut for G73 and G83.

Explanations

When the bottom of the hole has been reached, the spindle is stopped at the fixed rotation position, and the tool is moved in the direction opposite to the tool tip and retracted. This ensures that the machined surface is not damaged and enables precise and efficient boring to be performed.

Before specifying G76, use a miscellaneous function (M code) to rotate the spindle.

When the G76 command and M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled.

Boring

In a block that does not contain X, Y, Z, R, or any additional axes, boring is not performed.

Q/R

Be sure to specify a positive value in Q. If Q is specified with a negative value, the sign is ignored. Set the direction of shift in bits 4 (RD1) and 5 (RD2) of parameter 5101. Specify Q and R in a block that performs boring. If they are specified in a block that does not perform boring, they are not stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G76 in a single block. Otherwise, G76 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples

M3 S500; Cause the spindle to start rotating.
G90 G99 G76 X300. Y-250. Position, bore hole 1, then return to point R.
Z-150. R-120. Q5. Orient at the bottom of the hole, then shift by 5 mm.

P1000 F120.;
Y-550.;
Y-750.;
Position, drill hole 2, then return to point R.
Y-750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y-550.;
Position, drill hole 5, then return to point R.
G98 Y-750.;
Position, drill hole 6, then return to the initial


level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return **M5**; Cause the spindle to stop rotating.

13.1.4 Drilling Cycle, Spot Drilling (G81)

This cycle is used for normal drilling. Cutting feed is performed to the bottom of the hole. The tool is then retracted from the bottom of the hole in rapid traverse.

Format



Explanations

After positioning along the X– and Y–axes, rapid traverse is performed to point R.

Drilling is performed from point R to point Z.

The tool is then retracted in rapid traverse.

Before specifying G81, use a miscellaneous function (M code) to rotate the spindle.

When the G81 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is performed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Restrictions

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G81 in a single block.

Otherwise, G81 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

G98 Y-750.;

Examples M3 S2000; Cause the spindle to start rotating.

G90 G99 G81 X300. Y-250. Z-150. R-100. F120.;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.

Position, drill hole 6, then return to the initial

level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return M5; Cause the spindle to stop rotating.

13.1.5 Drilling Cycle Counter Boring Cycle

Format

(G82)

This cycle is used for normal drilling.

Cutting feed is performed to the bottom of the hole. At the bottom, a dwell is performed, then the tool is retracted in rapid traverse.

This cycle is used to drill holes more accurately with respect to depth.


G82 X_ Y_ Z_ R_ P_ F_ K_;

X_Y_: Hole position data

Z_ : The distance from point R to the bottom of the hole R_ : The distance from the initial level to point R level

P_ : Dwell time at the bottom of a hole

F_ : Cutting feed rateK_ : Number of repeats



Explanations

After positioning along the X- and Y-axes, rapid traverse is performed to point R.

Drilling is then performed from point R to point Z.

When the bottom of the hole has been reached, a dwell is performed. The tool is then retracted in rapid traverse.

Before specifying G82, use a miscellaneous function (M code) to rotate the spindle.

When the G82 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Restrictions

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G81 in a single block.

Otherwise, G81 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S2000; Cause the spindle to start rotating.

G90 G99 G82 X300. Y-250. Z-150. R-100. P1000 F120.;

Position, drill hole 2, and dwell for 1 s at the bottom of the hole, then return to point R.

Y-550.; Position, drill hole 2, then return to point R. Y-750.; Position, drill hole 3, then return to point R. X1000.; Position, drill hole 4, then return to point R. Y-550.; Position, drill hole 5, then return to point R.

G98 Y–750.; Position, drill hole 6, then return to the initial

level.

 $\textbf{G80 G28 G91 X0 Y0 Z0} \hspace{3mm} ; \hspace{3mm} \text{Return to the reference position return}$

M5; Cause the spindle to stop rotating.

13.1.6 **Peck Drilling Cycle** (G83)

This cycle performs peck drilling.

It performs intermittent cutting feed to the bottom of a hole while removing shavings from the hole.

Format

G83 X_Y_Z_R_Q_F_K_;

 $X_\ Y_: \ \mbox{Hole position data}$ $Z_: \ \mbox{The distance from point R to the bottom of the hole}$ R_: The distance from the initial level to point R level

Q_: Depth of cut for each cutting feed

F_: Cutting feedrate K_: Number of repeats

G83 (G98)	G83 (G99)
Point R Y Point Z	Point R Point R level

Explanations

Q represents the depth of cut for each cutting feed. It must always be specified as an incremental value.

In the second and subsequent cutting feeds, rapid traverse is performed up to a d point just before where the last drilling ended, and cutting feed is performed again. d is set in parameter (No.5115).

Be sure to specify a positive value in Q. Negative values are ignored. Before specifying G83, use a miscellaneous function (M code) to rotate the spindle.

When the G83 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• Q/R Specify Q and R in blocks that perform drilling. If they are specified in

a block that does not perform drilling, they cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G82 in a single block.

Otherwise, G82 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S2000; Cause the spindle to start rotating.

G90 G99 G83 X300. Y-250. Z-150. R-100. Q15. F120.;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.

G98 Y–750.; Position, drill hole 6, then return to the initial

level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return M5; Cause the spindle to stop rotating.

13.1.7 Small-hole peck drilling cycle (G83)

An arbor with the overload torque detection function is used to retract the tool when the overload torque detection signal (skip signal) is detected during drilling. Drilling is resumed after the spindle speed and cutting feedrate are changed. These steps are repeated in this peck drilling cycle.

The mode for the small-hole peck drilling cycle is selected when the M code in parameter 5163 is specified. The cycle can be started by specifying G83 in this mode. This mode is canceled when G80 is specified or when a reset occurs.

Format

G83 X_Y_Z_R_Q_F_I_K_P_;

X_ Y_: Hole position data

Z_: Distance from point R to the bottom of the hole

R_: Distance from the initial level to point R


Q_ : Depth of each cutF_ : Cutting feedrate

I_: Forward or backward traveling speed (same format as F above) (If this is omitted, the values in parameters No.5172 and No.5173 are assumed as defaults.)

K_: Number of times the operation is repeated (if required)

P_: Dwell time at the bottom of the hole

(If this is omitted, P0 is assumed as the default.)



- Δ : Initial clearance when the tool is retracted to point R and the clearance from the bottom of the hole in the second or subsequent drilling (parameter 5174)
- Q: Depth of each cut
- --> Path along which the tool travels at the rapid traverse rate
- Path along which the tool travels (forward or backward) at the rapid (- >) traverse rate during the cycle specified with parameters
- Path along which the tool travels at the programmed cutting feedrate

Explanations

 Component operations of the cycle

- *Positioning along the X-axis and Y-axis
- *Positioning at point R along the Z-axis
- *Drilling along the Z-axis (first drilling, depth of cut Q, incremental)
- Retraction (bottom of the hole \rightarrow small clearance Δ , incremental) Retraction (bottom of the hole \rightarrow point R) Advance (point R \rightarrow point at a height of clearance Δ from the bottom of the hole)
- \rightarrow Drilling (second or subsequent drilling, depth of cut Q + Δ , incremental)

Acceleration/deceleration during advancing and retraction is controlled according to the cutting feed acceleration/deceleration time constant. When retraction is performed, the position is checked at point R.

Specifying an M code

When the M code in parameter 5163 is specified, the system enters the mode for the small–hole peck drilling cycle.

This M code does not wait for FIN. Care must be taken when this M code is specified with another M code in the same block.

(Example) $M \square \square M03$; \rightarrow Waits for FIN. $M03 M \square \square$; \rightarrow Does not wait for FIN.

Specifying a G code

When G83 is specified in the mode for the small-hole peck drilling cycle, the cycle is started.

This continuous—state G code remains unchanged until another canned cycle is specified or until the G code for cancelling the canned cycle is specified. This eliminates the need for specifying drilling data in each block when identical drilling is repeated.

Signal indicating that the cycle is in progress

In this cycle, the signal indicating that the small-hole peck drilling cycle is in progress is output after the tool is positioned at the hole position along the axes not used for drilling. Signal output continues during positioning to point R along the drilling axis and terminates upon a return to point R or the initial level. For details, refer to the manual of the machine tool builder.

 Overload torque detection signal A skip signal is used as the overload torque detection signal. The skip signal is effective while the tool is advancing or drilling and the tool tip is between points R and Z. (The signal causes a retraction). For details, refer to the manual of the machine tool builder.

^{*}Dwell

^{*}Return to point R (or initial level) along the Z-axis, cycle end

Changing the drilling conditions

In a single G83 cycle, drilling conditions are changed for each drilling operation (advance \rightarrow drilling \rightarrow retraction). Bits 1 and 2 of parameter OLS, NOL No. 5160 can be specified to suppress the change in drilling conditions.

1. Changing the cutting feedrate

The cutting feedrate programmed with the F code is changed for each of the second and subsequent drilling operations. In parameters No.5166 and No.5167, specify the respective rates of change applied when the skip signal is detected and when it is not detected in the previous drilling operation.

Cutting feedrate = $F \times \alpha$

- <First drilling> α =1.0
- <Second or subsequent drilling> α = α × β ÷ 100, where β is the rate of change for each drilling operation

When the skip signal is detected during the previous drilling operation $\beta=51\%$ (parameter No. 5166)

When the skip signal is not detected during the previous drilling operation:β=b2%(parameter No. 5167)

If the rate of change in cutting feedrate becomes smaller than the rate specified in parameter 5168, the cutting feedrate is not changed. The cutting feedrate can be increased up to the maximum cutting feedrate.

2. Changing the spindle speed

The spindle speed programmed with the S code is changed for each of the second and subsequent advances. In parameters 5164 and 5165, specify the rates of change applied when the skip signal is detected and when it is not detected in the previous drilling operation.

Spindle speed = $S \times \gamma$

- <First drilling> γ =1.0
- <Second or subsequent drilling> $\gamma = \gamma \times \delta \div 100$, where δ is the rate of change for each drilling operation

When the skip signal is detected during the previous drilling operation $\beta=b1\%$ (parameter No. 5164)

When the skip signal is not detected during the previous drilling operation:β=b2%(parameter No. 5165)

When the cutting feedrate reaches the minimum rate, the spindle speed is not changed. The spindle speed can be increased up to a value corresponding to the maximum value of S analog data.

Advance and retraction

Advancing and retraction of the tool are not executed in the same manner as rapid—traverse positioning. Like cutting feed, the two operations are carried out as interpolated operations. The speed is subjected to exponential acceleration/deceleration. Note that the tool life management function excludes advancing and retraction from the calculation of the tool life.

Specifying address I

The forward or backward traveling speed can be specified with address I in the same format as address F, as shown below:

G83 I1000; (without decimal point) G83 I1000.; (with decimal point)

Both commands indicate a speed of 1000 mm/min.

Address I specified with G83 in the continuous–state mode continues to be valid until G80 is specified or until a reset occurs.

Functions that can be specified

In this canned cycle mode, the following functions can be specified:

- · Hole position on the X-axis, Y-axis, and additional axis
- · Operation and branch by custom macro
- · Subprogram (hole position group, etc.) calling
- · Switching between absolute and incremental modes
- · Coordinate system rotation
- Scaling (This command will not affect depth of cut Q or small clearance
- · Dry run
- · Feed hold

Single block

When single-block operation is enabled, drilling is stopped after each retraction.

Feedrate override

The feedrate override function works during cutting, retraction, and advancing in the cycle.

Custom macro interface

The number of retractions made during cutting and the number of retractions made in response to the overload signal received during cutting can be output to custom macro common variables (#100 to #149) specified in parameters No.5170 and No.5171. Parameters No.5170 and No.5171 can specify variable numbers within the range of #100 to #149.

Parameter No.5170: Specifies the number of the common variable to which the number of retractions made during cutting is output.

Parameter No.5171: Specifies the number of the common variable to which the number of retractions made in response to the overload signal received during cutting is output.

Examples

```
\begin{array}{l} N01\,M03\,S_{\_\_}\;;\\ N02\,M_{\_}\;;\\ N03\,G83\,X_{\_}\,Y_{\_}\,Z_{\_}\,R_{\_}\,Q_{\_}\,F_{\_}\,I_{\_}\,K_{\_}\,P_{\_}\;;\\ N04\,X_{\_}\,Y_{\_}\;;\\ \vdots\\ \vdots\\ N10\,G80\;; \end{array}
```

<Description of each block>

N01: Specifies forward spindle rotation and spindle speed.

N02: Specifies the M code to execute **G83** as the small–hole peck drilling cycle. The M code is specified in parameter No.5163.

N03: Specifies the small–hole peck drilling cycle. Drilling data (except K and P) is stored and drilling is started.

N04: Drills a small, deep hole at another position with the same drilling data as for N03


N10: Cancels the small–hole peck drilling cycle. The M code specified in **N02** is also canceled.

13.1.8 Tapping Cycle (G84)

This cycle performs tapping.

In this tapping cycle, when the bottom of the hole has been reached, the spindle is rotated in the reverse direction.

Format



Explanations

Tapping is performed by rotating the spindle clockwise. When the bottom of the hole has been reached, the spindle is rotated in the reverse direction for retraction. This operation creates threads.

Feedrate overrides are ignored during tapping. A feed hold does not stop the machine until the return operation is completed.

Before specifying G84, use a miscellaneous function (M code) to rotate the spindle.

When the G84 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When the K is used to specify number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled.

Drilling

In a block that does not contain X, Y, Z, R, or any other axes, drilling is not performed.

• R

Specify R in blocks that perform drilling. If it is specified in a block that does not perform drilling, it cannot be stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G84 in a single block. Otherwise, G84 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples

M3 S100; Cause the spindle to start rotating. G90 G99 G84 X300. Y-250. Z-150. R-120. P300 F120.;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.
Position, drill hole 6, then return to the initial


level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return **M5**; Cause the spindle to stop rotating.

13.1.9 Boring Cycle (G85)

Format

This cycle is used to bore a hole.



Explanations

After positioning along the X– and Y– axes, rapid traverse is performed to point R.

Drilling is performed from point R to point Z.

When point Z has been reached, cutting feed is performed to return to point R.

Before specifying G85, use a miscellaneous function (M code) to rotate the spindle.

When the G85 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G85 in a single block.

Otherwise, G85 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S100; Cause the spindle to start rotating.

G90 G99 G85 X300. Y-250. Z-150. R-120. F120. ;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.

G98 Y–750.; Position, drill hole 6, then return to the initial

level.

G80 G28 G91 X0 Y0 Z0; Return to the reference position return

M5; Cause the spindle to stop rotating.

13.1.10 Boring Cycle (G86)

Format


This cycle is used to bore a hole.

$\mathsf{G86}\;\mathsf{X}_{-}\;\mathsf{Y}_{-}\;\mathsf{Z}_{-}\;\mathsf{R}_{-}\;\mathsf{F}_{-}\;\mathsf{K}_{-}\;;$

X_Y_: Hole position data

Z_ : The distance from point R to the bottom of the hole R_ : The distance from the initial level to point R level

F_ : Cutting feed rate
K_ : Number of repeats



Explanations

After positioning along the X- and Y-axes, rapid traverse is performed to point R.

Drilling is performed from point R to point Z.

When the spindle is stopped at the bottom of the hole, the tool is retracted in rapid traverse.

Before specifying G86, use a miscellaneous function (M code) to rotate the spindle.

When the G86 command and M code are specified in the same block, the M code is executed at the time of the first positioning operation.

The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G86 in a single block.

Otherwise, G86 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S2000; Cause the spindle to start rotating.

G90 G99 G86 X300. Y-250. Z-150. R-100. F120.;

Position, drill hole 1, then return to point R.
Y–550.;
Position, drill hole 2, then return to point R.
Y–750.;
Position, drill hole 3, then return to point R.
X1000.;
Position, drill hole 4, then return to point R.
Y–550.;
Position, drill hole 5, then return to point R.

G98 Y–750.; Position, drill hole 6, then return to the initial

level.

G80 G28 G91 X0 Y0 Z0 ; Return to the reference position return

M5; Cause the spindle to stop rotating.

13.1.11

Boring Cycle Back Boring Cycle (G87)

Format

This cycle performs accurate boring.

$G87 X_Y_Z_R_Q_F_F_K_;$


X_ Y_: Hole position data


Z_ : The distance from the bottom of the hole to point Z R_ : The distance from the initial level to point R

(the bottom of the hole) level

Q_: Tool shift amount
P_: Dwell time
F_: Cutting feed rate
K_: Number of repeats

Oriented spindle stop





WARNING

Q (shift at the bottom of a hole) is a modal value retained in canned cycles. It must be specified carefully because it is also used as the depth of cut for G73 and G83.

Explanations

After positioning along the X– and Y–axes, the spindle is stopped at the fixed rotation position. The tool is moved in the direction opposite to the tool tip, positioning (rapid traverse) is performed to the bottom of the hole (point R).

The tool is then shifted in the direction of the tool tip and the spindle is rotated clockwise. Boring is performed in the positive direction along the Z-axis until point Z is reached.

At point Z, the spindle is stopped at the fixed rotation position again, the tool is shifted in the direction opposite to the tool tip, then the tool is returned to the initial level. The tool is then shifted in the direction of the tool tip and the spindle is rotated clockwise to proceed to the next block operation.

Before specifying G87, use a miscellaneous function (M code) to rotate the spindle.

When the G87 command and M code are specified in the same block, the M code is executed at the time of the first positioning operation.

The system then proceeds to the next drilling operation. When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed. When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Restrictions

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled.

Boring

In a block that does not contain X, Y, Z, R, or any additional axes, boring is not performed.

Q/R

Be sure to specify a positive value in Q. If Q is specified with a negative value, the sign is ignored. Set the direction of shift in bits 4 (RD1) and 5 (RD2) of parameter No.5101. Specify Q and R in a block that performs boring. If they are specified in a block that does not perform boring, they are not stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G87 in a single block. Otherwise, G87 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples

M3 S500: Cause the spindle to start rotating. G90 G87 X300. Y-250. Position, bore hole 1. Z-150, R-120, Q5, Orient at the initial level, then shift by 5 mm. P1000 F120.; Stop at point Z for 1 s. Y-550.; Position, drill hole 2. Y-750.: Position, drill hole 3. X1000.; Position, drill hole 4. Y-550.; Position, drill hole 5. Y-750.; Position, drill hole 6 G80 G28 G91 X0 Y0 Z0; Return to the reference position return M5; Cause the spindle to stop rotating.

13.1.12 Boring Cycle (G88)

Format

This cycle is used to bore a hole.

G88 X_ Y_ Z_ R_ P_ F_ K_ ;

X_ Y_: Hole position data

Z_ : The distance from point R to the bottom of the hole R_ : The distance from the initial level to point R level

P_: Dwell time at the bottom of a hole

F_ : Cutting feed rateK_ : Number of repeats

G88 (G98)	G88 (G99)
Spindle CW Initial level	Spindle CW Point R Point R level
Point Z Spindle stop after dwell	Point Z Spindle stop after dwell

Explanations

After positioning along the X- and Y-axes, rapid traverse is performed to point R. Boring is performed from point R to point R. When boring is completed, a dwell is performed, then the spindle is stopped. The tool is manually retracted from the bottom of the hole (point R) to point R. At point R, the spindle is rotated clockwise, and rapid traverse is performed to the initial level.

Before specifying G88, use a miscellaneous function (M code) to rotate the spindle.

When the G88 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G88 in a single block.

Otherwise, G88 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S2000; Cause the spindle to start rotating.

G90 G99 G88 X300. Y-250. Z-150. R-100. P1000 F120.;

Position, drill hole 1, return to point R then stop at the bottom of the hole for 1 s.

Y-550.; Position, drill hole 2, then return to point R. Y-750.; Position, drill hole 3, then return to point R. X1000.; Position, drill hole 4, then return to point R.

Y-550.; Position, drill hole 5, then return to point R. **G98 Y-750.**; Position, drill hole 6, then return to the initial

level.

 $\textbf{G80 G28 G91 X0 Y0 Z0} \hspace{0.1cm} ; \hspace{0.3cm} \text{Return to the reference position return} \\$

M5; Cause the spindle to stop rotating.

13.1.13 Boring Cycle (G89)

Format

This cycle is used to bore a hole.


G89 X_ Y_ Z_ R_ P_ F_ K_ ;

X_Y_: Hole position data

Z_ : The distance from point R to the bottom of the holeR_ : The distance from the initial level to point R level

P_: Dwell time at the bottom of a hole

F_ : Cutting feed rateK_ : Number of repeats



Explanations

This cycle is almost the same as G85. The difference is that this cycle performs a dwell at the bottom of the hole.

Before specifying G89, use a miscellaneous function (M code) to rotate the spindle.

When the G89 command and an M code are specified in the same block, the M code is executed at the time of the first positioning operation. The system then proceeds to the next drilling operation.

When K is used to specify the number of repeats, the M code is executed for the first hole only; for the second and subsequent holes, the M code is not executed.

When a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

Limitations

• Axis switching Before the drilling axis can be changed, the canned cycle must be

canceled.

• **Drilling** In a block that does not contain X, Y, Z, R, or any other axes, drilling is

not performed.

• R Specify R in blocks that perform drilling. If it is specified in a block that

does not perform drilling, it cannot be stored as modal data.

• Cancel Do not specify a G code of the 01 group (G00 to G03 or G60 (when the

MDL bit (bit 0 of parameter 5431) is set to 1)) and G89 in a single block.

Otherwise, G89 will be canceled.

• **Tool offset** In the canned cycle mode, tool offsets are ignored.

Examples M3 S100; Cause the spindle to start rotating.

G90 G99 G89 X300. Y-250. Z-150. R-120. P1000 F120.;

Position, drill hole 1, return to point R then stop at the bottom of the hole for 1 s.

Y-550.; Position, drill hole 2, then return to point R. Y-750.; Position, drill hole 3, then return to point R. X1000.; Position, drill hole 4, then return to point R. Y-550.; Position, drill hole 5, then return to point R. Position, drill hole 6, then return to the initial

level.

 $\textbf{G80 G28 G91 X0 Y0 Z0} \hspace{3mm} ; \hspace{3mm} \text{Return to the reference position return}$

M5; Cause the spindle to stop rotating.

13.1.14

Canned Cycle Cancel (G80)

G80 cancels canned cycles.

Format

G80:

Explanations

All canned cycles are canceled to perform normal operation. Point R and point Z are cleared. This means that R=0 and Z=0 in incremental mode. Other drilling data is also canceled (cleared).

Examples

M3 S100; Cause the spindle to start rotating.
G90 G99 G88 X300. Y-250. Z-150. R-120. F120.;

Position, drill hole 1, then return to point R.

Y-550.; Position, drill hole 2, then return to point R. Y-750.; Position, drill hole 3, then return to point R. Y-550.; Position, drill hole 4, then return to point R. Position, drill hole 5, then return to point R.

G98 Y–750.; Position, drill hole 6, then return to the initial level.


G80 G28 G91 X0 Y0 Z0 ;

Return to the reference position return,

canned cycle cancel

M5; Cause the spindle to stop rotating.

Program example using tool length offset and canned cycles



Offset value +200.0 is set in offset No.11, +190.0 is set in offset No.15, and +150.0 is set in offset No.31

Program example

N001 G92X0Y0Z0; Coordinate setting at reference position N002 G90 G00 Z250.0 T11 M6; Tool change N003 G43 Z0 H11; Initial level, tool length offset N004 S30 M3 Spindle start N005 G99 G81X400.0 R Y-350.0 Z-153,0R-97.0 F120; Positioning, then #1 drilling Positioning, then #2 drilling and point R level return N006 Y-550.0; N007 G98Y-750.0; Positioning, then #3 drilling and initial level return Positioning, then #4 drilling and point R level return N008 G99X1200.0; N009 Y-550.0; Positioning, then #5 drilling and point R level return N010 G98Y-350.0; Positioning, then #6 drilling and initial level return G00X0Y0M5: Reference position return, spindle stop N011 Tool length offset cancel, tool change N012 G49Z250.0T15M6; Initial level, tool length offset N013 G43Z0H15; N014 S20M3; Spindle start N015 G99G82X550.0Y-450.0 Positioning, then #7 drilling, point R level return Z-130.0R-97.0P300F70; N016 G98Y-650.0: Positioning, then #8 drilling, initial level return N017 G99X1050.0; Positioning, then #9 drilling, point R level return N018 G98Y-450.0; Positioning, then #10 drilling, initial level return Reference position return, spindle stop N019 G00X0Y0M5; N020 G49Z250.0T31M6: Tool length offset cancel, tool change Initial level, tool length offset N021 G43Z0H31; Spindle start N022 S10M3; G85G99X800.0Y-350.0 Positioning, then #11 drilling, point R level return N023 Z-153.0R47.0F50; N024 G91Y-200.0K2; Positioning, then #12, 13 drilling, point R level return G28X0Y0M5; Reference position return, spindle stop N025 N026 Tool length offset cancel G49Z0; N027 Program stop M0;

13.2 RIGID TAPPING

The tapping cycle (G84) and left–handed tapping cycle (G74) may be performed in standard mode or rigid tapping mode.

In standard mode, the spindle is rotated and stopped along with a movement along the tapping axis using miscellaneous functions M03 (rotating the spindle clockwise), M04 (rotating the spindle counterclockwise), and M05 (stopping the spindle) to perform tapping. In rigid mode, tapping is performed by controlling the spindle motor as if it were a servo motor and by interpolating between the tapping axis and spindle.

When tapping is performed in rigid mode, the spindle rotates one turn every time a certain feed (thread lead) which takes place along the tapping axis. This operation does not vary even during acceleration or deceleration.

Rigid mode eliminates the need to use a floating tap required in the standard tapping mode, thus allowing faster and more precise tapping.

13.2.1 Rigid Tapping (G84)

Format

When the spindle motor is controlled in rigid mode as if it were a servo motor, a tapping cycle can be sped up.

G84 X_ Y_ Z_ R_ P_ F_ K_ ;

X_Y_: Hole position data

Z_ : The distance from point R to the bottom of the hole and the position of the bottom of the hole

R: The distance from the initial level to point R level


P_: Dwell time at the bottom of the hole and at point R when a

return is made : Cutting feedrate

K_: Number of repeats (Only for necessity of repeat)

G84.2 X_ Y_ Z_ R_ P_ F_ L_ ; (FS15 format)

L_ : Number of repeats (only for necessity of repeat)



Explanations

After positioning along the X– and Y–axes, rapid traverse is performed to point R.

Tapping is performed from point R to point Z. When tapping is completed, the spindle is stopped and a dwell is performed. The spindle is then rotated in the reverse direction, the tool is retracted to point R, then the spindle is stopped. Rapid traverse to initial level is then performed. While tapping is being performed, the feedrate override and spindle override are assumed to be 100%.

However, the speed for extraction (operation 5) can be overridden by up to 200% depending on the setting at bit 4 (DOV) of parameter No.5200 and parameter No.5211.

Rigid mode

Rigid mode can be specified using any of the following methods:

- -Specify M29 S***** before a tapping command.
- Specify M29 S***** in a block which contains a tapping command.
- Specify G84 for rigid tapping (parameter G84 No. 5200 #0 set to 1).

Thread lead

In feed-per-minute mode, the thread lead is obtained from the expression, feedrate × spindle speed. In feed-per-revolution mode, the thread lead equals the feedrate speed.

Tool length compensation

If a tool length compensation (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

FS10/11–format command

Rigid tapping can be performed using FS10/11–format commands. Rigid tapping (Including data transfer to and from the PMC) is performed according to the sequence for the FS 21.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled. If the drilling axis is changed in rigid mode, P/S alarm (No. 206) is issued.

S command

If a speed higher than the maximum speed for the gear being used is specified, P/S alarm (No. 200) is issued.

 Distribution amount for the spindle For an analog spindle control circuit:

Upon specifying a speed command requiring more than 4096 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

For a serial spindle:

Upon specifying a speed command requiring more than 32767 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

F command

If a value exceeding the upper limit of cutting feedrate is specified, P/S alarm (No. 011) is issued.

Unit of F command

	Metric input	Inch input	Remarks
G94	1 mm/min	0.01 inch/min	Decimal point programming allowed
G95	0.01 mm/rev	0.0001 inch/rev	Decimal point programming allowed

M29

If an S command and axis movement are specified between M29 and G84, P/S alarm (No. 203) is issued. If M29 is specified in a tapping cycle, P/S alarm (No. 204) is issued.

R

Specify R in a block that performs drilling. If R is specified in a non-drilling block, it is not stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G84 in a single block. Otherwise, G84 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples

Z-axis feedrate 1000 mm/min

Spindle speed 1000 rpm Thread lead 1.0 mm

<Programming of feed per minute>

G94; Specify a feed–per–minute command.

G00 X120.0 Y100.0; Positioning

M29 S1000; Rigid mode specification

G84 Z-100.0 R-20.0 F1000; Rigid tapping <Programming of feed per revolution>

G95; Specify a feed–per–revolution command.

G00 X120.0 Y100.0; Positioning

M29 S1000; Rigid mode specification

G84 Z-100.0 R-20.0 F1.0; Rigid tapping

13.2.2 Left-handed Rigid **Tapping Cycle** (G74)

When the spindle motor is controlled in rigid mode as if it were a servo motor, tapping cycles can be sped up.

Format

G74 X_ Y_ Z_ R_ P_ F_ K_;

X_Y_: Hole position data

Z_: The distance from point R to the bottom of the hole and the position of the bottom of the hole

The distance from the initial level to point R level


P_: Dwell time at the bottom of the hole and at point R when return is made.

: Cutting feedrate

K_ : Number of repeats (Only for necessity of repeat)

G84.3 X_ Y_ Z_ R_ P_ F_ L_ ; (FS15 format)

L_ : Number of repeats (Only for necessity of repeat)



Explanations

After positioning along the X- and Y-axes, rapid traverse is performed to point R.

Tapping is performed from point R to point Z. When tapping is completed, the spindle is stopped and a dwell is performed. The spindle is then rotated in the normal direction, the tool is retracted to point R, then the spindle is stopped. Rapid traverse to initial level is then performed. While tapping is being performed, the feedrate override and spindle override are assumed to be 100%.

However, the speed for extraction (operation 5) can be overridden by up to 200% depending on the setting at bit 4 (DOV) of parameter 5200 and parameter 5211.

Rigid mode

Rigid mode can be specified using any of the following methods:

- Specify M29 S***** before a tapping command.
- Specify M29 S**** in a block which contains a tapping command.
- Specify G84 for rigid tapping. (parameter G84 No. 5200#0 set to1).

Thread lead

In feed-per-minute mode, the thread lead is obtained from the expression, feedrate × spindle speed. In feed-per-revolution mode, the thread lead equals the feedrate.

Tool length compensation

If a tool length offset (G43, G44, or G49) is specified in the canned cycle, the offset is applied at the time of positioning to point R.

FS10/11–format command

Rigid tapping can be performed using FS10/11–format commands. Rigid tapping (Including data transfer to and from the PMC) is performed according to the sequence for the FS 21.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled. If the drilling axis is changed in rigid mode,P/S alarm (No. 206) is issued.

S command

Specifying a rotation speed exceeding the maximum speed for the gear used causes P/S alarm (No. 200).

 Distribution amount for the spindle For an analog spindle control circuit:

Upon specifying a speed command requiring more than 4096 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

For a serial spindle:

Upon specifying a speed command requiring more than 32767 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

F command

Specifying a value that exceeds the upper limit of cutting feedrate causes P/S alarm (No. 011).

Unit of F command

	Metric input	Inch input	Remarks
G94	1 mm/min	0.01 inch/min	Decimal point programming allowed
G95	0.01 mm/rev	0.0001 inch/rev	Decimal point programming allowed

M29

Specifying an S command or axis movement between M29 and G84 causes P/S alarm (No. 203).

Then, specifying M29 in the tapping cycle causes P/S alarm (No. 204).

R

Specify R in a block that performs drilling. If R is specified in a non-drilling block, it ss not stored as modal data.

Cancel

Do not specify a G code of the 01 group (G00 to G03 or G60 (when the MDL bit (bit 0 of parameter 5431) is set to 1)) and G74 in a single block. Otherwise, G74 will be canceled.

Tool offset

In the canned cycle mode, tool offsets are ignored.

Examples Z-axis feedrate 1000 mm/min

Spindle speed 1000 rpm Thread lead 1.0 mm

<Programming for feed per minute>

G94; Specify a feed–per–minute command.

G00 X120.0 Y100.0; Positioning

M29 S1000; Rigid mode specification

G84 Z-100.0 R-20.0 F1000; Rigid tapping < Programming for feed per revolution>

G95; Specify a feed–per–revolution command.

G00 X120.0 Y100.0; Positioning

M29 S1000; Rigid mode specification

G74 Z-100.0 R-20.0 F1.0; Rigid tapping

13.2.3

Peck Rigid Tapping Cycle (G84 or G74)

Tapping a deep hole in rigid tapping mode may be difficult due to chips sticking to the tool or increased cutting resistance. In such cases, the peck rigid tapping cycle is useful.

In this cycle, cutting is performed several times until the bottom of the hole is reached. Two peck tapping cycles are available: High–speed peck tapping cycle and standard peck tapping cycle. These cycles are selected using the PCP bit (bit 5) of parameter 5200.

Format

G84 (or G74) X_Y_Z_R_P_Q_F_K_;

X_ Y_: Hole position data

Z_ : The distance from point R to the bottom of the hole and the position of the bottom of the hole

R_: The distance from the initial level to point R level

P_: Dwell time at the bottom of the hole and at point R when a return is made

Q_: Depth of cut for each cutting feed


F_ : The cutting feedrateK_ : Number of repeats

·High-speed peck tapping cycle (Parameter PCP(No.5200#5=0))

- The tool operates at a normal cutting feedrate. The normal time constant is used.
- (2) Retraction can be overridden. The retraction time constant is used.

- Peck tapping cycle
 (Parameter PCP(No.5200#5=1))
- The tool operates at a normal cutting feedrate. The normal time constant is used.
- (2) Retraction can be overridden. The retraction time constant is used.
- (3) Retraction can be overridden. The normal time constant is used.

During a rigid tapping cycle, in—position check is performed at the end of each operation of (1) and (2) in the peck tapping cycle.



Explanations

 High-speed peck tapping cycle After positioning along the X- and Y-axes, rapid traverse is performed to point R. From point R, cutting is performed with depth Q (depth of cut for each cutting feed), then the tool is retracted by distance d. The DOV bit (bit 4) of parameter 5200 specifies whether retraction can be overridden or not. When point Z has been reached, the spindle is stopped, then rotated in the reverse direction for retraction. Set the retraction distance, d, in parameter 5213.

Peck tapping cycle

After positioning along the X- and Y-axes, rapid traverse is performed to point R level. From point R, cutting is performed with depth Q (depth of cut for each cutting feed), then a return is performed to point R. The DOV bit (bit 4) of parameter 5200 specifies whether the retraction can be overridden or not. The moving of cutting feedrate F is performed from point R to a position distance d from the end point of the last cutting, which is where cutting is restarted. For this moving of cutting feedrate F, the specification of the DOV bit (bit 4) of parameter 5200 is also valid. When point Z has been reached, the spindle is stopped, then rotated in the reverse direction for retraction.

Set d (distance to the point at which cutting is started) in parameter 5213.

Limitations

Axis switching

Before the drilling axis can be changed, the canned cycle must be canceled. If the drilling axis is changed in rigid mode, P/S alarm (No. 206) is issued.

S command

Specifying a rotation speed exceeding the maximum speed for the gear used causes P/S alarm (No. 200).

 Distribution amount for the spindle For an analog spindle control circuit:

Upon specifying a speed command requiring more than 4096 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

For a serial spindle:

Upon specifying a speed command requiring more than 32767 pulses, in detection units, within 8 ms, a P/S alarm (No.202) is issued because the result of such an operation is unpredictable.

• F command

Specifying a value that exceeds the upper limit of cutting feedrate causes alarm (No. 011).

Unit of F

	Metric input	Inch input	Remarks
G94	1 mm/min	0.01 inch/min	Decimal point programming allowed
G95	0.01 mm/rev	0.0001 inch/rev	Decimal point programming allowed

M29

Specifying an S command or axis movement between M29 and G84 causes P/S alarm (No. 203).

Then, specifying M29 in the tapping cycle causes P/S alarm (No. 204).

Q/R

Specify Q and R in a block that performs drilling. If they are specified in a block that does not perform drilling, they are not stored as modal data. When Q0 is specified, the peck rigid tapping cycle is not performed.

13. FUNCTIONS TO SIMPLIFY PROGRAMMING	PROGRAMMING	B-63094EN/01
• Cancel	Do not specify a group 01 G code (G00 to G03) If they are specified together, G73 is canceled	
Tool offset	In the canned cycle mode, tool offsets are igner	ored.
13.2.4 Canned Cycle Cancel (G80)	The rigid tapping canned cycle is canceled. For see II–13.1.14.	or how to cancel this cycle,

13.3 OPTIONAL ANGLE CHAMFERING AND CORNER ROUNDING

Chamfering and corner rounding blocks can be inserted automatically between the following:

- ·Between linear interpolation and linear interpolation blocks
- ·Between linear interpolation and circular interpolation blocks
- ·Between circular interpolation and linear interpolation blocks
- ·Between circular interpolation and circular interpolationblocks

Format

- , C_ Chamfering
- , R_ Corner R


Explanations

When the above specification is added to the end of a block that specifies linear interpolation (G01) or circular interpolation (G02 or G03), a chamfering or corner rounding block is inserted.

Blocks specifying chamfering and corner rounding can be specified consecutively.


Chamfering

After C, specify the distance from the virtual corner point to the start and end points. The virtual corner point is the corner point that would exist if chamfering were not performed.




Corner R

After R, specify the radius for corner rounding.



Examples

N001 G92 G90 X0 Y0; N002 G00 X10.0 Y10.0; N003 G01 X50.0 F10.0,C5.0; N004 Y25.0,R8.0; N005 G03 X80.0 Y50.0 R30.0,R8.0; N006 G01 X50.0,R8.0; N007 Y70.0,C5.0; N008 X10.0,C5.0; N009 Y10.0; N010 G00 X0 Y0; N011 M0;



Restrictions

Plane selection

Chamfering and corner rounding can be performed only in the plane specified by plane selection (G17, G18, or G19). These functions cannot be performed for parallel axes.


Next block

A block specifying chamfering or corner rounding must be followed by a block that specifies a move command using linear interpolation (G01) or circular interpolation (G02 or G03). If the next block does not contain these specifications, P/S alarm No. 052 is issued.

• Plane switching

A chamfering or corner rounding block can be inserted only for move commands which are performed in the same plane. In a block that comes immediately after plane switching (G17, G18, or G19 is specified), neither chamfering nor corner rounding can be specified.

 Exceeding the move range If the inserted chamfering or corner rounding block causes the tool to go beyond the original interpolation move range, P/S alarm No.055 is issued.



Coordinate system

In a block that comes immediately after the coordinate system is changed (G92, or G52 to G59) or a return to the reference position (G28 to G30) is specified, neither chamfering nor corner rounding can be specified.

Travel distance 0

When two linear interpolation operations are performed, the chamfering or corner rounding block is regarded as having a travel distance of zero if the angle between the two straight lines is within +1. When linear interpolation and circular interpolation operations are performed, the corner rounding block is regarded as having a travel distance of zero if the angle between the straight line and the tangent to the arc at the intersection is within +1. When two circular interpolation operations are performed, the corner rounding block is regarded as having a travel distance of zero if the angle between the tangents to the arcs at the intersection is within +1.

Unavailable G codes

The following G codes cannot be used in a block that specifies chamfering or corner rounding. They also cannot be used between chamfering and corner rounding blocks that define a continuous figure.

·G codes of group 00 (except G04)

·G68 of group 16

Threading

Corner rounding cannot be specified in a threading block.

13.4 EXTERNAL MOTION FUNCTION (G81)

Upon completion of positioning in each block in the program, an external operation function signal can be output to allow the machine to perform specific operation.

Concerning this operation, refer to the manual supplied by the machine tool builder.

Format

G81 IP_; (IP_ Axis move command)

Explanations

Every time positioning for the IP_move command is completed, the CNC sends a external operation function signal to the machine. An external operation signal is output for each positioning operation until canceled by G80 or a group 01 G code.

Restrictions

A block without X or Y axis

No external operation signals are output during execution of a block that contains neither X nor Y.

Relationship with canned cycle G81

G81 can also be used for a drilling canned cycle (II–13.1.4). Whether G81 is to be used for an external motion function or for a drilling canned cycle is psecified with EXC, bit 1 of parameter No.5101.

13.5 INDEX TABLE INDEXING FUNCTION

By specifying indexing positions (angles) for the indexing axis (one rotation axis, A, B, or C), the index table of the machining center can be indexed.

Before and after indexing, the index table is automatically unclamped or clamped .

Explanations

Indexing position


Specify an indexing position with address A, B, or C (set to bit 0 of parameter ROT_x No.1006).

The indexing position is specified by either of the following (depending on bit 4 of parameter G90 No.5500):

- 1. Absolute value only
- 2. Absolute or incremental value depending on the specified G code: G90 or G91

A positive value indicates an indexing position in the counterclockwise direction. A negative value indicates an indexing position in the clockwise direction.

The minimum indexing angle of the index table is the value set to parameter 5512. Only multiples of the least input increment can be specified as the indexing angle. If any value that is not a multiple is specified, an P/S alarm (No. 135) occurs. Decimal fractions can also be entered. When a decimal fraction is entered, the 1's digit corresponds to degree units.



Direction and value of rotation

The direction of rotation and angular displacement are determined by either of the following two methods. Refer to the manual written by the machine tool builder to find out which method is applied.

1. Using the miscellaneous function specified in parameter No. 5511 (Address) (Indexing position) (Miscellaneous function);

Rotation in the negative direction

(Address) (Indexing position);

Rotation in the positive direction (No miscellaneous functions are specified.)

An angular displacement greater than 360° is rounded down to the corresponding angular displacement within 360° when bit 2 of parameter ABS No. 5500 specifies this option.

For example, when G90 B400.0 (miscellaneous function); is specified at a position of 0, the table is rotated by 40° in the negative direction.

2. Using no miscellaneous functions

By setting to bits 2, 3, and 4 of parameter ABS, INC,G90 No.5500, operation can be selected from the following two options.

Select the operation by referring to the manual written by the machine tool builder.

(1) Rotating in the direction in which an angular displacement becomes shortest

This is valid only in absolute mode. A specified angular dis-placement greater than 360° is rounded down to the correspond-ing angular displacement within 360° when bit 2 of parameter ABS No.5500 specifies this option.

For example, when G90 B400.0; is specified at a position of 0, the table is rotated by 40°in the positive direction.

(2) Rotating in the specified direction

In the absolute mode, the value set in bit 2 of parameter ABS No.5500 determines whether an angular displacement greater than 360° is rounded down to the corresponding angular displacement within 360°.

In the incremental mode, the angular displacement is not rounded down.

For example, when G90 B720.0; is specified at a position of 0, the table is rotated twice in the positive direction, when the angular displacement is not rounded down.

The table is always rotated around the indexing axis in the rapid traverse mode.

Dry runs cannot be executed for the indexing axis.

WARNING

If a reset is made during indexing of the index table, a reference position return must be made before each time the index table is indexed subsequently.

NOTE

- 1 Specify the indexing command in a single block. If the command is specified in a block in which another controlled axis is specified, P/S alarm (No.136) occurs.
- 2 The waiting state which waits for completion of clamping or unclamping of the index table is indicated on diagnostic screen 12.
- 3 The miscellaneous function specifying a negative direction is processed in the CNC.
 - The relevant M code signal and completion signal are sent between the CNC and the machine.
- 4 If a reset is made while waiting for completion of clamping or unclamping, the clamp or unclamp signal is cleared and the CNC exits the completion wait state.

Feedrate

Indexing function and other functions

Table13.5 (a) Index indexing function and other functions

Item	Explanation
Relative position display	This value is rounded down when bit 1 of parameter REL No. 5500 specifies this option.
Absolute position display	This value is rounded down when bit 2 of parameterABS No. 5500 specifies this option.
Automatic return from the reference position (G29) 2nd reference position return (G30)	Impossible to return
Movement in the machine coordinate system	Impossible to move
Single direction positioning	Impossible to specify
2nd auxiliary function (B code)	Possible with any address other than B that of the indexing axis.
Operations while moving the indexing axis	Unless otherwise processed by the machine, feed hold, interlock and emerrgency stop can be executed. Machine lock can be executed after indexing is completed.
SERVO OFF signal	Disabled The indexing axis is usually in the servo–off state.
Incremental commands for indexing the index table	The workpiece coordinate system and machine coordinate system must always agree with each other on the indexing axis (the workpiece zero point offset value is zero.).
Operations for indexing the index table	Manual operation is disabled in the JOG, INC, or HANDLE mode. A manual reference position return can be made. If the axis selection signal is set to zero during manual reference position return, movement is stopped and the clamp command is not executed.

14

COMPENSATION FUNCTION

General

This chapter describes the following compensation functions:

- 14.1 TOOL LENGTH OFFSET (G43, G44, G49)
- 14.2 AUTOMATIC TOOL LENGTH MEASUREMENT (G37)
- 14.3 TOOL OFFSET (G45–G48)
- 14.4 OVERVIEW OF CUTTER COMPENSATION C (G40-G42)
- 14.5 DETAILS OF CUTTER COMPENSATION C
- 14.6 TOOL COMPENSATION VALUES, NUMBER OF COMPENSATION VALUES, AND ENTERING VALUES FROM THE PROGRAM (G10)
- 14.7 SCALING (G50, G51)
- 14.8 COORDINATE SYSTEM ROTATION (G68, G69)
- 14.9 NORMAL DIRECTION CONTROL (G40.1, G41.1, G42.1 OR G150, G151, G152)
- 14.10 PROGRAMMABLE MIRROR IMAGE (G50.1, G51.1)

14.1 TOOL LENGTH OFFSET (G43,G44,G49)

This function can be used by setting the difference between the tool length assumed during programming and the actual tool length of the tool used into the offset memory. It is possible to compensate the difference without changing the program.

Specify the direction of offset with G43 or G44. Select a tool length offset value from the offset memory by entering the corresponding address and number (H code).




Fig14.1 Tool length offset

The following three methods of tool length offset can be used, depending on the axis along which tool length offset can be made.

·Tool length offset A

Compensates for the difference in tool length along the Z-axis.

·Tool length offset B

Compensates for the difference in tool length along the X–,Y–,or Z–axis.

·Tool length offset C

Compensates for the difference in tool length along a specified axis.

14.1.1 General

Format

	1	1
Tool length offset A	G43 Z_ H_ ; G44 Z_ H_ ;	Explanation of each address G43 : Positive offset
Tool length offset B	G17 G43 Z_ H_; G17 G44 Z_ H_; G18 G43 Y_ H_; G18 G44 Y_ H_; G19 G43 X_ H_; G19 G44 X_ H_;	 G44 : Negative offset G17 : XY plane selection G18 : ZX plane selection G19 : YZ plane selection α : Address of a specified axis H : Address for specifying the tool length offset
Tool length offset C	G43 α_ H_ ; G44 α_ H_ ;	value
Tool length offset cancel	G49 ; or H0 ;	

Explanations

Selection of tool length offset

Select tool length offset A, B, or C, by setting bits 0 and 1 of parameter TLC, TLB No. 5001.

Direction of the offset

When G43 is specified, the tool length offset value (stored in offset memory) specified with the H code is added to the coordinates of the end position specified by a command in the program. When G44 is specified, the same value is subtracted from the coordinates of the end position. The resulting coordinates indicate the end position after compensation, regardless of whether the absolute or incremental mode is selected.

If movement along an axis is not specified, the system assumes that a move command that causes no movement is specified. When a positive value is specified for tool length offset with G43, the tool is moved accordingly in the positive direction. When a positive value is specified with G44, the tool is moved accordingly in the negative direction. When a negative value is specified, the tool is moved in the opposite direction. G43 and G44 are modal G codes. They are valid until another G code belonging to the same group is used.

 Specification of the tool length offset value The tool length offset value assigned to the number (offset number) specified in the H code is selected from offset memory and added to or subtracted from the moving command in the program.

(1) Tool length offset A/B

When the offset numbers for tool length offset A/B are specified or modified, the offset number validation order varies, depending on the condition, as described below.

When OFH (bit 2 of parameter No. 5001) = 0

```
Oxxxx;
H01;
:
G43Z_; (1)
:
G44Z_H02; (2)
:
H03; (3) (1) Offset number H01 is valid.
(2) Offset number H02 is valid.
(3) Offset number H03 is valid.
```

When OFH (bit 2 of parameter No. 5001) = 1

```
Oxxx;
H01;
:
G43Z_; (1)
:
G44Z_H02; (2)
: (1) Offset number H00 is valid.
H03; (3) (2) Offset number H02 is valid.
: (3) Offset number H02 is valid.
```

(2) Cutter compensation C

When the offset numbers for cutter compensation C are specified or modified, the offset number validation order varies, depending on the condition, as described below.

When OFH (bit 2 of parameter No. 5001) = 0

```
Oxxxx;
H01;
:
G43P_;
:
G44P_H02;
:
H03;
:
(1) Offset number H01 is valid.
(2) Offset number H02 is valid.
(3) Offset number H03 is valid only for the axis to which compensation was applied most recently.
```

When OFH (bit 2 of parameter No. 5001) = 1

```
Oxxxx;
H01;
:
G43P_; (1)
:
G44P_H02; (2) (1) Offset number H00 is valid.
(2) Offset number H02 is valid.
H03; (3) (3) Offset number H02 is valid.
(However, the H number displayed is changed to 03.)
```

The tool length offset value may be set in the offset memory through the CRT/MDI panel.

The range of values that can be set as the tool length offset value is as follows.

	Metric input	Inch input
Tool length offset value	0 to ±999.999mm	0 to ±99.9999inch

WARNING

When the tool length offset value is changed due to a change of the offset number, the offset value changes to the new tool length offset value, the new tool length offset value is not added to the old tool length offset value.

H1: tool length offset value 20.0 H2: tool length offset value 30.0

G90 G43 Z100.0 H1; Z will move to 120.0 **G90 G43 Z100.0 H2**; Z will move to 130.0

CAUTION

When the tool length offset is used and set a parameter OFH (No. 5001#2) to 0, specify the tool length offset with H code and the cutter compensation with D code.

NOTE

The tool length offset value corresponding to offset No. 0, that is, H0 always means 0. It is impossible to set any other tool length offset value to H0.

Performing tool length offset along two or more

Tool length offset B can be executed along two or more axes when the axes are specified in two or more blocks.

Offset in X and Y axes.

G19 G43 H _ ; Offset in X axis
G18 G43 H _ ; Offset in Y axis
(Offsets in X and Y axes are performed)

If the TAL bit (bit 3 of parameter No. 5001) is set to 1, an alarm will not occur even when tool length offset C is executed along two or more axes at the same time.


Tool length offset cancel

To cancel tool length offset, specify G49 or H0. After G49 or H0 is specified, the system immediately cancels the offset mode.

NOTE

- After tool length offset B is executed along two or more axes, offset along all the axes is canceled by specifying G49. If H0 is specified, only offset along an axis perpendicular to the specified plane is canceled.
- In the case of the offset in three axes or more, if the offset is canceled by G49 code, the P/S alarm 015 is generated. Cancel the offset by using G49 and H0.

Examples



·Program

H1=-4.0 (Tool length offset value)	
N1 G91 G00 X120.0 Y80.0;	(1)
N2 G43 Z-32.0 H1 ;	(2)
N3 G01 Z-21.0 F1000 ;	(3)
N4 G04 P2000 ;	(4)
N5 G00 Z21.0 ;	(5)
N6 X30.0 Y-50.0 ;	(6)
N7 G01 Z-41.0 ;	(7)
N8 G00 Z41.0 ;	(8)
N9 X50.0 Y30.0 ;	(9)
N10 G01 Z-25.0;	(10)
N11 G04 P2000;	(11)
N12 G00 Z57.0 H0;	(12)
N13 X-200.0 Y-60.0 ;	(13)
N14 M2;	

14.1.2 G53, G28, G30, and G30.1 Commands in Tool Length Offset Mode This section describes the tool length offset cancellation and restoration performed when G53, G28, G30, or G31 is specified in tool length offset mode. Also described is the timing of tool length offset.

- (1) Tool length offset vector cancellation and restoration, performed when G53, G28, G30, or G30.1 is specified in tool length offset mode
- (2) Specification of the G43/G44 command for tool length offset A/B/C, and independent specification of the H command

Explanations

 Tool length offset vector cancellation When G53, G28, G30, or G30.1 is specified in tool length offset mode, tool length offset vectors are canceled as described below. However, the previously specified modal G code remains displayed; modal code display is not switched to G49.

(1) When G53 is specified

Command	Specified axis	Common to type A/B/C
G53P_;	Tool length offset axis	Canceled upon movement being performed according to a specified value
	Other than tool length offset axis	Not canceled

NOTE

When tool length offset is applied to multiple axes, all specified axes are subject to cancellation.

When tool length offset cancellation is specified at the same time, tool length offset vector cancellation is performed as indicated below.

Command	Specified axis	Common to type A/B/C
G49G53P_;	Tool length offset axis	Canceled upon movement being performed according to a specified value
	Other than tool length offset axis	Canceled upon movement being performed according to a specified value

(2) When G28, G30, or G30.1 is specified

Command	Specified axis	Common to type A/B/C
G28P_;	Tool length offset axis	Canceled upon movement to a reference position being performed
	Other than tool length offset axis	Not canceled

NOTE

When tool length offset is applied to multiple axes, all specified axes involved in reference position return are subject to cancellation.

When tool length offset cancellation is specified at the same time, tool length offset vector cancellation is performed as indicated below.

Command	Specified axis	Common to type A/B/C
G49G28P_;	Tool length offset axis	Canceled upon movement to an intermediate position being performed
	Other than tool length offset axis	Canceled upon movement to an intermediate position being performed

Tool length offset vector restoration

Tool length offset vectors, canceled by specifying G53, G28, G30, or G30.1 in tool length offset mode, are restored as described below.

(1) When OFH (bit 2 of parameter No. 5001) = 0

Туре	EVO (bit 6 of parameter No. 5001)	Restoration block
A/B	1	Block to be buffered next
	0	Block containing an H command or G43/44 command
С	Ignored	Block containing an H command Block containing a G43P_/G44P_ command

(2) When OFH (bit 2 of parameter No. 5001) = 1 In a mode other than tool length offset mode

Туре	EVO (bit 6 of parameter No. 5001)	Restoration block
A/B	1	Block to be buffered next
	0	Block containing an H command or G43/44 command
С	Ignored	Block containing an H command Block containing a G43P_/G44P_ command

In tool length offset mode

Туре	EVO (bit 6 of parameter No. 5001)	Restoration block
A/B	1	Block containing a G43/G44 block
	0	Block containing an H command and G43/44 command
С	Ignored	Block containing a G43P_H_/G44P_H_ command

WARNING

When tool length offset is applied to multiple axes, all axes for which G53, G28, G30, and G30.1 are specified are subject to cancellation. However, restoration is performed only for that axis to which tool length offset was applied last; restoration is not performed for any other axes.

NOTE

In a block containing G40, G41, or G42, the tool length offset vector is not restored.

14.2 AUTOMATIC TOOL LENGTH MEASUREMENT (G37)

By issuing G37 the tool starts moving to the measurement position and keeps on moving till the approach end signal from the measurement device is output. Movement of the tool is stopped when the tool tip reaches the measurement position.

Difference between coordinate value when tool reaches the measurement position and coordinate value commanded by G37 is added to the tool length offset amount currently used.




Fig. 14.2 (a). Automatic tool length measurement

Format

G92IP_; Sets the workpiece coordinate system. (It can be set with G54 to G59. See Chapter 7, "Coordinate System.")

H\bigcirc; Specifies an offset number for tool length offset.

G90 G37 IP_; Absolute command

G37 is valid only in the block in which it is specified. \mathbb{P} _ indicates the X-, Y-, Z-, or fourth axis.

Explanations

Setting the workpiece coordinate system

Set the workpiece coordinate system so that a measurement can be made after moving the tool to the measurement position. The coordinate system must be the same as the workpiece coordinate system for programming.

Specifying G37

Specify the absolute coordinates of the correct measurement position. Execution of this command moves the tool at the rapid traverse rate toward the measurement position, reduces the federate halfway, then continuous to move it until the approach end signal from the measuring instrument is issued. When the tool tip reaches the measurement position, the measuring instrument sends an approach end signal to the CNC which stops the tool.

Changing the offset value

The difference between the coordinates of the position at which the tool reaches for measurement and the coordinates specified by G37 is added to the current tool length offset value.

Offset value =

 $(Current\ compensation\ value) + [(Coordinates\ of\ the\ position\ at\ which\ the\ tool\ reaches\ for\ measurement) - (Coordinates\ specified\ by\ G37)]$

These offset values can be manually changed from MDI.

When automatic tool length measurement is executed, the tool moves as shown in Fig. 14.2 (b). If the approach end signal goes on while the tool is traveling from point B to point C, an alarm occurs. Unless the approach end signal goes on before the tool reaches point F, the same alarm occurs. The P/S alarm number is 080.




Fig14.2 (b) Tool movement to the measurement position

WARNING

When a manual movement is inserted into a movement at a measurement federate, return the tool to the!position before the inserted manual movement for restart.

NOTE

- 1 When an H code is specified in the same block as G37, an alarm is generated. Specify H code before the block!of G37.
- 2 The measurement speed (parameter No. 6241), deceleration position (parameter No. 6251), and permitted range of the approach end signal (parameter No. 6254) are specified by the machine tool builder.
- 3 When offset memory A is used, the offset value is changed. When offset memory B is used, the tool wear compensation value is changed.

When offset memory C is used, the tool wear compensation value for the H code is changed.

4 The approach end signal is monitored usually every 2 ms. The following measuring error is generated:

 ERR_{max} .: $Fm\times1/60\times T_S/1000$ where

T_S: Sampling period, for usual 2 (ms) ERR_{max}.: maximum measuring error (mm)

F_m: measurement federate (mm/min.)

For example, when $F_m = 1000 \text{ mm/min.}$, $ERR_{max} = 0.003 \text{m}$

5 The tool stops a maximum of 16 ms after the approach end signal is detected. But the value of the position!at which the approach end signal was detected (note the value when the tool stopped) is used to determine the

offset amount. The overrun for 16 ms is:

 Q_{max} . = $F_m \times 1/60 \times 16/1000$

Q_{max}.: maximum overrun (mm)

F_m: measurement federate (mm/min.)

Examples

G92 Z760.0 X1100.0; Sets a workpiece coordinate system with

respect to the programmed absolute zero point.

G00 G90 X850.0; Moves the tool to X850.0.

That is the tool is moved to a position that is a specified distance from the measurement

position along the Z-axis.


H01; Specifies offset number 1.

G37 Z200.0; Moves the tool to the measurement position.

G00 Z204.0; Retracts the tool a small distance along the

Z-axis.


For example, if the tool reaches the measurement position with Z198.0;, the compensation value must be corrected. Because the correct measurement position is at a distance of 200 mm, the compensation value is lessened by 2.0 mm (198.0 - 200.0 = -2.0).



14.3 TOOL OFFSET (G45-G48)

The programmed travel distance of the tool can be increased or decreased by a specified tool offset value or by twice the offset value.

The tool offset function can also be applied to an additional axis.



Format

G45 $\mathbf{IP}_{\mathbf{D}}$; Increase the travel distance by the tool offset value

G46 IP_D_; Decrease the travel distance by the tool offset value

G47 IP_D_; Increase the travel distance by twice the tool offset value

G48 IP_D_; Decrease the travel distance by twice the tool offset value

G45 to G48: One-shot G code for increasing or decreasing the travel

distance

IP: Command for moving the tool

D: Code for specifying the tool offset value

Explanations

Increase and decrease

As shown in Table 14.3(a), the travel distance of the tool is increased or decreased by the specified tool offset value.

In the absolute mode, the travel distance is increased or decreased as the tool is moved from the end position of the previous block to the position specified by the block containing G45 to G48.

Table 14.3 (a) Increase and decrease of the tool travel distance

G code	When a positive tool offset value is specified	When a negative tool offset value is specified
G45	Start position End position	Start position End position
G46	Start position End position	Start position End position
G47	Start position End position	Start position End position
G48	Start position End position	Start position End position

Programmed movement distance
Tool offset value
Actual movement position

If a move command with a travel distance of zero is specified in the incremental command (G91) mode, the tool is moved by the distance corresponding to the specified tool offset value.

If a move command with a travel distance of zero is specified in the absolute command (G90) mode, the tool is not moved.

Tool offset value

Once selected by D code, the tool offset value remains unchanged until another tool offset value is selected.

Tool offset values can be set within the following range:

Table 14.3 (b) Range of tool offset values

	Metric input	inch input
Tool offset value	0 to ±999.999mm	0 to ±99.9999inch
	0 to ±999.999deg	0 to ±999.999deg


D0 always indicates a tool offset value of zero.

WARNING

1 When G45 to G48 is specified to n axes (n=1-6) simultaneously in a motion block, offset is applied to all n axes.

When the cutter is offset only for cutter radius or diameter in taper cutting, overcutting or undercutting occurs.


Therefore, use cutter compensation (G40 or G42) shown in II-14.4 or 14.5.



2 G45 to G48 (tool offset) must not be used in the G41 or G42 (cutter compensation) mode.


NOTE

1 When the specified direction is reversed by decrease as shown in the figure below, the tool moves in the opposite direction.




2 Tool offset can be applied to circular interpolation (G02, G03) with the G45 to G48 commands only for 1/4 and 3/4 circles using addresses I, J and K by the parameter setting, providing that the coordinate rotation be not specified at the same time. This function is provided for compatibility with the conventional CNC tape without any cutter compensation. The function should not be used when a new CNC program is prepared.

Tool offset for circular interpolation



- 3 D code should be used in tool offset mode (G45 to G48). However, H code can be used by setting the parameter TPH (No. 5001#5) because of compatibility with conventional CNC tape format. The H code must be used under tool length offset cancel (G49).
- 4 G45 to G48 are ignored in canned cycle mode. Perform tool offset by specifying G45 to G48 before entering canned cycle mode and cancel the offset after releasing the canned cycle mode.

Examples



Program

```
N1 G91 G46 G00 X80.0 Y50.0 D01;
N2 G47 G01 X50.0 F120.0;
N3 Y40.0;
N4 G48 X40.0;
N5 Y-40.0;
N6 G45 X30.0;
N7 G45 G03 X30.0 Y30.0 J30.0;
N8 G45 G01 Y20.0;
N9 G46 X0;
                  Decreases toward the positive direction for
                  movement amount "0". The tool moves in the -X
                  direction by theoffset value.
N10 G46 G02 X-30.0 Y30.0 J30.0;
N11 G45 G01 Y0; Increase toward the positive direction for movement
                  amount "0". The tool moves in the +Y direction by
                  the offset value.
N12 G47 X-120.0;
N13 G47 Y-80.0;
N14 G46 G00 X80.0 Y-50.0;
```

14.4 OVERVIEW OF CUTTER COMPENSATION C (G40 – G42)

When the tool is moved, the tool path can be shifted by the radius of the tool (Fig. 14.4 (a)).

To make an offset as large as the radius of the tool, CNC first creates an offset vector with a length equal to the radius of the tool (start—up). The offset vector is perpendicular to the tool path. The tail of the vector is on the workpiece side and the head positions to the center of the tool.

If a linear interpolation or circular interpolation command is specified after start—up, the tool path can be shifted by the length of the offset vector during machining.

To return the tool to the start position at the end of machining, cancel the cutter compensation mode.




Fig. 14.4 (a) Outline of cutter compensation C

Format

 Start up (Tool compensation start)

 Cutter compensation cancel (offset mode cancel)

 Selection of the offset plane $\mathbf{G00} (\text{or G01}) \mathbf{G41} (\text{or G42}) \qquad \mathbf{IP}_{-} \, \mathbf{D}_{-} \, ;$

G41 : Cutter compensation left (Group07)G42 : Cutter compensation right (Group07)

IP _ : Command for axis movement

 \mathbf{D}_{-} : Code for specifying as the cutter compensation value(1–3digits)

(D code)

G40

G40 : Cutter compensation cancel(Group 07)

(Offset mode cancel)

IP − : Command for axis movement

Offset plane	Command for plane selection	₽_
ХрҮр	G17 ;	Xp_Yp_
ZpXp	G18 ;	Xp_Zp_
YpZp	G19 ;	Yp_Zp_

Explanations

Offset cancel mode

At the beginning when power is applied the control is in the cancel mode. In the cancel mode, the vector is always 0, and the tool center path coincides with the programmed path.

Start Up

When a cutter compensation command (G41 or G42, nonzero dimension words in the offset plane, and D code other than D0) is specified in the offset cancel mode, the CNC enters the offset mode.

Moving the tool with this command is called start-up.

Specify positioning (G00) or linear interpolation (G01) for start–up. If circular interpolation (G02, G03) is specified, P/S alarm 34 occurs.

When processing the start-up block and subsequent blocks, the CNC prereads two blocks.

Offset mode

In the offset mode, compensation is accomplished by positioning (G00), linear interpolation (G01), or circular interpolation (G02, G03). If two or more blocks that do not move the tool (miscellaneous function, dwell, etc.) are processed in the offset mode, the tool will make either an excessive or insufficient cut. If the offset plane is switched in the offset mode, P/S alarm 37 occurs and the tool is stopped.

Offset mode cancel

In the offset mode, when a block which satisfies any one of the following conditions is executed, the CNC enters the offset cancel mode, and the action of this block is called the offset cancel.

1. G40 has been commanded.

2. 0 has been commanded as the offset number for cutter compensation.

When performing offset cancel, circular arc commands (G02 and G03) are not available. If a circular arc is commanded, an P/S alarm (No. 034) is generated and the tool stops.

In the offset cancel, the control executes the instructions in that block and the block in the cutter compensation buffer. In the meantime, in the case of a single block mode, after reading one block, the control executes it and stops. By pushing the cycle start button once more, one block is executed without reading the next block.

Then the control is in the cancel mode, and normally, the block to be executed next will be stored in the buffer register and the next block is not read into the buffer for cutter compensation.




Fig. 14.4 (b) Changing the offset mode

 Change of the Cutter compensation value In general, the cutter compensation value shall be changed in the cancel mode, when changing tools. If the cutter compensation value is changed in offset mode, the vector at the end point of the block is calculated for the new cutter compensation value.




Fig. 14.4 (c) Changing the cutter compensation value

 Positive/negative cutter compensation value and tool center path If the offset amount is negative (–), distribution is made for a figure in which G41's and G42's are all replaced with each other on the program. Consequently, if the tool center is passing around the outside of the workpiece, it will pass around the inside, and vice versa.

The figure below shows one example. Generally, the offset amount is programmed to be positive (+).

When a tool path is programmed as in ((1)), if the offset amount is made negative (-), the tool center moves as in ((2)), and vice versa. Consequently, the same tape permits cutting both male and female shapes, and any gap between them can be adjusted by the selection of the offset amount. Applicable if start—up and cancel is A type. (See II—14.5.2 and 14.5.4)




Fig. 14.4 (d) Tool center paths when positive and negative cutter compensation values are specified

 Cutter compensation value setting Assign a cutter compensation values to the D codes on the MDI panel. The table below shows the range in which cutter compensation values can be specified.

	mm input	inch input
Cutter compensation value	0 to ±999.999mm	0 to ±99.9999inch

NOTE

- 1 The cutter compensation value corresponding to offset No. 0, that is, D0 always means 0. It is impossible to set D0 to any other offset amount.
- 2 Cutter compensation C can be specified by H code with parameter OFH (No. 5001 #2) set to 1.

Offset vector

The offset vector is the two dimensional vector that is equal to the cutter compensation value assigned by D code. It is calculated inside the control unit, and its direction is up—dated in accordance with the progress of the tool in each block.

The offset vector is deleted by reset.

Specifying a cutter compensation value


Specify a cutter compensation value with a number assigned to it. The number consists of 1 to 3 digits after address D (D code). The D code is valid until another D code is specified. The D code is used to specify the tool offset value as well as the cutter compensation value.

Plane selection and vector

Offset calculation is carried out in the plane determined by G17, G18 and G19, (G codes for plane selection). This plane is called the offset plane. Compensation is not executed for the coordinate of a position which is not in the specified plane. The programmed values are used as they are. In simultaneous 3 axes control, the tool path projected on the offset plane is compensated.

The offset plane is changed during the offset cancel mode. If it is performed during the offset mode, a P/S alarm (No. 37) is displayed and the machine is stopped.

Examples



G92 X0 Y0 Z0; Specifies absolute coordinates. The tool is positioned at the start position (X0, Y0, Z0). N1 G90 G17 G00 G41 D07 X250.0 Y550.0; Starts cutter compensation (start-up). The tool is shifted to the left of the programmed path by the distance specified in D07. In other words the tool path is shifted by the radius of the tool (offset mode) because D07 is set to 15 beforehand (the radius of the tool is 15 mm). N2 G01 Y900.0 F150; Specifies machining from P1 to P2. Specifies machining from P2 to P3. N3 X450.0; N4 G03 X500.0 Y1150.0 R650.0 : Specifies machining from P3 to P4. N5 G02 X900.0 R-250.0; Specifies machining from P4 to P5. N6 G03 X950.0 Y900.0 R650.0; Specifies machining from P5 to P6. N7 G01 X1150.0; Specifies machining from P6 to P7. N8 Y550.0; Specifies machining from P7 to P8. Specifies machining from P8 to P9. N9 X700.0 Y650.0; N10 X250.0 Y550.0; Specifies machining from P9 to P1.

Cancels the offset mode.

The tool is returned to the start position (X0, Y0, Z0).

N11 G00 G40 X0 Y0;

14.5 DETAILS OF CUTTER COMPENSATION C

This section provides a detailed explanation of the movement of the tool for cutter compensation C outlined in Section 14.4.


This section consists of the following subsections:

- **14.5.1** General
- 14.5.2 Tool Movement in Start-up
- 14.5.3 Tool Movement in Offset Mode
- 14.5.4 Tool Movement in Offset Mode Cancel
- 14.5.5 Interference Check
- 14.5.6 Over cutting by Cutter Compensation
- 14.5.7 Input command from MDI
- 14.5.8 G53,G28,G30 and G29 commands in cutter compensation C mode
- 14.5.9 Corner Circular Interpolation (G39)

14.5.1 General

Inner side and outer side

When an angle of intersection created by tool paths specified with move commands for two blocks is over 180°, it is referred to as "inner side." When the angle is between 0° and 180°, it is referred to as "outer side."



Meaning of symbols

The following symbols are used in subsequent figures:


- -S indicates a position at which a single block is executed once.
- -SS indicates a position at which a single block is executed twice.
- SSS indicates a position at which a single block is executed three times.
- -L indicates that the tool moves along a straight line.
- -C indicates that the tool moves along an arc.
- -r indicates the cutter compensation value.
- An intersection is a position at which the programmed paths of two blocks intersect with each other after they are shifted by r.
- indicates the center of the tool.

14.5.2 Tool Movement in Start-up


When the offset cancel mode is changed to offset mode, the tool moves as illustrated below (start-up):

Explanations


 Tool movement around an inner side of a corner (180° ≤ α)




 Tool movement around the outside of a corner at an obtuse angle (90° ≤ α<180°) Tool path in start—up has two types A and B, and they are selected by parameter SUP (No. 5003#0).




 Tool movement around the outside of an acute angle (α<90°) Tool path in start—up has two types A and B, and they are selected by parameter SUP (No.5003#0).



 Tool movement around the outside linear→linear at an acute angle less than 1 degree (α<1°)



 A block without tool movement specified at start-up If the command is specified at start-up, the offset vector is not created.



NOTE


For the definition of blocks that do not move the tool, see II-14.5.3.

14.5.3 Tool Movement in Offset Mode


In the offset mode, the tool moves as illustrated below:

Explanations

 Tool movement around the inside of a corner (180° ≤ α)




 Tool movement around the inside (α<1°) with an abnormally long vector, linear → linear




Also in case of arc to straight line, straight line to arc and arc to arc, the reader should infer in the same procedure.

 Tool movement around the outside corner at an obtuse angle (90° ≤ α<180°)




 Tool movement around the outside corner at an acute angle (α<90°)



When it is exceptional

on the arc


End position for the arc is not If the end of a line leading to an arc is programmed as the end of the arc by mistake as illustrated below, the system assumes that cutter compensation has been executed with respect to an imaginary circle that has the same center as the arc and passes the specified end position. Based on this assumption, the system creates a vector and carries out compensation. The resulting tool center path is different from that created by applying cutter compensation to the programmed path in which the line leading to the arc is considered straight.



The same description applies to tool movement between two circular paths.


There is no inner intersection

If the cutter compensation value is sufficiently small, the two circular tool center paths made after compensation intersect at a position (P). Intersection P may not occur if an excessively large value is specified for cutter compensation. When this is predicted, P/S alarm No.033 occurs at the end of the previous block and the tool is stopped. In the example shown below, tool center paths along arcs A and B intersect at P when a sufficiently small value is specified for cutter compensation. If an excessively large value is specified, this intersection does not occur.



The center of the arc is identical with the start position or the end position

If the center of the arc is identical with the start position or end point, P/S alarm (No. 038) is displayed, and the tool will stop at the end position of the preceding block.




 Change in the offset direction in the offset mode The offset direction is decided by G codes (G41 and G42) for cutter radius and the sign of cutter compensation value as follows.

Sign of offset amount Gcode	+	_
G41	Left side offset	Right side offset
G42	Right side offset	Left side offset


The offset direction can be changed in the offset mode. If the offset direction is changed in a block, a vector is generated at the intersection of the tool center path of that block and the tool center path of a preceding block. However, the change is not available in the start—up block and the block following it.

Tool center path with an intersection



tersection


Tool center path without an in- When changing the offset direction in block A to block B using G41 and G42, if intersection with the offset path is not required, the vector normal to block B is created at the start point of block B.



The length of tool center path larger than the circumference of a circle

Normally there is almost no possibility of generating this situation. However, when G41 and G42 are changed, or when a G40 was commanded with address I, J, and K this situation can occur.


In this case of the figure, the cutter compensation is not performed with more than one circle circumference: an arc is formed from P_1 to P_2 as shown. Depending on the circumstances, an alarm may be displayed due to the "Interference Check" described later. To execute a circle with more than one circumference, the circle must be specified in segments.



 Temporary cutter compensation cancel If the following command is specified in the offset mode, the offset mode is temporarily canceled then automatically restored. The offset mode can be canceled and started as described in II–15.6.2 and 15.6.4.


Specifying G28 (automatic return to the reference position) in the offset mode

If G28 is specified in the offset mode, the offset mode is canceled at an intermediate position. If the vector still remains after the tool is returned to the reference position, the components of the vector are reset to zero with respect to each axis along which reference position return has been made.



Specifying G29 (automatic return from the reference position) in the offset mode


If G29 is commanded in the offset mode, the offset will be cancelled at the intermediate point, and the offset mode will be restored automatically from the subsequent block.



Cutter compensation G code in the offset mode

The offset vector can be set to form a right angle to the moving direction in the previous block, irrespective of machining inner or outer side, by commanding the cutter compensation G code (G41, G42) in the offset mode, independently. If this code is specified in a circular command, correct circular motion will not be obtained.


When the direction of offset is expected to be changed by the command of cutter compensation G code (G41, G42), refer to Subsec.15.6.3.



Command cancelling the offset vector temporarily

During offset mode, if G92 (absolute zero point programming) is commanded, the offset vector is temporarily cancelled and thereafter offset mode is automatically restored.

In this case, without movement of offset cancel, the tool moves directly from the intersecting point to the commanded point where offset vector is canceled. Also when restored to offset mode, the tool moves directly to the intersecting point.




A block without tool movement

The following blocks have no tool movement. In these blocks, the tool will not move even if cutter compensation is effected.


```
M05; . M code output
S21; . S code output
G04 X10.0; Dwell
G10 L11 P01 R10.0; Cutter compensation value setting
(G17) Z200.0; Move command not included in the
offset plane.
G90; . G code only
G91 X0; Move distance is zero.
```

A block without tool movement specified in offset mode


When a single block without tool movement is commanded in the offset mode, the vector and tool center path are the same as those when the block is not commanded. This block is executed at the single block stop point.



However, when the move distance is zero, even if the block is commanded singly, tool motion becomes the same as that when more than one block of without tool movement are commanded, which will be described subsequently.




Two blocks without tool movement should not be commanded consecutively. If commanded, a vector whose length is equal to the offset value is produced in a normal direction to tool motion in earlier block, so overcutting may result.



Corner movement


When two or more vectors are produced at the end of a block, the tool moves linearly from one vector to another. This movement is called the corner movement.

If these vectors almost coincide with each other, the corner movement isn't performed and the latter vector is ignored.




If $\Delta Vx \leq \Delta V$ limit and $\Delta Vy \leq \Delta V$ limit, the latter vector is ignored. The ΔV limit is set in advance by parameter (No. 5010).

If these vectors do not coincide, a move is generated to turn around the corner. This move belongs to the latter block.



However, if the path of the next block is semicircular or more, the above function is not performed.

The reason for this is as follows:



If the vector is not ignored, the tool path is as follows:

$$P_1 \rightarrow P_2 \rightarrow P_3 \rightarrow (Circle) \rightarrow P_4 \rightarrow P_5 \rightarrow P_6$$

But if the distance between P2 and P3 is negligible, the point P3 is ignored. Therefore, the tool path is as follows:

$$P_2 \rightarrow P_4$$

Namely, circle cutting by the block N6 is ignored.


Interruption of manual operation

For manual operation during the cutter compensation, refer to Section III–3.5, "Manual Absolute ON and OFF."


14.5.4 Tool Movement in Offset Mode Cancel

Explanations


 Tool movement around an inside corner (180° ≤ α)




 Tool movement around an outside corner at an obtuse angle (90° ≤ α<180°) Tool path has two types, A and B; and they are selected by parameter SUP (No. 5003#0).




 Tool movement around an outside corner at an acute angle (α<90°) Tool path has two types, A and B : and they are selected by parameter SUP (No. 5003#0)



- Tool movement around the outside linear→linear at an acute angle less than 1 degree (α<1°)
- A block without tool movement specified together with offset cancel




When a block without tool movement is commanded together with an offset cancel, a vector whose length is equal to the offset value is produced in a normal direction to tool motion in the earlier block, the vector is cancelled in the next move command.




Block containing G40 and I_J_K_

The previous block contains G41 or G42


If a G41 or G42 block precedes a block in which G40 and I_, J_, K_ are specified, the system assumes that the path is programmed as a path from the end position determined by the former block to a vector determined by (I,J), (I,K), or (J,K). The direction of compensation in the former block is inherited.



In this case, note that the CNC obtains an intersection of the tool path irrespective of whether inner or outer side machining is specified




When an intersection is not obtainable, the tool comes to the normal position to the previous block at the end of the previous block.



The length of the tool center path larger than the circumference of a circle

In the example shown below, the tool does not trace the circle more than once. It moves along the arc from P1 to P2. The interference check function described in II–15.6.5 may raise an alarm.




To make the tool trace a circle more than once, program two or more arcs.

14.5.5 Interference Check


Tool overcutting is called interference. The interference check function checks for tool overcutting in advance. However, all interference cannot be checked by this function. The interference check is performed even if overcutting does not occur.

Explanations

- Criteria for detecting interference
- (1) The direction of the tool path is different from that of the programmed path (from 90 degrees to 270 degrees between these paths).



(2) In addition to the condition (1), the angle between the start point and end point on the tool center path is quite different from that between the start point and end point on the programmed path in circular machining(more than 180 degrees).



In the above example, the arc in block N6 is placed in the one quadrant. But after cutter compensation, the arc is placed in the four quadrants.

Correction of interference in advance

(1) Removal of the vector causing the interference

When cutter compensation is performed for blocks A, B and C and vectors V_1 , V_2 , V_3 and V_4 between blocks A and B, and V_5 , V_6 , V_7 and V_8 between B and C are produced, the nearest vectors are checked first. If interference occurs, they are ignored. But if the vectors to be ignored due to interference are the last vectors at the corner, they cannot be ignored.

Check between vectors V₄ and V₅

Interference — V_4 and V_5 are ignored.

Check between $V_{\rm 3}$ and $V_{\rm 6}$

Interference — V₃ and V₆ are ignored

Check between V2 and V7


Interference — V₂ and V₇ are Ignored

Check between V_1 and V_8


Interference — V_1 and V_8 are cannot be ignored

If while checking, a vector without interference is detected, subsequent vectors are not checked. If block B is a circular movement, a linear movement is produced if the vectors are interfered.

(Example 1) The tool moves linearly from V_1 to V_8




(Example 2) The tool moves linearly from V_1 , V_2 , V_7 , to V_8



(2) If the interference occurs after correction (1), the tool is stopped with an alarm.


If the interference occurs after correction (1) or if there are only one pair of vectors from the beginning of checking and the vectors interfere, the P/S alarm (No.41) is displayed and the tool is stopped immediately after execution of the preceding block. If the block is executed by the single block operation, the tool is stopped at the end of the block.



After ignoring vectors V_2 and V_5 because of interference, interference also occurs between vectors V_1 and V_6 . The alarm is displayed and the tool is stopped.


 When interference is assumed although actual interference does not occur

(1) Depression which is smaller than the cutter compensation value



There is no actual interference, but since the direction programmed in block B is opposite to that of the path after cutter compensation the tool stops and an alarm is displayed.

(2) Groove which is smaller than the cutter compensation value




Like (1), P/S alarm is displayed because of the interference as the direction is reverse in block B.


14.5.6 Overcutting by Cutter Compensation

Explanations


 Machining an inside corner at a radius smaller than the cutter radius When the radius of a corner is smaller than the cutter radius, because the inner offsetting of the cutter will result in overcuttings, an alarm is displayed and the CNC stops at the start of the block. In single block operation, the overcutting is generated because the tool is stopped after the block execution.



 Machining a groove smaller than the tool radius Since the cutter compensation forces the path of the center of the tool to move in the reverse of the programmed direction, overcutting will result. In this case an alarm is displayed and the CNC stops at the start of the block.




 Machining a step smaller than the tool radius When machining of the step is commanded by circular machining in the case of a program containing a step smaller than the tool radius, the path of the center of tool with the ordinary offset becomes reverse to the programmed direction. In this case, the first vector is ignored, and the tool moves linearly to the second vector position. The single block operation is stopped at this point. If the machining is not in the single block mode, the cycle operation is continued. If the step is of linear, no alarm will be generated and cut correctly. However uncut part will remain.



 Starting compensation and cutting along the Z-axis It is usually used such a method that the tool is moved along the Z axis after the cutter compensation is effected at some distance from the workpiece at the start of the machining.


In the case above, if it is desired to divide the motion along the Z axis into rapid traverse and cutting feed, follow the procedure below.




In the program example above, when executing block N1, blocks N3 and N6 are also entered into the buffer storage, and by the relationship among them the correct compensation is performed as in the figure above.

Then, if the block N3 (move command in Z axis) is divided as follows: As there are two move command blocks not included in the selected plane and the block N6 cannot be entered into the buffer storage, the tool center path is calculated by the information of N1 in the figure above. That is, the offset vector is not calculated in start—up and the overcutting may result.

The above example should be modified as follows:



The move command in the same direction as that of the move command after the motion in Z axis should be programmed.




As the block with sequence No. N2 has the move command in the same direction as that of the block with sequence No. N6, the correct compensation is performed.

14.5.7 Input Command from MDI

Cutter compensation C is not performed for commands input from the MDI.

However, when automatic operation using the absolute commands is temporarily stopped by the single block function, MDI operation is performed, then automatic operation starts again, the tool path is as follows:

In this case, the vectors at the start position of the next block are translated and the other vectors are produced by the next two blocks. Therefore, from next block but one, cutter compensation C is accurately performed.



When position P_A , P_B , and P_C are programmed in an absolute command, tool is stopped by the single block function after executing the block from P_A to P_B and the tool is moved by MDI operation. Vectors V_{B1} and V_{B2} are translated to V_{B1} ' and V_{B2} ' and offset vectors are recalculated for the vectors V_{C1} and V_{C2} between block $P_B - P_C$ and $P_C - P_D$.

However, since vector V_{B2} is not calculated again, compensation is accurately performed from position P_C .

14.5.8 G53,G28,G30,G30.1 and G29 Commands in Cutter Compensation C Mode

A function has been added which performs positioning by automatically canceling a cutter compensation vector when G53 is specified in cutter compensation C mode, then automatically restoring that cutter compensation vector with the execution of the next move command. The cutter compensation vector restoration mode is of FS16 type when CCN (bit 2 of parameter No. 5003) is set to 0; it is of FS15 type when CCN is set to 1.

When G28, G30, or G30.1 is specified in cutter compensation C mode, automatic reference position return is performed by automatically canceling a cutter compensation vector, that cutter compensation vector automatically being restored with the execution of the next move command. In this case, the timing and format of cutter compensation vector cancellation/restoration, performed when CCN (bit 2 of parameter No. 5003) is set to 1, are changed to FS15 type.

When CCN (bit 2 of parameter No. 5003) is set to 0, the conventional specification remains applicable.

When G29 is specified in cutter compensation C mode, the cutter compensation vector is automatically canceled/restored. In this case, the timing and format of cutter compensation vector cancellation/restoration, performed when CCN (bit 2 of parameter No. 5003) is set to 1, are changed to FS15 type.

When CCN (bit 2 of parameter No. 5003) is set to 0, the conventional specification remains applicable.


Explanations

G53 command in cutter compensation C mode


When G53 is specified in cutter compensation C mode, the previous block generates a vector that is perpendicular to the move direction and which has the same magnitude as the offset value. Then, the offset vector is canceled when movement to a specified position is performed in the machine coordinate system. In the next block, offset mode is automatically resumed.

Note that cutter compensation vector restoration is started when CCN (bit 2 of parameter No. 5003) is set to 0; when CCN is set to 1, an intersection vector is generated (FS15 type).


(1) G53 specified in offset mode When CCN (bit 2 of parameter No.5003)=0




When CCN (bit 2 of parameter No.5003)=1




(2) Incremental G53 specified in offset mode When CCN (bit 2 of parameter No.5003)=0




When CCN (bit2 of parameter No.5003)=1



(3) G53 specified in offset mode with no movement specified When CCN (bit2 of parameter No.5003)=0




When CCN (bit2 of parameter No.5003)=1




WARNING

1 When cutter compensation C mode is set and all–axis machine lock is applied, the G53 command does not perform positioning along the axes to which machine lock is applied. The vector, however, is preserved. When CCN (bit 2 of parameter No. 5003) is set to 0, the vector is canceled. (Note that even if the FS15 type is used, the vector is canceled when each–axis machine lock is applied.)


Example 1: When CCN (bit 2 of parameter No. 5003) = 0, type A is used, and all–axis machine lock is applied



Example 2: When CCN (bit 2 of parameter No. 5003) = 1 and all–axis machine lock is applied [FS15 type]




Example 3: When CCN (bit 2 of parameter No. 5003) = 1 and specified—axis machine lock is applied [FS15 type]



When G53 is specified for a compensation axis in cutter compensation mode, the vectors along the other axes are also canceled. (This also applies when CCN (bit 2 of parameter No.5003) is set to 1. When the FS15 type is used, only the vector along a specified axis is canceled. Note that the FS15 type cancellation differs from the actual FS15 specification in this point.)


Example: When CCN (bit 2 of parameter No.5003)=1[FS 15 type]



NOTE


1 When a G53 command specifies an axis that is not in the cutter compensation C plane, a perpendicular vector is generated at the end point of the previous block, and the tool does not move. In the next block, offset mode is automatically resumed (in the same way as when two or more continuous blocks do not specify any move commands).

Example: When CCN (bit 2 of parameter No. 5003) = 0, and type A is used



When a G53 block is specified to become a start-up block, the next block actually becomes the start-up block. When CCN (bit 2 of parameter No. 5003) is set to 1, an intersection vector is generated.


Example: When CCN (bit 2 of parameter No. 5003) = 0 and type A is used



 G28, G30, or G30.1 command in cutter compensation C mode When G28, G30, or G30.1 is specified in cutter compensation C mode, an operation of FS15 type is performed if CCN (bit 2 of parameter No. 5003) is set to 1.


This means that an intersection vector is generated in the previous block, and a perpendicular vector is generated at an intermediate position. Offset vector cancellation is performed when movement is made from the intermediate position to the reference position. As part of restoration, an intersection vector is generated between a block and the next block.

- (1) G28, G30, or G30.1, specified in offset mode (with movement to both an intermediate position and reference position performed)
 - (a) For return by G29 When CCN (bit 2 of parameter No. 5003) = 0




G29 command in cutter compensation C mode


When CCN (bit 2 of parameter No. 5003) = 1




(b) For return by G00 When CCN (bit 2 of parameter No. 5503) = 0




When CCN (bit 2 of parameter No. 5503) = 1




- (2) G28, G30, or G30.1, specified in offset mode (with movement to an intermediate position not performed)
 - (a) For return by G29 When CCN (bit 2 of parameter No. 5503) = 0




When CCN (bit 2 of parameter No. 5503) = 1



(b) For return by G00 When CCN (bit 2 of parameter No.5503)=0




When CCN (bit 2 of parameter No.5503)=1




(3) G28, G30, or G30.1, specified in offset mode (with movement to a reference position not performed)


(a) For return by G29 When CCN (bit 2 of parameter No.5503)=0




When CCN (bit 2 of parameter No.5503)=1




(b) For return by G00 When CCN (bit 2 of parameter No.5503)=0




When CCN (bit 2 of parameter No.5503)=1




- (4) G28, G30, or G30.1 specified in offset mode (with no movement performed)
 - (a) For return by G29 When CCN (bit 2 of parameter No.5503)=0




When CCN (bit 2 of parameter No.5503)=1



(b) For return by G00 When CCN (bit 2 of parameter No.5503)=0




When CCN (bit 2 of parameter No.5503)=1




WARNING

1 When a G28, G30, or G30.1 command is specified during all—axis machine lock, a perpendicular offset vector is applied at the intermediate position, and movement to the reference position is not performed; the vector is preserved. Note, however, that even if the FS15 type is used, the vector is canceled only when each—axis machine lock is applied. (The FS15 type preserves the vector even when each—axis machine lock is applied.)

Example1: When CCN (bit 2 of parameter No.5003)=1 and all–axis machine lock is applied




Example2: When CCN (bit 2 of parameter No.5003)=1 and each—axis machine lock is applied



When G28, G30, or G30.1 is specified for a compensation axis in cutter compensation mode, the vectors along the other axes are also canceled. (This also applies when CCN (bit 2 of parameter No. 5003) is set to 1. When the FS15 type is used, only the vector along a specified axis is canceled. Note that the FS15 type cancellation differs from the actual FS15 specification in this point.)


Example: When CCN (bit 2 of parameter No.5003)=1



NOTE


1 When a G28, G30, or G30.1 command specifies an axis that is not in the cutter compensation C plane, a perpendicular vector is generated at the end point of the previous block, and the tool does not move. In the next block, offset mode is automatically resumed (in the same way as when two or more continuous blocks do not specify any move commands).

Example: When CCN (bit 2 of parameter No. 5003) = 1



2 When a G28, G30, or G30.1 block is specified such that the block becomes a start—up block, a vector perpendicular to the move direction is generated at an intermediate position, then subsequently canceled at the reference position. In the next block, an intersection vector is generated.

Example: When CCN (bit 2 of parameter No.5003)=1




G29 command in cutter compensation C mode


When G29 is specified in cutter compensation C mode, an operation of FS15 type is performed if CCN (bit 2 of parameter No. 5003) is set to 1.

This means that an intersection vector is generated in the previous block, and vector cancellation is performed when a movement to an intermediate position is performed. When movement from the intermediate position to the return position is performed, the vector is restored; an intersection vector is generated between the block and the next block.

- (1) G29 specified in offset mode (with movement to both an intermediate position and reference position performed)
 - (a) For specification made immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1




(b) For specification made other than immediately after automatic reference position return


When CCN (bit 2 of parameter No.5003)=0




When CCN (bit 2 of parameter No.5003)=1




- (2) G29 specified in offset mode (with movement to an intermediate position not performed)
 - (a) For specification made immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1




(b) For specification made other than immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1




- (3) G29 specified in offset mode (with movement to a reference position not performed)
 - (a) For specification made immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1




(b) For specification made other than immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1



- (4) G29 specified in offset mode (with movement to an intermediate position and reference position not performed)
 - (a) For specification made immediately after automatic reference position return




When CCN (bit 2 of parameter No.5003)=1




(b) For specification made other than immediately after automatic reference position return

When CCN (bit 2 of parameter No.5003)=0




When CCN (bit 2 of parameter No.5003)=1



NOTE

When a G29 command is specified for an axis that is not in the cutter compensation C plane in cutter compensation C mode, a perpendicular vector is generated at the end point of the previous block, and the tool does not move. In the next block, an intersection vector is generated (in the same way as when two or more continuous blocks do not specify any move commands).



14.5.9 Corner Circular Interpolation (G39)

By specifying G39 in offset mode during cutter compensation C, corner circular interpolation can be performed. The radius of the corner circular interpolation equals the compensation value.

Format

```
In offset mode  \begin{array}{c} \textbf{G39} \ ; \\ \textbf{or} \\ \textbf{G39} \ \left\{ \begin{matrix} \textbf{I}\_\textbf{J}\_\\ \textbf{I}\_\textbf{K}\_\\ \textbf{J}\_\textbf{K}\_ \end{matrix} \right\} \ ; \\ \end{array}
```

Explanations

 Corner circular interpolation When the command indicated above is specified, corner circular interpolation in which the radius equals compensation value can be performed. G41 or G42 preceding the command determines whether the arc is clockwise or counterclockwise. G39 is a one–shot G code.

• G39 without I, J, or K

When G39; is programmed, the arc at the corner is formed so that the vector at the end point of the arc is perpendicular to the start point of the next block.

• G39 with I, J, and K

When G39 is specified with I, J, and K, the arc at the corner is formed so that the vector at the end point of the arc is perpendicular to the vector defined by the I, J, and K values.

Limitations

Move command


In a block containing G39, no move command can be specified.

Non-move command


Two or more consecutive non-move blocks must not be specified after a block containing G39 without I, J, or K. (A single block specifying a travel distance of zero is assumed to be two or more consecutive non-move blocks.) If the non-move blocks are specified, the offset vector is temporarily lost. Then, offset mode is automatically restored.

Examples

• G39 without I, J, or K



• G39 with I, J, and K



14.6 TOOL COMPENSATION VALUES, NUMBER OF COMPENSATION VALUES, AND ENTERING VALUES FROM THE PROGRAM (G10)

Tool compensation values include tool geometry compensation values and tool wear compensation (Fig. 14.6 (a)).




Fig. 14.6 (a) Geometric compensation and wear compensation

Tool compensation values can be entered into CNC memory from the CRT/MDI panel (see section III–11.4.1) or from a program. A tool compensation value is selected from the CNC memory when the corresponding code is specified after address H or D in a program.

The value is used for tool length compensation, cutter compensation, or the tool offset.

Explanations

 Valid range of tool compensation values Table 14.6 (a) shows the valid input range of tool compensation values.

Table 14.6 (a) The valid input range of tool compensation value

In- cre- ment sys- tem	Geometric compensation value		Wear compensation value	
	Metric input	Inch input	Metric input	Inch input
IS-B	±999.999 mm	±99.9999inch	±99.999 mm	±9.9999 inch
IS-C	±999.9999 mm	±99.99999inch	±99.9999 mm	±9.99999 inch

 Number of tool compensation values and the addresses to be specified The memory can hold 32, 64, 99, 200, 400, 499, or 999 tool compensation values (option).

Address D or H is used in the program. The address used depends on which of the following functions is used: tool length compensation(see II–14.1), tool offset (see II–14.3), cutter compensation B (see II–NO TAG), or cutter compensation C (see II–14.5).

The range of the number that comes after the address (D or H) depens on the number of tool compensation values: 0 to 32, 0 to 64, 0 to 99, 0 to 200, 0 to 400, 0 to 499, or 0 to 999.

 Tool compensation memory and the tool compensation value to be entered Tool compensation memory A, B, or C can be used. The tool compensation memory determines the tool compensation values that are entered (set) (Table 14.6 (b)).

Table14.6 (b) Setting contents tool compensation memory and tool compensation value

Tool compensation value	Tool compensation memory A	Tool compensation memory B	Tool compensation memory C
Tool geometry compensation value for address D	Set tool geometry + tool wear compensation values for addresses D and H (values can be specified with either address).	Set tool geometry compensation values for addresses D and H (values can be specified with either address).	set
Tool geometry compensation value for address H			set
Tool wear compensation for value address D		Set tool wear compensation values for addresses D and H (values can be specified with either address).	set
Tool wear compensation value for address H			set

Format

The programming format depends on which tool compensation memory is used.

Input of tool compensation value by programing

Table14.6 (c) Setting range of Tool compensation memory and Tool compensation value

Variety of tool compensation memory		Format
А	Tool compensation value (geometry compensation value+wear compensation value)	G10L11P_R_;
В	Geometry compensation value	G10L10P_R_;
	Wear compensation value	G10L11P_R_;
С	Geometry compensation value for H code	G10L10P_R_;
	Geometry compensation value for D code	G10L12P_R_;
	Wear compensation value for H code	G10L11P_R_;
	Wear compensation value for D code	G10L13P_R_;

P: Number of tool compensation

R: Tool compensation value in the absolute command(G90) mode Value to be added to the specified tool compensation value in the incremental command(G91) mode (the sum is also a tool compensation value.)

NOTE

To provide compatibility with the format of older CNC programs, the system allows L1 to be specified instead of L11.


14.7 SCALING (G50,G51)

A programmed figure can be magnified or reduced (scaling).

The dimensions specified with X_, Y_, and Z_ can each be scaled up or down with the same or different rates of magnification.

The magnification rate can be specified in the program.

Unless specified in the program, the magnification rate specified in the parameter is applied.



Format

SCALING UP OR DOWN ALONG ALL AXES AT THE SAME RATE OF MAGNIFICATION				
Format	Meaning of command			
G51X_Y_Z_P_; Scaling start Scaling is effective. (Scaling mode) G50; Scaling cancel	X_Y_Z : Absolute command for center coordinate value of scaling P_ : Scaling magnification			

Scaling up or down along each axes at a different rate of magnification (mirror image)					
Format	Meaning of command				
G51_X_Y_Z_I_J_K_;Scaling start Scaling is effective. (Scaling mode) G50 Scaling cancel	X_Y_Z Absolute command for center coordinate value of scaling I_J_K Scaling magnification for X axis Y axis and Z axis respectively				

WARNING

Specify G51 in a separate block. After the figure is enlarged or reduced, specify G50 to cancel the scaling mode.

Explanations

- Scaling up or down along all axes at the same rate of magnification
- Scaling of each axis, programmable mirror image (negative magnification)

Least input increment of scaling magnification is: 0.001 or 0.00001 It is depended on parameter SCR (No. 5400#7) which value is selected. If scaling P is not specified on the block of scaling (G51X_Y_Z_P_;), the scaling magnification set to parameter (No. 5411) is applicable. If X,Y,Z are omitted, the tool position where the G51 command was specified serves as the scaling center.

Each axis can be scaled by different magnifications. Also when a negative magnification is specified, a mirror image is applied. First of all, set a parameter XSC (No. 5400#6) which validates each axis scaling (mirror image).

Then, set parameter SCLx (No. 5401#0) to enable scaling along each axis. Least input increment of scaling magnification of each axis (I, J, K) is 0.001 or 0.00001(set parameter SCR (No. 5400#7)).

Magnification is set to parameter 5421 within the range +0.00001 to +9.99999 or +0.001 to +999.999

If a negative value is set, mirror image is effected.

If magnification I, J or K is not commanded, a magnification value set to parameter (No. 5421) is effective. However, a value other than 0 must be set to the parameter.

NOTE

Decimal point programming can not be used to specify the rate of magnification (I, J, K).




Fig14.7 (b) Scaling of each axis

Scaling of circular interpolation

Even if different magnifications are applie to each axis in circular interpolation, the tool will not trace an ellipse.

When different magnifications are applied to axes and a circular interpolation is specified with radius R, it becomes as following figure 14.7 (c) (in the example shown below, a magnification of 2 is applied to the X–component and a magnification of 1 is applied to the Y–component.).

```
G90 G00 X0.0 Y100.0;
G51 X0.0 Y0.0 Z0.0 I2000 J1000;
G02 X100.0 Y0.0 R100.0 F500;

Above commands are equivalent to the following command:
G90 G00 X0.0 Y100.0 Z0.0;
G02 X200.0 Y0.0 R200.0 F500;

Magnification of radius R depends on I, or J whichever is larger.
```

Fig. 14.7 (c) Scaling for circular interpolation1

When different magnifications are applied to axes and a circular interpolation is specified with I, J and K, it becomes as following figure 14.7 (d) (In the example shown below, a magnification of 2 is applied to the X-component and a magnification of 1 is applied to the Y-component.).

```
G90 G00 X0.0 Y0.0;
G51 X0.0 Y0.0 I2000 J1000;
G02 X100.0 Y0.0 I0.0 J-100.0 F500;

Above commands are equivalent to the following commands.

G90 G00 X0.0 Y100.0;
G02 X200.0 Y0.0 I0.0 J-100.0 F500;

In this case, the end point does not beet the radius, a linear section is included.

Y
(200.0)

Scaled shape

(100.0)

X
```

Fig. 14.7 (d) Scaling for circular interpolation 2

Tool compensation

This scaling is not applicable to cutter compensation values, tool length offset values, and tool offset values (Fig. 14.7 (e)).




Fig. 14.7 (e) Scaling during cutter compensation

Invalid scaling

Scaling is not applicable to the Z-axis movement in case of the following canned cycle.

- ·Cut-in value Q and retraction value d of peck drilling cycle (G83, G73).
- ·Fine boring cycle (G76)
- ·Shift value Q of X and Y axes in back boring cycle (G87).

In manual operation, the travel distance cannot be increased or decreased using the scaling function.

 Commands related to reference position return and coordinate system In scaling mode, G28, G30, or commands related to the coordinate system (G52 to G59) must not be specified. When any of these G codes is necessary, specify it after canceling scaling mode.

WARNING

- 1 If a parameter setting value is employed as a scaling magnification without specifying P, the setting value at G51 command time is employed as the scaling magnification, and a!change of this value, if any, is not effective.
- 2 Before specifying the G code for reference position return (G27, G28, G29, G30) or!coordinate system setting (G92), cancel the scaling mode.
- 3 If scaling results are rounded by counting fractions of 5 and over as a unit and disregarding the rest, the move amount may become zero. In this case, the block is!regarded as a no movement block, and therefore, it may affect the tool movement by!cutter compensation C. See the description of blocks that do not move the tool at II–14.5.3.

NOTE

- 1 The position display represents the coordinate value after scaling.
- 2 When a mirror image was applied to one axis of the specified plane, the following!results:
 - (1) Circular command Direction of rotation is reversed.
 - (2) Cutter compensation C Offset direction is reversed.
 - (3)Coordinate system rotation Rotation angle is reversed.

Examples

Example of a mirror image program

Subprogram

O9000;

G00 G90 X60.0 Y60.0;

G01 X100.0 F100;

G01 Y100.0;

G01 X60.0 Y60.0;

M99;

Main program

N10 G00 G90;

N20M98P9000;

N30 G51 X50.0 Y50.0 I-1000 J1000;

N40 M98 P9000;

N50 G51 X50.0 Y50.0 I-1000 J-1000;

N60 M98 P9000:

N70 G51 X50.0 Y50.0 I1000 J-1000

N80 M98 P9000;

N90 G50;




Fig. 14.7 (f) Example of a mirror image program

14.8 COORDINATE SYSTEM ROTATION (G68, G69)

A programmed shape can be rotated. By using this function it becomes possible, for example, to modify a program using a rotation command when a workpiece has been placed with some angle rotated from the programmed position on the machine. Further, when there is a pattern comprising some identical shapes in the positions rotated from a shape, the time required for programming and the length of the program can be reduced by preparing a subprogram of the shape and calling it after rotation.





Fig. 14.8 (a) Coordinate system rotation

Format






Fig. 14.8 (b) Coordinate system rotation

NOTE

When a decimal fraction is used to specify angular displacement (R_), the 1's digit corresponds to degree units.

Explanations

 G code for selecting a plane: G17,G18 or G19

Incremental command in coordinate system rotation mode

Center of rotation

Angular displacement

 Coordinate system rotation cancel command

Tool compensation

 Relationship with three-dimensional coordinate conversion (G68, G69) The G code for selecting a plane (G17,G18,or G19) can be specified before the block containing the G code for coordinate system rotation (G68). G17, G18 or G19 must not be designated in the mode of coordinate system rotation.

The center of rotation for an incremental command programmed after G68 but before an absolute command is the tool position when G68 was programmed (Fig. 14.8 (c)).

When α_{β} is not programmed, the tool position when G68 was programmed is assumed as the center of rotation.

When R_{_} is not specified, the value specified in parameter 5410 is assumed as the angular displacement.

The G code used to cancel coordinate system rotation (G69) may be specified in a block in which another command is specified.

Cutter compensation, tool length compensation, tool offset, and other compensation operations are executed after the coordinate system is rotated.

Both coordinate system rotation and three–dimensional coordinate conversion use the same G codes: G68 and G69. The G code with I, J, and K is processed as a command for three–dimensional coordinate conversion. The G code without I, J, and K is processed as a command for two–dimensional coordinate system rotation.

Limitations

- Commands related to reference position return and the coordinate system
- Incremental command

In coordinate system rotation mode, G codes related to reference position return (G27, G28, G29, G30, etc.) and those for changing the coordinate system (G52 to G59, G92, etc.) must not be specified. If any of these G codes is necessary, specify it only after canceling coordinate system rotation mode.

The first move command after the coordinate system rotation cancel command (G69) must be specified with absolute values. If an incremental move command is specified, correct movement will not be performed.

Explanations

Absolute/Incremental position commands




Fig. 14.8 (c) Absolute/incremental command during coordinate system rotation

Examples

 Cutter compensation C and coordinate system rotation




Fig. 14.8 (d) Cutter compensation C and coordinate system rotation

 Scaling and coordinate system rotation If a coordinate system rotation command is executed in the scaling mode (G51 mode), the coordinate value $(\alpha,\beta,)$ of the rotation center will also be scaled, but not the rotation angle (R). When a move command is issued, the scaling is applied first and then the coordinates are rotated.

A coordinate system rotation command (G68) should not be issued in cutter compensation C mode (G41, G42) on scaling mode (G51). The coordinate system rotation command should always be specified prior to setting the cutter compensation C mode.

1. When the system is not in cutter compensation mode C, specify the commands in the following order:

```
G51; scaling mode start
G68; coordinate system rotation mode start

G69; coordinate system rotation mode cancel
G50; scaling mode cancel
```

2. When the system is in cutter compensation model C, specify the commands in the following order (Fig.14.8(e)):

(cutter compensation C cancel)

G51; scaling mode start

 ${\sf G68}\;;\;\; {\sf coordinate}\; {\sf system}\; {\sf rotation}\; {\sf start}\;$

:

G41; cutter compensation C mode start

:




Fig. 14.8 (e) Scaling and coordinate system rotation in cutter compensation C mode

Repetitive commands for coordinate system rotation

It is possible to store one program as a subprogram and recall subprogram by changing the angle.

Sample program for when the RIN bit (bit 0 of parameter 5400) is set to 1. The specified angular displancement is treated as an absolute or incremental value depending on the specified G code (G90 or G91). G92 X0 Y0 G69 G17; G01 F200 H01; M98 P2100; M98 P072200; G00 G90 X0 Y0 M30; O 2200 G68 X0 Y0 G91 R45.0; G90 M98 P2100; M99; O 2100 G90 G01 G42 X0 Y-10.0; X4.142; X7.071 Y-7.071; G40; M99; Programmed path (0, 0)When offset is applied (0, -10.0)Subprogram

Fig. 14.8 (f) Coordinate system rotation command

14.9 NORMAL DIRECTION CONTROL (G40.1, G41.1, G42.1 OR G150, G151, G152) When a tool with a rotation axis (C-axis) is moved in the XY plane during cutting, the normal direction control function can control the tool so that the C-axis is always perpendicular to the tool path (Fig. 14.9 (a)).




Fig. 14.9 (a) Sample Movement of the tool

Format

G code	Function	Explanation
G41.1 or G151	Normal direction control left	If the workpiece is to the right of the tool path looking toward the direction in which the tool advances, the normal direction control left (G41.1 or G151) function is speci-
G42.1 or G152	Normal direction control right	fied. After G41.1 (or G151) or G42.1 (or G152) is specified, the normal direction control function is enabled (normal direction control
G40.1 or G150	Normal direction control cancel	mode). When G40.1 (or G150) is specified, the normal direction control mode is canceled.




Fig. 14.9 (b) Normal direction control left (G41.1)

Fig. 14.9 (c) Normal direction control right (G42.1)

Explanations

• Angle of the C axis

When viewed from the center of rotation around the C-axis, the angular displacement about the C-axis is determined as shown in Fig. 14.9 (d). The positive side of the X-axis is assumed to be 0 , the positive side of the Y-axis is 90°, the negative side of the X-axis is 180°, and the negative side of the Y-axis is 270°.




Fig. 14.9 (d) Angle of the C axis

 Normal direction control of the C axis When the cancel mode is switched to the normal direction control mode, the C-axis becomes perpendicular to the tool path at the beginning of the block containing G41.1 or G42.1.

In the interface between blocks in the normal direction control mode, a command to move the tool is automatically inserted so that the C-axis becomes perpendicular to the tool path at the beginning of each block. The tool is first oriented so that the C-axis becomes perpendicular to the tool path specified by the move command, then it is moved along the X-and Y axes.

In the cutter compensation mode, the tool is oriented so that the C–axis becomes perpendicular to the tool path created after compensation.

In single—block operation, the tool is not stopped between a command for rotation of the tool and a command for movement along the X- and Y-axes. A single—block stop always occurs after the tool is moved along the X- and Y-axes.




Fig. 14.9 (e) Point at which a Single–Block Stop Occurs in the Normal Direction Control Mode

Before circular interpolation is started, the C-axis is rotated so that the C-axis becomes normal to the arc at the start point. During circular interpolation, the tool is controlled so that the C-axis is always perpendicular to the tool path determined by circular interpolation.




Fig. 14.9 (f) Normal direction control of the circular interpolation

NOTE

During normal direction control, the C axis always rotates through an angle less than 180 deg. I.e., it rotates in whichever direction provides the shorter route.

C axis feedrate

Movement of the tool inserted at the beginning of each block is executed at the feedrate set in parameter 5481. If dry run mode is on at that time, the dry run feedrate is applied. If the tool is to be moved along the X-and Y-axes in rapid traverse (G00) mode, the rapid traverse feedrate is applied.

The federate of the C axis during circular interpolation is defined by the following formula.

F: Federate (mm/min or inch/min) specified by the corresponding block of the arc

Amount of movement of the C axis: The difference in angles at the beginning and the end of the

block.

NOTE

If the federate of the C axis exceeds the maximum cutting speed of the C axis specified to parameter No. 1422, the federate of each of the other axes is clamped to keep the federate of the C axis below the maximum cutting speed of the C axis.

- Normal direction control axis
- Angle for which figure insertion is ignored

A C-axis to which normal-direction control is applied can be assigned to any axis with parameter No. 5480.

When the rotation angle to be inserted, calculated by normal–direction control, is smaller than the value set with parameter No. 5482, the corresponding rotation block is not inserted for the axis to which normal–direction control is applied. This ignored rotation angle is added to the next rotation angle to be inserted, the total angle being subject to the same check at the next block.

If an angle of 360 degrees or more is specified, the corresponding rotation block is not inserted.


If an angle of 180 degrees or more is specified in a block other than that for circular interpolation with a C-axis rotation angle of 180 degrees or more, the corresponding rotation block is not inserted.

Movement for which arc insertion is ignored

Specify the maximum distance for which machining is performed with the same normal direction as that of the preceding block.


Linear movement

When distance N2, shown below, is smaller than the set value, machining for block N2 is performed using the same direction as that for block N1.



Circular movement

When the diameter of block N2, shown below, is smaller than the set value, machining for block N2 is performed using the same normal direction as that for block N1. The orientation of the axis to which normal–direction control is applied, relative to the normal direction of block N2, does not change as machining proceeds along the arc.




NOTE

- 1 Do not specify any command to the C axis during normal direction control. Any command specified at this time is ignored.
- 2 Before processing starts, it is necessary to correlate the workpiece coordinate of the C axis with the actual position of the C axis on the machine using the coordinate system setting (G92) or the like.
- 3 The helical cutting option is required to use this function. Helical cutting cannot be specified in the normal direction control mode.
- 4 Normal direction control cannot be performed by the G53 move command.
- 5 The C-axis must be a rotation axis.

14.10 PROGRAMMABLE MIRROR IMAGE (G50.1, G51.1)

A mirror image of a programmed command can be produced with respect to a programmed axis of symmetry (Fig. 14.10 (a)).



- (1) Original image of a programmed command
- (2) Image symmetrical about a line parallel to the Y-axis and crossing the X-axis at 50
- (3) Image symmetrical about point (50, 50)
- (4) Image symmetrical about a line parallel to the X-axis and crossing the Y-axis at 50

Fig. 14.10 (a) Programmable Mirror image

Format

G51.1 IP_; Setting a programmable image

A mirror image of a command specified in these blocks is produced with respect to the axis of symmetry specified by G51.1 IP_;.

G50.1 IP_; Canceling a programmable mirror image

IP_: Point (position) and axis of symmetry for producing a mirror image when specified with G51.1.

Axis of symmetry for producing a mirror image when specified with G50.1. Point of symmetry is not specified.

Explanations

Mirror image by setting

If the programmable mirror image function is specified when the command for producing a mirror image is also selected by a CNC external switch or CNC setting (see III–4.7), the programmable mirror image function is executed first.

 Mirror image on a single axis in a specified plane Applying a mirror image to one of the axes on a specified plane changes the following commands as follows:

Command	Explanation
Circular command	G02 and G03 are interchanged.
Cutter compensation	G41 and G42 are interchanged.
Coordinate rotation	CW and CCW (directions of rotation) are interchanged.

Limitations


 Scaling/coordinate system rotation Processing proceeds from program mirror image to scaling and coordinate rotation in the stated order. The commands should be specified in this order, and, for cancellation, in the reverse order. Do not specify G50.1 or G51.1 during scaling or coordinate rotation mode.

 Commands related to reference position return and coordinate system In programmable mirror image mode, G codes related to reference position return (G27, G28, G29, G30, etc.) and those for changing the coordinate system (G52 to G59, G92, etc.) must not be specified. If any of these G codes is necessary, specify it only after canceling the programmable mirror image mode.

15

CUSTOM MACRO

Although subprograms are useful for repeating the same operation, the custom macro function also allows use of variables, arithmetic and logic operations, and conditional branches for easy development of general programs such as pocketing and user—defined canned cycles. A machining program can call a custom macro with a simple command, just like a subprogram.



15.1 VARIABLES

An ordinary machining program specifies a G code and the travel distance directly with a numeric value; examples are G100 and X100.0.

With a custom macro, numeric values can be specified directly or using a variable number. When a variable number is used, the variable value can be changed by a program or using operations on the MDI panel.

#1=#2+100;

G01 X#1 F300;

Explanation

Variable representation

When specifying a variable, specify a number sign (#) followed by a variable number. General—purpose programming languages allow a name to be assigned to a variable, but this capability is not available for custom macros.

Example: #1

An expression can be used to specify a variable number. In such a case, the expression must be enclosed in brackets.

Example: #[#1+#2-12]

Types of variables

Variables are classified into four types by variable number.

Table 15.1 Types of variables

Variable number	Type of variable	Function
#0	Always null	This variable is always null. No value can be assigned to this variable.
#1 – #33	Local variables	Local variables can only be used within a macro to hold data such as the results of operations. When the power is turned off, local variables are initialized to null. When a macro is called, arguments are assigned to local variables.
#100 – #149 (#199) #500 – #531 (#999)	Common variables	Common variables can be shared among different macro programs. When the power is turned off, variables #100 to #149 are initialized to null. Variables #500 to #531 hold data even when the power is turned off. As an option, common variables #150 to #199 and #532 to #999 are also available. However, when these values are using.
#1000 —	System variables	System variables are used to read and write a variety of NC data items such as the current position and tool compensation values.

NOTE

Common variables #150 to #199 and #532 to #999 are optional.

Range of variable values

Local and common variables can have value 0 or a value in the following ranges:

 -10^{47} to -10^{-29} 10^{-29} to 10^{47}

If the result of calculation turns out to be invalid, an P/S alarm No. 111 is issued.

Omission of the decimal point

When a variable value is defined in a program, the decimal point can be omitted.

Example:

When #1=123; is defined, the actual value of variable #1 is 123.000.

Referencing variables

To reference the value of a variable in a program, specify a word address followed by the variable number. When an expression is used to specify a variable, enclose the expression in brackets.

Example: G01X[#1+#2]F#3;

A referenced variable value is automatically rounded according to the least input increment of the address.

Example:

When G00X#1; is executed on a 1/1000-mm CNC with 12.3456 assigned to variable #1, the actual command is interpreted as G00X12.346;.

To reverse the sign of a referenced variable value, prefix a minus sign (–) to #.

Example: G00X-#1;

When an undefined variable is referenced, the variable is ignored up to an address word.

Example:

When the value of variable #1 is 0, and the value of variable #2 is null, execution of G00X#1Y#2; results in G00X0;.

Common custom macro variables for tow paths (two-path control)

For two-path control, macro variables are provided for each path. Some common variables, however, can be used for both paths, by setting parameters No. 6036 and 6037 accordingly.

Undefined variable

When the value of a variable is not defined, such a variable is referred to as a "null" variable. Variable #0 is always a null variable. It cannot be written to, but it can be read.

(a) Ouotation

When an undefined variable is quotated, the address itself is also ignored.

[Example] When #1 is 0 and #2 is null, the result of executing G00 X#1 Y#2; will be the same as when G00 X0; is executed.

(b) Operation

< vacant > is the same as 0 except when replaced by < vacant>

When #1 = < vacant >	When #1 = 0
#2 = #1	#2 = #1
↓	↓
#2 = < vacant >	#2 = 0
#2 = #1*5	#2 = #1*5
↓	↓
#2 = 0	#2 = 0
#2 = #1+#1	#2 = #1 + #1
↓	↓
#2 = 0	#2 = 0

(c) Conditional expressions

< vacant > differs from 0 only for EQ and NE.

When #1 = < vacant >	When #1 = 0
#1 EQ #0	#1 EQ #0
↓	↓
Established	Not established
#1 NE 0	#1 NE 0
↓	↓
Established	Not established
#1 GE #0	#1 GE #0
↓	↓
Established	Established
#1 GT 0 ↓ Not established	#1 GT 0 ↓ Not established

VARIABLE			O1234 N12345
NO.	DATA	NO.	DATA
100	123.456	108	
101	0.000	109	
102		110	
103		111	
104		112	
105		113	
106		114	
107		115	
ACTUAL POSI	ITION (RELAT	IVE)	
х	0.000	Y	0.000
Z	0.000	В	0.000
MEM **** **	** ***	18:42:15	
[MACRO] [MENU] [C	PR] [] [(OPRT)]

- When the value of a variable is blank, the variable is null.
- The mark ******* indicates an overflow (when the absolute value of a variable is greater than 9999999) or an underflow (when the absolute value of a variable is less than 0.0000001).

Limitations

Program numbers, sequence numbers, and optional block skip numbers cannot be referenced using variables.

Example:

Variables cannot be used in the following ways:

O#1:

/#2G00X100.0;

N#3Y200.0;

15.2 SYSTEM VARIABLES

System variables can be used to read and write internal NC data such as tool compensation values and current position data. Note, however, that some system variables can only be read. System variables are essential for automation and general-purpose program development.

Explanations

values

• Interface signals

Signals can be exchanged between the programmable machine controller (PMC) and custom macros.

Table 15.2 (a) System variables for interface signals

Variable number	Function
#1000-#1015 #1032	A 16-bit signal can be sent from the PMC to a custom macro. Variables #1000 to #1015 are used to read a signal bit by bit. Variable #1032 is used to read all 16 bits of a signal at one time.
#1100-#1115 #1132	A 16-bit signal can be sent from a custom macro to the PMC. Variables #1100 to #1115 are used to write a signal bit by bit. Variable #1132 is used to write all 16 bits of a signal at one time.
#1133	Variable #1133 is used to write all 32 bits of a signal at one time from a custom macro to the PMC. Note, that values from –99999999 to +99999999 can be used for #1133.

For detailed information, refer to the connection manual (B-63003EN-1).

Tool compensation

Tool compensation values can be read and written using system variables. Usable variable numbers depend on the number of compensation pairs, whether a distinction is made between geometric compensation and wear compensation, and whether a distinction is made between tool length compensation and cutter compensation. When the number of compensation pairs is not greater than 200, variables #2001 to #2400 can also be used.

Table 15.2 (b) System variables for tool compensation memory A

Compensation number	System variable
1	#10001 (#2001)
:	:
200	#10200 (#2200)
:	:
999	#10999

Table 15.2 (c) System variables for tool compensation memory B

Compensation number	Geometry compensation	Wear compensation
1	#11001 (#2201)	#10001 (#2001)
200	#11200 (#2400)	#10200 (#2200)
999	#11999	#10999

Table 15.2 (d) System variables for tool compensation memory C

Compensation	Tool length compensation (H)		Cutter compensation (D)	
number	Geometric compensation	Wear compensation	Geomet- ric com- pensation	Wear com- pensation
1 : 200	#11001(#2201) : #11201(#2400)	#10001(#2001) : #10201(#2200)	#13001 :	#12001 :
: 999	: #11999	: #10999	: #13999	: #12999

Macro alarms

Table 15.2 (e) System variable for macro alarms

Variable number	Function
#3000	When a value from 0 to 200 is assigned to variable #3000, the CNC stops with an alarm. After an expression, an alarm message not longer than 26 characters can be described. The CRT screen displays alarm numbers by adding 3000 to the value in variable #3000 along with an alarm message.

Example:

#3000=1(TOOL NOT FOUND);

 \rightarrow The alarm screen displays "3001 TOOL NOT FOUND."

• Time information

Time information can be read and written.

Table 15.2 (f) System variables for time information

Variable number	Function
#3001	This variable functions as a timer that counts in 1–millisecond increments at all times. When the power is turned on, the value of this variable is reset to 0. When 2147483648 milliseconds is reached, the value of this timer returns to 0.
#3002	This variable functions as a timer that counts in 1–hour increments when the cycle start lamp is on. This timer preserves its value even when the power is turned off. When 9544.371767 hours is reached, the value of this timer returns to 0.
#3011	This variable can be used to read the current date (year/month/day). Year/month/day information is converted to an apparent decimal number. For example, September 28, 1994 is represented as 19940928.
#3012	This variable can be used to read the current time (hours/minutes/seconds). Hours/minutes/seconds information is converted to an apparent decimal number. For example, 34 minutes and 56 seconds after 3 p.m. is represented as 153456.

Automatic operation control

The control state of automatic operation can be changed.

Table 15.2 (g) System variable (#3003) for automatic operation control

#3003	Single block	Completion of an auxiliary function
0	Enabled	To be awaited
1	Disabled	To be awaited
2	Enabled	Not to be awaited
3	Disabled	Not to be awaited

- When the power is turned on, the value of this variable is 0.
- When single block stop is disabled, single block stop operation is not performed even if the single block switch is set to ON.
- When a wait for the completion of auxiliary functions (M, S, and T functions) is not specified, program execution proceeds to the next block before completion of auxiliary functions. Also, distribution completion signal DEN is not output.

Table 15.2 (h) System variable (#3004) for automatic operation control

#3004	Feed hold	Feedrate Override	Exact stop
0	Enabled	Enabled	Enabled
1	Disabled	Enabled	Enabled
2	Enabled	Disabled	Enabled
3	Disabled	Disabled	Enabled
4	Enabled	Enabled	Disabled
5	Disabled	Enabled	Disabled
6	Enabled	Disabled	Disabled
7	Disabled	Disabled	Disabled

- When the power is turned on, the value of this variable is 0.
- When feed hold is disabled:
- (1) When the feed hold button is held down, the machine stops in the single block stop mode. However, single block stop operation is not performed when the single block mode is disabled with variable #3003.
- (2) When the feed hold button is pressed then released, the feed hold lamp comes on, but the machine does not stop; program execution continues and the machine stops at the first block where feed hold is enabled.
- When feedrate override is disabled, an override of 100% is always applied regardless of the setting of the feedrate override switch on the machine operator's panel.

• When exact stop check is disabled, no exact stop check (position check) is made even in blocks including those which do not perform cutting.





Fig. 15.2 (a) Example of using variable #3004 in a tapping cycle

Settings

Settings can be read and written. Binary values are converted to decimals.



Mirror image

The mirror-image status for each axis set using an external switch or setting operation can be read through the output signal (mirror-image check signal). The mirror-image status present at that time can be checked. (See III-4.7)

The value obtained in binary is converted into decimal notation.

```
#3007
                        #6
                                   #5
                                                        #3
                                                                   #2
                                                                              #1
                                                                                         #0
                                                      4th axis
                                                                 3th axis
                                                                            2th axis
Setting
                                                                                       1th axis
                               0 (mirror-image function is disabled)
                                                                           is indicated.
                              1 (mirror-image function is enabled)
Example: If #3007 is 3, the mirror-image function is enabled for the first and second axes.
```

• When the mirror—image function is set for a certain axis by both the mirror—image signal and setting, the signal value and setting value are ORed and then output.

- When mirror—image signals for axes other than the controlled axes are turned on, they are still read into system variable #3007.
- System variable #3007 is a write-protected system variable. If an attempt is made to write data in the variable, P/S 116 alarm "WRITE PROTECTED VARIABLE" is issued.

Number of machined parts

The number (target number) of parts required and the number (completion number) of machined parts can be read and written.

Table 15.2(i) System variables for the number of parts required and the number of machined parts

Variable number	Function
#3901	Number of machined parts (completion number)
#3902	Number of required parts (target number)

NOTE

Do not substitute a negative value.

Modal information

Modal information specified in blocks up to the immediately preceding block can be read.

Table 15.2 (j) System variables for modal information

Variable number	Function	
#4001 #4002 #4003 #4004 #4005 #4006 #4007 #4008 #4009 #4010 #4011 #4012 #4013 #4014 #4015 #4016	G00, G01, G02, G03, G33 G17, G18, G19 G90, G91 G94, G95 G20, G21 G40, G41, G42 G43, G44, G49 G73, G74, G76, G80–G89 G98, G99 G50, G51 G65, G66, G67 G96,G97 G54–G59 G61–G64 G68, G69	(Group 01) (Group 02) (Group 03) (Group 04) (Group 05) (Group 06) (Group 07) (Group 08) (Group 10) (Group 11) (Group 12) (Group 13) (Group 14) (Group 15) (Group 16)
: #4022 #4102 #4107 #4109 #4111 #4113 #4114 #4115 #4119 #4120 #4130	: B code D code F code H code M code Sequence number Program number S code T code P code (number of the currently selected al workpiece coordinate system)	: (Group 22)

Example:

When #1=#4001; is executed, the resulting value in #1 is 0, 1, 2, 3, or 33.

If the specified system variable for reading modal information corresponds to a G code group which cannot be used, a P/S alarm is issued.

Current position

Position information cannot be written but can be read.

Table 15.2 (k) System variables for position information

Variable number	Position information	Coordinate system	Tool com- pensation value	Read operation during movement
#5001-#5004	Block end point	Workpiece coordinate system	Not included	Enabled
#5021-#5024	Current position	Machine coordinate system	Included	Disabled
#5041-#5044	Current position	Workpiece coordinate		
#5061-#5064	Skip signal position	system		Enabled
#5081-#5084	Tool length offset value			Disabled
#5101-#5104	Deviated servo position			

- The first digit (from 1 to 4) represents an axis number.
- The tool length offset value currently used for execution rather than the immediately preceding tool offset value is held in variables #5081 to 5088.
- The tool position where the skip signal is turned on in a G31 (skip function) block is held in variables #5061 to #5068. When the skip signal is not turned on in a G31 block, the end point of the specified block is held in these variables.
- When read during movement is "disabled," this means that expected values cannot be read due to the buffering (preread) function.

 Workpiece coordinate system compensation values (workpiece zero point offset values) Workpiece zero point offset values can be read and written.

Table 15.2 (I) System variables for workpiece zero point offset values

Variable number	Function
#5201	First-axis external workpiece zero point offset value
#5204	Fourth–axis external workpiece zero point offset value
#5221	First–axis G54 workpiece zero point offset value
#5224	Fourth–axis G54 workpiece zero point offset value
#5241	First–axis G55 workpiece zero point offset value
#5244	Fourth–axis G55 workpiece zero point offset value
#5261	First–axis G56 workpiece zero point offset value
#5264	Fourth–axis G56 workpiece zero point offset value
#5281	First–axis G57 workpiece zero point offset value
#5284	Fourth–axis G57 workpiece zero point offset value
#5301	First–axis G58 workpiece zero point offset value
#5304	Fourth–axis G58 workpiece zero point offset value
#5321	First–axis G59 workpiece zero point offset value
#5324	Fourth–axis G59 workpiece zero point offset value
#7001	First–axis workpiece zero point offset value (G54.1 P1)
#7004	Fourth–axis workpiece zero point offset value
#7021	First–axis workpiece zero point offset value (G54.1 P2)
#7024	Fourth–axis workpiece zero point offset value
:	:
#7941 :	First–axis workpiece zero point offset value (G54.1 P48)
#7944	Fourth-axis workpiece zero point offset value
#14001	First–axis workpiece zero point offset value (G54.1 P1)
#14004	Fourth-axis workpiece zero point offset value
#14021	First–axis workpiece zero point offset value (G54.1 P2)
#14024	Fourth-axis workpiece zero point offset value
:	:
#19980 :	First–axis workpiece zero point offset value (G54.1 P300)
#19984	Fourth-axis workpiece zero point offset value

The following variables can also be used:

Axis	Function	Variable	number
First axis	External workpiece zero point offset	#2500	#5201
	G54 workpiece zero point offset	#2501	#5221
	G55 workpiece zero point offset	#2502	#5241
	G56 workpiece zero point offset	#2503	#5261
	G57 workpiece zero point offset	#2504	#5281
	G58 workpiece zero point offset	#2505	#5301
	G59 workpiece zero point offset	#2506	#5321
Second	External workpiece zero point offset	#2600	#5202
axis	G54 workpiece zero point offset	#2601	#5222
	G55 workpiece zero point offset	#2602	#5242
	G56 workpiece zero point offset	#2603	#5262
	G57 workpiece zero point offset	#2604	#5282
	G58 workpiece zero point offset	#2605	#5302
	G59 workpiece zero point offset	#2606	#5322
Third axis	External workpiece zero point offset	#2700	#5203
	G54 workpiece zero point offset	#2701	#5223
	G55 workpiece zero point offset	#2702	#5243
	G56 workpiece zero point offset	#2703	#5263
	G57 workpiece zero point offset	#2704	#5283
	G58 workpiece zero point offset	#2705	#5303
	G59 workpiece zero point offset	#2706	#5323
Fourth axis	External workpiece zero point offset	#2800	#5204
	G54 workpiece zero point offset	#2801	#5224
	G55 workpiece zero point offset	#2802	#5244
	G56 workpiece zero point offset	#2803	#5264
	G57 workpiece zero point offset	#2804	#5284
	G58 workpiece zero point offset	#2805	#5304
	G59 workpiece zero point offset	#2806	#5324

NOTE

To use variables #2500 to #2806 and #5201 to #5328, optional variables for the workpiece coordinate systems are necessary.

Optional variables for 48 additional workpiece coordinate systems are #7001 to #7948 (G54.1 P1 to G54.1 P48).

15.3 ARITHMETIC AND LOGIC OPERATION

The operations listed in Table 15.3(a) can be performed on variables. The expression to the right of the operator can contain constants and/or variables combined by a function or operator. Variables #j and #K in an expression can be replaced with a constant. Variables on the left can also be replaced with an expression.

Table 15.3 (a) Arithmetic and logic operation

Function	Format	Remarks
Definition	#i=#j	
Sum Difference Product Quotient	#i=#j+#k; #i=#j-#k; #i=#j*#k; #i=#j/#k;	
Sine Arcsine Tangent Arctangent	#i=SIN[#j]; #i=COS[#j]; #i=TAN[#j]; #i=ATAN[#j]/[#k];	An angle is specified in degrees. 90 degrees and 30 minutes is represented as 90.5 degrees.
Square root Absolute value Rounding off Rounding down Rounding up Natural logarithm Exponential function	#i=SQRT[#j]; #i=ABS[#j]; #i=ROUND[#j]; #i=FIX[#j]; #i=FUP[#j]; #i=LN[#j]; #i=EXP[#j];	
OR XOR AND	#i=#j OR #k; #i=#j XOR #k; #i=#j AND #k;	A logical operation is per- formed on binary numbers bit by bit.
Conversion from BCD to BIN Conversion from BIN to BCD	#i=BIN[#j]; #i=BCD[#j];	Used for signal exchange to and from the PMC

Explanations

Angle units

The units of angles used with the SIN, COS, ASIN, ACOS, TAN, and ATAN functions are degrees. For example, 90 degrees and 30 minutes is represented as 90.5 degrees.

- ARCSIN #i = ASIN[#j];
- The solution ranges are as indicated below: When the NAT bit (bit 0 of parameter 6004) is set to 0: 270° to 90° When the NAT bit (bit 0 of parameter 6004) is set to 1: -90° to 90°-
- When #j is beyond the range of –1 to 1, P/S alarm No. 111 is issued.
- A constant can be used instead of the #j variable.
- ARCCOS #i = ACOS[#j];
- The solution ranges from 180° to 0°.
- When #j is beyond the range of –1 to 1, P/S alarm No. 111 is issued.
- A constant can be used instead of the #j variable.

ARCTAN #i = ATAN[#j]/[#k];

- Specify the lengths of two sides, separated by a slash (/).
- The solution ranges are as follows:

When the NAT bit (bit 0 of parameter 6004) is set to 0: 00 to 360°

[Example] When #1 = ATAN[-1]/[-1]; is specified, #1 is 225.0.

When the NAT bit (bit 0 of parameter 6004) is set to 1: -180° to 180°

[Example] When #1 = ATAN[-1]/[-1]; is specified, #1 is -135.0.0.

- A constant can be used instead of the #j variable.
- Natural logarithm #i = LN[#j];
- Note that the relative error may become 10^{-8} or greater.
- When the antilogarithm (#j) is zero or smaller, P/S alarm No. 111 is issued.
- A constant can be used instead of the #j variable.
- Exponential function #i = EXP[#j];
- Note that the relative error may become 10^{-8} or greater.
- When the result of the operation exceeds 3.65 X 10⁴⁷ (j is about 110), an overflow occurs and P/S alarm No. 111 is issued.
- A constant can be used instead of the #j variable.
- ROUND function
- When the ROUND function is included in an arithmetic or logic operation command, IF statement, or WHILE statement, the ROUND function rounds off at the first decimal place.

Example:

When #1=ROUND[#2]; is executed where #2 holds 1.2345, the value of variable #1 is 1.0.

• When the ROUND function is used in NC statement addresses, the ROUND function rounds off the specified value according to the least input increment of the address.

Example:

Creation of a drilling program that cuts according to the values of variables #1 and #2, then returns to the original position

Suppose that the increment system is 1/1000 mm, variable #1 holds 1.2345, and variable #2 holds 2.3456. Then,

G00 G91 X-#1: Moves 1.235 mm.

G01 X-#2 F300; Moves 2.346 mm.

G00 X[#1+#2]; Since 1.2345 + 2.3456 = 3.5801, the travel distance is 3.580, which does not return the tool to the original position.

This difference comes from whether addition is performed before or after rounding off. G00X-[ROUND[#1]+ROUND[#2]] must be specified to return the tool to the original position.

Rounding up and down to an integer

With CNC, when the absolute value of the integer produced by an operation on a number is greater than the absolute value of the original number, such an operation is referred to as rounding up to an integer. Conversely, when the absolute value of the integer produced by an operation on a number is less than the absolute value of the original number, such an operation is referred to as rounding down to an integer. Be particularly careful when handling negative numbers.

Example:

Suppose that #1=1.2 and #2=-1.2.

When #3=FUP[#1] is executed, 2.0 is assigned to #3.

When #3=FIX[#1] is executed, 1.0 is assigned to #3.

When #3=FUP[#2] is executed, -2.0 is assigned to #3.

When #3=FIX[#2] is executed, -1.0 is assigned to #3.

 Abbreviations of arithmetic and logic operation commands When a function is specified in a program, the first two characters of the function name can be used to specify the function (See III–9.7).

Example:

 $\begin{array}{l} \text{ROUND} \rightarrow \text{RO} \\ \text{FIX} \rightarrow \text{FI} \end{array}$

- Priority of operations
- 1 Functions
- 2 Operations such as multiplication and division (*, /, AND)
- 3 Operations such as addition and subtraction (+, -, OR, XOR)

Bracket nesting

Brackets are used to change the order of operations. Brackets can be used to a depth of five levels including the brackets used to enclose a function. When a depth of five levels is exceeded, P/S alarm No. 118 occurs.

```
Example) #1=SIN [ [ [#2+#3] *#4 +#5] *#6] ;

1
2
3
4
5
1 to 5 indicate the order of operations.
```

Limitations

Brackets

Brackets ([,]) are used to enclose an expression. Note that parentheses are used for comments.

Operation error

Errors may occur when operations are performed.

Table 15.3 (b) Errors involved in operations

Operation	Average error	Maximum error	Type of error
a = b*c	1.55×10 ⁻¹⁰	4.66×10 ⁻¹⁰	Relative error(*1)
a = b/c	4.66×10 ⁻¹⁰	1.88×10 ⁻⁹	$\left \begin{array}{c} arepsilon & arepsilon \ arepsilon & arepsilon \end{array} ight $
$a = \sqrt{b}$	1.24×10 ⁻⁹	3.73×10 ⁻⁹	α
a = b + c $a = b - c$	2.33×10 ⁻¹⁰	5.32×10 ⁻¹⁰	$ \begin{array}{c c} \text{Min} & \frac{\varepsilon}{b} & \text{"} & \frac{\varepsilon}{c} & \\ \end{array} $
a = SIN [b] a = COS [b]	5.0×10 ⁻⁹	1.0×10 ⁻⁸	Absolute error(*3)
a = ATAN [b]/[c] (*4)	1.8×10 ⁻⁶	3.6×10 ⁻⁶	ε degrees

NOTE

- 1 The relative error depends on the result of the operation.
- 2 Smaller of the two types of errors is used.
- 3 The absolute error is constant, regardless of the result of the operation.
- 4 Function TAN performs SIN/COS.
- The precision of variable values is about 8 decimal digits. When very large numbers are handled in an addition or subtraction, the expected results may not be obtained.

Example:

When an attempt is made to assign the following values to variables #1 and #2:

#1=9876543210123.456

#2=9876543277777.777

the values of the variables become:

#1=9876543200000.000

#2=9876543300000.000

In this case, when #3=#2-#1; is calculated, #3=100000.000 results. (The actual result of this calculation is slightly different because it is performed in binary.)

Also be aware of errors that can result from conditional expressions using EQ, NE, GE, GT, LE, and LT.

Example:

IF[#1 EQ #2] is effected by errors in both #1 and #2, possibly resulting in an incorrect decision.

Therefore, instead find the difference between the two variables with IF[ABS[#1-#2]LT0.001].

Then, assume that the values of the two variables are equal when the difference does not exceed an allowable limit (0.001 in this case).

• Also, be careful when rounding down a value.

Example:

When #2=#1*1000; is calculated where #1=0.002;, the resulting value of variable #2 is not exactly 2 but 1.99999997.

Here, when #3=FIX[#2]; is specified, the resulting value of variable #1 is not 2.0 but 1.0. In this case, round down the value after correcting the error so that the result is greater than the expected number, or round it off as follows:

#3=FIX[#2+0.001] #3=ROUND[#2]

Divisor When a divisor of zero is specified in a division or TAN[90], P/S alarm No. 112 occurs.

15.4 MACRO STATEMENTS AND NC STATEMENTS

The following blocks are referred to as macro statements:

- Blocks containing an arithmetic or logic operation (=)
- Blocks containing a control statement (such as GOTO, DO, END)
- Blocks containing a macro call command (such as macro calls by G65, G66, G67, or other G codes, or by M codes) Any block other than a macro statement is referred to as an NC statement.

Explanations

- Differences from NC statements
- NC statements that have the same property as macro statements
- Even when single block mode is on, the machine does not stop. Note, however, that the machine stops in the single block mode when bit 5 of parameter SBM No. 6000 is 1.
- Macro blocks are not regarded as blocks that involve no movement in the cutter compensation mode (seeII–15.7).
- NC statements that include a subprogram call command (such as subprogram calls by M98 or other M codes, or by T codes) and not include other command addresses except an O,N or L address have the same property as macro statements.
- The blocks not include other command addresses except an O,N,P or L address have the same property as macro statements.

15.5 BRANCH AND REPETITION

In a program, the flow of control can be changed using the GOTO statement and IF statement. Three types of branch and repetition operations are used:

Branch and repetition —	GOTO statement (unconditional branch)
	IF statement (conditional branch: if, then)
	WHILE statement (repetition while)

15.5.1 Unconditional Branch (GOTO Statement)

A branch to sequence number n occurs. When a sequence number outside of the range 1 to 99999 is specified, P/S alarm No. 128 occurs. A sequence number can also be specified using an expression.

GOTO n; n: Sequence number (1 to 99999)

Example:

GOTO1; GOTO#10;

15.5.2 Conditional Branch (IF Statement)

Specify a conditional expression after IF.

IF[<conditional expression>]GOTOn

If the specified conditional expression is satisfied, a branch to sequence number n occurs. If the specified condition is not satisfied, the next block is executed.

```
If the value of variable #1 is greater than 10, a branch to sequence number N2 occurs.

If the condition is not satisfied

IF [#1 GT 10] GOTO 2;

Processing

N2 G00 G91 X10.0;

If the condition is satisfied
```

IF[<conditional expression>]THEN

If the specified conditional expression is satisfied, a predetermined macro statement is executed. Only a single macro statement is executed.

```
If the values of #1 and #2 are the same, 0 is assigned to #3.

IF [#1 EQ #2] THEN#3=0;
```

Explanations

• Conditional expression

A conditional expression must include an operator inserted between two variables or between a variable and constant, and must be enclosed in brackets ([,]). An expression can be used instead of a variable.

Operators

Operators each consist of two letters and are used to compare two values to determine whether they are equal or one value is smaller or greater than the other value. Note that the inequality sign cannot be used.

Table 15.5.2 Operators

Operator	Meaning
EQ	Equal to(=)
NE	Not equal to(≠)
GT	Greater than(>)
GE	Greater than or equal to(≧)
LT	Less than(<)
LE	Less than or equal to(≦)

Sample program

The sample program below finds the total of numbers 1 to 10.

O9500:

#1=0;Initial value of the variable to hold the sum #2=1;Initial value of the variable as an addend

N1 IF[#2 GT 10] GOTO 2; Branch to N2 when the addend is greater than


10

#1=#1+#2; Calculation to find the sum

#2=#2+1; Next addend GOTO 1; Branch to N1 N2 M30;End of program

15.5.3 Repetition (While Statement)

Specify a conditional expression after WHILE. While the specified condition is satisfied, the program from DO to END is executed. If the specified condition is not satisfied, program execution proceeds to the block after END.




Explanations

While the specified condition is satisfied, the program from DO to END after WHILE is executed. If the specified condition is not satisfied, program execution proceeds to the block after END. The same format as for the IF statement applies. A number after DO and a number after END are identification numbers for specifying the range of execution. The numbers 1, 2, and 3 can be used. When a number other than 1, 2, and 3 is used, P/S alarm No. 126 occurs.

Nesting

The identification numbers (1 to 3) in a DO–END loop can be used as many times as desired. Note, however, when a program includes crossing repetition loops (overlapped DO ranges), P/S alarm No. 124 occurs.



Limitations

Infinite loops

When DO m is specified without specifying the WHILE statement, an infinite loop ranging from DO to END is produced.

Processing time

When a branch to the sequence number specified in a GOTO statement occurs, the sequence number is searched for. For this reason, processing in the reverse direction takes a longer time than processing in the forward direction. Using the WHILE statement for repetition reduces processing time.

Undefined variable

In a conditional expression that uses EQ or NE, a <vacant> and zero have different effects. In other types of conditional expressions, a <vacant> is regarded as zero.


Sample program

The sample program below finds the total of numbers 1 to 10.

```
O0001;
#1=0;
#2=1;
WHILE[#2 LE 10]DO 1;
#1=#1+#2;
#2=#2+1;
END 1;
M30;
```

15.6 MACRO CALL

A macro program can be called using the following methods:




Limitations

 Differences between macro calls and subprogram calls Macro call (G65) differs from subprogram call (M98) as described below.

- With G65, an argument (data passed to a macro) can be specified. M98 does not have this capability.
- When an M98 block contains another NC command (for example, G01 X100.0 M98Pp), the subprogram is called after the command is executed. On the other hand, G65 unconditionally calls a macro.
- When an M98 block contains another NC command (for example, G01 X100.0 M98Pp), the machine stops in the single block mode. On the other hand, G65 does not stops the machine.
- With G65, the level of local variables changes. With M98, the level of local variables does not change.

15.6.1 Simple Call (G65)

When G65 is specified, the custom macro specified at address P is called. Data (argument) can be passed to the custom macro program.



Explanations

Call

- After G65, specify at address P the program number of the custom macro to call.
- When a number of repetitions is required, specify a number from 1 to 9999 after address L. When L is omitted, 1 is assumed.
- By using argument specification, values are assigned to corresponding local variables.

Argument specification

Two types of argument specification are available. Argument specification I uses letters other than G, L, O, N, and P once each. Argument specification II uses A, B, and C once each and also uses I, J, and K up to ten times. The type of argument specification is determined automatically according to the letters used.

Argument specification I

Address	Variable number
А	#1
В	#2
С	#3
D	#7
E	#8
F	#9
Н	#11

Address	Variable number
I	#4
J	#5
K	#6
M	#13
Q	#17
R	#18
S	#19

Address	Variable number
Т	#20
U	#21
V	#22
W	#23
X	#24
Υ	#25
Z	#26

- Addresses G, L, N, O, and P cannot be used in arguments.
- Addresses that need not be specified can be omitted. Local variables corresponding to an omitted address are set to null.

Argument specification II

Argument specification II uses A, B, and C once each and uses I, J, and K up to ten times. Argument specification II is used to pass values such as three–dimensional coordinates as arguments.

Address	Variable number
Α	#1
В	#2
С	#3
l ₁	#4
J_1	#5
K ₁	#6
l ₂	#7
$\bar{J_2}$	#8
$\bar{K_2}$	#9
l ₃	#10
$\tilde{J_3}$	#11

,,,	amates a	s argumen
Γ	Address	Variable
		number
Γ	K ₃	#12
ı	I_4	#13
ı	J_4	#14
ı	K_4	#15
ı	l ₅	#16
ı	J_5	#17
ı	K_5	#18
ı	16	#19
ı	J_6	#20
1	K_6	#21
L	l ₇	#22

Address	Variable number
	Harrison
J ₇	#23
K ₇	#24
l ₈	#25
J ₈	#26
K ₈	#27
l ₉	#28
J_9	#29
K ₉	#30
I ₁₀	#31
J ₁₀	#32
K ₁₀	#33

• Subscripts of I, J, and K for indicating the order of argument specification are not written in the actual program.

Limitations

- Format
- Mixture of argument specifications I and II
- Position of the decimal point
- Call nesting
- Local variable levels

G65 must be specified before any argument.


The CNC internally identifies argument specification I and argument specification II. If a mixture of argument specification I and argument specification II is specified, the type of argument specification specified later takes precedence.

The units used for argument data passed without a decimal point correspond to the least input increment of each address. The value of an argument passed without a decimal point may vary according to the system configuration of the machine. It is good practice to use decimal points in macro call arguments to maintain program compatibility.

Calls can be nested to a depth of four levels including simple calls (G65) and modal calls (G66). This does not include subprogram calls (M98).


- Local variables from level 0 to 4 are provided for nesting.
- The level of the main program is 0.
- Each time a macro is called (with G65 or G66), the local variable level is incremented by one. The values of the local variables at the previous level are saved in the CNC.

 When M99 is executed in a macro program, control returns to the calling program. At that time, the local variable level is decremented by one; the values of the local variables saved when the macro was called are restored.



Sample program (bolt hole circle)

A macro is created which drills H holes at intervals of B degrees after a start angle of A degrees along the periphery of a circle with radius I. The center of the circle is (X,Y). Commands can be specified in either the absolute or incremental mode. To drill in the clockwise direction, specify a negative value for B.



Calling format

G65 P9100 Xx Yy Zz Rr Ff Ii Aa Bb Hh;

- X: X coordinate of the center of the circle (absolute or incremental specification)(#24)
- Y: Y coordinate of the center of the circle (absolute or incremental specification)(#25)
- Z: Hole depth (#26)
- R: Coordinates of an approach point (#18)
- F: Cutting feedrate (#9)
- I: Radius of the circle (#4)
- A: Drilling start angle (#1)
- B: Incremental angle (clockwise when a negative value is specified) (#2)
- H: Number of holes (#11)
- Program calling a macro program

O0002;

G90 G92 X0 Y0 Z100.0;

G65 P9100 X100.0 Y50.0 R30.0 Z-50.0 F500 I100.0 A0 B45.0 H5; M30;

 Macro program (called program) O9100;

#3=#4003; Stores G code of group 3.

G81 Z#26 R#18 F#9 K0; (Note) . Drilling cycle.

Note: L0 can also be used.

IF[#3 EQ 90]GOTO 1; Branches to N1 in the G90 mode.

#24=#5001+#24; Calculates the X coordinate of the center.

#25=#5002+#25; Calculates the Y coordinate of the center.

N1 WHILE[#11 GT 0]DO 1;

... Until the number of remaining holes reaches 0

#5=#24+#4*COS[#1]; Calculates a drilling position on the X-axis.

#6=#25+#4*SIN[#1]; Calculates a drilling position on the Y-axis.

G90 X#5 Y#6; Performs drilling after moving to the target position.

#1=#1+#2; Updates the angle.

#11=#11-1; Decrements the number of holes.

END 1:

G#3 G80; Returns the G code to the original state.

M99;

Meaning of variables:

#3: Stores the G code of group 3.

#5: X coordinate of the next hole to drill

#6: Y coordinate of the next hole to drill

15.6.2 Modal Call (G66)

Once G66 is issued to specify a modal call a macro is called after a block specifying movement along axes is executed. This continues until G67 is issued to cancel a modal call.

```
G66 P p L \( \) <argument—specification>;

P: Number of the program to call \( \ell : Repetition count (1 by default) \)
Argument: Data passed to the macro

O0001;
:
G66 P9100 L2 A1.0 B2.0;
G00 G90 X100.0;
Y200.0;
X150.0 Y300.0;
G67;
:
M30;

M99;
```

Explanations

Call

- Cancellation
- Call nesting
- Modal call nesting

Limitations

- After G66, specify at address P a program number subject to a modal call
- When a number of repetitions is required, a number from 1 to 9999 can be specified at address L.
- As with a simple call (G65), data passed to a macro program is specified in arguments.

When a G67 code is specified, modal macro calls are no longer performed in subsequent blocks.


Calls can be nested to a depth of four levels including simple calls (G65) and modal calls (G66). This does not include subprogram calls (M98).

Modal calls can be nested by specifying another G66 code during a modal call.

- In a G66 block, no macros can be called.
- G66 needs to be specified before any arguments.
- No macros can be called in a block which contains a code such as a miscellaneous function that does not involve movement along an axis.
- Local variables (arguments) can only be set in G66 blocks. Note that local variables are not set each time a modal call is performed.

Sample program

The same operation as the drilling canned cycle G81 is created using a custom macro and the machining program makes a modal macro call. For program simplicity, all drilling data is specified using absolute values.



Calling format

X: X coordinate of the hole (absolute specification only) (#24) Y: Y coordinate of the hole (absolute specification only) (#25) Z: Coordinates of position Z (absolute specification only) (#26) R: Coordinates of position R (absolute specification only) (#18)

G65 P9110 Xx Yy Zz Rr Ff LI;

Program that calls a macro program

O0001;

G28 G91 X0 Y0 Z0;

G92 X0 Y0 Z50.0;

G00 G90 X100.0 Y50.0;

G66 P9110 Z-20.0 R5.0 F500;

G90 X20.0 Y20.0;

X50.0:

Y50.0:

X70.0 Y80.0;

G67;

M30;

Macro program (program called)

O9110;

#1=#4001; Stores G00/G01.

#3=#4003; Stores G90/G91.

#4=#4109; Stores the cutting feedrate.

#5=#5003; Stores the Z coordinate at the start of drilling.

G00 G90 Z#18; Positioning at position R

G01 Z#26 F#9; Cutting feed to position Z

IF[#4010 EQ 98]GOTO 1; Return to position I

G00 Z#18; Positioning at position R

GOTO 2;


N1 G00 Z#5; Positioning at position I

N2 G#1 G#3 F#4; Restores modal information.

M99;

15.6.3 Macro Call Using G Code

By setting a G code number used to call a macro program in a parameter, the macro program can be called in the same way as for a simple call (G65).



Explanations

By setting a G code number from 1 to 9999 used to call a custom macro program (O9010 to O9019) in the corresponding parameter (N0.6050 to No.6059), the macro program can be called in the same way as with G65. For example, when a parameter is set so that macro program O9010 can be called with G81, a user–specific cycle created using a custom macro can be called without modifying the machining program.

 Correspondence between parameter numbers and program numbers

Program number	Parameter number
O9010	6050
O9011	6051
O9012	6052
O9013	6053
O9014	6054
O9015	6055
O9016	6056
O9017	6057
O9018	6058
O9019	6059

Repetition

As with a simple call, a number of repetitions from 1 to 9999 can be specified at address L.

Argument specification

As with a simple call, two types of argument specification are available: Argument specification I and argument specification II. The type of argument specification is determined automatically according to the addresses used.


Limitations

Nesting of calls using G codes

In a program called with a G code, no macros can be called using a G code. A G code in such a program is treated as an ordinary G code. In a program called as a subprogram with an M or T code, no macros can be called using a G code. A G code in such a program is also treated as an ordinary G code.

15.6.4 Macro Call Using an M Code

By setting an M code number used to call a macro program in a parameter, the macro program can be called in the same way as with a simple call (G65).



Explanations

By setting an M code number from 1 to 99999999 used to call a custom macro program (9020 to 9029) in the corresponding parameter (No.6080 to No.6089), the macro program can be called in the same way as with G65.

 Correspondence between parameter numbers and program numbers

Program number	Parameter number
O9020	6080
O9021	6081
O9022	6082
O9023	6083
O9024	6084
O9025	6085
O9026	6086
O9027	6087
O9028	6088
O9029	6089

Repetition

As with a simple call, a number of repetitions from 1 to 9999 can be specified at address L.

Argument specification


As with a simple call, two types of argument specification are available: Argument specification I and argument specification II. The type of argument specification is determined automatically according to the addresses used.

Limitations

- An M code used to call a macro program must be specified at the start of a block.
- In a macro called with a G code or in a program called as a subprogram with an M or T code, no macros can be called using an M code. An M code in such a macro or program is treated as an ordinary M code.

15.6.5 Subprogram Call Using an M Code

By setting an M code number used to call a subprogram (macro program) in a parameter, the macro program can be called in the same way as with a subprogram call (M98).



Explanations

By setting an M code number from 1 to 99999999 used to call a subprogram in a parameter (No.6071 toNo. 6079), the corresponding custom macro program (O9001 to O9009) can be called in the same way as with M98.

 Correspondence between parameter numbers and program numbers

Program number	Parameter number
O9001	6071
O9002	6072
O9003	6073
O9004	6074
O9005	6075
O9006	6076
O9007	6077
O9008	6078
O9009	6079

Repetition

As with a simple call, a number of repetitions from 1 to 9999 can be specified at address L.

Argument specification

Argument specification is not allowed.

M code


An M code in a macro program that has been called is treated as an ordinary M code.

Limitations

In a macro called with a G code or in a program called with an M or T code, no subprograms can be called using an M code. An M code in such a macro or program is treated as an ordinary M code.

15.6.6 Subprogram Calls Using a T Code

By enabling subprograms (macro program) to be called with a T code in a parameter, a macro program can be called each time the T code is specified in the machining program.



Explanations

Call

By setting bit 5 of parameter TCS No.6001 to 1, the macro program O9000 can be called when a T code is specified in the machining program. A T code specified in a machining program is assigned to common variable #149.

Limitations

In a macro called with a G code or in a program called with an M or T code, no subprograms can be called using a T code. A T code in such a macro or program is treated as an ordinary T code.

15.6.7 Sample Program

Conditions

By using the subprogram call function that uses M codes, the cumulative usage time of each tool is measured.

- The cumulative usage time of each of tools T01 to T05 is measured. No measurement is made for tools with numbers greater than T05.
- The following variables are used to store the tool numbers and measured times:

#501 Cumulative usage time of tool number 1
#502 Cumulative usage time of tool number 2
#503 Cumulative usage time of tool number 3
#504 Cumulative usage time of tool number 4
#505 Cumulative usage time of tool number 5

 Usage time starts being counted when the M03 command is specified and stops when M05 is specified. System variable #3002 is used to measure the time during which the cycle start lamp is on. The time during which the machine is stopped by feed hold and single block stop operation is not counted, but the time used to change tools and pallets is included.

Operation check

Parameter setting

Set 3 in parameter No.6071, and set 05 in parameter No.6072.

Variable value setting

Set 0 in variables #501 to #505.

O0001;

Program that calls a macro program

```
T01 M06;
M03;
M05; Changes #501.
T02 M06;
M03;
M05; Changes #502.
T03 M06;
M03;
M05; Changes #503.
T04 M06:
M03;
M05; Changes #504.
T05 M06;
M03;
M05; Changes #505.
M30;
```

Macro program (program called)

O9001(M03); Macro to start counting

M01:

IF[#4120 EQ 0]GOTO 9; No tool specified

IF[#4120 GT 5]GOTO 9; Out-of-range tool number

#3002=0; Clears the timer.

 $N9\ M03;\ Rotates$ the spindle in the forward direction.

M99;

O9002(M05); Macro to end counting

M01:

IF[#4120 EQ 0]GOTO 9; No tool specified

IF[#4120 GT 5]GOTO 9; Out-of-range tool number

#[500+#4120]=#3002+#[500+#4120]; Calculates cumulative time.

N9 M05; Stops the spindle.

M99;

15.7 PROCESSING MACRO STATEMENTS


For smooth machining, the CNC prereads the NC statement to be performed next. This operation is referred to as buffering. In cutter compensation mode (G41, G42), the NC prereads NC statements two or three blocks ahead to find intersections. Macro statements for arithmetic expressions and conditional branches are processed as soon as they are read into the buffer. Blocks containing M00, M01, M02, or M30, blocks containing M codes for which buffering is suppressed by setting parameters No.3411 to No.3420, and blocks containing G31 are not preread.


Explanations

 When the next block is not buffered (M codes that are not buffered, G31, etc.)

 Buffering the next block in other than cutter compensation mode (G41, G42) (normally


prereading one block)






When N1 is being executed, the next NC statement (N4) is read into the buffer. The macro statements (N2, N3) between N1 and N4 are processed during execution of N1.

 Buffering the next block in cutter compensation mode (G41, G42)



When N1 is being executed, the NC statements in the next two blocks (up to N5) are read into the buffer. The macro statements (N2, N4) between N1 and N5 are processed during execution of N1.

 When the next block involves no movement in cutter compensation C (G41, G42) mode



When the NC1 block is being executed, the NC statements in the next two blocks (up to N5) are read into the buffer. Since N5 is a block that involves no movement, an intersection cannot be calculated. In this case, the NC statements in the next three blocks (up to N7) are read. The macro statements (N2, N4, and N6) between N1 and N7 are processed during execution of N1.

15.8 REGISTERING CUSTOM MACRO PROGRAMS

Custom macro programs are similar to subprograms. They can be registered and edited in the same way as subprograms. The storage capacity is determined by the total length of tape used to store both custom macros and subprograms.

15.9 LIMITATIONS

MDI operation

The macro call command can be specified in MDI mode. During automatic operation, however, it is impossible to switch to the MDI mode for a macro program call.

Sequence number search

A custom macro program cannot be searched for a sequence number.

• Single block

Even while a macro program is being executed, blocks can be stopped in the single block mode.

A block containing a macro call command (G65, G66, or G67) does not stop even when the single block mode is on. Blocks containing arithmetic operation commands and control commands can be stopped in single block mode by setting SBM (bit 5 of parameter 6000) to 1.

Single block stop operation is used for testing custom macro programs. Note that when a single block stop occurs at a macro statement in cutter compensation C mode, the statement is assumed to be a block that does not involve movement, and proper compensation cannot be performed in some cases. (Strictly speaking, the block is regarded as specifying a movement with a travel distance 0.)

Optional block skip

A / appearing in the middle of an <expression> (enclosed in brackets [] on the right-hand side of an arithmetic expression) is regarded as a division operator; it is not regarded as the specifier for an optional block skip code.

Operation in EDIT mode

By setting NE8 (bit 0 of parameter 3202) and NE9 (bit 4 of parameter 3202) to 1, deletion and editing are disabled for custom macro programs and subprograms with program numbers 8000 to 8999 and 9000 to 9999. This prevents registered custom macro programs and subprograms from being destroyed by accident. When the entire memory is cleared (by pressing the RESET and DELETE keys at the same time to turn on the power), the contents of memory such as custom macro programs are deleted.

Reset

With a reset operation, local variables and common variables #100 to #149 are cleared to null values. They can be prevented from clearing by setting, CLV and CCV (bits 7 and 6 of parameter 6001). System variables #1000 to #1133 are not cleared.

A reset operation clears any called states of custom macro programs and subprograms, and any DO states, and returns control to the main program.

 Display of the PROGRAM RESTART As with M98, the M and T codes used for subprogram calls are not displayed.

Feed hold

When a feed hold is enabled during execution of a macro statement, the machine stops after execution of the macro statement. The machine also stops when a reset or alarm occurs.

 Constant values that can be used in <expression> +0.0000001 to +99999999 -99999999 to -0.0000001

The number of significant digits is 8 (decimal). If this range is exceeded, P/S alarm No. 003 occurs.

15.10 EXTERNAL OUTPUT COMMANDS

In addition to the standard custom macro commands, the following macro commands are available. They are referred to as external output commands.

- BPRNT
- DPRNT
- POPEN
- PCLOS

These commands are provided to output variable values and characters through the reader/punch interface.

Explanations

Specify these commands in the following order:

Open command: POPEN

Before specifying a sequence of data output commands, specify this command to establish a connection to an external input/output device.

Data output command: BPRNT or DPRNT

Specify necessary data output.

Close command: PCLOS


When all data output commands have completed, specify PCLOS to release a connection to an external input/output device.

Open command POPEN

POPEN

POPEN establishes a connection to an external input/output device. It must be specified before a sequence of data output commands. The CNC outputs a DC2 control code.

Data output command BPRNT




The BPRNT command outputs characters and variable values in binary.

- (i) Specified characters are converted to the codes according to the setting data (ISO) that is output at that time.
 - Specifiable characters are as follows:
 - Letters (A to Z)
 - Numbers
 - Special characters (*, /, +, -, etc.)


An asterisk (*) is output by a space code.

- (ii) All variables are stored with a decimal point. Specify a variable followed by the number of significant decimal places enclosed in brackets. A variable value is treated as 2–word (32–bit) data, including the decimal digits. It is output as binary data starting from the highest byte.
- (iii) When specified data has been output, an EOB code is output according to the setting code (ISO).
- (iv) Null variables are regarded as 0.

Example)



Data output command DPRNT



The DPRNT command outputs characters and each digit in the value of a variable according to the code set in the settings (ISO).

- (i) For an explanation of the DPRNT command, see Items (i), (iii), and (iv) for the BPRNT command.
- (ii) When outputting a variable, specify # followed by the variable number, then specify the number of digits in the integer part and the number of decimal places enclosed in brackets.


One code is output for each of the specified number of digits, starting with the highest digit. For each digit, a code is output according to the settings (ISO). The decimal point is also output using a code set in the settings (ISO).

Each variable must be a numeric value consisting of up to eight digits. When high—order digits are zeros, these zeros are not output if PRT (bit1 of parameter 6001) is 1. If parameter PRT is 0, a space code is output each time a zero is encountered.

When the number of decimal places is not zero, digits in the decimal part are always output. If the number of decimal places is zero, no decimal point is output.

When PRT (bit 1 of parameter 6001) is 0, a space code is output to indicate a positive number instead of +; if parameter PRT is 1, no code is output.

Example)



Close command PCLOS

PCLOS;

The PCLOS command releases a connection to an external input/output device. Specify this command when all data output commands have terminated. DC4 control code is output from the CNC.

Required setting

Specify the channel use for setting data (I/O channel). According to the specification of this data, set data items (such as the baud rate) for the reader/punch interface.

I/O channel 0 : Parameters (No.101, No.102 and No.103) I/O channel 1 : Parameters (No.111, No.112 and No.113) I/O channel 2 : Parameters (No.112, No.122 and No.123)

Never specify the output device FANUC Cassette or Floppy for punching. When specifying a DPRNT command to output data, specify whether leading zeros are output as spaces (by setting PRT (bit 1 of parameter 6001) to 1 or 0).

To indicate the end of a line of data in ISO code, specify whether to use only an LF (CRO, of bit 4 of parameter 6001 is 0) or an LF and CR (CRO of bit 4 of parameter 6001 is 1).

NOTE

- 1 It is not necessary to always specify the open command (POPEN), data output command (BPRNT, DPRNT), and close command (PCLOS) together. Once an open command is specified at the beginning of a program, it does not need to be specified again except after a close command was specified.
- 2 Be sure to specify open commands and close commands in pairs. Specify the close command at the end of the program. However, do not specify a close command if no open command has been specified.
- 3 When a reset operation is performed while commands are being output by a data output command, output is stopped and subsequent data is erased. Therefore, when a reset operation is performed by a code such as M30 at the end of a program that performs data output, specify a close command at the end of the program so that processing such as M30 is not performed until all data is output.
- 4 Abbreviated macro words enclosed in brackets [] remains unchanged. However, note that when the characters in brackets are divided and input several times, the second and subsequent abbreviations are converted and input.
- 5 O can be specified in brackets []. Note that when the characters in brackets [] are divided and input several times, O is omitted in the second and subsequent inputs.

15.11 INTERRUPTION TYPE CUSTOM MACRO

When a program is being executed, another program can be called by inputting an interrupt signal (UINT) from the machine. This function is referred to as an interruption type custom macro function. Program an interrupt command in the following format:

Format

M96 POOO; Enables custom macro interrupt
M97; Disables custom macro interrupt

Explanations

Use of the interruption type custom macro function allows the user to call a program during execution of an arbitrary block of another program. This allows programs to be operated to match situations which vary from time to time.

- (1) When a tool abnormality is detected, processing to handle the abnormality is started by an external signal.
- (2) A sequence of machining operations is interrupted by another machining operation without the cancellation of the current operation.
- (3) At regular intervals, information on current machining is read.

 Listed above are examples like adaptive control applications of the interruption type custom macro function.




Fig 15.11 Interruption type sustom macro function

When M96Pxxxx is specified in a program, subsequent program operation can be interrupted by an interrupt signal (UINT) input to execute the program specified by Pxxxx.

When the interrupt signal (UINT, marked by * in Fig. 15.11 is input during execution of the interrupt program or after M97 is specified, it is ignored.

15.11.1 Specification Method

Explanations


• Interrupt conditions

A custom macro interrupt is available only during program execution. It is enabled under the following conditions

- When memory operation or MDI operation is selected
- When STL (start lamp) is on
- When a custom macro interrupt is not currently being processed

Specification

Generally, the custom macro interrupt function is used by specifying M96 to enable the interrupt signal (UINT) and M97 to disable the signal. Once M96 is specified, a custom macro interrupt can be initiated by the input of the interrupt signal (UINT) until M97 is specified or the NC is reset. After M97 is specified or the NC is reset, no custom macro interrupts are initiated even when the interrupt signal (UINT) is input. The interrupt signal (UINT) is ignored until another M96 command is specified.



The interrupt signal (UINT) becomes valid after M96 is specified. Even when the signal is input in M97 mode, it is ignored. When the signal input in M97 mode is kept on until M96 is specified, a custom macro interrupt is initiated as soon as M96 is specified (only when the status—triggered scheme is employed); when the edge—triggered scheme is employed, the custom macro interrupt is not initiated even when M96 is specified.

NOTE

For the status-triggered and edge-triggered schemes, see Item "Custom macro interrupt signal (UINT)" of II- 15.11.2.

15.11.2

Details of Functions

Explanations

 Subprogram-type interrupt and macro-type interrupt

 M codes for custom macro interrupt control

 Custom macro interrupts and NC statements

> Type I (when an interrupt is performed even in the middle of a block)

There are two types of custom macro interrupts: Subprogram-type interrupts and macro-type interrupts. The interrupt type used is selected by MSB (bit 5 of parameter 6003).

(a) Subprogram-type interrupt

An interrupt program is called as a subprogram. This means that the levels of local variables remain unchanged before and after the interrupt. This interrupt is not included in the nesting level of subprogram calls.

(b) Macro-type interrupt

An interrupt program is called as a custom macro. This means that the levels of local variables change before and after the interrupt. The interrupt is not included in the nesting level of custom macro calls. When a subprogram call or a custom macro call is performed within the interrupt program, this call is included in the nesting level of subprogram calls or custom macro calls. Arguments cannot be passed from the current program even when the custom macro interrupt is a macro—type interrupt.

In general, custom macro interrupts are controlled by M96 and M97. However, these M codes, may already being used for other purposes (such as an M function or macro M code call) by some machine tool builders. For this reason, MPR (bit 4 of parameter 6003) is provided to set M codes for custom macro interrupt control.


When specifying this parameter to use the custom macro interrupt control M codes set by parameters, set parameters 6033 and 6034 as follows: Set the M code to enable custom macro interrupts in parameter 6033, and set the M code to disable custom macro interrupts in parameter 6034. When specifying that parameter–set M codes are not used, M96 and M97 are used as the custom macro control M codes regardless of the settings of parameters 6033 and 6034.

The M codes used for custom macro interrupt control are processed internally (they are not output to external units). However, in terms of program compatibility, it is undesirable to use M codes other than M96 and M97 to control custom macro interrupts.

When performing a custom macro interrupt, the user may want to interrupt the NC statement being executed, or the user may not want to perform the interrupt until the execution of the current block is completed. MIN (bit 2 of parameter 6003)is used to select whether to perform interrupts even in the middle of a block or to wait until the end of the block.

- (i) When the interrupt signal (UINT) is input, any movement or dwell being performed is stopped immediately and the interrupt program is executed.
- (ii) If there are NC statements in the interrupt program, the command in the interrupted block is lost and the NC statement in the interrupt program is executed. When control is returned to the interrupted program, the program is restarted from the next block after the interrupted block.

(iii) If there are no NC statements in the interrupt program, control is returned to the interrupted program by M99, then the program is restarted from the command in the interrupted block.




Type II (when an interrupt is performed at the end of the block)

- (i) If the block being executed is not a block that consists of several cycle operations such as a drilling canned cycle and automatic reference position return (G28), an interrupt is performed as follows:

 When an interrupt signal (UINT) is input, macro statements in the interrupt program are executed immediately unless an NC statement
- executed until the current block is completed.(ii) If the block being executed consists of several cycle operations, an interrupt is performed as follows:

When the last movement in the cycle operations is started, macro statements in the interrupt program are executed unless an NC statement is encountered. NC statements are executed after all cycle operations are completed.

is encountered in the interrupt program. NC statements are not



 Conditions for enabling and disabling the custom macro interrupt signal The interrupt signal becomes valid after execution starts of a block that contains M96 for enabling custom macro interrupts. The signal becomes invalid when execution starts of a block that contains M97.

While an interrupt program is being executed, the interrupt signal becomes invalid. The signal become valid when the execution of the block that immediately follows the interrupted block in the main program is started after control returns from the interrupt program. In type I, if the interrupt program consists of only macro statements, the interrupt signal becomes valid when execution of the interrupted block is started after control returns from the interrupt program.

 Custom macro interrupt during execution of a block that involves cycle operation

For type I

Even when cycle operation is in progress, movement is interrupted, and the interrupt program is executed. If the interrupt program contains no NC statements, the cycle operation is restarted after control is returned to the interrupted program. If there are NC statements, the remaining operations in the interrupted cycle are discarded, and the next block is executed.

For type II

When the last movement of the cycle operation is started, macro statements in the interrupt program are executed unless an NC statement is encountered. NC statements are executed after cycle operation is completed.


Custom macro interrupt signal (UINT)

There are two schemes for custom macro interrupt signal (UINT) input: The status—triggered scheme and edge—triggered scheme. When the status—triggered scheme is used, the signal is valid when it is on. When the edge triggered scheme is used, the signal becomes valid on the rising edge when it switches from off to on status.

One of the two schemes is selected with TSE (bit 3 of parameter 6003). When the status—triggered scheme is selected by this parameter, a custom macro interrupt is generated if the interrupt signal (UINT) is on at the time the signal becomes valid. By keeping the interrupt signal (UINT) on, the interrupt program can be executed repeatedly.

When the edge—triggered scheme is selected, the interrupt signal (UINT) becomes valid only on its rising edge. Therefore, the interrupt program is executed only momentarily (in cases when the program consists of only macro statements). When the status—triggered scheme is inappropriate, or when a custom macro interrupt is to be performed just once for the entire program (in this case, the interrupt signal may be kept on), the edge—triggered scheme is useful.

Except for the specific applications mentioned above, use of either scheme results in the same effects. The time from signal input until a custom macro interrupt is executed does not vary between the two schemes.




In the above example, an interrupt is executed four times when the status triggered scheme is used; when the edge-triggered scheme is used, the interrupt is executed just once.

Return from a custom macro interrupt

To return control from a custom macro interrupt to the interrupted program, specify M99. A sequence number in the interrupted program can also be specified using address P. If this is specified, the program is searched from the beginning for the specified sequence number. Control is returned to the first sequence number found.

When a custom macro interrupt program is being executed, no interrupts are generated. To enable another interrupt, execute M99. When M99 is specified alone, it is executed before the preceding commands terminate. Therefore, a custom macro interrupt is enabled for the last command of the interrupt program. If this is inconvenient, custom macro interrupts should be controlled by specifying M96 and M97 in the program.

When a custom macro interrupt is being executed, no other custom macro interrupts are generated; when an interrupt is generated, additional interrupts are inhibited automatically. Executing M99 makes it possible for another custom macro interrupt to occur. M99 specified alone in a block is executed before the previous block terminates. In the following example, an interrupt is enabled for the Gxx block of O1234. When the signal is input, O1234 is executed again. O5678 is controlled by M96 and M97. In this case, an interrupt is not enabled for O5678 (enabled after control is returned to O1000).



NOTE

When an M99 block consists only of address O, N, P, L, or M, this block is regarded as belonging to the previous block in the program. Therefore, a single–block stop does not occur for this block. In terms of programming, the following and are basically the same. (The difference is whether GO is executed before M99 is recognized.)

GOXOO;
M99;


 Custom macro interrupt and modal information A custom macro interrupt is different from a normal program call. It is initiated by an interrupt signal (UINT) during program execution. In general, any modifications of modal information made by the interrupt program should not affect the interrupted program.

For this reason, even when modal information is modified by the interrupt program, the modal information before the interrupt is restored when control is returned to the interrupted program by M99.

When control is returned from the interrupt program to the interrupted program by M99 Pxxxx, modal information can again be controlled by the program. In this case, the new continuous information modified by the interrupt program is passed to the interrupted program. Restoration of the old modal information present before the interrupt is not desirable. This is because after control is returned, some programs may operate differently depending on the modal information present before the interrupt. In this case, the following measures are applicable:

(1) The interrupt program provides modal information to be used after control is returned to the interrupted program.

(2) After control is returned to the interrupted program, modal information is specified again as necessary.



Modal information when control is returned by M99


Modal information when control is returned by M99 P○○○

 System variables (position information values) for the interrupt program The modal information present before the interrupt becomes valid. The new modal information modified by the interrupt program is made invalid.

The new modal information modified by the interrupt program remains valid even after control is returned. The old modal information which was valid in the interrupted block can be read using custom macro system variables #4001 to #4120.

Note that when modal information is modified by the interrupt program, system variables #4001 to #4120 are not changed.

- The coordinates of point A can be read using system variables #5001 and up until the first NC statement is encountered.
- The coordinates of point A' can be read after an NC statement with no move specifications appears.
- The machine coordinates and workpiece coordinates of point B' can be read using system variables #5021 and up and #5041 and up.



 Custom macro interrupt and custom macro modal call When the interrupt signal (UINT) is input and an interrupt program is called, the custom macro modal call is canceled (G67). However, when G66 is specified in the interrupt program, the custom macro modal call becomes valid. When control is returned from the interrupt program by M99, the modal call is restored to the state it was in before the interrupt was generated. When control is returned by M99Pxxxx;, the modal call in the interrupt program remains valid.

 Custom macro interrupt and program restart When the interrupt signal (UINT) is input while a return operation is being performed in the dry run mode after the search operation for program restart, the interrupt program is called after restart operation terminates for all axes. This means that interrupt type II is used regardless of the parameter setting.

16

PATTERN DATA INPUT FUNCTION

This function enables users to perform programming simply by extracting numeric data (pattern data) from a drawing and specifying the numerical values from the MDI panel.

This eliminates the need for programming using an existing NC language.

With the aid of this function, a machine tool builder can prepare the program of a hole machining cycle (such as a boring cycle or tapping cycle) using the custom macro function, and can store it into the program memory.

This cycle is assigned pattern names, such as BOR1, TAP3, and DRL2.


An operator can select a pattern from the menu of pattern names displayed on the screen.

Data (pattern data) which is to be specified by the operator should be created in advance with variables in a drilling cycle.

The operator can identify these variables using names such as DEPTH, RETURN RELIEF, FEED, MATERIAL or other pattern data names. The operator assigns values (pattern data) to these names.

16.1 DISPLAYING THE PATTERN MENU

Pressing the office key and [MENU] is displayed on the following pattern menu screen.



HOLE PATTERN: This is the menu title. An arbitrary character string

consisting of up to 12 characters can be specified.

BOLT HOLE: This is the pattern name. An arbitrary character

string consisting of up to 10 characters can be

specified, including katakana.

The machine tool builder should specify the character strings for the menu title and pattern name using the custom macro, and load the character strings into program memory as a subprogram of program No. 9500.


 Macro commands specifying the menu title $\begin{array}{lll} \text{Menu title}: & C_1 \ C_2 \ C_3 \ C_4 \ C_5 \ C_6 \ C_7 \ C_8 \ C_9 C_{10} \ C_{11} \ C_{12} \\ C_1, C_2, & C_{12}: Characters in the menu title (12 characters) \end{array}$

Macro instruction

G65 H90 P_p Q_q R_r I_i J_j K_k :

H90:Specifies the menu title

p: Assume a1 and a2 to be the codes of characters C1 and C2. Then,



- q : Assume a_3 and a_4 to be the codes of characters C_3 and $C_4.$ Then, $q{=}a_3\,10^3{+}a_4$
- r : Assume a_5 and a_6 to be the codes of characters C_5 and C_6 . Then, $r=a_5\,10^3+a_6$
- i : Assume a_7 and a_8 to be the codes of characters C_7 and $C_8. Then, \\ i=a_7\,10^3+a_8$
- j : Assume a_9 and a_{10} to be the codes of characters C_9 and $C_{10}.$ Then, $j{=}a_9\,10^3{+}a_{10}$
- k : Assume a_{11} and a_{12} to be the codes of characters C_{11} and $C_{12}.Then, \ k \! = \! a_{11} \, 10^3 \! + \! a_{12}$

Example) If the title of the menu is"HOLE PATTERN" then the macro instruction is as follows:

G65 H90 P072079 Q076069 R032080

HO LE $\sqcup P$

I065084 J084069 K082078;

AT TE RN

For codes corresponding to these characters, refer to the table in II–16.3.

 Macro instruction describing the pattern name Pattern name: C₁ C₂ C₃ C₄ C₅ C₆ C₇ C₈ C₉C₁₀

 C_1 , C_2 , C_{10} : Characters in the pattern name (10 characters)

Macro instruction

G65 H91 $P_n Q_q R_r I_i J_j K_k$;

H91: Specifies the menu title

- n : Specifies the menu No. of the pattern name $n_{=}1\ to\ 10$
- q : Assume a_1 and a_2 to be the codes of characters C_1 and C_2 . Then, $q{=}a_1{_\times}10^3{+}a_2$
- r : Assume a_3 and a_4 to be the codes of characters C_3 and $C_4.$ Then, $r{=}a_{3\ast}10^3{+}a_4$
- i : Assume a_5 and a_6 to be the codes of characters C_5 and C_6 . Then, $i{=}a_{5_\times}10^3{+}a_6$
- j : Assume a_7 and a_8 to be the codes of characters C_7 and C_8 . Then, $i=a_{7\times}10^3+a_8$
- k : Assume a_9 and a_{10} to be the codes of characters C_9 and C_{10} . Then, $k = a_{9 \times} 10^3 + a_{10}$

Example) If the pattern name of menu No. 1 is "BOLT HOLE" then the macro instruction is as follows.

G65 H91 P1 Q066079 R076084 I032072 J079076 K069032;

BO

LT

 \sqcup H

OL

 $E \sqcup$

Pattern No. selection

To select a pattern from the pattern menu screen, enter the corresponding pattern No. The following is an example.



The selected pattern No. is assigned to system variable #5900. The custom macro of the selected pattern can be started by starting a fixed program (external program No. search) with an external signal then referring to the system variable #5900 in the program.

NOTE

If each characters of P, Q, R, I, J, and K are not specified in a macro instruction, two spaces are assigned to each omitted character.

Example

Custom macros for the menu title and hole pattern names.

```
MENU : HOLE PATTERN
                                O0000 N00000
      1. BOLT HOLE
      2.
         GRID
      3.
         LINE ANGLE
          TAPPING
         DRILLING
      5.
         BORING
      6.
      7.
         POCKET
      8. PECK
      9. TEST PATRN
     10.
          BACK
MDI ****
                      16:05:59
[ MACRO ] [ MENU ] [ OPR ] [
                                 ] [ (OPRT) ]
```

O9500:

N12M99;

N1G65 H90 P072 079 Q076 069 R032 080 I 065 084 J 084 069 K082 078; HOLE PATTERN N2G65 H91 P1 Q066 079 R076 084 I 032 072 J 079 076 K069 032 ; 1.BOLT HOLE N3G65 H91 P2 Q071 082 R073 068; 2.GRID N4G65 H91 P3 Q076 073 R078 069 I 032 065 J 078071 K076069 ; 3.LINE ANGLE N5G65 H91 P4 Q084 065 R080 080 I 073 078 J 071 032 ; 4.TAPPING N6G65 H91 P5 Q068 082 R073 076 I 076 073 J 078 071; 5.DRILLING N7G65 H91 P6 Q066079 R082073 I 078 071; 6.BORING 7.POCKET N8G65 H91 P7 Q080 079 R067 075 I 069 084; N9G65 H91 P8 Q080069 R067075; 8.PECK N10G65 H91 P9 Q084 069 R083 084 I032 080 J065 084 K082 078; 9.TEST PATRN N11G65 H91 P10 Q066 065 R067 0750; 10.BACK

16.2 PATTERN DATA DISPLAY

When a pattern menu is selected, the necessary pattern data is displayed.

```
00001 N00000
 VAR. : BOLT HOLE
  NO. NAME DATA
                  COMMENT
  500 TOOL
  501STANDARD X 0.000 *BOLT HOLE
  502STANDARD Y 0.000 CIRCLE*
  503RADIUS 0.000 SET PATTERN
  504S. ANGL 0.000 DATA TO VAR.
  505HOLES NO0.000 NO.500-505.
  506 0.000
  507 0.000
 ACTUAL POSITION (RELATIVE)
         0.000
                  Y
                      0.000
    Z
         0.000
MDI **** ***
                      16:05:59
 MACRO ] [ MENU ] [
                     OPR ] [
                                   ] [(OPRT)]
```

BOLT HOLE: This is the pattern data title. A character string

consisting of up to 12 characters can be set.

TOOL: This is the variable name. A character string

consisting of up to 10 characters can be set.

BOLT HOLE CIRCLE :

This is a comment statement. A character string can be displayed consisting of up to 8 lines, 12 characters per line.

(It is permissible to use <u>katakana</u> in a character string or line.) The machine tool builder should program the character strings of pattern data title, pattern name, and variable name using the custom macro, and load them into the program memory as a subprogram whose No. is 9500 plus the pattern No. (O9501 to O9510).

Macro instruction specifying the pattern data title (the menu title)

Menu title : $C_1 C_2 C_3 C_4 C_5 C_6 C_7 C_8 C_9 C_{10} C_{11} C_{12}$

 C_1 , C_2 ... C_{12} : Characters in the menu title (12 characters)

Macro instruction

G65 H92 P_n Q_q R_r I_i J_j K_k ;

H92: Specifies the pattern name

p : Assume a_1 and a_2 to be the codes of characters C_1 and $C_2.$ Then, $p{=}a_1{_{\scriptscriptstyle \perp}}10^3{+}a_2$

See 17.3 for character codes.

- q : Assume a_3 and a_4 to be the codes of characters C_3 and C_4 . Then, $q=a_{3\times}10^3+a_4$
- r : Assume a_5 and a_6 to be the codes of characters C_5 and $C_6.$ Then, $r{=}a_{5\ast}10^3{+}a_6$
- i : Assume a_7 and a_8 to be the codes of characters C_7 and $C_8.$ Then, $i{=}a_{7\star}10^3{+}a_8$
- j : Assume a_9 and a_{10} to be the codes of characters C_9 and $C_{10}.$ Then, $j{=}a_{9\ast}10^3{+}a_{10}$
- k : Assume a_{11} and a_{12} to be the codes of characters C_{11} and $C_{12}.$ Then, $k{=}a_{11^{\times}}10^3{_+}a_{12}$

Example) Assume that the pattern data title is "BOLT HOLE." The macro instruction is given as follows:

G65 H92 P<u>066079</u> Q<u>076084</u> R<u>032072</u> I<u>079076</u> J<u>069032;</u> BO LT □ H OL E

 Macro instruction specifying the variable name Variable name : $C_1 C_2 C_3 C_4 C_5 C_6 C_7 C_8 C_9 C_{10}$

 $C_{1, C_{2, ...,}} C_{10}$: Characters in the variable name (10 characters)

Macro instruction

G65 H93 $P_n Q_q R_r I_i J_j K_k$;

H93: Specifies the variable name

- n : Specifies the menu No. of the variable name
- q : Assume a_1 and a_2 to be the codes of characters C_1 and $C_2.$ Then, $q{=}a_1{{}_\times}10^3{+}a_2$
- r : Assume a_3 and a_4 to be the codes of characters C_3 and C_4 . Then, $r=a_3.10^3+a_4$
- i : Assume a_5 and a_6 to be the codes of characters C_5 and C_6 . Then, $i=a_{5},10^3+a_6$
- j : Assume a_7 and a_8 to be the codes of characters C_7 and C_8 . Then, $i=a_{7_x}10^3+a_8$
- k : Assume a_9 and a_{10} to be the codes of characters C_9 and C_{10} . Then, $k=a_{9},10^3a+a_{10}$

Example) Assume that the variable name of the variable No. 503 is "RADIUS." The macro instruction is given as follows:

G65 H93 P503 Q<u>082065</u> R<u>068073</u> I<u>085083</u> ; RA DI US

NOTE

Variable names can be assigned to 32 common variables #500 to #531, which are not cleared when the power is turned off.

Macro instruction to describe a comment

One comment line: C_1 C_2 C_3 C_4 C_5 C_6 C_7 C_8 C_9 C_{10} C_{11} C_{12} $C_{1, C_2, \cdots}$, C_{12} : Character string in one comment line (12 characters) Macro instruction

G65 H94 P_n Q_q R_r I_i J_j K_k;

H94: Specifies the comment

p : Assume a_1 and a_2 to be the codes of characters C_1 and $C_2. \ \,$ Then, $p{=}a_1{_{^{\times}}}10^3{+}a_2$

See 17.7 for character codes.

- q : Assume a_3 and a_4 to be the codes of characters C_3 and C_4 . Then, $q{=}a_3{\scriptscriptstyle \times}10^3{+}a_4$
- r : Assume a_5 and a_6 to be the codes of characters C_5 and C_6 . Then, $r=a_5,10^3+a_6$
- i : Assume a_7 and a_8 to be the codes of characters C_7 and $C_8. Then, \\ i=a_{7*}10^3+a_8$
- j : Assume a_9 and a_{10} to be the codes of characters C_9 and $C_{10}.$ Then, $_{j=a_{9\ast}10^3+a_{10}}$
- k : Assume a_{11} and a_{12} to be the codes of characters C_{11} and $C_{12.}$ Then, $k{=}a_{11^{\times}}10^3{+}a_{12}$

A comment can be displayed in up to eight lines. The comment consists of the first line to the eighth line in the programmed sequence of G65 H94 for each line.

Example) Assume that the comment is "BOLT HOLE." The macro instruction is given as follows:

G65 H94 P<u>042066</u> Q<u>079076</u> R<u>084032</u> I<u>072079</u> J<u>076069</u>; *B OL T— HO LE

Examples

Macro instruction to describe a parameter title , the variable name, and a comment.

```
00001 N00000
 VAR. : BOLT HOLE
      NAME DATA
                   COMMENT
  NO.
  500\,\mathtt{TOOL}
  501STANDARD X 0.000 *BOLT HOLE
  502STANDARD Y 0.000 CIRCLE*
  503RADIUS 0.000 SET PATTERN
  504S. ANGL 0.000 DATA TO VAR.
  505HOLES NO0.000 NO.500-505.
  506 0.000
  507 0.000
 ACTUAL POSITION (RELATIVE)
          0.000
                   Y
    Х
     Z
          0.000
MDI **** ***
                      16:05:59
 MACRO ] [ MENU ] [ OPR ] [
                                    ] [(OPRT)]
```

O9501:

N1G65 H92 P066 079 Q076 084 R032 072 I 079 076 J069 032 ; VAR: BOLT HOLE N2G65 H93 P500 Q084 079 R079076; #500 TOOL N3G65 H93 P501 Q075 073 R074 085 I078 032 J088 032; #501 KIJUN X N4G65 H93 P502 Q075 073 R074 085 I 078 032 J089 032 ; #502 KIJUN Y N5G65 H93 P503 Q082 065 R068 073 I 085 083 ; #503 RADIUS N6G65 H93 P504 Q083 046 R032 065 I 078 071 J 076 032; #504 S.ANGL N7G65 H93 P505 Q072 079 R076 069 I 083 032 J078 079 K046 032 ; #505 HOLES NO N8G65 H94: Comment N9G65 H94 P042 066 Q079 076 R084 032 I072 079 J076 069; *BOLT HOLE N10G65 H94 R032 067 I073 082 J067 076 K069 042; CIRCLE* N11G65 H94 P083 069 Q084 032 080 065 I084 084 J069 082 K078 032; SET PATTERN N12G65 H94 P068 065 Q084 065 R032 084 I079 032 J086 065 K082046 ; DATA NO VAR. N13G65 H94 P078 079 Q046 053 R048 048 I045 053 J048 053 K046 032; No.500-505 N14M99;

16.3
CHARACTERS AND
CODES TO BE USED
FOR THE PATTERN
DATA INPUT
FUNCTION

Table.16.3(a) Characters and codes to be used for the pattern data input function

Char- acter	Code	Comment	Char- acter	Code	Comment		
А	065		6	054			
В	066		7	055			
С	067		8	056			
D	068		9	057			
Е	069			032	Space		
F	070		!	033	Exclama- tion mark		
G	071		"	034	Quotation mark		
Н	072		#	035	Hash sign		
I	073		\$	036	Dollar sign		
J	074		%	037	Percent		
K	075		&	038	Ampersand		
L	076		,	039	Apostrophe		
M	077		(040	Left parenthesis		
N	078)	041	Right parenthesis		
0	079		*	042	Asterisk		
Р	080		+	043	Plus sign		
Q	081		,	044	Comma		
R	082		_	045	Minus sign		
S	083			046	Period		
Т	084		/	047	Slash		
U	085		:	058	Colon		
V	086		;	059	Semicolon		
W	087		<	060	Left angle bracket		
Х	088		=	061	Equal sign		
Y	089		>	062	Right angle bracket		
Z	090		?	063	Question mark		
0	048		@	064	HAt"mark		
1	049		[091	Left square bracket		
2	050		٨	092			
3	051		¥	093	Yen sign		
4	052]	094	Right squar bracket		
5	053			095	Underscore		

NOTE

Right and left parentheses cannot be used.

Table 16.3 (b)Numbers of subprograms employed in the pattern data input function

Subprogram No.	Function
O9500	Specifies character strings displayed on the pattern data menu.
O9501	Specifies a character string of the pattern data corresponding to pattern No.1
O9502	Specifies a character string of the pattern data corresponding to pattern No.2
O9503	Specifies a character string of the pattern data corresponding to pattern No.3
O9504	Specifies a character string of the pattern data corresponding to pattern No.4
O9505	Specifies a character string of the pattern data corresponding to pattern No.5
O9506	Specifies a character string of the pattern data corresponding to pattern No.6
O9507	Specifies a character string of the pattern data corresponding to pattern No.7
O9508	Specifies a character string of the pattern data corresponding to pattern No.8
O9509	Specifies a character string of the pattern data corresponding to pattern No.9
O9510	Specifies a character string of the pattern data corresponding to pattern No.10

Table. 16.3 (c)Macro instructions used in the pattern data input function

G code	H code	Function
G65	H90	Specifies the menu title.
G65	H91	Specifies the pattern name.
G65	H92	Specifies the pattern data title.
G65	G93	Specifies the variable name.
G65	H94	Specifies the comment.

Table. 16.3 (d)System variables employed in the pattern data input function

System variable	Function
#5900	Pattern No. selected by user.



PROGRAMMABLE PARAMETER ENTRY (G10)

General

The values of parameters can be entered in a lprogram. This function is used for setting pitch error compensation data when attachments are changed or the maximum cutting feedrate or cutting time constants are changed to meet changing machining conditions.

Format

Format G10L50; Parameter entry mode setting N_R_; For parameters other than the axis type N_P_R_; For axis type parameters G11; Parameter entry mode cancel

Meaning of command

N_: Parameter No. (4digids) or compensation position No. for pitch errors compensation +10,000 (5digid)

R_: Parameter setting value (Leading zeros can be omitted.)

P_: Axis No. 1 to 8 (Used for entering axis type parameters)

Explanations

- Parameter setting value (R_)
- Axis No.(P)

Do not use a decimal point in a value set in a parameter (R_). a decimal point cannot be used in a custom macro variable for R_either.

Specify an axis number (P_) from 1 to 8 (up to eight axes) for an axis type parameter. The control axes are numbered in the order in which they are displayed on the CNC display.

For example, specity P2 for the control axis which is displayed second.

WARNING

- 1 Do not fail to perform reference point return manually after changing the pitch error compensation data or backlash compensation data. Without this, the machine position can deviate from the correct position.
- 2 The canned-cycle mode must be cancelled before entering of parameters. When not cancelled, the drilling motion may be activated.

NOTE

Other NC statements cannot be specified while in parameter input mode.

Examples

1. Set bit 2 (SBP) of bit type parameter No. 3404

G10L50; Parameter entry mode

N3404 R 00000100; SBP setting

G11; cancel parameter entry mode

2. Change the values for the Z-axis (3rd axis) and A-axis (4th axis) in axis type parameter No. 1322 (the coordinates of stored stroke limit 2 in the positive direction for each axis).

G10L50; Parameter entry mode

N1322P3R4500; Modify Z axis **N1322P4R12000**; Modify A axis

G11; cancel parameter entry mode

18

MEMORY OPERATION USING FS10/11 TAPE FORMAT

General

Memory operation of the program registered by FS10/11 tape format is possible with setting of the setting parameter (No. 0001#1).

Explanations

Data formats for cutter compensation, subprogram calling, and canned cycles are different between this Series and Series 10/11. The Series 10/11 data formats can be processed for memory operation. Other data formats must comply with this Series. When a value out of the specified range for this Series is registered, an alarm occurs. Functions not available in this Series cannot be registered or used for memory operation.

 Address for the cutter compensation offset number Offset numbers are specified by address D in the Series 10/11. When an offset number is specified by address D, the modal value specified by address H is replaced with the offset number specified by address D.

Subprogram call

If a subprogram number of more than four digits is specified, the four low-order digits are regarded as the subprogram number. If no repeat count is specified, 1 is assumed.

Table 18 (a) Subprogram call data format

CNC	Data format				
Series 10/11	M98 POOO LOO; P: Subprogram number L: Repetition count				
Series 16/18/21	M98 POOO GOOD ; Repetition count Subprogram number				

 Address for the canned cycle repetition count The Series 10/11 and Series 16/18/21 use different addresses for the repeat count for canned cycles as listed in Table 18 (b).

Table 18 (b) Address for times of repetition of canned cycle


CNC	Address				
Series 10/11	L				
Series 16/18/21	К				

19

HIGH SPEED CUTTING FUNCTIONS

19.1 FEEDRATE CLAMPING BY ARC RADIUS

When an arc is cut at a high speed in circular interpolation, a radial error exists between the actual tool path and the programmed arc. An approximation of this error can be obtained from the following expression:



$$\Delta r = \frac{1}{2} (T_1^2 + T_2^2) \frac{v^2}{r}$$

∆r : Maximum radial error (mm)

v : Feedrate (mm/s) r : Arc radius (mm)

Γ₁: Time constant (s) for exponential acceleration/deceleration of

cutting feed

T₂ Time constant of the servo motor (s)

When actual machining is performed, radius r of the arc to be machined and permissible error Dr are given. Then, maximum allowable feedrate v (mm/min) is determined from the above expression.

The function for clamping the feedrate by the arc radius automatically clamps the feedrate of arc cutting to the value set in a parameter. This function is effective when the specified feedrate may cause the radial error for an arc with a programmed radius to exceed the permissible degree of error.

For details, refer to the relevant manual published by the machine tool builder.

19.2 LOOK-AHEAD CONTROL (G08)

This function is designed for high-speed precise machining. With this function, the delay due to acceleration/deceleration and the delay in the servo system which increase as the feedrate becomes higher can be suppressed.

The tool can then follow specified values accurately and errors in the machining profile can be reduced.

This function becomes effective when look-ahead control mode is entered.

For details, refer to the relevant manual published by the machine tool builder

Format

G08 P

P1: Turn on look-ahead control mode. P0: Turn off look-ahead control mode.

Explanations

Available functions

In look–ahead control mode, the following functions are available:

- (1) Linear acceleration/deceleration before interpolation
- (2) Automatic corner deceleration function

For details on the above functions, see the descriptions of the functions. Each function, specific parameters are provided.

Reset

Look-ahead control mode is canceled by reset.

Limitations

• G08 command

Specify G08 code only in a block.


Functions that cannot be specified

In the look-ahead control mode, the functions listed below cannot be specified. To specify these functions, cancel the look-ahead control mode, specify the desired function, then set look-ahead control mode again.

- · Rigid tapping function
- · Cs contour axis control function
- · Feed per rotation
- · Feed at address F with one digit
- · C-axis normal direction control function
- · Polar coordinate interpolation function
- · Cylindrical interpolation function
- · Involute interpolation function
- · Exponential interpolation
- · Three-dimensional coordinate conversion
- · Retrace function
- · Normal direction control
- · Polar coordinate command
- · Index table indexing
- · Tool withdrawal and return
- · Threading and synchronous feed
- · High-speed cycle machining
- · Handle interrupt
- · Program restart
- · Simplified synchronization control
- · Feed stop
- · High-speed skip function
- · Constant surface speed control
- · Interrupt type custom macro
- · Small-diameter peck drilling cycle
- · High-speed remote buffer A/B
- · Automatic tool length measurement
- · Skip cutting
- G28 (low–speed reference position return)

19.3 HIGH-SPEED REMOTE BUFFER

A remote buffer can continuously supply a large amount of data to the CNC at high speeds when connected to the host computer or input/output equipment via a serial interface.




When the remote buffer is connected online to the host computer, fast and reliable DNC operation is possible.

The remote buffer function includes high–speed remote buffer A and high–speed remote buffer B for high–speed machining. High–speed remote buffer A uses binary data. High–speed remote buffer B uses NC language. For details on remote buffer specifications, refer to the "Remote Buffer Supplement" (B–61802E–1).

19.3.1 High-speed remote buffer A (G05)

Specify G05 only in a block using normal NC command format. Then specify move data in the special format explained below. When zero is specified as the travel distance along all axes, normal NC command format can be used again for subsequent command specification.




Format

VBinary input operation enabled: G05;

VBinary input operation disabled: The travel distance along

all axes are set to zero.

VData format for binary input operation



In the data format for binary input operation, the travel distance along each axis (2 bytes) per unit time is specified. The travel distances along all axes are placed sequentially from the first axis, then a check byte is added. (The data length for one block is [2 x N + 1] bytes).

All data must be specified in binary.

Explanations

Selecting the unit time

The unit time (in ms) can be selected by setting bits 4, 5, and 6 of parameter IT0,IT1,IT2 No. 7501.

Travel distance data

The following unit is used for specifying the travel distance along each axis. (A negative travel distance is indicated in 2's complement.)

Increment system	IS-B	IS-C	Unit		
Millimeter machine	0.001	0.0001	mm		
Inch machine	0.0001	0.00001	inch		

The data format of the travel distance is as follows. The bits marked * are used to specify a travel distance per unit time.

15	14		. –			-	_	-	-	-	-	-		-	-
*	*	*	*	*	*	*	0	*	*	*	*	*	*	*	0

Example: When the travel distance is 700 μm per unit time (millimeter machine with increment system IS–B)

_			12		_	_	_		_						_	
0	0	0	0	1	0	1	0	0	1	1	1	1	0	0	0	

Check Byte

All bytes of the block except for the check byte ([2*N] bytes) are summed up, and any bits above 8th bit are discarded.

Transfer speed

The CNC reads $(2 \times N + 1)$ —byte data (where N is the number of axes) for every unit time that is set in the parameter. To allow the CNC to continue machining without interruption, the following minimum baud rate is required for data transfer between the host and remote buffer:

$$(2\times N+1) \times \frac{-11}{T} \times 1000 \text{ baud (T : Unit time)}$$

Cutter compensation

If G05 is specified in cutter compensation mode, the P/S 178 alarm is issued.

• Feed hold and interlock

Feed hold and interlock are effective.

Mirror image

The mirror image function (programmable mirror image and setting mirror image) cannot be turned on or off in the G05 mode.

Acceleration / deceleration type

In binary input operation mode, when tool movement starts and stops in cutting feed mode, exponential acceleration/deceleration is performed (the acceleration/deceleration time constant set in parameter No. 1622 is used).

Limitations

Modal command

In binary input operation mode, only linear interpolation as specified in the defined data format is executed (equivalent to the incremental command for linear interpolation).

Invalid functions

The single block, feedrate override, and maximum cutting feedrate clamp functions have no effect. The program restart, block restart, and high–speed machining functions cannot be used. In addition, miscellaneous functions cannot be executed in binary operation.

Memory registration

No data can be stored in memory.

19.3.2 High-speed remote buffer B (G05)

High–speed remote buffer A uses binary data. On the other hand, high–speed remote buffer B can directly use NC language coded with equipment such as an automatic programming unit to perform high–speed machining.

Format

G05P01; Start high-speed machining G05P00; End high-speed machining

Example: O1234;

G05P01; ← Start high–speed machining

X_Y_Z_;

G05P00 ; ← End high–speed machining

M02;

Explanations

Specified data

The following data can be specified during high–speed machining:

Address	Data				
X	Travel distance along the X-axis				
Y	Travel distance along the Y-axis				
Z	Travel distance along the Z-axis				
F	Cutting feedrate				

Data other than the above cannot be specified.

Number of controlled axes

Be sure to set 3 in parameter No. 7510 as the number of controlled axes.

Limitations

Incremental command

Move commands can be specified only in incremental mode.

 Functions that cannot be specified Cutter compensation B and C cannot be specified. The feedrate cannot be overridden.

Feedrate clamp

The maximum cutting feedrate clamp function is disabled.

• Binary data format

The format of high-speed remote buffer A can also be used for high-speed remote buffer B. This format, however, cannot be used together with NC language within the same program.

20

AXIS CONTROL FUNCTIONS

20.1 SIMPLE SYNCHRONOUS CONTROL

It is possible to change the operating mode for two or more specified axes to either synchronous operation or normal operation by an input signal from the machine.

Synchronous control can be performed for up to four pairs of axes with the Series 16, or up to three pairs with the Series 18, according to the parameter setting (parameter No. 8311).

The following operating modes are applicable to machines having two tables driven independently by separate control axes. The following example is of a machine with two tables driven independently by the Y axis and V axis. If the axis names and axis sets that are actually being used differ from those in the example, substitute the actual names for those below.




Fig. 20(a) Example of axis configuration of the machine operated by simple synchronous control

Explanations

Synchronous operation

This mode is used for, for example, machining large workpieces that extend over two tables.

While operating one axis with a move command, it is possible to synchronously move the other axis. In the synchronous mode, the axis to which the move command applies is called the master axis, and the axis that moves synchronously with the master axis is called the slave axis. In this example, it is assumed that Y axis is the master axis and V axis is the slave axis. Here, the Y axis and the V axis move synchronously in accordance with program command Yyyyy issued to the Y axis (master axis).

Synchronous operation here means that the move command for the master axis is issued simultaneously to both the servo motor for the master axis and that for the slave axis. In synchronous operation, the servo motor for the slave axis is not compensated for the deviation which is always detected between the two servo motors.

Deviation alarms are also not detected. Synchronous operation is possible during automatic operation, jog feed, manual handle feed using the manual pulse generator, and incremental feed, but is not possible during manual reference position return.

Normal operation

This operating mode is used for machining different workpieces on each table. The operation is the same as in ordinary CNC control, where the movement of the master axis and slave axis is controlled by the independent axis address (Y and V). It is possible to issue the move commands to both the master axis and slave axis in the same block.

- (1) The Y axis moves normally according to program command Yyyyy issued to the master axis.
- (2) The V axis moves normally according to program command Vvvvv issued to the slave axis.
- (3) The Y axis and the V axis move simultaneously according to program command YyyyyVvvvv.
 Both automatic and manual operations are the same as in ordinary CNC control.
- Switching between synchronous operation and normal operation

For how to switch between the synchronous operation and normal operation modes, refer to the relevant manual published by the machine tool builder.

 Automatic reference position return When the automatic reference position return command (G28) and the 2nd/3rd/4th reference position return command (G30) are issued during synchronous operation, the V axis follows the same movement as the Y axis returns to the reference position. If the V axis is positioned at the reference position after the return movement is complete, the reference position return complete signal of the V axis goes on when that of the Y axis goes on.

As a rule, commands G28 and G30 must be issued in the normal operating mode.

 Automatic reference position return check When the automatic reference position return check command (G27) is issued during synchronous operation, the V axis and Y axis move in tandem. If both the Y axis and the V axis have reached their respective reference positions after the movement is complete, the reference position return complete signals go on. If either axis is not at the reference position, an alarm is issued. As a rule, command G27 must be issued in the normal operating mode.

Specifying the slave axis

When a move command is issued to the slave axis during synchronous operation, a P/S alarm (No. 213) is issued.

Master axis and slave axis

The axis to be used as the master axis is set in parameter No. 8311. The slave axis is selected by an external signal.

 Displaying actual speed for master axis only Setting bit 7 (SMF) of parameter No. 3105 to 1 suppresses display of the actual speed of the slave axes.

Limitations

 Setting a coordinate system In synchronous axis control, commands that require no axis motion, such as the workpiece coordinate system setup command (G92) and the local coordinate system setup command (G52), are set to the Y axis by program command Yyyyy issued to the master axis.

 Externally-requested deceleration, interlock, and machine lock

For signals such as external deceleration, interlock, and machine lock, only the signals issued to the master axis are valid in the synchronous operating mode. Signals issued to other axes are ignored.

Pitch error compensation

Both the pitch error and backlash are compensated independently for the master axis and the slave axis.

Manual absolute

Turn on the manual absolute switch during synchronous operation. If it is off, the slave axis may not move correctly.

 Synchronization error check using positional deviation The difference between the master axis and slave axis in servo positional deviation is always monitored. If the difference exceeds the parameter–set limit, an P/S alarm (No. 213) is issued.

 Synchronization error check using machine coordinates The difference between the master axis and slave axis in machine coordinates is always monitored. If the difference exceeds the parameter—set limit, an P/S alarm (No. 407) is issued.

Synchronization

When the power is turned on, compensation pulses are output for the slave axis to match the machine position of the master axis with the machine position of the slave axis. (This is enabled only when the absolute position detection function is used.)

 Compensation for out-of-synchronism Compensation for out—of—synchronism (where the difference between the master and slave axes in servo positional deviation is always monitored and the servo motor for the slave axis is compensated to reduce the difference) is not performed.

 Manual reference position return When the machine is manually returned to the reference position during synchronous operation, both the master axis and the slave axis move synchronously until the acceleration movement is complete. However, grid detection thereafter is carried out independently.

20.2 ROTARY AXIS ROLL-OVER

Explanations


Examples

The roll-over function prevents coordinates for the rotation axis from overflowing. The roll-over function is enabled by setting bit 0 of parameter ROAx 1008 to 1.

For an incremental command, the tool moves the angle specified in the command. For an absolute command, the coordinates after the tool has moved are values set in parameter No. 1260, and rounded by the angle corresponding to one rotation. The tool moves in the direction in which the final coordinates are closest when bit 1 of parameter RABx No. 1008 is set to 0. Displayed values for relative coordinates are also rounded by the angle corresponding to one rotation when bit 2 of parameter RRLx No. 1008 is set to 1.

Assume that axis A is the rotating axis and that the amount of movement per rotation is 360.000 (parameter No. 1260 = 360000). When the following program is executed using the roll—over function of the rotating axis, the axis moves as shown below.

G90 A0 ;	Sequence number	Actual movement value	Absolute coordinate value after movement end
N1 G90 A-150.0 ;	N1	-150	210
N2 G90 A540.0 ;	N2	-30	180
N3 G90 A-620.0 ;	N3	-80	100
N4 G91 A380.0 ;	N4	+380	120
N5 G91 A-840.0 ;	N5	-840	0



NOTE

This function cannot be used together with the indexing function of the index table.

III. OPERATION



GENERAL

1.1 MANUAL OPERATION

Explanations

 Manual reference position return (See Section III–3.1) The CNC machine tool has a position used to determine the machine position.

This position is called the reference position, where the tool is replaced or the coordinate are set. Ordinarily, after the power is turned on, the tool is moved to the reference position.

Manual reference position return is to move the tool to the reference position using switches and pushbuttons located on the operator's panel.




Fig. 1.1 (a) Manual reference position return

The tool can be moved to the reference position also with program commands.

This operation is called automatic reference position return (See Section II–6).

The tool movement by manual operation

Using machine operator's panel switches, pushbuttons, or the manual handle, the tool can be moved along each axis.




Fig. 1.1 (b) The tool movement by manual operation

The tool can be moved in the following ways:

- (i) Jog feed (See Section III–3.2)
 The tool moves continuously while a pushbutton remains pressed.
- (ii) Incremental feed (See Section III–3.3)

 The tool moves by the predetermined distance each time a button is pressed.
- (iii) Manual handle feed (See Section III–3.4)
 By rotating the manual handle, the tool moves by the distance corresponding to the degree of handle rotation.

1.2 TOOL MOVEMENT BY PROGRAMMINGAUTOMATIC OPERATION

Automatic operation is to operate the machine according to the created program. It includes memory, MDI and DNC operations. (See Section III–4).




Fig.1.2 (a) Tool movement by programming

Explanations

Memory operation

After the program is once registered in memory of CNC, the machine can be run according to the program instructions. This operation is called memory operation.




Fig.1.2 (b) Memory operation

MDI operation

After the program is entered, as an command group, from the MDI keyboard, the machine can be run according to the program. This operation is called MDI operation.




Fig.1.2 (c) MDI operation

DNC operation

In this mode of operation, the program is not registered in the CNC memory. It is read from the external input/output devices instead. This is called DNC operation. This mode is useful when the program is too large to fit the CNC memory.

1.3 AUTOMATIC OPERATION

Explanations

• Program selection

Select the program used for the workpiece. Ordinarily, one program is prepared for one workpiece. If two or more programs are in memory, select the program to be used, by searching the program number (Section III–9.3).




Fig. 1.3 (a) Program selection for automatic operation

 Start and stop (See Section III-4) Pressing the cycle start pushbutton causes automatic operation to start. By pressing the feed hold or reset pushbutton, automatic operation pauses or stops. By specifying the program stop or program termination command in the program, the running will stop during automatic operation. When one process machining is completed, automatic operation stops.




Fig. 1.3 (b) Start and stop for automatic operation

 Handle interruption (See Section III-4.7) While automatic operation is being executed, tool movement can overlap automatic operation by rotating the manual handle.




Fig. 1.3 (c) Handle Interruption for automatic operation

1.4 TESTING A PROGRAM

Before machining is started, the automatic running check can be executed. It checks whether the created program can operate the machine as desired. This check can be accomplished by running the machine actually or viewing the position display change (without running the machine) (See Section III–5).

1.4.1 Check by Running the Machine

Explanations

Dry run (See Section III-5.4) Remove the workpiece, check only movement of the tool. Select the tool movement rate using the dial on the operator's panel.




Fig. 1.4 (a) Dry run

 Feedrate override (See Section III-5.2) Check the program by changing the feedrate specified in the program.




Fig. 1.4 (b) Feedrate override

Single block (See Section III-5.5)

When the cycle start pushbutton is pressed, the tool executes one operation then stops. By pressing the cycle start again, the tool executes the next operation then stops. The program is checked in this manner.




Fig. 1.4 (c) Single block

1.4.2 How to View the Position Display Change without Running the Machine

Explanations

 Machine lock (See Sections III-5.1)




Fig1.4 (d) Machine lock

 Auxiliary function lock (See Section III-5.1) When automatic running is placed into the auxiliary function lock mode during the machine lock mode, all auxiliary functions (spindle rotation, tool replacement, coolant on/off, etc.) are disabled.

1.5 EDITING A PART PROGRAM

After a created program is once registered in memory, it can be corrected or modified from the MDI panel (See Section III–9).

This operation can be executed using the part program storage/edit function.




Fig. 1.5 (a) Part program editing

1.6 DISPLAYING AND SETTING DATA

The operator can display or change a value stored in CNC internal memory by key operation on the MDI screen (See III–11).




Fig. 1.6 (a) Displaying and setting data

Explanations

Offset value




Fig.1.6 (b) Displaying and setting offset values

The tool has the tool dimension (length, diameter). When a workpiece is machined, the tool movement value depends on the tool dimensions. By setting tool dimension data in CNC memory beforehand, automatically generates tool routes that permit any tool to cut the workpiece specified by the program. Tool dimension data is called the offset value (See Section III–11.4.1).




Fig. 1.6 (c) Offset value

Displaying and setting operator's setting data

Apart from parameters, there is data that is set by the operator in operation. This data causes machine characteristics to change.

For example, the following data can be set:

- Inch/Metric switching
- Selection of I/O devices
- Mirror image cutting on/off

The above data is called setting data (See Section III–11.4.3).




Fig. 1.6 (d) Displaying and setting operator's setting data

Displaying and setting parameters

The CNC functions have versatility in order to take action in characteristics of various machines.

For example, CNC can specify the following:

- Rapid traverse rate of each axis
- Whether increment system is based on metric system or inch system.
- How to set command multiply/detect multiply (CMR/DMR)

Data to make the above specification is called parameters (See Section III–11.5.1).

Parameters differ depending on machine tool.




Fig. 1.6 (e) Displaying and setting parameters

Data protection key

A key called the data protection key can be defined. It is used to prevent part programs, offset values, parameters, and setting data from being registered, modified, or deleted erroneously (See Section III–11).





Fig. 1.6 (f) Data protection key

1.7 DISPLAY

1.7.1 Program Display


The contents of the currently active program are displayed. In addition, the programs scheduled next and the program list are displayed. (See Section III–11.2.1)



The cursor indicates the currently executed location

1.7.2 Current Position Display

The current position of the tool is displayed with the coordinate values. The distance from the current position to the target position can also be displayed. (See Section III–11.1.1 to 11.1.3)



```
ACTUAL POSITION (ABSOLUTE)

X 150.000
Y 300.000
Z 100.000

PART COUNT 30
RUN TIME 0H41M CYCLE TIME 0H 0M22S
MEM *** *** *** 19:47:45

[ABS] ( REL ) ( ALL ) ( (OPRT) )
```


1.7.3 Alarm Display

When a trouble occurs during operation, error code and alarm message are displayed on the screen. (See Section III–7.1)

See APPENDIX G for the list of error codes and their meanings.

1.7.4 Parts Count Display, Run Time Display

When this option is selected, two types of run time and number of parts are displayed on the screen. (See Section lll–11.4.5)



1.7.5 Graphic Display

Programmed tool movement can be displayed on the following planes: (See Section III–12)

- 1) XY plane
- 2) YZ plane
- 3) XZ plane
- 4) Three dimensional display




Fig. 1.7 (a) Graphic display

1.8 DATA INPUT / OUTPUT

Programs, offset values, parameters, etc. input in CNC memory can be output to paper tape, cassette, or a floppy disk for saving. After once output to a medium, the data can be input into CNC memory.




Fig. 1.8 (a) Data output

2

OPERATIONAL DEVICES


The available operational devices include the setting and display unit attached to the CNC, the machine operator's panel, and external input/output devices such as a tape reader, PPR, Handy File, Floppy Cassette, and FA Card.

2.1 SETTING AND DISPLAY UNITS


The setting and display units are shown in Subsections 2.1.1 to 2.1.6 of Part III.

CNC control unit with 7.2"/8.4" LCD	III-2.1.1
CNC control unit with 9.5"/10.4" LCD	III-2.1.2
Separate-type small MDI unit	III-2.1.3
Separate-type standard MDI unit (horizontal type)	III-2.1.4
Separate-type standard MDI unit (vertical type)	III-2.1.5
Separate-type standard MDI unit (vertical type)	
(for 210 <i>i</i>)	III-2.1.6


2.1.1 **CNC Control Unit with** 7.2"/8.4" LCD




2.1.2 **CNC Control Unit with** 9.5"/10.4" LCD




2.1.3 Separate-Type Small MDI Unit




2.1.4 Separate-Type **Standard MDI Unit** (Horizontal Type)



2.1.5 Separate-Type Standard MDI Unit (Vertical Type)



2.1.6 Separate-Type Standard MDI Unit (Vertical Type) (for 210*i*)



2.2 EXPLANATION OF THE KEYBOARD

Table 2.2 Explanation of the MDI keyboard

Number	Name	Explanation	
1	RESET key	Press this key to reset the CNC, to cancel an alarm, etc.	
2	HELP key	Press this button to use the help function when uncertain about the operation of an MDI key (help function).	
3	Soft keys	The soft keys have various functions, according to the Applications. The soft key functions are displayed at the bottom of the screen.	
4	Address and numeric keys N 4	Press these keys to input alphabetic, numeric, and other characters.	
5	SHIFT key	Some keys have two characters on their keytop. Pressing the <shift> key switches the characters. Special character \hat{E} is displayed on the screen when a character indicated at the bottom right corner on the keytop can be entered.</shift>	
6	INPUT key	When an address or a numerical key is pressed, the data is input to the buffer, and it is displayed on the screen. To copy the data in the key input buffer to the offset register, etc., press the key. This key is equivalent to the [INPUT] key of the soft keys, and either can be pressed to produce the same result.	
7	Cancel key	Press this key to delete the last character or symbol input to the key input buffer. When the key input buffer displays >N001X100Z_ and the cancel CAN key is pressed, Z is canceled and >N001X100_ is displayed.	
8	Program edit keys ALTER INSERT DELETE	Press these keys when editing the program. ALTER: : Alteration INSERT: : Insertion DELETE: : Deletion	
9	Function keys POS PROG	Press theses keys to switch display screens for each function. See III – 2.3 for detailas of the function keys.	


Table 2.2 Explanation of the MDI keyboard

Number	Name	Explanation	
10	Cursor move keys	There are four different cursor move keys.	
		: This key is used to move the cursor to the right or in the forward direction. The cursor is moved in short units in the forward direction.	
		: This key is used to move the cursor to the left or in the reverse direction. The cursor is moved in short units in the reverse direction.	
		: This key is used to move the cursor in a downward or forward direction. The cursor is moved in large units in the forward direction.	
		: This key is used to move the cursor in an upward or reverse direction.	
		The cursor is moved in large units in the reverse direction.	
11	Page change keys	Two kinds of page change keys are described below.	
	PAGE	: This key is used to changeover the page on the screen in the forward direction.	
	PAGE	: This key is used to changeover the page on the screen in the reverse direction.	

2.3 FUNCTION KEYS AND SOFT KEYS

The function keys are used to select the type of screen (function) to be displayed. When a soft key (section select soft key) is pressed immediately after a function key, the screen (section) corresponding to the selected function can be selected.

2.3.1 General Screen Operations



- 1 Press a function key on the MDI panel. The chapter selection soft keys that belong to the selected function appear.
- 2 Press one of the chapter selection soft keys. The screen for the selected chapter appears. If the soft key for a target chapter is not displayed, press the continuous menu key (next-menu key). In some cases, additional chapters can be selected within a chapter.
- 3 When the target chapter screen is displayed, press the operation selection key to display data to be manipulated.
- **4** To redisplay the chapter selection soft keys, press the return menu key.

The general screen display procedure is explained above. However, the actual display procedure varies from one screen to another. For details, see the description of individual operations.

сиѕтом

2.3.2 Function Keys	Function keys are provided to select the type of screen to be displayed. The following function keys are provided on the MDI panel:
POS	Press this key to display the position screen .
PROG	Press this key to display the program screen .
OFFSET SETTING	Press this key to display the offset/setting screen .
SYSTEM	Press this key to display the system screen .
MESSAGE	Press this key to display the message screen .
GRAPH	Press this key to display the graphics screen .

Press this key to display the ${f custom}$ screen (conversational macro screen).


2.3.3 Soft Keys


To display a more detailed screen, press a function key followed by a soft key. Soft keys are also used for actual operations.


The following illustrates how soft key displays are changed by pressing each function key.


The symbols in the following figures mean as shown below:		
	: Indicates screens	
	: Indicates a screen that can be displayed by pressing a function key(*1)	
[]	: Indicates a soft key(*2)	
()	: Indicates input from the MDI panel.	
[_]	: Indicates a soft key displayed in green.	
	: Indicates the continuous menu key (rightmost soft key)(*3).	


- *1 Press function keys to switch between screens that are used frequently.
- *2 Some soft keys are not displayed depending on the option configuration.
- *3 In some cases, the continuous menu key is omitted when the 12 soft keys display unit is used.















































2.3.4 Key Input and Input Buffer

When an address and a numerical key are pressed, the character corresponding to that key is input once into the key input buffer. The contents of the key input buffer is displayed at the bottom of the screen. In order to indicate that it is key input data, a ">" symbol is displayed immediately in front of it. A "_" is displayed at the end of the key input data indicating the input position of the next character.




Fig. 2.3.4 Key input buffer display

To input the lower character of the keys that have two characters inscribed on them, first press the SHIFT key and then the key in question.

When the SHIFT key is pressed, "_" indicating the next character input position changes to "~". Now lowercase characters can be entered (shift state).

When a character is input in shift status the shift status is canceled. Furthermore, if the shift status is pressed in shift status, the shift status is canceled.

It is possible to input up to 32 characters at a time in the key input buffer. Press the CAN key to cancel a character or symbol input in the key input buffer.

(Example)

When the key input buffer displays $> \! N001X100Z_{-}$ and the cancel CAN key is pressed, Z is canceled and $> \! N001X100_{-}$ is displayed.

2.3.5 **Warning Messages**

After a character or number has been input from the MDI panel, a data check is executed when NPUT key or a soft key is pressed. In the case of incorrect input data or the wrong operation a flashing warning message will be displayed on the status display line.



Fig. 2.3.5 Warning message display

Table 2.3.5 Warning Messages

Warning message	Content	
FORMAT ERROR	The format is incorrect.	
WRITE PROTECT	Key input is invalid because of data protect key or the parameter is not write enabled.	
DATA IS OUT OF RANGE	The input value exceeds the permitted range.	
TOO MANY DIGITS	The input value exceeds the permitted number of digits.	
WRONG MODE	Parameter input is not possible in any mode other than MDI mode.	
EDIT REJECTED	It is not possible to edit in the current CNC status.	

2.3.6 Soft Key Configuration

There are 12 soft keys in the 10.4"LCD/MDI or 9.5"LCD/MDI. As illustrated below, the 5 soft keys on the right and those on the right and left edges operate in the same way as the 7.2"LCD or 8.4" LCD, whereas the 5 keys on the left hand side are expansion keys dedicated to the 10.4"LCD or 9.5"LCD.




Fig. 2.3.6 (a) LCD soft key configuration

Whenever a position display appears in the left half of the screen after a function key other than pos is pressed, the soft keys on the left half of the soft key display area are displayed as follows:



The soft key corresponding to the position display is indicated in reverse video.

This manual may refer to 10.4" and 9.5" LCD display units as 12 soft key types, and 7.2" and 8.4" LCD display units as 7 soft key types.

2.4 EXTERNAL I/O DEVICES

Five types of external input/output devices are available. This section outlines each device. For details on these devices, refer to the corresponding manuals listed below.

Table 2.4 (a) External I/O device

Device name	Usage	Max. storage capacity	Reference manual
FANUC Handy File	Easy-to-use, multi function input/output device. It is designed for FA equipment and uses floppy disks.	3600m	B-61834E
FANUC Floppy Cassette	Input/output device. Uses floppy disks.	2500m	B-66040E
FANUC FA Card	Compact input/output device. Uses FA cards.	160m	B-61274E
FANUC PPR	Input/output device consisting of a paper tape reader, tape punch, and printer.	275m	B-58584E
Portable Tape Reader	Input device for reading paper tape.		Appendix H


The following data can be input/output to or from external input/output devices:

- 1. Programs
- 2. Offset data
- 3. Parameters
- 4. Custom macro common variables

For how data is input and output, see III-8.

Parameter

Before an external input/output device can be used, parameters must be set as follows.




CNC has three channels of reader/punch interfaces. The input/output device to be used is specified by setting the channel connected to that device in setting parameter I/O CHANNEL.

The specified data, such as a baud rate and the number of stop bits, of an input/output device connected to a specific channel must be set in parameters for that channel in advance.

For channel 1, two combinations of parameters to specify the input/output device data are provided.

The following shows the interrelation between the reader/punch interface parameters for the channels.




2.4.1 FANUC Handy File

The Handy File is an easy-to-use, multi function floppy disk input/output device designed for FA equipment. By operating the Handy File directly or remotely from a unit connected to the Handy File, programs can be transferred and edited.


The Handy File uses 3.5—inch floppy disks, which do not have the problems of paper tape (i.e., noisy during input/output, easily broken, and bulky).

One or more programs (up to 1.44M bytes, which is equivalent to the memory capacity of 3600–m paper tape) can be stored on one floppy disk.



2.4.2 FANUC Floppy Cassette


When the Floppy Cassette is connected to the CNC, machining programs stored in the CNC can be saved on a Floppy Cassette, and machining programs saved in the Floppy Cassette can be transferred to the CNC.



2.4.3 FANUC FA Card

An FA Card is a memory card used as an input medium in the FA field. It is compact, but has a large memory capacity with high reliability, and requires no special maintenance.


When an FA Card is connected to the CNC via the card adapter, machining programs stored in the CNC can be transferred to and saved in an FA Card. Machining programs stored on an FA Card can also be transferred to the CNC.



2.4.4 FANUC PPR


The FANUC PPR consists of three units: A printer, paper tape punch, and paper tape reader.

When the PPR is used alone, data can be read from the tape reader and printed or punched out. It is also possible to perform TH and TV checks on data that was read.



2.4.5 Portable Tape Reader

The portable tape reader is used to input data from paper tape.



2.5 POWER ON/OFF

2.5.1

Turning on the Power

Procedure of turning on the power

Procedure

- 1 Check that the appearance of the CNC machine tool is normal. (For example, check that front door and rear door are closed.)
- **2** Turn on the power according to the manual issued by the machine tool builder.
- **3** After the power is turned on, check that the position screen is displayed. An alarm screen is displayed if an alarm occurs upon power–on. If the screen shown in Section III–2.5.2 is displayed, a system failure may have occurred.

ACTUAL POSITION(ABSOLUTE) O1000 N00010 123.456 X 363.233 0.000 PART COUNT RUN TIME 0H15M CYCLE TIME 0H 0M38S 3000 MM/M ACT.F S 0 T0000 MEM STRT MTN *** 09:06:35 [ABS] [REL] [ALL] [HNDL] [OPRT]

4 Check that the fan motor is rotating.

WARNING


Until the positional or alarm screen is displayed at the power on, do not touch them. Some keys are used for the maintenance or special operation purpose. When they are pressed, unexpected operation may be caused.

2.5.2 Screen Displayed at Power-on

If a hardware failure or installation error occurs, the system displays one of the following three types of screens then stops.


Information such as the type of printed circuit board installed in each slot is indicated. This information and the LED states are useful for failure recovery.

Slot status display




For more information about the types of printed circuit boards and module functions, refer to the MAINTENANCE MANUAL (B–63085EN).

Screen indicating module setting status



Display of software configuration



The software configuration can be displayed on the system configuration screen also.

Refer to the MAINTENANCE MANUAL (B–63085EN) for the system configuration screen.

2.5.3 Power Disconnection

Power Disconnection

Procedure

- 1 Check that the LED indicating the cycle start is off on the operator's panel.
- 2 Check that all movable parts of the CNC machine tool is stopping.
- 3 If an external input/output device such as the Handy File is connected to the CNC, turn off the external input/output device.
- 4 Continue to press the POWER OFF pushbutton for about 5 seconds.
- 5 Refer to the machine tool builder's manual for turning off the power to the machine.

3

MANUAL OPERATION

MANUAL OPERATION are six kinds as follows:

- 3.1 Manual reference position return
- 3.2 Jog feed
- 3.3 Incremental feed
- 3.4 Manual handle feed
- 3.5 Manual absolute on/off


3.1 MANUAL REFERENCE POSITION RETURN

The tool is returned to the reference position as follows:


The tool is moved in the direction specified in parameter ZMI (bit 5 of No. 1006) for each axis with the reference position return switch on the machine operator's panel. The tool moves to the deceleration point at the rapid traverse rate, then moves to the reference position at the FL speed. The rapid traverse rate and FL speed are specified in parameters (No. 1420,1421, and 1425).

Fourstep rapid traverse override is effective during rapid traverse.

When the tool has returned to the reference position, the reference position return completion LED goes on. The tool generally moves along only a single axis, but can move along three axes simultane ously when specified so in parameter JAX(bit 0 of No.1002).



Procedure for Manual Reference Position Return



Procedure 1

- 1 Press the reference position return switch, one of the mode selection switches.
- 2 To decerease the feedrate, press a rapid traverse override switch. When the tool has returned to the reference position, the reference position return completion LED goes on.
- 3 Press the feed axis and direction selection switch corresponding to the axis and direction for reference position return. Continue pressing the switch until the tool returns to the reference position. The tool can be moved along three axes simultaneously when specified so in an appropriate parameter setting. The tool moves to the deceleration point at the rapid traverse rate, then moves to the reference position at the FL speed set in a parameter.
- 4 Perform the same operations for other axes, if necessary.

 The above is an example. Refer to the appropriate manual provided by the machine tool builder for the actual operations.

ZERO POSITION MIRRROR IMAGE									
Х	Υ	Z	С	X2	Y2	Z2	X	Υ	Z
PRO- GRAM STOP	M02/ M30	MANU ABS	SPINDLE ORI	TAP	ATC READY				MC?

Explanations

Automatically setting the coordinate system

Bit 0 (ZPR) of parameter No. 1201 is used for automatically setting the coordinate system. When ZPR is set, the coordinate system is automatically determined when manual reference position return is performed.

When α , β and γ are set in parameter 1250, the workpiece coordinate system is determined so that reference point on the tool holder or the position of the tip of the reference tool is $X=\alpha$, $Y=\beta$, $Z=\gamma$ when reference position return is performed. This has the same effect as specifying the following command for reference position return:

G92X $\underline{\alpha}$ Y $\underline{\beta}$ Z $\underline{\gamma}$;

However, when options of the workpiece coordinate system is selected, it is not able to use.

Restrictions

Moving the tool again

Once the REFERENCE POSITION RETURN COMPLETION LED lights at the completion of reference position return, the tool does not move unless the REFERENCE POSITION RETURN switch is turned off.


Reference position return completion LED

The REFERENCE POSITION RETURN COMPLETION LED is extinguished by either of the following operations:

- Moving from the reference position.
- Entering an emergency stop state.
- The distance to return to reference position

For the distance (Not in the deceleration condition) to return the tool to the reference position, refer to the manual issued by the machine tool builder.

3.2 JOG FEED




In the jog mode, pressing a feed axis and direction selection switch on the machine operator's panel continuously moves the tool along the selected axis in the selected direction.

The jog feedrate is specified in a parameter (No.1423)

The jog feedrate can be adjusted with the jog feedrate override dial.

Pressing the rapid traverse switch moves the tool at the rapid traverse feedrate (No. 1424) regardless of the postiotion of the jog feedrate override dial. This function is called the manual rapid traverse.

Manual operation is allowed for one axis at a time. 3 axes can be selected at a time by parameter JAX (No.1002#0).




Procedure for JOG feed




Procedure

- 1 Press the jog switch, one of the mode selection switches.
- 2 Press the feed axis and direction selection switch corresponding to the axis and direction the tool is to be moved. While the switch is pressed, the tool moves at the feedrate specified in a parameter (No. 1423). The tool stops when the switch is released.
- 3 The jog feedrate can be adjusted with the jog feedrate override dial.
- 4 Pressing the rapid traverse switch while pressing a feed axis and direction selection switch moves the tool at the rapid traverse rate while the rapid traverse switch is pressed. Rapid traverse override by the rapid traverse override switches is effective during rapid traverse.

The above is an example. Refer to the appropriate manual provided by the machine tool builder for the actual operations.



JOG FEED RATE OVERRIDE



Limitations

 Acceleration/decelera – tion for rapid traverse Feedrate, time constant and method of automatic acceleration/ deceleration for manual rapid traverse are the same as G00 in programmed command.

• Change of modes


Changing the mode to the jog mode while pressing a feed axis and direction selection switch does not enable jog feed. To enable jog feed, enter the jog mode first, then press a feed axis and direction selection switch.

 Rapid traverse prior to reference position return If reference position return is not performed after power—on, pushing RAPID TRAVERSE button does not actuate the rapid traverse but the remains at the JOG feedrate. This function can be disabled by setting parameter RPD (No.1401#01).


3.3 INCREMENTAL FEED


In the incremental (INC) mode, pressing a feed axis and direction selection switch on the machine operator's panel moves the tool one step along the selected axis in the selected direction. The minimum distance the tool is moved is the least input increment. Each step can be 10, 100, or 1000 times the least input increment.

This mode is effective when a manual pulse generator is not connected.



Procedure for Incremental Feed






- 1 Press the INC switch, one of the mode selection switches.
- 2 Select the distance to be moved for each step with the magnification dial.
- 3 Press the feed axis and direction selection switch corresponding to the axis and direction the tool is to be moved. Each time a switch is pressed, the tool moves one step. The feedrate is the same as the jog feedrate.
- 4 Pressing the rapid traverse switch while pressing a feed axis and direction selection switch moves the tool at the rapid traverse rate. Rapid traverse override by the rapid traverse override switch is effective during rapid traverse.

The above is an example. Refer to the appropriate manual provided by the machine tool builder for the actual operations.


3.4 MANUAL HANDLE FEED


In the handle mode, the tool can be minutely moved by rotating the manual pulse generator on the machine operator's panel. Select the axis along which the tool is to be moved with the handle feed axis selection switches.

The minimum distance the tool is moved when the manual pulse generator is rotated by one graduation is equal to the least input increment. Or the distance the tool is moved when the manual pulse generator is rotated by one graduation can be magnified by 10 times or by one of the two magnifications specified by parameters (No. 7113 and 7114).



Procedure for Manual Handle Feed





- 1 Press the HANDLE switch, one of the mode selection switches.
- 2 Select the axis along which the tool is to be moved by pressing a handle feed axis selection switch.
- 3 Select the magnification for the distance the tool is to be moved by pressing a handle feed magnification switch. The minimum distance the tool is moved when the manual pulse generator is rotated by one graduation is equal to the least input increment.
- 4 Move the tool along the selected axis by rotating the handle. Rotating the handle 360 degrees moves the tool the distance equivalent to 100 graduations.

The above is an example. Refer to the appropriate manual provided by the machine tool builder for the actual operations.

Explanations

 Availability of manual pulse generator in Jog mode (JHD) Parameter JHD (bit 0 of No. 7100) enables or disables the manual handle feed in the JOG mode.

When the parameter JHD(bit 0 of No. 7100) is set 1,both manual handle feed and incremental feed are enabled.

 Availability of manual pulse generator in TEACH IN JOG mode (THD) Parameter THD (bit 1 of No. 7100) enables or disables the manual handle feed in the TEACH IN JOG mode.

 A command to the MPG exceeding rapid traverse rate (HPF) Parameter HPF (No. 7117) specifies as follows:

• Parameter HPF (No. 7117) (It is available when parameter HPF is 0.)

Set value 0: The feedrate is clamped at the rapid traverse rate and

generated pulses exceeding the rapid traverse rate are ignored. (The distance the tool is moved may not match the graduations on the manual pulse generator.)

Other than 0:

The feedrate is clamped at the rapid traverse rate and generated pulses exceeding the rapid traverse rate are not ignored but accumulated in the CNC until the limit specified in parameter No. 7117 is reached.

(No longer rotating the handle does not immediately stop the tool. The tool is moved by the pulses accumulated

in the CNC before it stops.)

 Movement direction of an axis to the rotation of MPG (HNG_X) Parameter HNGx (No. 7102 #0) switches the direction of MPG in which the tool moves along an axis, corresponding to the direction in which the handle of the manual pulse generator is rotated.

Restrictions

Number of MPGs

Up to three manual pulse generators can be connected, one for each axis. The three manual pulse generators can be simultaneously operated.

WARNING

Rotating the handle quickly with a large magnification such as x100 moves the tool too fast. The feedrate is clamped at the rapid traverse feedrate.

NOTE

Rotate the manual pulse generator at a rate of five rotations per second or lower. If the manual pulse generator is rotated at a rate higher than five rotations per second, the tool may not stop immediately after the handle is no longer rotated or the distance the tool moves may not match the graduations on the manual pulse generator.

3.5 MANUAL ABSOLUTE ON AND OFF

Whether the distance the tool is moved by manual operation is added to the coordinates can be selected by turning the manual absolute switch on or off on the machine operator's panel. When the switch is turned on, the distance the tool is moved by manual operation is added to the coordinates. When the switch is turned off, the distance the tool is moved by manual operation is not added to the coordinates.




Fig. 3.5(a) Coordinates with the switch ON




Fig. 3.5(b) Coordinates with the switch OFF

Explanation


The following describes the relation between manual operation and coordinates when the manual absolute switch is turned on or off, using a program example.


The subsequent figures use the following notation:

Movement of the tool when the switch is on Movement of the tool when the switch is off


The coordinates after manual operation include the distance the tool is moved by the manual operation. When the switch is off, therefore, subtract the distance the tool is moved by the manual operation.

 Manual operation after the end of block Coordinates when block $\boxed{2}$ has been executed after manual operation (X-axis +20.0, Y-axis +100.0) at the end of movement of block.




 Manual operation after a feed hold 

 When reset after a manual operation following a feed hold



 When a movement command in the next block is only one axis When there is only one axis in the following command, only the commanded axis returns.




- When the next move block is an incremental
- Manual operation during cutter compensation

When the following commands are incremental commands, operation is the same as when the switch is OFF.

When the switch is OFF

After manual operation is performed with the switch OFF during cutter compensation, automatic operation is restarted then the tool moves parallel to the movement that would have been performed if manual movement had not been performed. The amount of separation equals to the amount that was performed manually.




When the switch is ON during cutter compensation

Operation of the machine upon return to automatic operation after manual intervention with the switch is ON during execution with an absolute command program in the cutter compensation mode will be described. The vector created from the remaining part of the current block and the beginning of the next block is shifted in parallel. A new vector is created based on the next block, the block following the next block and the amount of manual movement. This also applies when manual operation is performed during cornering.


Manual operation performed in other than cornering

Assume that the feed hold was applied at point P_H while moving from P_A to P_B of programmed path P_A , P_B , and P_C and that the tool was manually moved to $P_{H'}$. The block end point P_B moves to the point $P_{B'}$ by the amount of manual movement, and vectors V_{B1} and V_{B2} at P_B also move to $V_{B1'}$ and $V_{B2'}$. Vectors V_{C1} and V_{C2} between the next two blocks $P_B - P_C$ and $P_C - P_D$ are discarded and new vectors $V_{C1'}$ and $V_{C2'}$ ($V_{C2'} = V_{C2}$ in this example) are produced from the relation between $P_{B'} - P_C$ and $P_C - P_D$. However, since $V_{B2'}$ is not a newly calculated vector, correct offset is not performed at block $P_{B'} - P_C$. Offset is correctly performed after P_C .



Manual operation during cornering


This is an example when manual operation is performed during cornering. $V_{A2'}$, $V_{B1'}$, and $V_{B2'}$ are vectors moved in parallel with V_{A2} , V_{B1} and V_{B2} by the amount of manual movement. The new vectors are calculated from V_{C1} and V_{C2} . Then correct cutter compensation is performed for the blocks following Pc.



Manual operation after single block stop

Manual operation was performed when execution of a block was terminated by single block stop.

Vectors V_{B1} and V_{B2} are shifted by the amount of manual operation. Sub–sequent processing is the same as case a described above. An MDI operation can also be interveneted as well as manual operation. The movement is the same as that by manual operation.





AUTOMATIC OPERATION

Programmed operation of a CNC machine tool is referred to as automatic operation.

This chapter explains the following types of automatic operation:

• MEMORY OPERATION

Operation by executing a program registered in CNC memory

• MDI OPERATION

Operation by executing a program entered from the MDI panel

DNC operation

Operation while reading a program from an input/output device

• PROGRAM RESTART

Restarting a program for automatic operation from an intermediate point

SCHEDULING FUNCTION

Scheduled operation by executing programs (files) registered in an external input/output device (Handy File, Floppy Cassette, or FA Card)

• SUBPROGRAM CALL FUNCTION

Function for calling and executing subprograms (files) registered in an external input/output device (Handy File, Floppy Cassette, or FA Card) during memory operation

• MANUAL HANDLE INTERRUPTION

Function for performing manual feed during movement executed by automatic operation

MIRROR IMAGE

Function for enabling mirror—image movement along an axis during automatic operation

• MANUAL INTERVENTION AND RETURN

Function restarting automatic operation by returning the tool to the position where manual intervention was started during automatic operation

4.1 MEMORY OPERATION

Programs are registered in memory in advance. When one of these programs is selected and the cycle start switch on the machine operator's panel is pressed, automatic operation starts, and the cycle start LED goes on.

When the feed hold switch on the machine operator's panel is pressed during automatic operation, automatic operation is stopped temporarily. When the cycle start switch is pressed again, automatic operation is restarted.

When the RESET key on the MDI panel is pressed, automatic operation terminates and the reset state is entered.

For the two-path control, the programs for the two tool posts can be executed simultaneously so the two tool posts can operate independently at the same time.

The following procedure is given as an example. For actual operation, refer to the manual supplied by the machine tool builder.

Procedure for Memory Operation

Procedure

- 1 Press the **MEMORY** mode selection switch.
- 2 Select a program from the registered programs. To do this, follow the steps below.
 - **2–1** Press \bigcap rod isplay the program screen.
 - 2–2 Press address O
 - **2–3** Enter a program number using the numeric keys.
 - **2–4** Press the **[O SRH]** soft key.
- 3 For the two-path control, select the tool post to be operated with the tool post selection switch on the machine operator's panel.
- 4 Press the cycle start switch on the machine operator's panel. Automatic operation starts, and the cycle start LED goes on. When automatic operation terminates, the cycle start LED goes off.
- 5 To stop or cancel memory operation midway through, follow the steps below.
 - a. Stopping memory operation

Press the feed hold switch on the machine operator's panel. The feed hold LED goes on and the cycle start LED goes off. The machine responds as follows:

- (i) When the machine was moving, feed operation decelerates and stops.
- (ii) When dwell was being performed, dwell is stopped.
- (iii) When M, S, or T was being executed, the operation is stopped after M. S. or T is finished.

When the cycle start switch on the machine operator's panel is pressed while the feed hold LED is on, machine operation restarts.

b. Terminating memory operation

Press the RESET key on the MDI panel.

Automatic operation is terminated and the reset state is entered. When a reset is applied during movement, movement decelerates then stops.

Explanation

Memory operation

After memory operation is started, the following are executed:

- (1) A one–block command is read from the specified program.
- (2) The block command is decoded.
- (3) The command execution is started.
- (4) The command in the next block is read.
- (5) Buffering is executed. That is, the command is decoded to allow immediate execution.
- (6) Immediately after the preceding block is executed, execution of the next block can be started. This is because buffering has been executed.
- (7) Hereafter, memory operation can be executed by repeating the steps (4) to.(6)

Stopping and terminating memory operation

Memory operation can be stopped using one of two methods: Specify a stop command, or press a key on the machine operator's panel.

- The stop commands include M00 (program stop), M01 (optional stop), and M02 and M30 (program end).
- There are two keys to stop memory operation: The feed hold key and reset key.

Program stop (M00)

Memory operation is stopped after a block containing M00 is executed. When the program is stopped, all existing modal information remains unchanged as in single block operation. The memory operation can be restarted by pressing the cycle start button. Operation may vary depending on the machine tool builder. Refer to the manual supplied by the machine tool builder.

Optional stop (M01)

Similarly to M00, memory operation is stopped after a block containing M01 is executed. This code is only effective when the Optional Stop switch on the machine operator's panel is set to ON. Operation may vary depending on the machine tool builder. Refer to the manual supplied by the machine tool builder.

Program end (M02, M30) When M02 or M30 (specified at the end of the main program) is read, memory operation is terminated and the reset state is entered.

In some machines, M30 returns control to the top of the program. For details, refer to the manual supplied by the machine tool builder.

Feed hold

When Feed Hold button on the operator's panel is pressed during memory operation, the tool decelerates to a stop at a time.

Reset

Automatic operation can be stopped and the system can be made to the reset state by using $\begin{bmatrix} \text{RESET} \end{bmatrix}$ key on the MDI panel or external reset signal.

When reset operation is applied to the system during a tool moving status, the motion is slowed down then stops.

Optional block skip

When the optional block skip switch on the machine operator's panel is turned on, blocks containing a slash (/) are ignored.

 Cycle start for the two-path control For the two-path control, a cycle start switch is provided for each tool post. This allows the operator to activate a single tool posts to operate them at the same time in memory operation or MDI operation. In general, select the tool post to be operated with the tool post selection switch on the machine operator's panel and then press the cycle start button to activate the selected tool post. (The procedure may vary with the machine tool builder.)

Calling a subprogram stored in an external input/output device

A file (subprogram) in an external input/output device such as a Floppy Cassette can be called and executed during memory operation. For details, see Section 4.6.

4.2 MDI OPERATION

In the **MDI** mode, a program consisting of up to 10 lines can be created in the same format as normal programs and executed from the MDI panel. MDI operation is used for simple test operations.

The following procedure is given as an example. For actual operation, refer to the manual supplied by the machine tool builder.

Procedure for MDI Operation

Procedure

- 1 Press the **MDI** mode selection switch. For the two–path control, select the tool post for which a program is to be created with the tool post selection switch. Create a separate program for each tool post.
- 2 Press the PROG function key on the MDI panel to select the program screen. The following screen appears:

```
PROGRAM (MDI)
                             0010
                                  00002
O0000;
G00 G90 G94 G40 G80 G50 G54
    G22
        G21
            G49
                 G98 G67
                         G64
      ΗМ
      S
 MDI
                        20:40:05
 PRGRM
          MDI
               CURRNT | NEXT | (OPRT)
```

Program number O0000 is entered automatically.

- 3 Prepare a program to be executed by an operation similar to normal program editing. M99 specified in the last block can return control to the beginning of the program after operation ends. Word insertion, modification, deletion, word search, address search, and program search are available for programs created in the MDI mode. For program editing, see III–9.
- **4** To entirely erase a program created in MDI mode, use one of the following methods:
 - **a.** Enter address \bigcirc , then press the \bigcirc key on the MDI panel.
 - **b.** Alternatively, press the RESET key. In this case, set bit 7 of parameter MCL No. 3203 to 1 in advance.

5 To execute a program, set the cursor on the head of the program. (Start from an intermediate point is possible.) Push Cycle Start button on the operator's panel. By this action, the prepared program will start. (For the two–path control, select the tool post to be operated with the tool post selection switch on the machine operator's panel beforehand.) When the program end (M02, M30) or ER(%) is executed, the prepared program will be automatically erased and the operation will end.

By command of M99, control returns to the head of the prepared program.

```
O0001 N00003
PROGRAM (MDI)
00000 G00 X100.0 Y200.;
M03
G01 Z120.0 F500;
M93 P9010;
G00 Z0.0;
G00
     G90 G94 G40 G80
                       G50 G54
                                G69
    G22 G21
              G49 G98
                       G67
                           G64
                                G15
     в нм
        D
      S
  F
MDI
          MDI CURRNT NEXT
```

- **6** To stop or terminate MDI operation in midway through, follow the steps below.
 - a. Stopping MDI operation

Press the feed hold switch on the machine operator's panel. The feed hold LED goes on and the cycle start LED goes off. The machine responds as follows:

- (i) When the machine was moving, feed operation decelerates and stops.
- (ii) When dwell was being performed, dwell is stopped.
- (iii) When M, S, or T was being executed, the operation is stopped after M, S, or T is finished.

When the cycle start switch on the machine operator's panel is pressed, machine operation restarts.

b. Terminating MDI operation

Press the RESET key on the MDI panel.

Automatic operation is terminated and the reset state is entered. When a reset is applied during movement, movement decelerates then stops.

Explanation

The previous explanation of how to execute and stop memory operation also applies to MDI operation, except that in MDI operation, M30 does not return control to the beginning of the program (M99 performs this function).

Erasing the program

Programs prepared in the **MDI** mode will be erased in the following cases:

- In MDI operation, if M02, M30 or ER(%) is executed. (If bit 6 (MER) of parameter No. 3203 is set to 1, however, the program is erased when execution of the last block of the program is completed by single–block operation.)
- In **MEMORY** mode, if memory operation is performed.
- In **EDIT** mode, if any editing is performed.
- Background editing is performed.
- Upon reset when bit 7 (MCL) of parameter No. 3203 is set to 1

After the editing operation during the stop of MDI operation was done, operation starts from the current cursor position.

 Editing a program during MDI operation A program can be edited during MDI operation. The editing of a program, however, is disabled until the CNC is reset, when bit 5 (MIE) of parameter No. 3203 is set accordingly.

Limitations

Restart

Program registration

Programs created in MDI mode cannot be registered.

 Number of lines in a program

A program can have as many lines as can fit on one page of the screen. A program consisting of up to six lines can be created. When parameter MDL (No. 3107 #7) is set to 0 to specify a mode that suppresses the display of continuous—state information, a program of up to 10 lines can be created.

If the created program exceeds the specified number of lines, % (ER) is deleted (prevents insertion and modification).

Subprogram nesting

Calls to subprograms (M98) can be specified in a program created in the MDI mode. This means that a program registered in memory can be called and executed during MDI operation. In addition to the main program executed by automatic operation, up to two levels of subprogram nesting are allowed (when the custom macro option is provided, up to four levels are allowed).




Fig. 4.2 Nesting level of subprograms called from the MDI program

Macro call

When the custom macro option is provided, macro programs can also be created, called, and executed in the **MDI** mode. However, macro call commands cannot be executed when the mode is changed to **MDI** mode after memory operation is stopped during execution of a subprogram.

Memory area

When a program is created in the **MDI** mode, an empty area in program memory is used. If program memory is full, no programs can be created in the **MDI** mode.

4.3 DNC OPERATION

By activating automatic operation during the DNC operation mode (RMT), it is possible to perform machining (DNC operation) while a program is being read in via reader/puncher interface, or remote buffer. If the floppy cassette directory display option is available, it is possible to select files (programs) saved in an external input/output unit of a floppy format (Handy File, Floppy Cassettes, or FA card) and specify (schedule) the sequence and frequency of execution for automatic operation. (see III–4.4)

To use the DNC operation function, it is necessary to set the parameters related to the reader/punch interface, and remote buffer in advance.


DNC OPERATION

Procedure


- 1 Search for the program (file) to be executed.
- 2 Press the REMOTE switch on the machine operator's panel to set RMT mode, then press the cycle start switch. The selected file is executed. For details of the use of the REMOTE switch, refer to the relevant manual supplied by the machine tool builder.
- Program check screen (7.2"/8.4"LCD)

```
PROGRAM CHECK
                                    O0001 N00020
O0010;
G92 G90 X100 Y200 Z50;
G00 X0 Y0 Z0;
G01 Z250 F1000
(RELATIVE) (DIST TO GO)
                          G00
                               G94
                                    G80
   100.000
            Χ
                   0.000
                          G17
                               G21
                                    G98
   100.000
            Υ
                   0.000
                          G90
                               G49
                                    G80
Ζ
     0.000
            Ζ
                   0.000
                          G22
                               G49
                                    G67
     0.000
                   0.000
                               В
С
     0.000
            С
                   0.000
                               M
                          Η
HD.T
          NX.T
                          D
                               Μ
                               M
ACT.F
               SACT
                             REPEAT
RMT STRT MTN ***
                          21:20:05
 ABS ]
                                   ] [ (OPRT) ]
          REL ] [
                          ] [
```

Program screen (7.2"/8.4"LCD)



Program screen (9.5"/10.4"LCD)



During DNC operation, the program currently being executed is displayed on the program check screen and program screen.

The number of displayed program blocks depends on the program being executed

Any comment enclosed between a control—out mark "(" and control—in mark ")" within a block is also displayed.

Explanations

- During DNC operation, programs stored in memory can be called.
- During DNC operation, macro programs stored in memory can be called.

Limitations

- Limit on number of characters
- M198 (command for calling a program from within an external input/output unit)

Custom macro

M99

Alarm

In program display, no more than 256 characters can be displayed. Accordingly, character display may be truncated in the middle of a block.

In DNC operation, M198 cannot be executed. If M198 is executed, P/S alarm No. 210 is issued.

In DNC operation, custom macros can be specified, but no repeat instruction and branch instruction can be programmed. If a repeat instruction or branch instruction is executed, P/S alarm No. 123 is issued. When reserved words (such as IF, WHILE, COS, and NE) used with custom macros in DNC operation are displayed during program display, a blank is inserted between adjacent characters.

Example

[During DNC operation] #102=SIN[#100]; \rightarrow #102 = S I N[#100]; IF[#100NE0]GOTO5; \rightarrow I F[#100NE0] G O T O 5;


When control is returned from a subprogram or macro program to the calling program during DNC operation, it becomes impossible to use a return command (M99P****) for which a sequence number is specified.

Number	Message	Contents
086	DR SIGNAL OFF	When entering data in the memory by using Reader / Puncher interface, the ready signal (DR) of reader / puncher was turned off. Power supply of I/O unit is off or cable is not connected or a P.C.B. is defective.
123	CAN NOT USE MACRO COMMAND IN DNC	Macro control command is used during DNC operation. Modify the program.
210	CAN NOT COMAND M198/M199	Or M198 is executed in the DNC operation. Modify the program.

4.4 PROGRAM RESTART

This function specifies Sequence No. of a block to be restarted when a tool is broken down or when it is desired to restart machining operation after a day off, and restarts the machining operation from that block. It can also be used as a high–speed program check function.

There are two restart methods: the P-type method and Q-type method.



Procedure for Program Restart by Specifying a Sequence Number

Procedure 1

[PTYPE]


[QTYPE]

- 1 Retract the tool and replace it with a new one. When necessary, change the offset. (Go to step 2.)
- 1 When power is turned ON or emergency stop is released, perform all necessary operations at that time, including the reference position return.
- 2 Move the machine manually to the program starting point (machining start point), and keep the modal data and coordinate system in the same conditions as at the machining start.
- 3 If necessary, modify the offset amount.

Procedure 2

[COMMON TO P TYPE / Q TYPE]


- 1 Turn the program restart switch on the machine operator's panel ON.
- 2 Press Prog key to display the desired program.
- 3 Find the program head.
- 4 Enter the sequence number of the block to be restarted, then press th **[P TYPE]** or **[Q TYPE]** soft key.



N _____ { [Q TYPE] } or [P TYPE] _____ Sequence number

If the same sequence number appears more than once, the location of the target block must be specified. Specify a frequency and a sequence number.

The sequence number is searched for, and the program restart screen appears on the CRT display.



DESTINATION shows the position at which machining is to restart. DISTANCE TO GO shows the distance from the current tool position to the position where machining is to restart. A number to the left of each axis name indicates the order of axes (determined by parameter setting) along which the tool moves to the restart position.

The coordinates and amount of travel for restarting the program can be displayed for up to five axes. If your system supports six or more axes, pressing the [RSTR] soft key again displays the data for the sixth and subsequent axes. (The program restart screen displays only the data for CNC-controlled axes.)

M: Fourteen most recently specified M codes

- T: Two most recently specified T codes
- S: Most recently specified S code
- B: Most recently specified B code

Codes are displayed in the order in which they are specified. All codes are cleared by a program restart command or cycle start in the reset state.

- Turn the program re–start switch OFF. At this time, the figure at the left side of axis name DISTANCE TO GO blinks.
- Check the screen for the M, S, T, and B codes to be executed. If they are found, enter the MDI mode, then execute the M, S, T, and B functions. After execution, restore the previous mode.

These codes are not displayed on the program restart screen.

- Check that the distance indicated under DISTANCE TO GO is correct. Also check whether there is the possibility that the tool might hit a workpiece or other objects when it moves to the machining restart position. If such a possibility exists, move the tool manually to a position from which the tool can move to the machining restart position without encountering any obstacles.
- Press the cycle start button. The tool moves to the machining restart position at the dry run feedrate sequentially along axes in the order specified by parameter settings (No. 7310). Machining is then restarted.

Procedure for Program Restart by Specifying a Block Number

Procedure 1


[PTYPE]

[QTYPE]


- 1 Retract the tool and replace it with a new one. When necessary, change the offset. (Go to step 2.)
- 1 When power is turned ON or emergency stop is released, perform all necessary operations at that time, including the reference position return.
- 2 Move the machine manually to the program starting point (machining start point), and keep the modal data and coordinate system in the same conditions as at the machining start.
- 3 If necessary, modify the offset amount.

Procedure 2

[COMMON TO P TYPE / Q TYPE]



- 1 Turn the program restart switch on the machine operator's panel ON.
- 2 Press | PROG | key to display the desired program.
- 3 Find the program head. Press function RESET key.
- 4 Enter the number of the block to be restarted then press the [P TYPE] or [Q TYPE] soft key. The block number cannot exceed eight digits.
- 5 The block number is searched for, and the program restart screen appears on the display.



DESTINATION shows the position at which machining is to restart. DISTANCE TO GO shows the distance from the current tool position to the position where machining is to restart. A number to the left of each axis name indicates the order of axes (determined by parameter setting) along which the tool moves to the restart position.

The coordinates and amount of travel for restarting the program can be displayed for up to five axes. If your system supports six or more axes, pressing the **[RSTR]** soft key again displays the data for the sixth and subsequent axes. (The program restart screen displays only the data for CNC–controlled axes.)

M: Fourteen most recently specified M codes

- T: Two most recently specified T codes
- S: Most recently specified S code
- B: Most recently specified B code

Codes are displayed in the order in which they are specified. All codes are cleared by a program restart command or cycle start in the reset state.

- **6** Turn the program re–start switch OFF. At this time, the figure at the left side of axis name DISTANCE TO GO blinks.
- 7 Check the screen for the M, S, T, and B codes to be executed. If they are found, enter the MDI mode, then execute the M, S, T, and B functions. After execution, restore the previous mode.

 These codes are not displayed on the program restart screen.
- 8 Check that the distance indicated under DISTANCE TO GO is correct. Also check whether there is the possibility that the tool might hit a workpiece or other objects when it moves to the machining restart position. If such a possibility exists, move the tool manually to a position from which the tool can move to the machining restart position without encountering any obstacles.
- 9 Press the cycle start button. The tool moves to the machining restart position at the dry run feedrate sequentially along axes in the order specified by parameter settings (No. 7310). Machining is then restarted.

Explanations

Block number

When the CNC is stopped, the number of executed blocks is displayed on the program screen or program restart screen. The operator can specify the number of the block from which the program is to be restarted, by referencing the number displayed on the CRT. The displayed number indicates the number of the block that was executed most recently. For example, to restart the program from the block at which execution stopped, specify the displayed number, plus one.

The number of blocks is counted from the start of machining, assuming one NC line of a CNC program to be one block.

< Example 1 >

CNC Program	Number of blocks
O 0001;	1
G90 G92 X0 Y0 Z0;	2
G01 X100. F100;	3
G03 X01 -50. F50;	4
M30;	5

<	Exam	ple	2 >
---	------	-----	-----

CNC Program	Number of blocks
O 0001;	1
G90 G92 X0 Y0 Z0;	2
G90 G00 Z100.;	3
G81 X100. Y0. Z-120. R-80. F50.;	4
#1 = #1 + 1;	4
#2 = #2 + 1;	4
#3 = #3 + 1;	4
G00 X0 Z0;	5
M30;	6

Macro statements are not counted as blocks.

- Storing / clearing the block number
- Block number when a program is halted or stopped

The block number is held in memory while no power is supplied. The number can be cleared by cycle start in the reset state.

The program screen usually displays the number of the block currently being executed. When the execution of a block is completed, the CNC is reset, or the program is executed in single—block stop mode, the program screen displays the number of the program that was executed most recently.

When a CNC program is halted or stopped by feed hold, reset, or single-block stop, the following block numbers are displayed:

Feed hold: Block being executed Reset: Block executed most recently

Single-block stop: Block executed most recently

For example, when the CNC is reset during the execution of block 10, the displayed block number changes from 10 to 9.

MDI intervention

When MDI intervention is performed while the program is stopped by single-block stop, the CNC commands used for intervention are not counted as a block.

 Block number exceeding eight digits When the block number displayed on the program screen exceeds eight digits, the block number is reset to 0 and counting continues.

Limitations

P-type restart

Under any of the following conditions, P-type restart cannot be performed:

- When automatic operation has not been performed since the power was turned on
- · When automatic operation has not been performed since an emergency stop was released
- When automatic operation has not been performed since the coordinate system was changed or shifted (change in an external offset from the workpiece reference point)

Restart block

The block to be restarted need not be the block which was interrupted; operation can restart with any block. When P-type restart is performed, the restart block must use the same coordinate system as when operation was interrupted.

Single block

When single block operation is ON during movement to the restart position, operation stops every time the tool completes movement along an axis. When operation is stopped in the single block mode, MDI intervention cannot be performed.

Manual intervention

During movement to the restart position, manual intervention can be used to perform a return operation for an axis if it has not yet been performed for the axis. A return operation cannot be done further on axes for which a return has already been completed.

Reset

Never reset during the time from the start of a search at restart until machining is restarted. Otherwise, restart must be performed again from the first step.

Manual absolute

Regardless of whether machining has started or not, manual operation must be performed when the manual absolute mode is on.

Reference position return

If no absolute–position detector (absolute pulse coder) is provided, be sure to perform reference position return after turning on the power and before performing restart.

Alarm

Alarm No.	Contents
071	The specified block number for restarting the program is not found.
094	After interruption, a coordinate system was set, then P-type restart was specified.
095	After interruption, the coordinate system shift was changed, then P–type restart was specified.
096	After interruption, the coordinate system was changed, then P–type restart was specified.
097	When automatic operation has not been performed since the power was turned on, emergency stop was released, or P/S alarm 094 to 097 was reset, P-type restart was specified.
098	After the power was turned on, restart operation was performed without reference position return, but a G28 command was found in the program.
099	A move command was specified from the MDI panel during a restart operation.
5020	An erroneous parameter was specififed for restarting a program.

WARNING


As a rule, the tool cannot be returned to a correct position under the following conditions. Special care must be taken in the following cases since none of them cause an alarm:

- Manual operation is performed when the manual absolute mode is OFF.
- Manual operation is performed when the machine is locked.
- When the mirror image is used.
- When manual operation is performed in the course of axis movement for returning operation.
- When the program restart is commanded for a block between the block for skip cutting and subsequent absolute command block.

4.5 SCHEDULING FUNCTION

The schedule function allows the operator to select files (programs) registered on a floppy—disk in an external input/output device (Handy File, Floppy Cassette, or FA Card) and specify the execution order and number of repetitions (scheduling) for performing automatic operation. It is also possible to select only one file from the files in the external input/output device and execute it during automatic operation.

This function is effective, when the floppy cassette directory display option is avairable and the floppy cassette is selected as the valid I/O device.



List of files in an external input/output device



Set file number and number of repetitions.

ORDER	FILE NO	REPETITION
01	0002	2
02	0003	1
03	0004	3
04	0001	2

Scheduling screen



Executing automatic operation

Procedure for Scheduling Function

Procedure

- Procedure for executing one file
- 1 Press the **MEMORY** switch on the machine operator's panel, then press the PROG function key on the MDI panel.
- 2 Press the rightmost soft key (continuous menu key), then press the **[FL. SDL]** soft key. A list of files registered in the Floppy Cassette is displayed on screen No. 1. To display more files that are not displayed on this screen, press the page key on the MDI panel. Files registered in the Floppy Cassette can also be displayed successively.

FILE DIR	ECTORY	O0001 N00000
CURRE	ENT SELECTED : SCH	EDULE
NO.	FILE NAME	(METER) VOL
0000	SCHEDULE	
0001	PARAMETER	58.5
0002	ALL PROGRAM	11.0
0003	O0001	1.9
0004	O0002	1.9
0005	O0010	1.9
0006	O0020	1.9
0007	O0040	1.9
8000	O0050	1.9
MEM :	**** *** ***	19 : 14 : 47
(PRGRI		$\Big) \Big(SCHDUL \Big) \Big((OPRT) \Big)$

Screen No.1

3 Press the [(OPRT)] and [SELECT] soft keys to display "SELECT FILE NO." (on screen No. 2). Enter a file number, then press the [F SET] and [EXEC] soft keys. The file for the entered file number is selected, and the file name is indicated after "CURRENT SELECTED:".

FILE DIRECTORY	O0001 N00000
CURRENT SELECTED:00040	
NO. FILE NAME	(METER) VOL
0000 SCHEDULE 0001 PARAMETER	58.5
0002 ALL PROGRAM	11.0
0003 O0001	1.9
0004 O0002	1.9
0005 O0010	1.9
0006 O0020 0007 O0040	1.9 1.9
0007 00040 0008 00050	1.9
SELECT FILE NO.=7	1.9
>_ MEM **** ***	40 - 47 - 40
	19:17:10
(F SET) () () (EXEC)
	· · · · · · · · · · · · · · · · · · ·

Screen No.2

4 Press the **REMOTE** switch on the machine operator's panel to enter the **RMT** mode, then press the cycle start switch. The selected file is executed. For details on the **REMOTE** switch, refer to the manual supplied by the machine tool builder. The selected file number is indicated at the upper right corner of the screen as an F number (instead of an O number).

```
FILE DIRECTORY F0007 N00000

CURRENT SELECTED:00040

RMT **** *** *** 13:27:54

( PRGRM ) ( ) ( DIR ) ( SCHDUL ) ( (OPRT) )
```

Screen No.3

- Procedure for executing the scheduling function
- 1 Display the list of files registered in the Floppy Cassette. The display procedure is the same as in steps 1 and 2 for executing one file.
- 2 On screen No. 2, press the [(OPRT)] and [SELECT] soft keys to display "SELECT FILE NO."
- 3 Enter file number 0, and press the **[F SET]**, and **[EXEC]** soft keys. "SCHEDULE" is indicated after "CURRENT SELECTED:".
- 4 Press the leftmost soft key (return menu key) and the **[SCHDUL]** soft key. Screen No. 4 appears.


Screen No.4

B-63094EN/01

Move the cursor and enter the file numbers and number of repetitions in the order in which to execute the files. At this time, the current number of repetitions "CUR.REP" is 0.

Press the **REMOTE** switch on the machine operator's panel to enter the RMT mode, then press the start switch. The files are executed in the specified order. When a file is being executed, the cursor is positioned at the number of that file.

The current number of repetitions CUR.REP is increased when M02 or M30 is executed in the program being run.



Screen No.5

Explanations

 Specifying no file number

Endless repetition

Clear

 Return to the program screen

If no file number is specified on screen No. 4 (the file number field is left blank), program execution is stopped at that point. To leave the file number field blank, press numeric key then INPUT.

If a negative value is set as the number of repetitions, <LOOP> is displayed, and the file is repeated indefinitely.

When the [(OPRT)], [CLEAR], and [EXEC] soft keys are pressed on screen No. 4, all data is cleared. However, these keys do not function while a file is being executed.

When the soft key [PRGRM] is pressed on screen No. 1, 2, 3, 4, or 5, the program screen is displayed.

Restrictions

Number of repetitions

 Number of files registered

M code

Up to 9999 can be specified as the number of repetitions. If 0 is set for a file, the file becomes invalid and is not executed.

By pressing the page key on screen No. 4, up to 20 files can be registered.

When M codes other than M02 and M30 are executed in a program, the current number of repetitions is not increased.

 Displaying the floppy disk directory during file execution During the execution of file, the floppy directory display of background editing cannot be referenced.

 Restarting automatic operation To resume automatic operation after it is suspended for scheduled operation, press the reset button.

 Scheduling function for the two-path control The scheduling function can be used only for a single tool post.

Alarm

Alarm No.	Description
086	An attempt was made to execute a file that was not registered in the floppy disk.
210	M198 and M099 were executed during scheduled operation, or M198 was executed during DNC operation.


4.6 SUBPROGRAM CALL FUNCTION (M198)

The subprogram call function is provided to call and execute subprogram files stored in an external input/output device(Handy File, FLOPPY CASSETTE, FA Card)during memory operation.

When the following block in a program in CNC memory is executed, a subprogram file in the external input/output device is called:

To use this function, the Floppy Cassette directory display option must be installed.

Format



Explanation

The subprogram call function is enabled when parameter No.0102 for the input/output device is set to 3. When the custom macro option is provided, either format 1 or 2 can be used. A different M code can be used for a subprogram call depending on the setting of parameter No.6030. In this case, M198 is executed as a normal M code. The file number is specified at address P. If the SBP bit (bit 2) of parameter No.3404 is set to 1, a program number can be specified. When a file number is specified at address P. Fxxxx is indicated instead of Oxxxx.




Fig.4.6 Program flow when m198 is specified

Restrictions

Subprogram call function with two-path control

For the two-path control, subprograms in a floppy cassette cannot be called for the two tool posts at the same time.

NOTE

- 1 When M198 in the program of the file saved in a floppy cassette is executed, a P/S alarm (No.210) is given. When a program in the memory of CNC is called and M198 is executed during execution of a program of the file saved in a floppy cassette, M198 is changed to an ordinary M–code.
- When MDI is intervened and M198 is executed after M198 is commanded in the memory mode, M198 is changed to an ordinary M-code. When the reset operation is done in the MDI mode after M198 is commanded in the MEMORY mode, it does not influence on the memory operation and the operation is continued by restarting it in the MEMORY mode.

4.7 MANUAL HANDLE INTERRUPTION

The movement by manual handle operation can be done by overlapping it with the movement by automatic operation in the automatic operation mode.




Fig 4.7 Manual handle interruption

Handle interruption axis selection signals
 For the handle interruption axis selection signals, refer to the manual supplied by the machine tool builder.

During automatic operation, handle interruption is enabled for an axis if the handle interruption axis selection signal for that axis is on. Handle interruption is performed by turning the handle of the manual pulse generator.

WARNING

The travel distance by handle interruption is determined according to the amount by which the manual pulse generator is turned and the handle feed magnification (x1, x10, xM, xN).

Since this movement is not accelerated or decelerated, it is very dangerous to use a large magnification value for handle interruption.

The move amount per scale at x1 magnification is 0.001 mm (metric output) or 0.0001 inch (inch output).

NOTE

Handle interruption is disabled when the machine is locked during automatic operation.

Explanations

Relation with other functions

The following table indicates the relation between other functions and the movement by handle interrupt.

Display	Relation
Machine lock	Machine lock is effective. The tool does not move even when this signal turns on.
Interlock	Interlock is effective. The tool does not move even when this signal turns on.
Mirror image	Mirror image is not effective. Interrupt functions on the plus direction by plus direction command, even if this signal turns on.

Position display

The following table shows the relation between various position display data and the movement by handle interrupt.

Display	Relation
Absolute coordinate value	Handle interruption does not change absolute coordinates.
Relative Handle interruption does not change relative coordinate value coordinates.	
Machine coordinate value	Machine coordinates are changed by the travel distance specified by handle interruption.

• Travel distance display

Press the function key Pos, then press the chapter selection soft key

[HNDL].

The move amount by the handle interrupt is displayed. The following 4 kinds of data are displayed concurrently.

HANDLE INTERRUPTION	O0000 N02000		
(INPUT UNIT)	(OUTPUT UNIT)		
X 69.594	X 69.594		
Y 137.783	Y 137.783		
Z –61.439	Z –61.439		
(RELATIVE)	(DISTANCE TO GO)		
X 0.000	X 0.000		
Y 0.000	Y 0.000		
Z 0.000	Z 0.000		
PART COUNT 287 RUN TIME 1H 12M CYCLE TIME 0H 0M 0S			
MDI *** *** ***	10 : 29 : 51		
(ABS)(REL)(ALL) (HNDL) ((OPRT))		

(a) INPUT UNIT : Handle interrupt move amount in input unit system

> Indicates the travel distance specified by handle interruption according to the least input increment.

(b) OUTPUT UNI: Handle interrupt move amount in output unit

system

Indicates the travel distance specified by handle interruption according to the least command

increment.

(c) RELATIVE : Position in relative coordinate system

These values have no effect on the travel distance

specified by handle interruption.

(d) DISTANCE TO GO: The remaining travel distance in the current

block has no effect on the travel distance

specified by handle interruption.

The handle interrupt move amount is cleared when the manual reference position return ends every axis.

4.8 MIRROR IMAGE

During automatic operation, the mirror image function can be used for movement along an axis. To use this function, set the mirror image switch to ON on the machine operator's panel, or set the mirror image setting to ON from the MDI panel.




Fig 4.8 Mirror image

Procedure

The following procedure is given as an example. For actual operation, refer to the manual supplied by the machine tool builder.

- 1 Press the single block switch to stop automatic operation. When the mirror image function is used from the beginning of operation, this step is omitted.
- **2** Press the mirror image switch for the target axis on the machine operator's panel.

Alternatively, turn on the mirror image setting by following the steps below:

- 2–1 Set the MDI mode.
- 2–2 Press the OFFSET function key.
- **2–3** Press the **[SETING]** soft key for chapter selection to display the setting screen.

- **2–4** Move the cursor to the mirror image setting position, then set the target axis to 1.
- 3 Enter an automatic operation mode (memory mode or MDI mode), then press the cycle start button to start automatic operation.

Explanations

- The mirror image function can also be turned on and off by setting bit 0 of parameter 0012 (MIRx) to 1 or 0.
- For the mirror image switches, refer to the manual supplied by the machine tool builder.

Limitations

The direction of movement during manual operation, the direction of movement from an intemidiate point to the reference position during automatic reference position return (G28), the direction of approach during unidirectional positioning (G60), and the shift direction in a boring cycle (G76, G87) cannot be reserved.

4.9 MANUAL INTERVENTION AND RETURN

In cases such as when tool movement along an axis is stopped by feed hold during automatic operation so that manual intervention can be used to replace the tool: When automatic operation is restarted, this function returns the tool to the position where manual intervention was started. To use the conventional program restart function and tool withdrawal and return function, the switches on the operator's panel must be used in conjunction with the MDI keys. This function does not require such operations.

Before this function can be used, MIN (bit 0 of parameter No. 7001) must be set to 1.

Explanations

• **Manual absolute on/off**In manual absolute off mode, the tool does not return to the stop position, but instead operates according to the manual absolute on/off function.

• **Override** For the return operation, the dry run feedrate is used, and the jog feedrate override function is enabled.

• **Return operation** Return operation is performed according to positioning based on nonlinear interpolation.

• **Single block**If the single block stop switch is on during return operation, the tool stops at the stop position and restarts movement when the cycle start switch is pressed.

• **Cancellation** If a reset occurs or an alarm is issued during manual intervention or the return operation, this function is cancelled.

• **MDI mode** This function can be used in the MDI mode as well.

Limitations

 Enabling and disabling manual intervention and return


This function is enabled only when the automatic operation hold LED is on. When there is no travel distance remaining, this function has no effect even if a feed hold stop is performed with the automatic operation hold signal *SP (bit 5 of G008).

Offset
 When the tool is replaced using manual intervention for a reason such as damage, the tool movement cannot be restarted by a changed offset in the middle of the interrupted block.


 Machine lock, mirror image, and scaling When performing manual intervention, never use the machine lock, mirror image, or scaling functions.

Example


1. The N1 block cuts a workpiece




2. The tool is stopped by pressing the feed hold switch in the middle of the N1 block (point A).



3. After retracting the tool manually to point B, tool movement is restarted.



4. After automatic return to point A at the dry run feedrate, the remaining move command of the N1 block is executed.



WARNING

When performing manual intervention, pay particular attention of machining and the shape of the workpiece so that the machine and tool are not damaged.



TEST OPERATION

The following functions are used to check before actual machining whether the machine operates as specified by the created program.

- 5.1 Machine Lock and Auxiliary Function Lock
- 5.2 Feedrate Override
- 5.3 Rapid Traverse Override
- 5.4 Dry Run
- 5.5 Single Block

5.1 MACHINE LOCK AND AUXILIARY FUNCTION LOCK

To display the change in the position without moving the tool, use machine lock.

There are two types of machine lock: all—axis machine lock, which stops the movement along all axes, and specified—axis machine lock, which stops the movement along specified axes only. In addition, auxiliary function lock, which disables M, S, and T commands, is available for checking a program together with machine lock.




Fig. 5.1 Machine lock

Procedure for Machine Lock and Auxiliary Function Lock

Machine Lock

Press the machine lock switch on the operator's panel. The tool does not move but the position along each axis changes on the display as if the tool were moving.

Some machines have a machine lock switch for each axis. On such machines, press the machine lock switches for the axes along which the tool is to be stopped. Refer to the appropriate manual provided by the machine tool builder for machine lock.

WARNING

The positional relationship between the workpiece coordinates and machine coordinates may differ before and after automatic operation using machine lock. In such a case, specify the workpiece coordinate system by using a coordinate setting command or by performing manual reference position return.

Auxiliary Function Lock

Press the auxiliary function lock switch on the operator's panel. M, S, T and B codes are disabled and not executed. Refer to the appropriate manual provided by the machine tool builder for auxiliary function lock.

Restrictions

 M, S, T, B command by only machine lock M, S, T and B commands are executed in the machine lock state.

 Reference position return under Machine Lock When a G27, G28, or G30 command is issued in the machine lock state, the command is accepted but the tool does not move to the reference position and the reference position return LED does not go on.

 M codes not locked by auxiliary function lock M00, M01, M02, M30, M98, and M99 commands are executed even in the auxiliary function lock state. M codes for calling a subprogram (parameters No. 6071 to 6079) and those for calling a custom macro (parameter No. 6080 to 6089) are also executed.

5.2 FEEDRATE OVERRIDE

A programmed feedrate can be reduced or increased by a percentage (%) selected by the override dial. This feature is used to check a program. For example, when a feedrate of 100 mm/min is specified in the program, setting the override dial to 50% moves the tool at 50 mm/min.





Fig. 5.2 Feedrate override

Procedure for Feedrate Override



JOG FEED RATE OVERRIDE

Set the feedrate override dial to the desired percentage (%) on the machine operator's panel, before or during automatic operation.

On some machines, the same dial is used for the feedrate override dial and jog feedrate dial. Refer to the appropriate manual provided by the machine tool builder for feedrate override.

Restrictions

Override Range

The override that can be specified ranges from 0 to 254%. For individual machines, the range depends on the specifications of the machine tool builder.

Override during thread

During threading, the override is ignored and the feedrate remains as specified by program.

5.3 RAPID TRAVERSE OVERRIDE

An override of four steps (F0, 25%, 50%, and 100%) can be applied to the rapid traverse rate. F0 is set by a parameter (No. 1421).





Fig. 5.3 Rapid traverse override

Rapid Traverse Override

Procedure



Rapid traverse override

Explanation

Select one of the four feedrates with the rapid traverse override switch during rapid traverse. Refer to the appropriate manual provided by the machine tool builder for rapid traverse override.

The following types of rapid traverse are available. Rapid traverse override can be applied for each of them.

- 1) Rapid traverse by G00
- 2) Rapid traverse during a canned cycle
- 3) Rapid traverse in G27, G28, G29, G30, G53
- 4) Manual rapid traverse
- 5) Rapid traverse of manual reference position return

5.4 DRY RUN

The tool is moved at the feedrate specified by a parameter regardless of the feedrate specified in the program. This function is used for checking the movement of the tool under the state taht the workpiece is removed from the table.




Fig. 5.4 Dry run

Procedure for Dry Run

Procedure

Press the dry run switch on the machine operator's panel during automatic operation.

The tool moves at the feedrate specified in a parameter. The rapid traverse switch can also be used for changing the feedrate.

Refer to the appropriate manual provided by the machine tool builder for dry run.

Explanation

• Dry run feedrate



The dry run feedrate changes as shown in the table below according to the rapid traverse switch and parameters.

Rapid traverse	Program command	
button	Rapid traverse	Feed
ON	Rapid traverse rate	Dry run feedrate × Max.JV *2)
OFF	Dry run speed×JV,or rapid traverse rate *1)	Dry run feedrate×JV *2)

Max. cutting feedrate Setting by parameter No.1422

Rapid traverse rate Setting by parameter No.1420

Dry run feedrate Setting by parameter No.1410

JV: Jog feedrate override

- *1) Dry run feedrate x JV when parameter RDR (bit 6 of No. 1401) is
 - 1. Rapid traverse rate when parameter RDR is 0.
- *2) Clamped to the maximum cutting feedrate

JVmax: Maximum value of jog feedrate override

5.5 SINGLE BLOCK

Pressing the single block switch starts the single block mode. When the cycle start button is pressed in the single block mode, the tool stops after a single block in the program is executed. Check the program in the single block mode by executing the program block by block.




Fig. 5.5 (a) Single block

Procedure for Single block

Procedure

- 1 Press the single block switch on the machine operator's panel. The execution of the program is stopped after the current block is executed.
- 2 Press the cycle start button to execute the next block. The tool stops after the block is executed.

Refer to the appropriate manual provided by the machine tool builder for single block execution.

Explanation

 Reference position return and single block If G28 to G30 are issued, the single block function is effective at the intermediate point.

 Single block during a canned cycle In a canned cycle, the single block stop points are the end of ①, ②, and ⑥ shown below. When the single block stop is made after the point ① or ②, the feed hold LED lights.




Fig. 5.5 (b) Single block during canned cycle

 Subprogram call and single block Single block stop is not performed in a block containing M98P_;. M99; or G65.

However, single block stop is even performed in a block with M98P_ or M99 command, if the block contains an address other than O, N, P, L.



SAFETY FUNCTIONS

To immediately stop the machine for safety, press the Emergency stop button. To prevent the tool from exceeding the stroke ends, Overtravel check and Stroke check are available. This chapter describes emergency stop., overtravel check, and stroke check.

6.1 EMERGENCY STOP

If you press Emergency Stop button on the machine operator's panel, the machine movement stops in a moment.




Fig. 6.1 Emergency stop

This button is locked when it is pressed. Although it varies with the machine tool builder, the button can usually be unlocked by twisting it.

Explanation

EMERGENCY STOP interrupts the current to the motor. Causes of trouble must be removed before the button is released.

6.2 OVERTRAVEL

When the tool tries to move beyond the stroke end set by the machine tool limit switch, the tool decelerates and stops because of working the limit switch and an OVER TRAVEL is displayed.




Fig. 6.2 Overtravel

Explanation

- Overtravel during automatic operation
- Overtravel during manual operation
- Releasing overtravel

Alarm

When the tool touches a limit switch along an axis during automatic operation, the tool is decelerated and stopped along all axes and an overtravel alarm is displayed.

In manual operation, the tool is decelerated and stopped only along the axis for which the tool has touched a limit switch. The tool still moves along the other axes.

Press the reset button to reset the alarm after moving the tool to the safety direction by manual operation. For details on operation, refer to the operator's manual of the machine tool builder.

Alarm No.	Message	Description
506	Overtravel: +n	The tool has exceeded the hardware—specified overtravel limit along the positive nth axis (n: 1 to 8).
507	Overtravel: -n	The tool has exceeded the hardware–specified overtravel limit along the negative nth axis (n: 1 to 8).

6.3 STROKE CHECK

Three areas which the tool cannot enter can be specified with stored stroke check 1, stored stroke check 2, and stored stroke check 3.




Fig. 6.3 (a) Stroke check

When the tool exceeds a stored stroke limit, an alarm is displayed and the tool is decelerated and stopped.

When the tool enters a forbidden area and an alarm is generated, the tool can be moved in the reverse direction from which the tool came.

Explanation

Stored stroke check 1

Parameters (Nos. 1320, 1321 or Nos. 1326, 1327) set boundary. Outside the area of the set limits is a forbidden area. The machine tool builder usually sets this area as the maximum stroke.

 Stored stroke check 2 (G22, G23) Parameters (Nos. 1322, 1323) or commands set these boundaries. Inside or outside the area of the limit can be set as the forbidden area. Parameter OUT (No. 1300#0) selects either inside or outside as the forbidden area.

In case of program command a G22 command forbids the tool to enter the forbidden area, and a G23 command permits the tool to enter the forbidden area. Each of G22; and G23; should be commanded independently of another commands in a block.

The command below creates or changes the forbidden area:




Fig. 6.3(b) Creating or changing the forbidden area using a program

When setting the area by parameters, points A and B in the figure below must be set.




Fig. 6.3 (c) Creating or changing the forbidden area using a parameters

In stored stroke check 2, even if you mistake the order of the coordinate value of the two points, a rectangular, with the two points being the apexes, will be set as the area.

When you set the forbidden area through parameters (Nos. 1322, 1323), the data should be specified by the distance from the machine coordinate system in the least command increment. (Output increment)

If it is set by a G22 command, specify the data by the distance from the machine coordinate system in the least input increment (Input increment.) The programmed data are then converted into the numerical values in the least command increment, and the values are set as the parameters.

Confirm the checking position (the top of the tool or the tool chuck) before programming the forbidden area.

If point A (The top of the tool) is checked in Fig. 6.3 (d), the distance "a" should be set as the data for the stored stroke limit function. If point B (The tool chuck) is checked, the distance "b" must be set. When checking the tool tip (like point A), and if the tool length varies for each tool, setting the forbidden area for the longest tool requires no re—setting and results in safe operation.

 Checkpoint for the forbidden area




Fig. 6.3 (d) Setting the forbidden area

 Forbidden area over lapping Area can be set in piles.




Fig. 6.3 (e) Setting the forbidden area over lapping

Unnecessary limits should be set beyond the machine stroke.

 Overrun amount of stored stroke limit If the maximum rapid traverse rate is F (mm/min), the maximum overrun amount, L (mm), of the stored stroke limit is obtained from the following expression:

L (mm) = F/7500

The tool enters the specified inhibited area by up to L (mm). Bit 7 (BFA) of parameter No. 1300 can be used to stop the tool when it reaches a point L mm short of the specified area. In this case, the tool will not enter the inhibited area.

 Effective time for a forbidden area

Each limit becomes effective after the power is turned on and manual reference position return or automatic reference position return by G28 has been performed.

After the power is turned on, if the reference position is in the forbidden area of each limit, an alarm is generated immediately. (Only in G22 mode for stored stroke limit 2).

Releasing the alarms

If the enters a forbidden area and an alarm is generated, the tool can be moved only in the backward direction. To cancel the alarm, move the tool backward until it is outside the forbidden area and reset the system. When the alarm is canceled, the tool can be moved both backward and forward.

- Change from G23 to G22 in a forbidden area
- When G23 is switched to G22 in the forbidden area, the following results.
- (1) When the forbidden area is inside, an alarm is informed in the next move.
- (2) When the forbidden area is outside, an alarm is informed immediately.

Parameter BFA (bit 7 of No. 1300) selects whether an alarm is displayed immediately before the tool enters the forbidden area or immediately after the tool has entered the forbidden area.

• Timing for displaying an alarm

Alarms

Alarm Number	Message	Contents				
500	OVER TRAVEL: +n	Exceeded the n-th axis (1-8) + side stored stroke limit I.				
501	OVER TRAVEL: -n	Exceeded the n-th axis (1-8) - side stored stroke limit I.				
502	OVER TRAVEL: +n	Exceeded the n-th axis (1-8) + side stored stroke limit II.				
503	OVER TRAVEL: -n	Exceeded the n-th axis (1-8) - side stored stroke limit II.				



ALARM AND SELF-DIAGNOSIS FUNCTIONS

When an alarm occurs, the corresponding alarm screen appears to indicate the cause of the alarm. The causes of alarms are classified by error codes. Up to 25 previous alarms can be stored and displayed on the screen (alarm history display).


The system may sometimes seem to be at a halt, although no alarm is displayed. In this case, the system may be performing some processing. The state of the system can be checked using the self-diagnostic function.

7.1 ALARM DISPLAY

Explanations

Alarm screen

When an alarm occurs, the alarm screen appears.



 Another method for alarm displays In some cases, the alarm screen does not appear, but an ALM is displayed at the bottom of the screen.

PARAM	METER	(AXIS	/UNIT)				O1000	N00010
1001	0	0	0	0	0	0	0	INM 0
1002	0	0	XIK 0	0	0	0	DLZ 0	JAX 0
1003	0	0	0	0	0	0	0 ISC	0
1004	0	0	0	0	0	0	0	0
	* * * *				M 08	: 41		0 T0000
(NO.S	RH)(ON:1)(OFF	:0) (+11	NPU	т)(т	NPUT)

In this case, display the alarm screen as follows:

- 1. Press the function key MESSAGE
- 2. Press the chapter selection soft key [ALARM].

• Reset of the alarm

Error codes and messages indicate the cause of an alarm. To recover from an alarm, eliminate the cause and press the reset key.

• Error codes

The error codes are classified as follows:

No. 000 to 255 : P/S alarm (Program errors) (*)
No. 300 to 349 : Absolute pulse coder (APC) alarms
No. 350 and 399 : Serial pulse coder (SPC) alarms

No. 400 to 499 : Servo alarms
No. 500 to 599 : Overtravel alarms
No. 700 to 749 : Overheat alarms
No. 750 to 799 : Spindle alarms
No. 900 to 999 : System alarms

No. 5000 to : P/S alarm (Program errors)

* For an alarm (No. 000 to 255) that occurs in association with background operation, the indication "xxxBP/S alarm" is provided (where xxx is an alarm number). Only a BP/S alarm is provided for No. 140.

See the error code list in the appendix for details of the error codes.

7.2 ALARM HISTORY DISPLAY

Up to 25 of the most recent CNC alarms are stored and displayed on the screen.

Display the alarm history as follows:

Procedure for Alarm History Display


Procedure

- 1 Press the function key MESSAGE
- 2 Press the chapter selection soft key [HISTRY].

The alarm history appears.

The following information items are displayed.

- (1)The date the alarm was issued
- (2)Alarm No.
- (3) Alarm message (some contains no message)
- 3 Change the page by the 1–page change key.
- 4 To delete the recorded information, press the softkey **[(OPRT)]** then the **[DELETE]** key.



- (1) The date the alarm was issued
- (2) Alarm No.
- (3) Alarm message (some contains no message)
- (4) Page No.

7.3 CHECKING BY SELF-DIAGNOSTIC SCREEN

The system may sometimes seem to be at a halt, although no alarm has occurred. In this case, the system may be performing some processing. The state of the system can be checked by displaying the self–diagnostic screen.

Procedure for Diagnois

Procedure

- 1 Press the function key System
- 2 Press the chapter select key [DGNOS].
- 3 The diagnostic screen has more than 1 pages. Select the screen by the following operation.
 - (1) Change the page by the 1–page change key.
 - (2) Method by soft key
 - Key input the number of the diagnostic data to be displayed.
 - Press [N SRCH].

```
DIAGNOSTIC (GENERAL)
                                 O0000 N0000
000
     WAITING FOR FIN SIGNAL
                                        :0
001
     MOTION
                                        :0
                                        :0
002
     DWELL
     IN-POSITION CHECK
                                        :0
003
     FEEDRATE OVERRIDE 0%
                                        :0
004
005
     INTERLOCK/START-LOCK
                                        :0
     SPINDLE SPEED ARRIVAL CHECK
>_
EDIT
                           14:51:55
                         SYSTEM (OPRT)
         DGNOS
 PARAM
```

Explanations

Diagnostic numbers 000 to 015 indicate states when a command is being specified but appears as if it were not being executed. The table below lists the internal states when 1 is displayed at the right end of each line on the screen.

Table 7.3 (a) Alarm displays when a command is specified but appears as if it were not being executed

No.	Display	Internal status when 1 is displayed
000	WAITING FOR FIN SIGNAL	M, S. T function being executed
001	MOTION	Move command in automatic operation being executed
002	DWELL	Dwell being executed
003	IN-POSITION CHECK	In–position check being executed
004	FEEDRATE OVERRIDE 0%	Cutting feed override 0%
005	INTERLOCK/START-LOCK	Interlock ON
006	SPINDLE SPEED ARRIVAL CHECK	Waiting for spindle speed arrival signal to turn on
010	PUNCHING	Data being output via reader puncher interface
011	READING	Data being input via reader puncher interface
012	WAITING FOR (UN) CLAMP	Waiting for index table clamp/unclamp before B axis index table indexing start/after B axis index table indexing end to complete
013	JOG FEEDRATE OVERRIDE 0%	Jog override 0%
014	WAITING FOR RESET.ESP.RRW.OFF	Emergency stop, external reset, reset & rewind, or MDI panel reset key on
015	EXTERNAL PROGRAM NUMBER SEARCH	External program number searching

Table 7.3 (b) Alarm displays when an automatic operation is stopped or paused.

No.	Display	Internal status when 1 is displayed
020	CUT SPEED UP/DOWN	Set when emergency stop turns on or when servo alarm occurs
021	RESET BUTTON ON	Set when reset key turns on
022	RESET AND REWIND ON	Reset and rewind turned on
023	EMERGENCY STOP ON	Set when emergency stop turns on
024	RESET ON	Set when external reset, emergency stop, reset, or reset & rewind key turns on
025	STOP MOTION OR DWELL	A flag which stops pulse distribution. It is set in the following cases. (1) External reset turned on. (2) Reset & rewind turned on. (3) Emergency stop turned on. (4) Feed hold turned on. (5) The MDI panel reset key turned on. (6) Switched to the manual mode(JOG/HANDLE/INC). (7) Other alarm occurred. (There is also alarm which is not set.)

The table below shows the signals and states which are enabled when each diagnostic data item is 1. Each combination of the values of the diagnostic data indicates a unique state.

020	CUT SPEED UP/DOWN	1	0	0	0	1	0	0
021	RESET BUTTON ON	0	0	1	0	0	0	0
022	RESET AND REWIND ON	0	0	0	0	0	0	0
023	EMERGENCY STOP ON	1	0	0	0	0	0	0
024	RESET ON	1	1	1	1	0	0	0
025	5 STOP MOTION OR DWELL		1	1	1	1	1	0
Extern MDI re Reset Servo Chang	ency stop signal input al reset signal input eset button turned on & rewind input alarm generation ed to another mode or feed hold block stop							

Diagnostic numbers 030 and 031 indicate TH alarm states.

No.	Display	Meaning of data
030	CHARACTER NUMBER TH DATA	The position of the character which caused TH alarm is displayed by the number of characters from the beginning of the block at TH alarm
031	TH DATA	Read code of character which caused TH alarm



DATA INPUT/OUTPUT


NC data is transferred between the NC and external input/output devices such as the Handy File.

The following types of data can be entered and output:

- 1.Program
- 2.Offset data
- 3.Parameter
- 4.Pitch error compensation data
- 5.Custom macro common variable

Before an input/output device can be used, the input/output related parameters must be set.

For how to set parameters, see III-2 "OPERATIONAL DEVICES".



8.1 FILES

Of the external input/output devices, the FANUC Handy File and FANUC Floppy Cassette use floppy disks as their input/output medium, and the FANUC FA Card uses an FA card as its input/output medium.

In this manual, these input/output medium is generally referred to as a floppy. However, when the description of one input/output medium varies from the description of another, the name of the input/output medium is used. In the text below, a floppy represents a floppy disk or FA card.

Unlike an NC tape, a floppy allows the user to freely choose from several types of data stored on one medium on a file-by-file basis.


Input/output is possible with data extending over more than one floppy disk.

Explanations

What is a File

The unit of data, which is input/output between the floppy and the CNC by one input/output operation (pressing the VREADW or VPUNCHW key), is called a HfileI. When inputting CNC programs from, or outputting them to the floppy, for example, one or all programs within the CNC memory are handled as one file.

Files are assigned automatically file numbers 1,2,3,4 and so on, with the lead file as 1.



 Request for floppy replacement When one file has been entered over two floppies, LEDs on the adaptor flash alternately on completion of data input/output between the first floppy and the CNC, prompting floppy replacement. In this case, take the first floppy out of the adaptor and insert a second floppy in its place. Then, data input/output will continue automatically.

Floppy replacement is prompted when the second floppy and later is required during file search—out, data input/output between the CNC and the floppy, or file deletion.

Floppy 1



Since floppy replacement is processed by the input/output device, no special operation is required. The CNC will interrupt data input/output operation until the next floppy is inserted into the adaptor.

When reset operation is applied to the CNC during a request for floppy replacement, the CNC is not reset at once, but reset after the floppy has been replaced.

Protect switch

The floppy is provided with the write protect switch. Set the switch to the write enable state. Then, start output operation.




Fig. 8.1. Protect swtich

• Writing memo

Once written in the cassette or card, data can subsequently be read out by correspondence between the data contents and file numbers. This correspondence cannot be verified, unless the data contents and file numbers are output to the CNC and displayed. The data contents can be displayed with display function for directory of floppy disk (See Section III–8.8).

To display the contents, write the file numbers and the contents on the memo column which is the back of floppy.

(Entry example on MEMO)

File 1 NC parameters

File 2 Offset data

File 3 NC program O0100

. .


. .

File (n-1) NC program O0500 File n NC program O0600

8.2 FILE SEARCH

When the program is input from the floppy, the file to be input first must be searched.

For this purpose, proceed as follows:



File heading

Procedure

- 1 Press the EDIT or MEMORY switch on the machine operator's panel.
- 2 Press function key PROG , then the program contents display screen or program check screen appears.
- 3 Press soft key [(OPRT)].
- 4 Press the rightmost soft key (next–menu key).
- 5 Enter address N.
- **6** Enter the number of the file to search for.
 - \cdot NO

The beginning of the cassette or card is searched.

· One of N1 to N9999

Of the file Nos. 1 to 9999, a designated file is searched.

· N-9999

The file next to that accessed just before is searched.

· N-9998

When N-9998 is designated, N-9999 is automatically inserted each time a file is input or output. This condition is reset by the designation of N1,N1 to 9999, or N-9999 or reset.

7 Press soft keys [F SRH] and [EXEC]. The specified file is searched for.

Explanation

File search by N−9999

The same result is obtained both by sequentially searching the files by specifying Nos. N1 to N9999 and by first searching one of N1 to N9999 and then using the N–9999 searching method. The searching time is shorter in the latter case.

Alarm

Alarm No.	Description
	The ready signal (DR) of an input/output device is off.
86	An alarm is not immediately indicated in the CNC even when an alarm occurs during head searching (when a file is not found, or the like).
	An alarm is given when the input/output operation is performed after that. This alarm is also raised when N1 is specified for writing data to an empty floppy. (In this case, specify No.)

8.3

FILE DELETION

Files stored on a floppy can be deleted file by file as required.

File deletion

Procedure

- 1 Insert the floppy into the input/output device so that it is ready for writing.
- 2 Press the EDIT switch on the machine operator's panel.
- 3 Press function key Prog , then the program contents display screen appears.
- 4 Press soft key [(OPRT)]
- 5 Press the rightmost soft key [>] (next–menu key).
- **6** Enter address N.
- 7 Enter the number (from 1 to 9999) of the file to delete.
- 8 Press soft key [DELETE] and then press soft key [DELETE]. The file specified in step 7 is deleted.

Explanations

 File number after the file is deleted When a file is deleted, the file numbers after the deleted file are each decremented by one. Suppose that a file numbered k was deleted. In this case, files are renumbered as follows:

 $\begin{array}{ccc} \text{Before deletion} & \text{after deletion} \\ 1 \text{ to } (k>1) & 1 \text{ to } (k>1) \\ k & \text{Deleted} \\ (k+1) \text{ to } n & k \text{ to } (n>1) \end{array}$

Protect switch

Set the write protect switch to the write enable state to delete the files.

8.4 PROGRAM INPUT/OUTPUT

8.4.1 Inputting a Program

This section describes how to load a program into the CNC from a floppy or NC tape.

Inputting a program

Procedure

- 1 Make sure the input device is ready for reading.

 For the two–path control, select the tool post for which a program to be input is used with the tool post selection switch.
- 2 Press the EDIT switch on the machine operator's panel.
- **3** When using a floppy, search for the required file according to the procedure in **III–8.2**.
- 4 Press function key [PROG], then the program contents display screen or program directory screen appears.
- 5 Press soft key [(OPRT)].
- 6 Press the rightmost soft key (next-menu key).
- 7 After entering address O, specify a program number to be assigned to the program. When no program number is specified here, the program number used on the floppy or NC tape is assigned.
- 8 Press soft keys [READ] and [EXEC]
 The program is input and the program number specified in step 7 is assigned to the program.

Explanations

Collation

If a program is input while the data protect key on the machine operator's panel turns ON, the program loaded into the memory is verified against the contents of the floppy or NC tape.

If a mismatch is found during collation, the collation is terminated with an alarm (P/S No. 079).

If the operation above is performed with the data protection key turns OFF, collation is not performed, but programs are registered in memory.

 Inputting multiple programs from an NC tape When a tape holds multiple programs, the tape is read up to ER (or %).

_								_
	01111	M02;	O2222	M30;	O3333	M02;	ER(%)	

Program numbers on a NC tape

- When a program is entered without specifying a program number.
- \cdot The O-number of the program on the NC tape is assigned to the program.
 - If the program has no O–number, the N–number in the first block is assigned to the program.
- · When the program has neither an O-number nor N-number, the previous program number is incremented by one and the result is assigned to the program.
- · When the program does not have an O-number but has a five-digit sequence number at the start of the program, the lower four digits of the sequence number are used as the program number. If the lower four digits are zeros, the previously registered program number is incremented by one and the result is assigned to the program.
- When a program is entered with a program number

 The O-number on the NC tape is ignored and the specified number is
 assigned to the program. When the program is followed by additional
 programs, the first additional program is given the program number.
 Additional program numbers are calculated by adding one to the last
 program.

Program registration in the background

The method of registration operation is the same as the method of foreground operation. However, this operation registers a program in the background editing area. As with edit operation, the operations described below are required at the end to register a program in foreground program memory.

[(OPRT)] [BG-END]

Additional program input

You can input a program to be appended to the end of a registered program.

Registered program ◯1234 ;	Input program ○5678;	Program after input ◯1234 ;
	000000; 00000;	
□□□□ ; □□□ ; %	0000; 000; %	□□□ ; □□□ ; %
70	70	05678;
		00000;
		○○○ ; %

In the above example, all lines of program O5678 are appended to the end of program O1234. In this case, program number O5678 is not registered. When inputting a program to be appended to a registered program, press the **[READ]** soft key without specifying a program number in step 8. Then, press the **[CHAIN]** and **[EXEC]** soft keys.

- In entire program input, all lines of a program are appended, except for its O number.
- When canceling additional input mode, press the reset key or the [CAN] or [STOP] soft key.

- Pressing the [CHAIN] soft key positions the cursor to the end of the registered program. Once a program has been input, the cursor is positioned to the start of the new program.
- Additional input is possible only when a program has already been registered.

If an attempt has been made to register a program having the same number as that of a previously registered program, P/S alarm 073 is issued and the program cannot be registered.

 Defining the same program number as that of an existing program

Alarm

Alarm No.	Description
70	The size of memory is not sufficient to store the input programs
73	An attempt was made to store a program with an existing program number.
79	The verification operation found a mismatch between a program loaded into memory and the contents of the program on the floppy or NC tape.

8.4.2 Outputting a Program

A program stored in the memory of the CNC unit is output to a floppy or NC tape.

Outputting a program

Procedure

- 1 Make sure the output device is ready for output.

 For the two–path control, select the tool post for which a program to be output is used with the tool post selection switch.
- 2 To output to an NC tape, specify the punch code system (ISO or EIA) using a parameter.
- **3** Press the EDIT switch on the machine operator's panel.
- 4 Press function key ROG, then the program contents display screen or program directory screen appears.
- 5 Press soft key [(OPRT)].
- **6** Press the rightmost soft key [▷] (next–menu key).
- 7 Enter address O.
- **8** Enter a program number. If –9999 is entered, all programs stored in memory are output.

To output multiple programs at one time, enter a range as follows : $O\Delta\Delta\Delta\Delta, O\Box\Box\Box\Box$

Programs No. $\Delta\Delta\Delta\Delta$ to No. $\Box\Box\Box\Box$ are output.

The program library screen displays program numbers in ascending order when bit 4 (SOR) of parameter No. 3107 is set to 1.

9 Press soft keys [PUNCH] and [EXEC]
The specified program or programs are output.

Explanations (Output to a floppy)

File output location

When output is conducted to the floppy, the program is output as the new file after the files existing in the floppy. New files are to be written from the beginning with making the old files invalid, use the above output operation after the N0 head searching.

- An alarm while a program is output
- When P/S alarm (No. 86) occurs during program output, the floppy is restored to the condition before the output.
- Outputting a program after file heading

When program output is conducted after N1 to N9999 head searching, the new file is output as the designated n—th position. In this case, 1 to n—1 files are effective, but the files after the old n—th one are deleted. If an alarm occurs during output, only the 1 to n—1 files are restored.

Efficient use of memory

To efficiently use the memory in the cassette or card, output the program by setting parameter NFD (No. 0101#7,No. 0111#7 or 0121#7) to 1. This parameter makes the feed is not output, utilizing the memory efficiently.

On the memo record

Head searching with a file No. is necessary when a file output from the CNC to the floppy is again input to the CNC memory or compared with the content of the CNC memory. Therefore, immediately after a file is output from the CNC to the floppy, record the file No. on the memo.

 Punching programs in the background

Punch operation can be performed in the same way as in the foreground. This function alone can punch out a program selected for foreground operation.


<0> (Program No.) [PUNCH] [EXEC]: Punches out a specified program.

<0> H–9999I [PUNCH] [EXEC]: Punches out all programs.

Explanations (Output to an NC tape)

Format

A program is output to paper tape in the following format:



If three–feet feeding is too long, press the can key during feed punching to cancel the subsequent feed punching.

TV check

A space code for TV check is automatically punched.

ISO code

When a program is punched in ISO code, two CR codes are punched after an LF code.

```
-----LF CR CR
```


By setting NCR (bit 3 of parameter No. 0100), CRs can be omitted so that each LF appears without a CR.

Stopping the punch

Press the RESET key to stop punch operation.

Punching all programs

All programs are output to paper tape in the following format.



The sequence of the programs punched is undefined.

8.5 OFFSET DATA INPUT AND OUTPUT

8.5.1 Inputting Offset Data

Offset data is loaded into the memory of the CNC from a floppy or NC tape. The input format is the same as for offset value output. See III–8.5.2. When an offset value is loaded which has the same offset number as an offset number already registered in the memory, the loaded offset data replaces existing data.

Inputting offset data

Procedure

- 1 Make sure the input device is ready for reading.

 For the two-path control, select the tool post for which offset data to be input is used with the tool post selection switch.
- 2 Press the EDIT switch on the machine operator's panel.
- **3** When using a floppy, search for the required file according to the procedure in III–8.2.
- 4 Press function key $\begin{bmatrix} offset \\ setting \end{bmatrix}$, then the tool compensation screen appears.
- 5 Press soft keys [(OPRT)].
- 6 Press rightmost soft key (next menu key).
- 7 Press soft keys [READ] and [EXEC].
- **8** The input offset data will be displayed on the screen after completion of input operation.

8.5.2 Outputting Offset Data

All offset data is output in a output format from the memory of the CNC to a floppy or NC tape.

Outputting offset data

Procedure

- 1 Make sure the output device is ready for output. For the two-path control, select the tool post for which offset data to be input is used with the tool post selection switch.
- 2 Specify the punch code system (ISO or EIA) using a parameter.
- **3** Press the EDIT switch on the machine operator's panel.
- 4 Press function key $\begin{bmatrix} offset \\ setting \end{bmatrix}$, then the tool compensation screen appears.
- 5 Press soft key [(OPRT)].
- 6 Press the rightmost soft key (next-menu key)
- 7 Press soft keys [PUNCH] and [EXEC].
 Offset data is output in the output format described below.

Explanations

Output format

Output format is as follows:

Format

(1) For tool compensation memory A

G10 L11 P_R_;

where P_: Offset No.

R_: Tool compensation amount

(2) For tool compensation memory B

Setting/changing the geometric compensation amount

G10 L10 P_R_;

Setting/changing the wear compensation amount

G10 L11 P_R_;

(3) For tool compensation memory C

Setting/changing the geometric compensation amount for H code

G10 L10 P_R_;

Setting/changing the geometric compensation amount for D code

G10 L12 P_R_;

Setting/changing the wear compensation amount for H code

G10 L11 P_R_;

Setting/changing the wear compensation amount for D code $G10\ L13\ P\ R\$;

The L1 command may be used instead of L11 for format compatibility of the conventional CNC.

Output file name

When the floppy disk directory display function is used, the name of the output file is OFFSET.

8.6 INPUTTING AND OUTPUTTING PARAMETERS AND PITCH ERROR COMPENSATION DATA

Parameters and pitch error compensation data are input and output from different screens, respectively. This chapter describes how to enter them.

8.6.1 Inputting Parameters

Parameters are loaded into the memory of the CNC unit from a floppy or NC tape. The input format is the same as the output format. See III–8.6.2. When a parameter is loaded which has the same data number as a parameter already registered in the memory, the loaded parameter replaces the existing parameter.

Inputting parameters

Procedure

- 1 Make sure the input device is ready for reading.

 For the two–path control, select the tool post for which parameters to be input are used with the tool post selection switch.
- **2** When using a floppy, search for the required file according to the procedure in **III–8.2**.
- **3** Press the EMERGENCY STOP button on the machine operator's panel.
- 4 Press function key OFFSET SETTING
- **5** Press the soft key **[SETING]** for chapter selection, then the setting screen appears.
- **6** Enter 1 in response to the prompt for "PARAMETER WRITE (PWE)" in setting data. Alarm P/S100 (indicating that parameters can be written) appears.
- 7 Press soft key SYSTEM .
- **8** Press chapter selection soft key **[PARAM]**, then the parameter screen appears.
- 9 Press soft key [(OPRT)].
- 10 Press the rightmost soft key (next-menu key).
- 11 Press soft keys [READ] and [EXEC].
 Parameters are read into memory. Upon completion of input, the "INPUT" indicator at the lower–right corner of the screen disappears.
- 12 Press function key OFFSET SETTING
- 13 Press soft key [SETING] for chapter selection.
- **14** Enter 0 in response to the prompt for "PARAMETER WRITE (PWE)" in setting data.

- 15 Turn the power to the CNC back on.
- 16 Release the EMERGENCY STOP button on the machine operator's panel.

8.6.2 **Outputting Parameters**

All parameters are output in the defined format from the memory of the CNC to a floppy or NC tape.

Outputting parameters

Procedure

- 1 Make sure the output device is ready for output.

 For the two–path control, select the tool post for which parameters to be input are used with the tool post selection switch.
- 2 Specify the punch code system (ISO or EIA) using a parameter.
- **3** Press the EDIT switch on the machine operator's panel.
- 4 Press function key system, then the parameter screen appears.
- 5 Press chapter selection soft key [PARAM].
- 6 Press soft key [(OPRT)].
- 7 Press rightmost soft key [>] (next–menu key).
- **8** Press soft keys [PUNCH].
- **9** To output all parameters, press the **[ALL]** soft key. To output only parameters which are set to other than 0, press the **[NON–0]** soft key.
- 10 Press soft key [EXEC].
 All parameters are output in the defined format.

Explanations

Output format

Output format is as follows:

N ... P;

 $N \dots A1P \dots A2P \dots AnP \dots$;

 $N \dots P \dots$;

N ...: Parameter No.

A ...: Axis No.(n is the number of control axis)

P . . . : Parameter setting value .

 Suppressing output of parameters set to 0 To suppress the output of the following parameters, press the **[PUNCH]** soft key then **[NON–0]** soft key.

	Other than axis type	Axis type
Bit type	Parameter for which all bits are set to 0	Parameter for an axis for which all bits are set to 0.
Value type	Paramter whose value is 0.	Parameter for an axis for which the value is 0.

Output file name

When the floppy disk directory display function is used, the name of the output file is PARAMETER.

Once all parameters have been output, the output file is named ALL PARAMETER. Once only parameters which are set to other than 0 have been output, the output file is named NON-0. PARAMETER.

8.6.3 **Inputting Pitch error** compensation data

Pitch error compensation data are loaded into the memory of the CNC from a floppy or NC tape. The input format is the same as the output format. See III-8.6.4. When a pitch error compensation data is loaded which has the corresponding data number as a pitch error compensation data already registered in the memory, the loaded data replaces the existing data.

Pitch error compensation data

Procedure

- 1 Make sure the input device is ready for reading. For the two-path control, select the tool post for which pitch error compensation data to be input is used with the tool post selection switch.
- 2 When using a floppy, search for the required file according to the procedure in III-8.2.
- 3 Press the EMERGENCY STOP button on the machine operator's panel.
- 4 Press function key OFFSET SETTING .
- 5 Press the soft key **[SETING]** for chapter selection.
- Enter 1 in response to the prompt for writing parameters (PWE). Alarm P/S100 (indicating that parameters can be written) appears.
- 7 Press soft key | SYSTEM | .
- 8 Press the rightmost soft key (next-menu key)and press chapter selection soft key [PITCH].
- 9 Press soft key [(OPRT)].
- 10 Press the rightmost soft key (next-menu key).
- 11 Press soft keys [READ] and [EXEC]. Parameters are read into memory. Upon completion of input, the "INPUT" indicator at the lower–right corner of the screen disappears.
- 12 Press function key OFFSET SETTING
- 13 Press soft key [SETING] for chapter selection.
- 14 Enter 0 in response to the prompt for "PARAMETER WRITE (PWE)" in setting data.

- 15 Turn the power to the CNC back on.
- **16** Release the EMERGENCY STOP button on the machine operator's panel.

Explanations

Pitch error compensation

Parameters 3620 to 3624 and pitch error compensation data must be set correctly to apply pitch error compensation correctly (See III–11.5.2).

8.6.4 Outputting Pitch Error Compensation Data

All pitch error compensation data are output in the defined format from the memory of the CNC to a floppy or NC tape.

Outputting Pitch Error Compensation Data

Procedure

- 1 Make sure the output device is ready for output. For the two-path control, select the tool post for which pitch error compensation data to be input is used with the tool post selection switch.
- 2 Specify the punch code system (ISO or EIA) using a parameter.
- **3** Press the EDIT switch on the machine operator's panel.
- 4 Press function key SYSTEM.
- 5 Press the rightmost soft key [>] (next-menu key) and press chapter selection soft key [PITCH].
- 6 Press soft key [(OPRT)].
- 7 Press rightmost soft key (next-menu key).
- 8 Press soft keys [PUNCH] and [EXEC].
 All parameters are output in the defined format.

Explanations

Output format

Output format is as follows:

N 10000 P; N 11023 P;

 $N \ldots$: Pitch error compensation point No. +10000

P . . . : Pitch error compensation data

Output file name

When the floppy disk directory display function is used, the name of the output file is "PITCH ERROR".

8.7 INPUTTING/OUTPUTTING CUSTOM MACRO COMMON VARIABLES

8.7.1

Inputting Custom Macro Common Variables

The value of a custom macro common variable (#500 to #999) is loaded into the memory of the CNC from a floppy or NC tape. The same format used to output custom macro common variables is used for input. See III–8.7.2. For a custom macro common variable to be valid, the input data must be executed by pressing the cycle start button after data is input. When the value of a common variable is loaded into memory, this value replaces the value of the same common variable already existing (if any) in memory.

Inputting custom macro common variables

Procedure

- 1 Register the program which has been output, as described in Section III–8.7.2, in memory according to the program input procedure described in Section III–8.4.1.
- **2** Press the MEMORY switch on the machine operator's panel upon completing input.
- 3 Press the cycle start button to execute the loaded program.
- 4 Display the macro vriable screen to chek whether the values of the common variables have been set correctly.

Display of the macro variable screen

- · Press function key OFFSET SETTING.
- · Press the rightmost soft key (next-menu key).
- · Press soft key [MACRO].
- · Select a variable with the page keys or numeric keys and soft key [NO.SRH].

Explanations

• Common variables

The common variables (#500 to #531) can be input and output. When the option for adding a common variable is specified, values from #500 to #999 can be input and output. #100 to #199 can be input and output when bit 3 (PU5) of parameter No. 6001 is set to 1.

8.7.2 Outputting Custom

Macro Common Variable

Custom macro common variables (#500 to #999) stored in the memory of the CNC can be output in the defined format to a floppy or NC tape.

Outputting custom macro common variable

Procedure

- 1 Make sure the output device is ready for output.
- 2 Specify the punch code system (ISO or EIA) using a parameter.
- **3** Press the EDIT switch on the machine operator's panel.
- 4 Press function key OFFSET SETTING
- 5 Press the rightmost soft key (next-menu key), then press soft key [MACRO].
- 6 Press soft key [(OPRT)].
- 7 Press the rightmost soft key (next-menu key).
- 8 Press soft keys [PUNCH] and [EXEC].
 Common variables are output in the defined format.

Explanations

Output format

The output format is as follows:

- (1) The precision of a variable is maintained by outputting the value of the variable as <expression>.
- (2) Undefined variable
- (3) When the value of a variable is 0
- Output file name

When the floppy disk directory display function is used, the name of the output file is "MACRO VAR".

• Common variable

The common variables (#500 to #531) can be input and output.

When the option for adding a common variable is specified, values from #500 to #999 can be input and output.

#100 to #199 can be input and output when bit 3 (PU5) of parameter No. 6001 is set to 1.

8.8 DISPLAYING DIRECTORY OF FLOPPY CASSETTE

On the floppy directory display screen, a directory of the FANUC Handy File, FANUC Floppy Cassette, or FANUC FA Card files can be displayed. In addition, those files can be loaded, output, and deleted.

DIRECTORY (FLOPPY) NO. FILE NAME	O0001 N00000 (METER) VOL
0001 PARAMETER 0002 00001 0003 00002 0004 00010 0005 00040 0006 00050 0007 00100 0008 01000 0009 09500	58.5 1.9 1.9 1.3 1.3 1.9 1.9
EDIT *** ** *** (PRGRM) (DIR	11 : 51 : 12 (OPRT)

8.8.1 Displaying the Directory

Displaying the directory of floppy cassette files

Procedure 1

Use the following procedure to display a directory of all the files stored in a floppy:

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key PROG .
- 3 Press the rightmost soft key (next-menu key).
- 4 Press soft key [FLOPPY].
- 5 Press page key page or page or
- **6** The screen below appears.

```
DIRECTORY (FLOPPY)
                                            O0001 N00000
  NO. FILE NAME
                                             (METER) VOL
  0001 PARAMETER
                                                    58.5
 0002 O0001
                                                      1.9
 0003 O0002
                                                      1.9
 0004 O0010
                                                      1.3
 0005 O0040
                                                      1.3
 0006 O0050
                                                      1.9
 0007 O0100
                                                      1.9
 0008 O1000
                                                      1.9
 0009 O9500
                                                      1.6
 ig( \ \mathsf{F} \ \mathsf{SRH} \ ig) ig( \ \mathsf{READ} \ ig) ig( \ \mathsf{PUNCH} \ ig) ig( \ \mathsf{DELETE} \ ig) ig(
```

Fig.8.8.1 (a)

7 Press a page key again to display another page of the directory.

Procedure 2

Use the following procedure to display a directory of files starting with a specified file number :

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key Prog .
- 3 Press the rightmost soft key (next–menu key).
- 4 Press soft key [FLOPPY].
- 5 Press soft key [(OPRT)].
- **6** Press soft key [F SRH].
- 7 Enter a file number.
- **8** Press soft keys [F SET] and [EXEC].
- **9** Press a page key to display another page of the directory.
- 10 Press soft key [CAN] to return to the soft key display shown in the screen of Fig 8.8.1 (a).

```
DIRECTORY (FLOPPY)
                                O0001 N00000
                                 (METER) VOL
  NO. FILE NAME
  0005 O0040
                                        1.3
  0006 O0050
                                        1.9
  0007 O0100
                                        1.9
  0008 O1000
                                        1.9
  0009 O9500
                                        1.6
SEARCH
FILE NO. =
                            11:54:19
                          )( CAN )( EXEC )
F SET ][
```

Fig.8.8.1 (b)

Explanations

Screen fields and their meanings


NO:Displays the file number

FILE NAME: Displays the file name.

(METER) : Converts and prints out the file capacity to paper tape

length. You can also produce H

(FEET) I by setting the INPUT UNIT to INCH of the setting data.VOL. : When the file is multi-volume, that state is displayed.



8.8.2 Reading Files

The contents of the specified file number are read to the memory of NC.

Reading files

Procedure

- 1 Press the EDIT switch on the machine operator's panel. For the two–path control, select the tool post for which a file is to be input in memory with the tool post selection switch.
- 2 Press function key Prog .
- 3 Press the rightmost soft key (next-menu key).
- 4 Press soft key [FLOPPY].
- 5 Press soft key [(OPRT)].
- **6** Press soft key [READ].

```
DIRECTORY (FLOPPY)
                               O0001 N00000
 NO. FILE NAME
                               (METER) VOL
 0001 PARAMETER
                                     58.5
 0002 O0001
                                      1.9
 0003 O0002
                                      1.9
 0004 O0010
                                      1.3
 0005 O0040
                                      1.3
 0006 O0050
                                      1.9
 0007 O0100
                                      1.9
 0008 O1000
                                      1.9
 0009 O9500
                                      1.6
READ
                          PROGRAM NO. =
FILE NO. =
                           11:55:04
(FSET)(OSET)(STOP)(CAN)(EXEC)
```

- 7 Enter a file number.
- **8** Press soft key [F SET].
- **9** To modify the program number, enter the program number, then press soft key **[O SET]**.
- 10 Press soft key **[EXEC]**. The file number indicated in the lower–left corner of the screen is automatically incremented by one.
- 11 Press soft key [CAN] to return to the soft key display shown in the screen of Fig. 8.8.1.(a).

8.8.3 Outputting Programs

Any program in the memory of the CNC unit can be output to a floppy as a file.

Outputting programs

Procedure

- 1 Press the EDIT switch on the machine operator's panel. For the two–path control, select the tool post for which a file is to be input in memory with the tool post selection switch.
- 2 Press function key PROG
- 3 Press the rightmost soft key (next-menu key).
- 4 Press soft key [FLOPPY].
- 5 Press soft key [(OPRT)].
- 6 Press soft key [PUNCH].

```
DIRECTORY (FLOPPY)
                               O0002 N01000
 NO. FILE NAME
                               (METER) VOL
 0001 PARAMETER
                                     58.5
 0002 O0001
                                      1.9
 0003 O0002
                                      1.9
 0004 O0010
                                      1.3
 0005 O0040
                                      1.3
 0006 O0050
                                      1.9
 0007 O0100
                                      1.9
 0008 O1000
                                      1.9
 0009 O9500
                                      1.6
PUNCH
                          PROGRAM NO. =
FILE NO. =
(fSET)(OSET)(STOP)(CAN)(EXEC)
```

- 7 Enter a program number. To write all programs into a single file, enter –9999 in the program number field. In this case, the file name "ALL.PROGRAM" is registered.
- **8** Press soft key [O SET].
- 9 Press soft key [EXEC]. The program or programs specified in step 7 are written after the last file on the floppy. To output the program after deleting files starting with an existing file number, key in the file number, then press soft key [F SET] followed by soft key [EXEC].
- 10 Press soft key [CAN] to return to the soft key display shown in the screen of Fig.8.8.1(a).

8.8.4 **Deleting Files**

The file with the specified file number is deleted.

Deleting files

Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- Press function key | PROG | .
- 3 Press the rightmost soft key \triangleright (next–menu key).
- 4 Press soft key [FLOPPY].
- 5 Press soft key [(OPRT)].
- **6** Press soft key [DELETE].

```
DIRECTORY (FLOPPY)
                                O0001 N00000
                                (METER) VOL
 NO. FILE NAME
  0001 PARAMETER
                                      58.5
  0002 O0001
                                       1.9
  0003 O0002
                                       1.9
  0004 O0010
                                       1.3
  0005 O0040
                                       1.3
  0006 O0050
                                       1.9
  0007 O0100
                                       1.9
  0008 O1000
                                       1.9
  0009 O9500
                                       1.6
DELETE
FILE NO. =
              NAME=
                           11:55:51
                         ) CAN ) EXEC
```

Specify the file to be deleted.

When specifying the file with a file number, type the number and press soft key [F SET]. When specifying the file with a file name, type the name and press soft key [F NAME].

8 Press soft key **[EXEC]**.

The file specified in the file number field is deleted. When a file is deleted, the file numbers after the deleted file are each decremented by one.

9 Press soft key **[CAN]** to return to the soft key display shown in the screen of Fig. 8.8.1(a).

Restrictions

 Inputting file numbers and program numbers with keys If **[F SET]** or **[O SET]** is pressed without key inputting file number and program number, file number or program number shows blank. When 0 is entered for file numbers or program numbers, 1 is displayed.

I/O devices

To use channel 0 ,set a device number in parameter (No. 102). Set the I/O device number to parameter (No. 112) when cannel 1 is used. Set it to (No. 0122) when channel 2 is used.

Significant digits

For the numeral input in the data input area with FILE No. and PROGRAM No., only lower 4 digits become valid.

Collation

When the data protection key on the machine operator's panel is ON, no programs are read from the floppy. They are verified against the contents of the memory of the CNC instead.

ALARM

Alarm No.	Contents
71	An invalid file number or program number was entered. (Specified program number is not found.)
79	Verification operation found a mismatch between a program loaded into memory and the contents of the floppy
86	The dataset–ready signal (DR) for the input/output device is turned off. (The no file error or duplicate file error occurred on the input/output device because an invalid file number, program number, or file name was entered.


8.9 OUTPUTTING A PROGRAM LIST FOR A SPECIFIED GROUP

CNC programs stored in memory can be grouped according to their names, thus enabling the output of CNC programs in group units. Section III–11.3.3 explains the display of a program listing for a specified group.

Procedure for Outputting a Program List for a Specified Group

Procedure

1 Display the program list screen for a group of programs, as described in Section III–11.3.2.



- 2 Press the **[(OPRT)]** operation soft key.
- 3 Press the right–most soft key (continuous menu key).
- 4 Press the [PUNCH] operation soft key.
- 5 Press the [AL-GRP] operation soft key.

The CNC programs in the group for which a search is made are output. When these programs are output to a floppy disk, they are output to a file named GROUP.PROGRAM.



8.10 DATA INPUT/OUTPUT ON THE ALL IO SCREEN

To input/output a particular type of data, the corresponding screen is usually selected. For example, the parameter screen is used for parameter input from or output to an external input/output unit, while the program screen is used for program input or output. However, programs, parameters, offset data, and macro variables can all be input and output using a single common screen, that is, the ALL IO screen.




Fig. 8.10 ALL IO screen (when channel 3 is being used for input/output)

8.10.1 Setting Input/Output–Related Parameters

Input/output-related parameters can be set on the ALL IO screen. Parameters can be set, regardless of the mode.

Setting input/output-related parameters

Procedure

- 1 Press function key System .
- 2 Press the rightmost soft key (next-menu key) several times.
- 3 Press soft key [ALL IO] to display the ALL IO screen.

NOTE

- 1 If program or floppy is selected in EDIT mode, the program directory or floppy screen is displayed.
- 2 When the power is first turned on, program is selected by default.

```
READ/PUNCH (PROGRAM)
                                    O1234 N12345
I/O CHANNEL
                      3
                            TV CHECK
DEVICE NUM.
                            PUNCH CODE
                                            ISO
BAUDRATE
                   4800
                            INPUT CODE
                                          ASCII
STOP BIT
                     2
                            FEED OUTPUT
                                          FEED
NULL INPUT (EIA)
                            EOB OUTPUT (ISO) CR
                    NO
TV CHECK (NOTES)
                    ON
                            BAUDRATE CLK. INNER
                    OFF
CD CHECK (232C)
                            RESET/ALARM
                                            ON
PARITY BIT
                    OFF
                            SAT COMMAND
                                          HOST
INTERFACE
                  RS422
                            COM PROTCOL
                                             Α
END CODE
                    EXT
                            COM CODE
                                          ASCII
(0:EIA 1:ISO)>1
                                   12:34:56
 PRGRM | PARAM | OFFSET | MACRO | (OPRT)
```

NOTE

Baud rate clock, CD check (232C), reset/alarm report, and the parity bit for parameter No. 134, as well as the communication code, end code, communication protocol, interface, and SAT command for parameter No. 135 are displayed only when channel 3 is being used for input/output.

- 4 Select the soft key corresponding to the desired type of data (program, parameter, and so forth).
- 5 Set the parameters corresponding to the type of input/output unit to be used. (Parameter setting is possible regardless of the mode.)

8.10.2 Inputting and Outputting Programs

A program can be input and output using the ALL IO screen. When entering a program using a cassette or card, the user must specify the input file containing the program (file search).

File search

Procedure

- 1 Press soft key **[PRGRM]** on the ALL IO screen, described in Section 8.10.1.
- 2 Select **EDIT** mode. A program directory is displayed.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.
 - · A program directory is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.

O0001 N00010

PROGRAM (NUM.) MEMORY (CHAR.)
USED : 60 3321
FREE : 2 429

O0010 O0001 O0003 O0002 O0555 O0999
O0062 O0004 O0005 O1111 O0969 O6666
O0021 O1234 O0588 O0020 O0040

>_
EDIT **** *** *** 14:46:09

(F SRH) (READ) (PUNCH) (DELETE) ((OPRT))

- 4 Enter address N.
- 5 Enter the number of the file to be found.
 - · N0

The first floppy file is found.

One of N1 to N9999

Among the files numbered from 1 to 9999, a specified file is found.


· N-9999

The file immediately after that used most recently is found.

· N-9998

When –9998 is specified, the next file is found. Then, each time a file input/output operation is performed, N–9999 is automatically inserted. This means that subsequent files can be sequentially found automatically.

This state is canceled by specifying N0, N1 to N9999, or N-9999, or upon a reset.



6 Press soft keys [F SRH] and [EXEC]. The specified file is found.

Explanations

Difference between N0 and N1

When a file already exists in a cassette or card, specifying N0 or N1 has the same effect. If N1 is specified when there is no file on the cassette or card, an alarm is issued because the first file cannot be found. Specifying N0 places the head at the start of the cassette or card, regardless of whether the cassette/card already contains files. So, no alarm is issued in this case. N0 can be used, for example, when a program is written into a new cassette or card, or when a previously used cassette or card is used once all the files it contains have been erased.

Alarm issue during file search

If an alarm (file search failure, for example) is generated during file search, the CNC does not issue an alarm immediately. However, a P/S alarm (No. 086) is issued if input/output is subsequently performed on that file.


File search using N-9999

Instead of sequentially searching for files by specifying actual file numbers every time, the user can specify the first file number, then find the subsequent files by specifying N–9999. When N–9999 is specified, the time required for file search can be reduced.

Inputting a program

Procedure

- 1 Press soft key **[PRGRM]** on the ALL IO screen, described in Section 8.10.1.
- **2** Select EDIT mode. A program directory is displayed.
- 3 Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.
 - · A program directory is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.



- 4 To specify a program number to be assigned to an input program, enter address O, followed by the desired program number.

 If no program number is specified, the program number in the file or on the NC tape is assigned as is.
- Press soft key [READ], then [EXEC].

The program is input with the program number specified in step 4 assigned.

To cancel input, press soft key [CAN].


To stop input prior to its completion, press soft key [STOP].



Outputting programs

Procedure

- 1 Press soft key **[PRGRM]** on the ALL IO screen, described in Section 8.10.1.
- **2** Select EDIT mode. A program directory is displayed.
- 3 Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.
 - · A program directory is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.



- 4 Enter address O.
- Enter a desired program number.

 If −9999 is entered, all programs in memory are output.

 To output a range of programs, enter ΟΔΔΔΔ, Ο□□□□. The programs numbered from ΔΔΔΔ to □□□□ are output.

 When bit 4 (SOR) of parameter No. 3107 for sorted display is set to 1 on the program library screen, programs are output in order, starting from those having the smallest program numbers.
- 6 Press soft key [PUNCH], then [EXEC].
 The specified program or programs are output. If steps 4 and 5 are omitted, the currently selected program is output.
 To cancel output, press soft key [CAN].
 To stop output prior to its completion, press soft key [STOP].

Deleting files

Procedure

- 1 Press soft key **[PRGRM]** on the ALL IO screen, described in Section 8.10.1.
- **2** Select EDIT mode. A program directory is displayed.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.
 - · A program directory is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.

O0001 N00010

PROGRAM (NUM.) MEMORY (CHAR.)
USED : 60 3321
FREE : 2 429

O0010 O0001 O0003 O0002 O0555 O0999
O0062 O0004 O0005 O1111 O0969 O6666
O0021 O1234 O0588 O0020 O0040

>_
EDIT **** *** *** *** 14:46:09

(F SRH) (READ) (PUNCH) (DELETE) ((OPRT))

- 4 Press soft key [DELETE].
- 5 Enter a file number, from 1 to 9999, to indicate the file to be deleted.
- 6 Press soft key **[EXEC]**. The k-th file, specified in step 5, is deleted.



Explanations

File numbers after deletion

After deletion of the k-th file, the previous file numbers (k+1) to n are decremented by 1 to k to (n-1).

Before deletion	After deletion
1 to (k–1)	1 to (k-1)
K	Delete
(k+1) to n	k to (n−1)

• Write protect

Before a file can be deleted, the write protect switch of the cassette must be set to make the cassette writable.


8.10.3 Inputting and Outputting Parameters

Parameters can be input and output using the ALL IO screen.

Inputting parameters

Procedure

- 1 Press soft key **[PARAM]** on the ALL IO screen, described in Section 8.10.1.
- 2 Select EDIT mode.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.





4 Press soft key [READ], then [EXEC].

The parameters are read, and the "INPUT" indicator blinks at the lower-right corner of the screen. Upon the completion of input, the "INPUT" indicator is cleared from the screen.

To cancel input, press soft key [CAN].

Outputting parameters

Procedure

- 1 Press soft key **[PARAM]** on the ALL IO screen, described in Section 8.10.1.
- 2 Select EDIT mode.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.

READ/PUNCH (PAR	AMETER)	O123	4 N12345
I/O CHANNEL	3	TV CHECK	OFF
DEVICE NUM.	0	PUNCH CODE	ISO
BAUDRATE	4800	INPUT CODE	ASCII
STOP BIT	2	FEED OUTPUT	FEED
NULL INPUT (EIA)	NO	EOB OUTPUT (IS	SO) CR
TV CHECK (NOTES)	ON	BAUDRATE CLK.	INNER
CD CHECK (232C)	OFF	RESET/ALARM	ON
PARITY BIT	OFF	COM CODE	ASCII
END CODE	EXT	COM PROTCOL	Α
INTERFACE	RS422	SAT COMMAND	HOST
(0:EIA 1:ISO)>1_			
MDI **** ***	*** ***	12:34:	56
()(REAI	D)(PUNC	4)()()



4 Press soft key [PUNCH], then [EXEC].

The parameters are output, and the "OUTPUT" indicator blinks at the lower–right corner of the screen. Upon the completion of output, the "OUTPUT" indicator is cleared from the screen.

To cancel output, press soft key [CAN].


8.10.4 Inputting and Outputting Offset Data

Offset data can be input and output using the ALL IO screen.

Inputting offset data

Procedure

- 1 Press soft key [OFFSET] on the ALL IO screen, described in Section 8.10.1.
- **2** Select EDIT mode.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.





4 Press soft key [READ], then [EXEC].

The offset data is read, and the "INPUT" indicator blinks at the lower-right corner of the screen.

Upon the completion of input, the "INPUT" indicator is cleared from the screen.


To cancel input, press soft key [CAN].

Outputting offset data

Procedure

- 1 Press soft key **[OFFSET]** on the ALL IO screen, described in Section 8.10.1.
- 2 Select EDIT mode.
- 3 Press soft key **[(OPRT)]**. The screen and soft keys change as shown below

READ/PUNCH (OFF	SET)	O1234	4 N12345
I/O CHANNEL DEVICE NUM. BAUDRATE STOP BIT NULL INPUT (EIA) TV CHECK (NOTES) CD CHECK (232C) PARITY BIT END CODE INTERFACE	3 0 4800 2 NO ON OFF OFF EXT RS422	TV CHECK PUNCH CODE INPUT CODE FEED OUTPUT EOB OUTPUT (IS BAUDRATE CLK. RESET/ALARM COM CODE COM PROTCOL SAT COMMAND	FEED SO) CR INNER ON ASCII A
(0:EIA 1:ISO)>1_ MDI **** *** () (REAI	*** *** D)(PUNCH	12:34: H) () (56



4 Press soft key [PUNCH], then [EXEC].

The offset data is output, and the "OUTPUT" indicator blinks at the lower–right corner of the screen. Upon the completion of output, the "OUTPUT" indicator is cleared from the screen.

To cancel output, press soft key [CAN].


8.10.5 Outputting Custom Macro Common Variables


Custom macro common variables can be output using the ALL IO screen.

Outputting custom macro common variables

Procedure

- 1 Press soft key [MACRO] on the ALL IO screen, described in Section 8.10.1.
- 2 Select EDIT mode.
- **3** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.





4 Press soft key [PUNCH], then [EXEC].

The custom macro common variables are output, and the "OUTPUT" indicator blinks at the lower-right corner of the screen. Upon the completion of output, the "OUTPUT" indicator is cleared from the screen.

To cancel output, press soft key [CAN].

NOTE

To input a macro variable, read the desired custom macro statement as a program, then execute the program.


8.10.6 Inputting and Outputting Floppy Files

The ALL IO screen supports the display of a directory of floppy files, as well as the input and output of floppy files.


Displaying a file directory

Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [FLOPPY].
- 3 Select EDIT mode. The floppy screen is displayed.
- **4** Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.
 - · The floppy screen is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.



- 5 Press soft key [F SRH].
- **6** Enter the number of the desired file, then press soft key [**F SET**].
- 7 Press soft key **[EXEC]**. A directory is displayed, with the specified file uppermost. Subsequent files in the directory can be displayed by pressing the page key.



```
READ/PUNCH (FLOPPY)
                                         O1234 N12345
  No.
         FILE NAME
                                           (Meter) VOL
         PARAMETER
ALL.PROGRAM
00001
 0001
                                           46.1
 0002
0003
                                           12.3
                                            1.9
 0004
          O0002
                                            1.9
 0005
          O0003
                                            1.9
         O0004
O0005
O0010
 0006
                                            1.9
 0007
                                            1.9
 8000
                                            1.9
 0009
          O0020
                                            1.9
 F SRH
    File No.=2
 >2_
                                         12:34:56
EDIT
                     )(
                                )( CAN )( EXEC )
```


A directory in which the first file is uppermost can be displayed simply by pressing the page key. (Soft key **[F SRH]** need not be pressed.)

Inputting a file

Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [FLOPPY].
- 3 Select EDIT mode. The floppy screen is displayed.
- 4 Press soft key [(OPRT)]. The screen and soft keys change as shown below

The floppy screen is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.



- 5 Press soft key [READ].
- **6** Enter the number of a file or program to be input.
 - Setting a file number: Enter the number of the desired file, then press soft key **[F SET]**.
 - · Setting a program number: Enter the number of the desired program, then press soft key [O SET].
- 7 Press soft key [EXEC].

The specified file or program is read, and the "INPUT" indicator blinks at the lower-right corner of the screen. Upon the completion of input, the "INPUT" indicator is cleared from the screen.


(FSET) (OSET) (STOP) (CAN) (EXEC)

Outputting a file

Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [FLOPPY].
- 3 Select EDIT mode. The floppy screen is displayed.
- 4 Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.

The floppy screen is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.



- 5 Press soft key [PUNCH].
- 6 Enter the number of the program to be output, together with a desired output file number.
 - · Setting a file number: Enter the number of the desired file, then press soft key [F SET].
 - · Setting a program number: Enter the number of the desired program, then press soft key [O SET].
- 7 Press soft key [EXEC].

The specified program is output, and the "OUTPUT" indicator blinks at the lower-right corner of the screen. Upon the completion of output, the "OUTPUT" indicator is cleared from the screen.

If no file number is specified, the program is written at the end of the currently registered files.


(FSET) (OSET) (STOP) (CAN) (EXEC)

Deleting a file


Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [FLOPPY].
- **3** Select EDIT mode. The floppy screen is displayed.
- 4 Press soft key **[(OPRT)]**. The screen and soft keys change as shown below.

The floppy screen is displayed only in EDIT mode. In all other modes, the ALL IO screen is displayed.




- 5 Press soft key [DELETE].
- **6** Enter the number of the desired file, then press soft key **[F SET]**.
- 7 Press soft key **[EXEC]**. The specified file is deleted. After the file has been deleted, the subsequent files are shifted up.



8.10.7 Memory Card Input/Output

Data held in CNC memory can be saved to a memory card in MS–DOS format. Data held on a memory card can be loaded into CNC memory. A save or load operation can be performed using soft keys while the CNC is operating.

Loading can be performed in either of two ways. In the first method, all saved memory data is loaded. In the second method, only selected data is loaded.



- The CNC memory size (*1) is displayed at all times.
- · When no memory card is inserted, the message field (*4) displays a message prompting the user to insert a memory card, but does not display the memory card states (*2 and *3).
- · If an inserted memory card is invalid (if there is no attribute memory, or if the attribute memory does not contain any device information), the message field (*4) displays an error message, but does not display the memory card states (*2 and *3).


Saving memory data

Data held in CNC memory can be saved to a memory card in MS–DOS format.

Saving memory data

Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [M-CARD].
- 3 Place the CNC in the emergency stop state.
- **4** When a memory card is inserted, the state of the memory card is displayed as shown below.





- 5 Press soft key [SAVE].
- 6 A message prompting the user to confirm the operation is displayed. Press soft key **[EXEC]** to execute the save operation.
- 7 As the data is being saved to the card, the message "RUNNING" blinks, and the number of bytes saved is displayed in the message field.
- **8** Once all data has been saved to the card, the message "COMPLETED" is displayed in the message field, with the message "PRESS RESET KEY." displayed on the second line.
- **9** Press the RESET key. The displayed messages are cleared from the screen, and the display of the memory card state is replaced with that of the saved file.

NOTE

All CNC memory data is saved to a memory card. CNC memory data cannot be saved selectively.

Explanations

• File name

The file name used for save operation is determined by the amount of SRAM mounted in the CNC.

SRAM file

Amount of SRAM	256KB	0.5 MB
Number of files	SRAM256A. FDB	SRAM0_5A. FDB

Canceling saving

To cancel file save prior to its completion, press the $\fbox{\tt RESET}$ key on the MDI panel.

Memory card replacement request

When the memory card has less than 512K bytes of free space, a memory card replacement request is displayed. Insert a new memory card.

Loading Data into Memory (Restoration)


CNC memory data that has been saved to a memory card can be loaded (restored) back into CNC memory.

CNC memory data can be loaded in either of two ways. In the first method, all saved memory data is loaded. In the second method, only selected data is loaded.

Loading memory data

Procedure


- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [M-CARD].
- **3** Place the CNC in the emergency stop state.
- **4** When a memory card is inserted, the state of the memory card is displayed as shown below.




- 5 Press soft key [LOAD].
- 6 With cursor keys 1 and 1, select the file to be loaded from the memory card.

A system having 1.0MB or 2.5MB of CNC RAM may require the loading of multiple files. All or selective data load can be specified for each file.

7 To perform selective data loading, press soft key [SELECT], then select the data to be loaded. Each time the soft key is pressed, the information displayed changes cyclically, as shown below.



8 After checking the file selection, press soft key **[EXEC]**.



- **9** During loading, the message "RUNNING" blinks, and the number of bytes loaded is displayed in the message field.
- 10 Upon the completion of loading, the message "COMPLETED" is displayed in the message field, with the message "PRESS RESET KEY." displayed on the second line.
- 11 Press the RESET key. The messages are cleared from the screen.

Explanations

Canceling loading

To cancel file load prior to its completion, press the RESET key on the MDI panel.

Turning off the power after loading

off, then back on, for the load to become effective. When necessary, the message "TURN OFF POWER." is displayed in the message field.

Depending on the type of data, the system power may have to be turned

Parameter/PMC data

Before performing parameter/PMC data load, enable parameter write.

Program/offset data

Before performing program/offset data load, set the data protection key, on the machine operator's panel, to the ON position.

 Loading files from multiple memory cards When multiple files are to be loaded from multiple memory cards, a message requesting memory card replacement is displayed.

NOTE

If the saved data and CNC system onto which the saved data is to be loaded do not satisfy the conditions described below, an error message is displayed in the message field, and loading is disabled. Note, however, that in selective loading, even if the CNC system structure differs from that of a saved file, the file is never the less loaded.

- The size of a saved file does not match the size of CNC
- · The saved file has a different extension.


Memory card formatting

Before a file can be saved to a memory card, the memory card must be formatted.


Formatting a memory card

Procedure

- 1 Press the rightmost soft key (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- 2 Press soft key [M-CARD].
- 3 Place the CNC in the emergency stop state.
- **4** When a memory card is inserted, the state of the memory card is displayed as shown below.



- 5 Press soft key [FORMAT].
- A message prompting the user to confirm the operation is displayed. Press soft key **[EXEC]** to execute the formatting operation.
- 7 As formatting is being performed, the message "FORMATTING" blinks.
- **8** Upon the completion of formatting, the message "COMPLETED" is displayed in the message field.




Deleting files

Unnecessary saved files can be deleted from a memory card.


Deleting files

Procedure

- 1 Press the rightmost soft key [>] (next-menu key) on the ALL IO screen, described in Section 8.10.1.
- Press soft key [M-CARD].
- Place the CNC in the emergency stop state.
- When a memory card is inserted, the state of the memory card is displayed as shown below.



Press soft key [DELETE].



- After checking the file selection, press soft key **[EXEC]**.
- As detection is being performed, the message "DELETING" blinks in the message field.
- Upon the completion of deletion, the message "COMPLETED" is displayed in the message field

NOTE

An SRAM of 1M bytes or more will contain multiple files. To delete the contents of such an SRAM, delete all the contained files.



Messages and restrictions

Messages

Message	Description
INSERT MEMORY CARD.	No memory card is inserted.
UNUSABLE MEMORY CARD	The memory card does not contain device information.
FORMAT MEMORY CARD.	The memory card is not formatted. Format the memory card before use.
THE FILE IS UNUSABLE.	The format or extension of the file to be loaded is invalid. Alternatively, the data stored on the memory card does not match the CNC memory size.
REPLACE MEMORY CARD.	Replace the memory card.
FILE SYSTEM ERROR □□□	An error occurred during file system processing. □□□ represents a file system error code.
SET EMERGENCY STOP STATE.	Save/load operation is enabled in the emergency stop state only.
WRITE-PROTECTED	Save operation: The protect switch of the memory card is set to the disabled position. Load operation: Parameter write is disabled.
VOLTAGE DECREASED.	The battery voltage of the memory card has dropped. (The battery requires replacement.)
DEVICE IS BUSY.	Another user is using the memory card. Alternatively, the device cannot be accessed because automatic operation is in progress.
SRAM → MEMORY CARD?	This message prompts the user to confirm the start of data saving.
MEMORY CARD → SRAM?	This message prompts the user to confirm the start of data loading.
DO YOU WANT TO DELETE FILE(S)?	This message prompts the user to confirm the start of deletion.
DO YOU WANT TO PERFORM FORMAT- TING?	This message prompts the user to confirm the start of formatting.
SAVING	Saving is currently being performed.
LOADING	Loading is currently being performed.
DELETING	File deletion is currently being performed.
FORMATTING	Memory card formatting is currently being performed.
COMPLETED	Save or load processing has been completed.
PRESS RESET KEY.	Press the RESET key.
TURN OFF POWER.	Turn the power off, then back on again.

File system error codes

Code	Meaning
102	The memory card does not have sufficient free space.
105	No memory card is mounted.
106	A memory card is already mounted.
110	The specified directory cannot be found.
111	There are too many files under the root directory to allow a directory to be added.
114	The specified file cannot be found.
115	The specified file is protected.
117	The file has not yet been opened.
118	The file is already open.
119	The file is locked.
122	The specified file name is invalid.
124	The extension of the specified file is invalid.
129	A non–corresponding function was specified.
130	The specification of a device is invalid.
131	The specification of a pathname is invalid.
133	Multiple files are open at the same time.
135	The device is not formatted.
140	The file has the read/write disabled attribute.

Restrictions

Memory card size

The size of the memory card to be used must be larger than that of the RAM module mounted in the CNC. The size of the RAM module can be determined from the system configuration screen.

 Memory card specifications Use a memory card that conforms to PCMCIA Ver. 2.0, or JEIDA Ver. 4.1.

Attribute memory

A memory card which has no attribute memory, or no device information in its attribute memory, cannot be used.

Compatibility of saved data

Data saved to a memory card is compatible only with CNCs that have the same hardware configuration and the same option configuration.

• Flash ROM card

A flash ROM card can be used only for data loading.

 Operation during automatic operation During automatic operation, the contents of a memory card cannot be displayed, formatted, or deleted. To enable these operations, therefore, stop or suspend automatic operation.

8.11 DATA INPUT/OUTPUT USING A MEMORY CARD

By setting the I/O channel (parameter No. 20) to 4, files on a memory card can be referenced, and different types of data such as part programs, parameters, and offset data on a memory card can be input and output in text file format.

The major functions are listed below.

- Displaying a directory of stored files

 The files stored on a memory card can be displayed on the directory screen.
- · Searching for a file

A search is made for a file on a memory card and, if found, it is displayed on the directory screen.

· Reading a file


Text-format files can be read from a memory card.

· Writing a file

Data such as part programs can be stored to a memory card in text file format.

· Deleting a file


A file can be selected and deleted from a memory card.




Displaying a directory of stored files

Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key PROG
- 3 Press the rightmost soft key (continuous–menu key).
- 4 Press soft key **[CARD]**. The screen shown below is displayed. Using page keys 1 and 1, the screen can be scrolled.



5 Comments relating to each file can be displayed by pressing soft key [DIR+].



6 Repeatedly pressing soft key [DIR+] toggles the screen between the display of comments and the display of sizes and dates.
Any comment described after the O number in the file is displayed.
Up to 18 characters can be displayed on the screen.

Searching for a file

Procedure

(FSRH) (FREAD) (N READ) (PUNCH) (DELETE)

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key Prog .
- 3 Press the rightmost soft key (continuous–menu key).
- 4 Press soft key [CARD]. The screen shown below is displayed.

	_			
(DIRECTO	ORY (M–CAR	D)	O0034 N00045
	No.	FILE NAME	,	DATE
	0001	O1000	123456	96/07/10
	0001	O1000	8458	96/07/30
	0003	O0002	3250	96/07/30
	0004	O2000	73456	96/07/31
	0005	O2001	3444	96/07/31
	0006	O3001	8483	96/08/02
	0007	O3300	406	96/08/05
	8000	O3400 O3500	2420 7460	96/07/31 96/07/31
	0009	03500	7400	90/07/31
~	,			, ,
	PROG	}	DIR +	(OPRT)
		<i>/</i> \		

- 5 Press soft key [(OPRT)].
- 6 Set the number of the desired file number with soft key [F SRH]. Then, start the search by pressing soft key [EXEC]. If found, the file is displayed at the top of the directory screen.

When a search is made for file number 19



~

Reading a file

Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- **2** Press function key PROG.
- 3 Press the rightmost soft key (continuous–menu key).
- 4 Press soft key [CARD]. Then, the screen shown below is displayed.

```
O0034 N00045
DIRECTORY (M-CARD)
  No.
        FILE NAME
                           SIZE
                                       DATE
 0001
         O1000
                          123456
                                     96/07/10
 0002
         O1001
                            8458
                                     96/07/30
 0003
         O0002
                            3250
                                     96/07/30
 0004
         O2000
                           73456
                                     96/07/31
 0005
         O2001
                            3444
                                     96/07/31
 0006
         O3001
                            8483
                                     96/08/02
 0007
         O3300
                             406
                                     96/08/05
 8000
         O3400
                            2420
                                     96/07/31
 0009
         O3500
                            7460
                                     96/07/31
                   DIR +
  PROG |
                                          (OPRT)
```

(F SRH) (F READ) (N READ) (PUNCH) (DELETE)

- 5 Press soft key **[(OPRT)]**.
- **6** To specify a file number, press soft key **[F READ]**. The screen shown below is displayed.

```
DIRECTORY (M-CARD)
                                O0001 N00010
       FILÈ NAME
                              COMMENT
  No.
 0019
       O1000
                           (MAIN PROGRAM)
 0020
       O1010
                           (SUBPROGRAM-1)
 0021
       O1030
                           (COMMENT
 READ
       FILE NAME=20
                           PROGRAM No.=120
                                 15:40:21
 F NAME O SET STOP CAN
                                   EXEC
```

- 7 Enter file number 20 from the MDI panel, then set the file number by pressing soft key [F SET]. Next, enter program number 120, then set the program number by pressing soft key [O SET]. Then, press soft key [EXEC].
 - · File number 20 is registered as O0120 in the CNC.
 - Set a program number to register a read file with a separate O number. If no program number is set, the O number in the file name column is registered.

8 To specify a file with its file name, press soft key **[N READ]** in step 6 above. The screen shown below is displayed.

```
DIRECTORY (M-CARD)
                                 O0001 N00010
       FILE NAME
                               COMMENT
  No.
 0012
        O0050
                            (MAIN PROGRAM)
 0013
        TESTPRO
                            (SUB PROGRAM-1)
                            (MACRO PROGRAM)
 0014
        O0060
 READ
              FILE NAME =TESTPRO
            PROGRAM No. =1230
 EDIT ***
                                   15:40:21
                    STOP ]
```

9 To register file name TESTPRO as O1230, enter file name TESTPRO from the MDI panel, then set the file name with soft key [F NAME]. Next, enter program number 1230, then set the program number with soft key [O SET]. Then, press soft key [EXEC].

Writing a file

Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key PROG.
- 3 Press the rightmost soft key [>] (continuous–menu key).
- 4 Press soft key [CARD]. The screen shown below is displayed.

```
DIRECTORY (M-CARD)
                                      O0034 N00045
  No.
         FILE NAME
                            SIZE
                                        DATE
 0001
         O1000
                          123456
                                      96/07/10
 0002
         O1001
                            8458
                                      96/07/30
 0003
         O0002
                            3250
                                      96/07/30
 0004
         O2000
                           73456
                                      96/07/31
 0005
         O2001
                            3444
                                      96/07/31
 0006
                            8483
         O3001
                                      96/08/02
 0007
                             406
                                      96/08/05
         O3300
 8000
         O3400
                            2420
                                      96/07/31
 0009
         O3500
                            7460
                                      96/07/31
                   DIR +
  PROG
```

- 5 Press soft key [(OPRT)].
- **6** Press soft key [PUNCH].
- 7 Enter a desired O number from the MDI panel, then set the program number with soft key **[O SET]**.

When soft key **[EXEC]** is pressed after the setting shown below has been made, for example, the file is written under program number O1230.

```
PUNCH FILE NAME = PROGRAM No. =1230

EDIT *** **** *** *** 15:40:21

(F NAME) (O SET) (STOP) (CAN) (EXEC)
```

8 In the same way as for O number setting, enter a desired file name from the MDI panel, then set the file name with soft key [F SET]. When soft key [EXEC] is pressed after the setting shown below has been made, for example, the file is written under program number O1230 and file name ABCD12.

```
PUNCH FILE NAME =ABCD12
PROGRAM No. =1230

EDIT *** **** *** **** 15:40:21

(F NAME) (O SET) (STOP) (CAN) (EXEC)
```

(F SRH) (F READ) (N READ) (PUNCH) (DELETE)

Explanations

 Registering the same file name When a file having the same name is already registered in the memory card, the existing file will be overwritten.

• Writing all programs

To write all programs, set program number = -9999. If no file name is specified in this case, file name PROGRAM.ALL is used for registration.

• File name restrictions

The following restrictions are imposed on file name setting:

<File name setting>

 $\times \times \times \times \times \times \times \times$.

1

Not longer than 8 characters

Extension not longer than 3 characters

Deleting a file

Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key PROG.
- 3 Press the rightmost soft key (continuous–menu key).
- 4 Press soft key [CARD]. The screen shown below is displayed.

```
DIRECTORY (M-CARD)
                                       O0034 N00045
         FILÈ NAME
  No.
                            SIZE
                                        DATE
 0001
         O1000
                          123456
                                       96/07/10
 0002
         O1001
                                      96/07/30
                             8458
 0003
         O0002
                             3250
                                      96/07/30
 0004
         O2000
                            73456
                                       96/07/31
 0005
         O2001
                             3444
                                       96/07/31
 0006
                             8483
         O3001
                                       96/08/02
 0007
                             406
         O3300
                                       96/08/05
 8000
         O3400
                             2420
                                      96/07/31
 0009
         O3500
                             7460
                                       96/07/31
                    ) [ DIR + ] [
  PROG
                                          (OPRT)
```

- 5 Press soft key [(OPRT)].
- 6 Set the number of the desired file with soft key [DELETE], then press soft key [EXEC]. The file is deleted, and the directory screen is displayed again.

When file number 21 is deleted

```
DIRECTORY (M-CARD)
                                  O0034 N00045
        FILE NAME
                                 COMMENT
  No.
 0019
        O1000
                             (MAIN PROGRAM)
 0020
        O1010
                             (SUBPROGRAM-1)
 0021
        O1020
                              (COMMENT
 0022
        O1030
                             (COMMENT
```

File name O1020 is deleted.


/			
1	DIRECT	ORY (M-CARD)	O0034 N00045
	No.	FILÈ NAME	COMMENT
١	0019	O1000	(MAIN PROGRAM)
١	0020	O1010	(SUBPROGRAM-1)
١	0021	O1020	(COMMENT)
	0022	O1030	(COMMENT)

File number 21 is assigned to the next file name.

(F SRH) (F READ) (N READ) (PUNCH) (DELETE)


Batch input/output with a memory card

On the ALL IO screen, different types of data including part programs, parameters, offset data, pitch error data, custom macros, and workpiece coordinate system data can be input and output using a memory card; the screen for each type of data need not be displayed for input/output.



Procedure

- 1 Press the EDIT switch on the machine operator's panel.
- 2 Press function key SYSTEM.
- **3** Press the rightmost soft key (continuous–menu key) several times.
- 4 Press soft key [ALL IO]. The screen shown below is displayed.



Upper part: Directory of files on the memory card Lower part: Directory of registered programs

- 5 With cursor keys 1 and 1, the user can choose between upper part scrolling and lower part scrolling. (An asterisk (*) displayed at the left edge indicates the part for which scrolling is possible.)
 - Used for memory card file directory scrolling.
 - : Used for program directory scrolling.
- 6 With page keys 1 and 1, scroll through the file directory or program directory.

Explanations

• Each data item

When this screen is displayed, the program data item is selected. The soft keys for other screens are displayed by pressing the rightmost soft key [M-CARD] represents a separate memory card function for saving and restoring system RAM data. (See Sections 8.10.7.)

When a data item other than program is selected, the screen displays only a file directory.

A data item is indicated, in parentheses, on the title line.

READ/P	UNCH (PARAMETER)	00	0001 N00001
No.	FILE NAME	SIZE	DATE
0001	O0222	32010	96/04/06
0002	O1003	4450	96/05/04
0003	MACROVAR.DAT	653400	96/05/12
0004	O0003	4610	96/05/04
0005	O0001	4254	96/06/04
0006	O0002	750	96/06/04
0007	CNCPARAM.DAT	34453	96/06/04

- Program directory display
- Using each function

Program directory display does not match bit 0 (NAM) of parameter No. 3107, or bit 4 (SOR) of parameter No. 3107.

Display the following soft keys with soft key [(OPRT)].

The operation of each function is the same as on the directory (memory card) screen. Soft key **[O SET]**, used for program number setting, and the "PROGRAM NUMBER =" indication are not displayed for data items other than program.

[F SRH] : Finds a specified file number.[F READ] : Reads a specified file number.

[PUNCH] : Writes a file.

[N READ]: Reads a file under a specified file name.

[DELETE]: Deletes a specified file number.

NOTE

With a memory card, RMT mode operation and the subprogram call function (based on the M198 command) cannot be used.

File format and error messages

Format

All files that are read from and written to a memory card are of text format. The format is described below.

B-63094EN/01

A file starts with % or LF, followed by the actual data. A file always ends with %. In a read operation, data between the first % and the next LF is skipped. Each block ends with an LF, not a semicolon (;).

- · LF: 0A (hexadecimal) of ASCII code
- · When a file containing lowercase letters, kana characters, and several special characters (such as \$, \, and !) is read, those letters and characters are ignored.

Example:

```
%
O0001(MEMORY CARD SAMPLE FILE)
G17 G49 G97
G92 X-11.3 Y2.33
...
...
M30
%
```

- · ASCII code is used for input/output, regardless of the setting parameter (ISO/EIA).
- · Bit 3 of parameter No. 0100 can be used to specify whether the end of block code (EOB) is output as "LF" only, or as "LF, CR, CR."

Error messages

If an error occurs during memory card input/output, a corresponding error message is displayed.

 $\times \times \times \times$ represents a memory card error code.

Memory Card Error Codes


Code	Meaning
102	The memory card does not have sufficient free space.
105	No memory card is mounted.
106	A memory card is already mounted.
110	The specified directory cannot be found.
111	There are too many files under the root directory to allow a directory to be added.
114	The specified file cannot be found.
115	The specified file is protected.
117	The file has not yet been opened.
118	The file is already open.
119	The file is locked.
122	The specified file name is invalid.
124	The extension of the specified file is invalid.
129	A non–corresponding function was specified.
130	The specification of a device is invalid.
131	The specification of a pathname is invalid.
133	Multiple files are open at the same time.
135	The device is not formatted.
140	The file has the read/write disabled attribute.



EDITING PROGRAMS

General

This chapter describes how to edit programs registered in the CNC. Editing includes the insertion, modification, deletion, and replacement of words. Editing also includes deletion of the entire program and automatic insertion of sequence numbers. The extended part program editing function can copy, move, and merge programs. This chapter also describes program number search, sequence number search, word search, and address search, which are performed before editing the program.



9.1 INSERTING, ALTERING AND DELETING A WORD

This section outlines the procedure for inserting, modifying, and deleting a word in a program registered in memory.

Procedure for inserting, altering and deleting a word

- 1 Select **EDIT** mode.
- 2 Press Prog
- 3 Select a program to be edited.
 If a program to be edited is selected, perform the operation 4.
 If a program to be edited is not selected, search for the program number.
- 4 Search for a word to be modified.
 - · Scan method
 - · Word search method
- 5 Perform an operation such as altering, inserting, or deleting a word.

Explanation

Concept of word and editing unit

A word is an address followed by a number. With a custom macro, the concept of word is ambiguous.

So the editing unit is considered here.

The editing unit is a unit subject to alteration or deletion in one operation. In one scan operation, the cursor indicates the start of an editing unit. An insertion is made after an editing unit.

Definition of editing unit

- (i) Program portion from an address to immediately before the next address
- (ii) An address is an alphabet, **IF**, **WHILE**, **GOTO**, **END**, **DO**=,or; (**EOB**). According to this definition, a word is an editing unit.

The word "word," when used in the description of editing, means an editing unit according to the precise definition.

WARNING

The user cannot continue program execution after altering, inserting, or deleting data of the program by suspending machining in progress by means of an operation such as a single block stop or feed hold operation during program execution. If such a modification is made, the program may not be executed exactly according to the contents of the program displayed on the screen after machining is resumed. So, when the contents of memory are to be modified by part program editing, be sure to enter the reset state or reset the system upon completion of editing before executing the program.

9.1.1 Word Search

A word can be searched for by merely moving the cursor through the text (scanning), by word search, or by address search.

Procedure for scanning a program

Press the cursor key .
 The cursor moves forward word by word on the screen; the cursor is displayed at a selected word.

2 Press the cursor key (

The cursor moves backward word by word on the screen; the cursor is displayed at a selected word.


Example) When Z1250.0 is scanned



- 3 Holding down the cursor key or scans words continuously.
- 4 The first word of the next block is searched for when the cursor key is pressed.
- The first word of the previous block is searched for when the cursor key is pressed.
- 6 Holding down the cursor key or moves the cursor to the head of a block continuously.
- 7 Pressing the page key displays the next page and searches for the first word of the page.
- 8 Pressing the page key displays the previous page and searches for the first word of the page.
- 9 Holding down the page key or displays one page after another.

Procedure for searching a word

Example) of Searching for S12




- 1 Key in address S
- 2 Key in $\begin{bmatrix} 1 \end{bmatrix}$ $\begin{bmatrix} 2 \end{bmatrix}$.
 - · S12 cannot be searched for if only S1 is keyed in.
 - · S09 cannot be searched for by keying in only S9. To search for S09, be sure to key in S09.
- 3 Pressing the [SRH↓] key starts search operation.

 Upon completion of search operation, the cursor is displayed at S12.

 Pressing the [SRH↑] key rather than the [SRH↓] key performs search operation in the reverse direction.

Procedure for searching an address

Example) of Searching for M03



- 1 Key in address M.
- 2 Press the [SRH↓] key.
 Upon completion of search operation, the cursor is displayed at M03.
 Pressing the [SRH↑] key rather than the [SRH↓] key performs search operation in the reverse direction.

Alarm

Alarm number	Description
71	The word or address being searched for was not found.

9.1.2 Heading a Program

The cursor can be jumped to the top of a program. This function is called heading the program pointer. This section describes the three methods for heading the program pointer.

Procedure for Heading a Program

Method 1

1 Press RESET when the program screen is selected in EDIT mode.

When the cursor has returned to the start of the program, the contents of the program are displayed from its start on the screen.

Method 2

Search for the program number.

- 1 Press address O, when a program screen is selected in the MEMORY or EDIT mode.
- 2 Input a program number.
- 3 Press the soft key [O SRH].

Method 3

- 1 Select [MEMORY] or [EDIT] mode.
- 2 Press Prog
- 3 Press the **[(OPRT)]** key.
- 4 Press the [REWIND] key.

9.1.3 Inserting a Word

Procedure for inserting a word

- 1 Search for or scan the word immediately before a word to be inserted.
- 2 Key in an address to be inserted.
- 3 Key in data.
- 4 Press the [INSERT] key.

Example of Inserting T15

Procedure

1 Search for or scan Z1250.

```
Program O0050 N01234
O0050 ;
N01234 X100.0 Z1250.0 ;
S12 ;
N56789 M03 ;
M02 ;
%
```

- 2 Key in T 1 5.
- 3 Press the NSERT key.

```
Program O0050 N01234
O0050 ;
N01234 X100.0 Z1250.0 715 ;
■ T15 is inserted.
S12 ;
N56789 M03 ;
M02 ;
%
```

9.1.4

Altering a Word

Procedure for altering a word

- 1 Search for or scan a word to be altered.
- 2 Key in an address to be inserted.
- 3 Key in data.
- 4 Press the ALTER key.

Example of changing T15 to M15

Procedure

1 Search for or scan T15.

```
Program O0050 N01234
O0050 ;
N01234 X100.0 Z1250.0 T15 ;
S12 ;
N56789 M03 ;
M02 ;
%
```

- 2 Key in M 1 5.
- 3 Press the ALTER key.

```
Program O0050 N01234
O0050 ;
N1234 X100.0 Z1250.0 M15 ;
S12 ;
N5678 M03 ;
M02 ;
%
```

9.1.5 Deleting a Word

Procedure for deleting a word

- 1 Search for or scan a word to be deleted.
- 2 Press the DELETE key.

Example of deleting X100.0

Procedure

1 Search for or scan X100.0.

```
Program O0050 N01234
O0050;
N01234 X100.0 Z1250.0 M15;
S12;
N56789 M03;
M02;
%
```

2 Press the DELETE key.

```
Program O0050 N01234
O0050;
N01234 Z1250.0 M15;
X100.0 is deleted.
S12;
N56789 M03;
M02;
%
```

9.2 DELETING BLOCKS

A block or blocks can be deleted in a program.

9.2.1 Deleting a Block

The procedure below deletes a block up to its EOB code; the cursor advances to the address of the next word.

Procedure for deleting a block

- 1 Search for or scan address N for a block to be deleted.
- 2 Key in FOB
- 3 Press the DELETE

Example of deleting a block of N01234

Procedure

1 Search for or scan N01234.

```
Program O0050 N01234
O0050 ;
N01234 Z1250.0 M15 ;
S12 ;
N56789 M03 ;
M02 ;
%
O0050 N01234
N01234 is searched for/scanned.
```

- 2 Key in FOB.
- 3 Press the DELETE key.

```
Program
O0050 N01234
Block containing
N01234 has
been deleted.

N56789 M03;
M02;
%
```

9.2.2 Deleting Multiple Blocks

The blocks from the currently displayed word to the block with a specified sequence number can be deleted.

Procedure for deleting multiple blocks

- 1 Search for or scan a word in the first block of a portion to be deleted.
- 2 Key in address N
- 3 Key in the sequence number for the last block of the portion to be deleted.
- 4 Press the DELETE key.

Example of deleting blocks from a block containing N01234 to a block containing N56789

Procedure

1 Search for or scan N01234.

```
Program O0050 N01234
O0050;
N01234 Z1250.0 M15;
S12;
N56789 M03;
M02;
%
```

2 Key in N 5 6 7 8 9.

```
Program
O0050 N01234
O0050;
N01234
Z1250.0 M15;
S12;
N56789 M03;
M02;
%
Underlined part is deleted.
```

3 Press the belete key.

```
Program
O0050 N01234
O0050;
M02;
%
Blocks from block containing N01234 to block containing N56789 have been deleted.
```

NOTE

When there are too many blocks to be deleted, a P/S alarm (No.070) may be generated. If this happens, reduce the number of blocks to be deleted.

9.3 PROGRAM NUMBER SEARCH

When memory holds multiple programs, a program can be searched for. There are three methods as follows.

Procedure for program number search

Method 1

- 1 Select **EDIT** or **MEMORY** mode.
- 2 Press Prog to display the program screen.
- 3 Key in address O
- 4 Key in a program number to be searched for.
- 5 Press the [O SRH] key.
- **6** Upon completion of search operation, the program number searched for is displayed in the upper–right corner of the screen If the program is not found, P/S alarm No. 71 occurs.

Method 2

- 1 Select **EDIT** or **MEMORY** mode.
- 2 Press PROG to display the program screen.
- 3 Press the **[O SRH]** key. In this case, the next program in the directory is searched for .

Method 3

This method searches for the program number (0001 to 0015) corresponding to a signal on the machine tool side to start automatic operation. Refer to the relevant manual prepared by the machine tool builder for detailed information on operation.

- 1 Select **MEMORY** mode.
- 2 Set the reset state(*1)
 - •The reset state is the state where the LED for indicating that automatic operation is in progress is off. (Refer to the relevant manual of the machine tool builder.)
- 3 Set the program number selection signal on the machine tool side to a number from 01 to 15.
 - · If the program corresponding to a signal on the machine tool side is not registered, P/S alarm (No. 059) is raised.
- 4 Press the cycle start button.
 - · When the signal on the machine tool side represents 00, program number search operation is not performed.

Alarm

No.	Contents
59	The program with the selected number cannot be searched during external program number search.
71	The specified program number was not found during program number search.

9.4 SEQUENCE NUMBER SEARCH

Sequence number search operation is usually used to search for a sequence number in the middle of a program so that execution can be started or restarted at the block of the sequence number.

Example) Sequence number 02346 in a program (O0002) is searched for.

```
Program
                      O0001;
                     N01234 X100.0 Z100.0;
                      S12;
Selected program -
                   → 00002 :
                                                This section is
                      N02345 X20.0 Z20.0;
                                                searched starting at
Target sequence
                     N02346 X10.0 Y10.0;
                                                the beginning.
number is found.
                                                (Search operation is
                      O0003;
                                                performed only within a
                                                program.)
```

Procedure for sequence number search

- 1 Select **MEMORY** mode.
- 2 Press Prog
- 3 · If the program contains a sequence number to be searchedfor, perform the operations 4 to 7 below.
 - · If the program does not contain a sequence number to be searched for, select the program number of the program that contains the sequence number to be searched for.
- 4 Key in address N
- 5 Key in a sequence number to be searched for.
- 6 Press the [N SRH] key.
- 7 Upon completion of search operation, the sequence number searched for is displayed in the upper–right corner of the screen.

 If the specified sequence number is not found in the program currently selected, P/S alarm No. 060 occurs.

Explanations

Operation during Search

Those blocks that are skipped do not affect the CNC. This means that the data in the skipped blocks such as coordinates and M, S, and T codes does not alter the CNC coordinates and modal values.

So, in the first block where execution is to be started or restarted by using a sequence number search command, be sure to enter required M, S, and T codes and coordinates. A block searched for by sequence number search usually represents a point of shifting from one process to another. When a block in the middle of a process must be searched for to restart execution at the block, specify M, S, and T codes, G codes, coordinates, and so forth as required from the MDI after closely checking the machine tool and NC states at that point.


Checking during search

During search operation, the following checks are made:

- · Optional block skip
- · P/S alarm (No. 003 to 010)

Limitations

Searching in sub-program During sequence number search operation, M98Pxxxx (subprogram call) is not executed. So a P/S alarm (No.060) is raised if an attempt is made to search for a sequence number in a subprogram called by the program currently selected.



If an attempt is made to search for N8888 in the example above, an alarm is raised.

Alarm

Number	Contents	
60	Command sequence number was not found in the sequence number search.	

9.5 DELETING PROGRAMS

Programs registered in memory can be deleted, either one program by one program or all at once. Also, More than one program can be deleted by specifying a range.

9.5.1 Deleting One Program

A program registered in memory can be deleted.

Procedure for deleting one program

- 1 Select the **EDIT** mode.
- 2 Press Prog to display the program screen.
- 3 Key in address O
- 4 Key in a desired program number.
- 5 Press the DELETE key.

 The program with the entered program number is deleted.

9.5.2 Deleting All Programs

All programs registered in memory can be deleted.

Procedure for deleting all programs

- 1 Select the **EDIT** mode.
- 2 Press Prog to display the program screen.
- 3 Key in address O.
- **4** Key in –9999.
- 5 Press edit key DELETE to delete all programs.

9.5.3

Deleting More Than One Program by Specifying a Range

Programs within a specified range in memory are deleted.

Procedure for deleting more than one program by specifying a range

- 1 Select the **EDIT** mode.
- 2 Press PROG to display the program screen.
- 3 Enter the range of program numbers to be deleted with address and numeric keys in the following format:
 OXXXX,OYYYY
 where XXXX is the starting number of the programs to be deleted and YYYY is the ending number of the programs to be deleted.
- 4 Press edit key DELETE to delete programs No. XXXX to No. YYYY.

9.6 EXTENDED PART PROGRAM EDITING FUNCTION

With the extended part program editing function, the operations described below can be performed using soft keys for programs that have been registered in memory.

Following editing operations are available:

- · All or part of a program can be copied or moved to another program.
- · One program can be merged at free position into other programs.
- · A specified word or address in a program can be replaced with another word or address.

9.6.1 Copying an Entire Program

A new program can be created by copying a program.





Fig. 9.6.1 Copying an entire program

In Fig. 9.6.1, the program with program number xxxx is copied to a newly created program with program number yyyy. The program created by copy operation is the same as the original program except the program number.

Procedure of copying an entire program

- 1 Enter the **EDIT** mode.
- 2 Press function key Prog
- 3 Press soft key [(OPRT)].
- 4 Press the continuous menu key.
- 5 Press soft key [EX-EDT].
- 6 Check that the screen for the program to be copied is selected and press soft key [COPY].
- 7 Press soft key [ALL].
- 8 Enter the number of the new program (with only numeric keys) and press the NPUT key.
- **9** Press soft key **[EXEC]**.



9.6.2 Copying Part of a Program

A new program can be created by copying part of a program.




Fig. 9.6.2 Copying part of a program


In Fig. 9.6.2, part B of the program with program number xxxx is copied to a newly created program with program number yyyy. The program for which an editing range is specified remains unchanged after copy operation.

Procedure for copying part of a program

1 Perform steps 1 to 6 in III-9.6.1.



- 2 Move the cursor to the start of the range to be copied and press soft key [CRSR \sim].
- 3 Move the cursor to the end of the range to be copied and press soft key [~CRSR] or [~BTTM] (in the latter case, the range to the end of the program is copied regardless of the position of the cursor).





5 Press soft key **[EXEC]**.



9.6.3 Moving Part of a Program

A new program can be created by moving part of a program.





Fig. 9.6.3 Moving part of a program

In **Fig. 9.6.3**, part B of the program with program number xxxx is moved to a newly created program with program number yyyy; part B is deleted from the program with program number xxxx.

Procedure for moving part of a program

- 1 Perform steps 1 to 5 in III–9.6.1.
- 2 Check that the screen for the program to be moved is selected and press soft key [MOVE].
- 3 Move the cursor to the start of the range to be moved and press soft key [CRSR∼].
- 4 Move the cursor to the end of the range to be moved and press soft key [∼CRSR] or [∼BTTM](in the latter case, the range to the end of the program is copied regardless of the position of the cursor).
- 5 Enter the number of the new program (with only numeric keys) and press the NPUT key.
- **6** Press soft key **[EXEC]**.





0 ∼ **9**

Numeric keys

9.6.4 Merging a Program

Another program can be inserted at an arbitrary position in the current program.





Fig. 9.6.4 Merging a program at a specified location

In **Fig. 9.6.4**, the program with program number XXXX is merged with the program with program number YYYY. The OYYYY program remains unchanged after merge operation.

Procedure for merging a program







- 1 Perform steps 1 to 5 in III-9.6.1.
- 2 Check that the screen for the program to be edited is selected and press soft key [MERGE].
- 3 Move the cursor to the position at which another program is to be inserted and press soft key [~'CRSR] or [~BTTM'](in the latter case, the end of the current program is displayed).
- 4 Enter the number of the program to be inserted (with only numeric keys) and press the keys.
- 5 Press soft key **[EXEC]**. The program with the number specified in step 4 is inserted before the cursor positioned in step 3.

9.6.5 Supplementary Explanation for Copying, Moving and Merging

Explanations

Setting an editing range

The setting of an editing range start point with [CRSR~] can be changed freely until an editing range end point is set with [~CRSR] or [~BTTM]. If an editing range start point is set after an editing range end point, the editing range must be reset starting with a start point.

The setting of an editing range start point and end point remains valid until an operation is performed to invalidate the setting.

One of the following operations invalidates a setting:

- An edit operation other than address search, word search/scan, and search for the start of a program is performed after a start point or end point is set.
- · Processing is returned to operation selection after a start point or end point is set.
- Without specifying a program number

In copying program and moving program, if **[EXEC]** is pressed without specifying a program number after an editing range end point is set, a program with program number O0000 is registered as a work program. This O0000 program has the following features:

- The program can be edited in the same way as a general program. (Do not run the program.)
- If a copy or move operation is newly performed, the previous information is deleted at execution time, and newly set information (all or part of the program) is reregistered. (In merge operation, the previous information is not deleted.) However, the program, when selected for foreground operation, cannot be reregistered in the background. (A BP/S alarm No. 140 is raised.) When the program is reregistered, a free area is produced. Delete such a free area with the
- · When the program becomes unnecessary, delete the program by a normal editing operation.
- Editing when the system waiting for a program number to be entered

When the system is waiting for a program number to be entered, no edit operation can be performed.

Limitations

 Number of digits for program number If a program number is specified by 5 or more digits, a format error is generated.

Alarm

Alarm no.	Contents		
70	Memory became insufficient while copying or inserting a program. Copy or insertion is terminated.		
101	The power was interrupted during copying, moving, or inserting a program and memory used for editing must be cleared. When this alarm occurs, press the key while pressing function key PROG. Only the program being edited is deleted.		

9.6.6 Replacement of **Words and Addresses**

Replace one or more specified words.

Replacement can be applied to all occurrences or just one occurrence of specified words or addresses in the program.

Procedure for hange of words or addresses


1 Perform steps 1 to 5 in III–9.6.1.



2 Press soft key [CHANGE].



3 Enter the word or address to be replaced.



4 Press soft key [BEFORE].



6 Press soft key [AFTER].



Press soft key **[EXEC]** to replace all the specified words or addresses after the cursor.

Press soft key [1–EXEC] to search for and replace the first occurrence of the specified word or adress after the cursor.

Press soft key [SKIP] to only search for the first occurrence of the specified word or address after the cursor.

Examples

 Replace X100 with Y200 [CHANGE] [AFTER][EXEC]

 Replace X100Y200 with X30

2 [BEFORE] [CHANGE] 3 [AFTER][EXEC]

Replace IF with WHILE

[BEFORE] W Н [AFTER] [CHANGE] [EXEC]

Replace X with ,C10

[CHANGE] X [BEFORE] 1 [AFTER][EXEC]

Explanation

Replacing custom macros

The following custom macro words are replaceable:

IF, WHILE, GOTO, END, DO, BPRNT, DPRINT, POPEN, PCLOS

The abbreviations of custom macro words can be specified.

When abbreviations are used, however, the screen displays the abbreviations as they are key input, even after soft key [BEFORE] and

[AFTER] are pressed.

Restrictions

 The number of characters for replacement Up to 15 characters can be specified for words before or after replacement.

(Sixteen or more characters cannot be specified.)

• The characters for replacement

Words before or after replacement must start with a character representing an address.(A format error occurs.)

9.7 EDITING OF CUSTOM MACROS

Unlike ordinary programs, custom macro programs are modified, inserted, or deleted based on editing units.

Custom macro words can be entered in abbreviated form.

Comments can be entered in a program.

Refer to the III–10.1 for the comments of a program.

Explanations

Editing unit

When editing a custom macro already entered, the user can move the cursor to each editing unit that starts with any of the following characters and symbols:

- (a) Address
- (b) # located at the start of the left side of a substitution statement
- (c) /, (,=, and;
- (d) First character of IF, WHILE, GOTO, END, DO, POPEN, BPRNT, DPRNT and PCLOS

On the CRT screen, a blank is placed before each of the above characters and symbols.

(Example) Head positions where the cursor is placed

<u>N</u>001<u>X</u>-#100<u>;</u>

#1 = 123;

N002 /2 X[12/#3];

N003 X-SQRT[#3/3*[#4+1]];

N004 X-#2 Z#1;

N005 # 5 = 1 + 2 - # 10;

<u>IF[#1NE0] GOTO10:</u>

WHILE[#2LE5] DO1;

#[200+#2] = #2*10;

#2 = #2 + 1;

END1:

Abbreviations of custom macro word

When a custom macro word is altered or inserted, the first two characters or more can replace the entire word.

Namely,

$\mathbf{WHILE} \to \mathbf{WH}$	$\mathbf{GOTO} \to \mathbf{GO}$	$XOR \to XO$	$AND \to AN$
$\mathbf{SIN} \to \mathbf{SI}$	$\mathbf{ASIN} \to \mathbf{AS}$	$\mathbf{COS} \to \mathbf{CO}$	$ACOS \rightarrow AC$
$TAN \to TA$	$ATAN \to AT$	$\mathbf{SQRT} \to \mathbf{SQ}$	$\mathbf{ABS} \to \mathbf{AB}$
$BCD \to BC$	$BIN \to BI$	$FIX \to FI$	$FUP \to FU$
$ROUND \to RO$	$END \to EN$	$\mathbf{EXP} \to \mathbf{EX}$	$\textbf{THEN} \to \textbf{TH}$
$POPEN \rightarrow PO$	$BPRNT \to BP$	$\mathbf{DPRNT} \to \mathbf{DP}$	$PCLOS \rightarrow PC$

(Example) Keying in

WH [AB [#2] LE RO [#3]]

has the same effect as

WHILE [ABS [#2] LE ROUND [#3]]

The program is also displayed in this way.

9.8 BACKGROUND EDITING

Editing a program while executing another program is called background editing. The method of editing is the same as for ordinary editing (foreground editing).

A program edited in the background should be registered in foreground program memory by performing the following operation:

During background editing, all programs cannot be deleted at once.

Procedure for background editing

- Enter EDIT or MEMORY mode.
 Memory mode is allowed even while the program is being executed.
- 2 Press function key Prog
- 3 Press soft key **[(OPRT)]**, then press soft key **[BG-EDT]**. The background editing screen is displayed (PROGRAM (BG-EDIT) is displayed at the top left of the screen).
- **4** Edit a program on the background editing screen in the same way as for ordinary program editing.
- 5 After editing is completed, press soft key **[(OPRT)]**, then press soft key **[BG–EDT]**. The edited program is registered in foreground program memory.

Explanation

 Alarms during background editing Alarms that may occur during background editing do not affect foreground operation. Conversely, alarms that may occur during foreground operation do not affect background editing. In background editing, if an attempt is made to edit a program selected for foreground operation, a BP/S alarm (No. 140) is raised. On the other hand, if an attempt is made to select a program subjected to background editing during foreground operation (by means of subprogram calling or program number search operation using an external signal), a P/S alarm (Nos. 059, 078) is raised in foreground operation. As with foreground program editing, P/S alarms occur in background editing. However, to distinguish these alarms from foreground alarms, BP/S is displayed in the data input line on the background editing screen.

9.9 PASSWORD FUNCTION

The password function (bit 4 (NE9) of parameter No. 3202) can be locked using parameter No. 3210 (PASSWD) and parameter No. 3211 (KEYWD) to protect program Nos. 9000 to 9999. In the locked state, parameter NE9 cannot be set to 0. In this state, program Nos. 9000 to 9999 cannot be modified unless the correct keyword is set.

A locked state means that the value set in the parameter PASSWD differs from the value set in the parameter KEYWD. The values set in these parameters are not displayed. The locked state is released when the value already set in the parameter PASSWD is also set in parameter KEYWD. When 0 is displayed in parameter PASSWD, parameter PASSWD is not set.

Procedure for locking and unlocking

Locking

- 1 Set the MDI mode.
- **2** Enable parameter writing. At this time, P/S alarm No. 100 is issued on the CNC.
- **3** Set parameter No. 3210 (PASSWD). At this time, the locked state is set.
- 4 Disable parameter writing.
- 5 Press the RESET key to release the alarm state.

Unlocking

- 1 Set the MDI mode.
- **2** Enable parameter writing. At this time, P/S alarm No. 100 is issued on the CNC.
- 3 In parameter No. 3211 (KEYWD), set the same value as set in parameter No. 3210 (PASSWD) for locking. At this time, the locked state is released.
- 4 Set bit 4 (NE9) of parameter No. 3202 to 0.
- 5 Disable parameter writing.
- **6** Press the RESET key to release the alarm state.
- 7 Subprograms from program Nos. 9000 to 9999 can now be edited.

Explanations

Setting parameter PASSWD The locked state is set when a value is set in the parameter PASSWD. However, note that parameter PASSWD can be set only when the locked state is not set (when PASSWD = 0, or PASSWD = KEYWD). If an attempt is made to set parameter PASSWD in other cases, a warning is given to indicate that writing is disabled. When the locked state is set (when PASSWD = 0 and PASSWD = KEYWD), parameter NE9 is automatically set to 1. If an attempt is made to set NE9 to 0, a warning is given to indicate that writing is disabled.

 Changing parameter PASSWD Parameter PASSWD can be changed when the locked state is released (when PASSWD = 0, or PASSWD = KEYWD). After step 3 in the procedure for unlocking, a new value can be set in the parameter PASSWD. From that time on, this new value must be set in parameter KEYWD to release the locked state.

Setting 0 in parameter PASSWD

When 0 is set in the parameter PASSWD, the number 0 is displayed, and the password function is disabled. In other words, the password function can be disabled by either not setting parameter PASSWD at all, or by setting 0 in parameter PASSWD after step 3 of the procedure for unlocking. To ensure that the locked state is not entered, care must be taken not to set a value other than 0 in parameter PASSWD.

Re-locking

After the locked state has been released, it can be set again by setting a different value in parameter PASSWD, or by turning the power to the NC off then on again to reset parameter KEYWD.

CAUTION

Once the locked state is set, parameter NE9 cannot be set to 0 and parameter PASSWD cannot be changed until the locked state is released or the memory all-clear operation is performed. Special care must be taken in setting parameter PASSWD.

10

CREATING PROGRAMS

Programs can be created using any of the following methods:

- · MDI keyboard
- · PROGRAMMING IN TEACH IN MODE
- · CONVERSATIONAL AUTOMATIC PROGRAMMING FUNCTION
- AUTOMATIC PROGRAM PREPARATION DEVICE (FANUC SYSTEM P)

This chapter describes creating programs using the MDI panel, Teach IN mode, and conversational programming with graphic function. This chapter also describes the automatic insertion of sequence numbers.

10.1 CREATING PROGRAMS USING THE MDI PANEL

Programs can be created in the EDIT mode using the program editing functions described in III–9.

Procedure for Creating Programs Using the MDI Panel

Procedure

- 1 Enter the **EDIT** mode.
- 2 Press the PROG key.
- 3 Press address key O and enter the program number.
- 4 Press the NSERT key.
- 5 Create a program using the program editing functions described in III–9.

Explanation

Comments in a program

Comments can be written in a program using the control in/out codes.

Example) O0001 (FANUC SERIES 16); M08 (COOLANT ON);

- When the key is pressed after the control—out code "(", comments, and control—in code ")" have been typed, the typed comments are registered.
- When the key is pressed midway through comments, to enter the rest of comments later, the data typed before the pressed may not be correctly registered (not entered, modified, or lost) because the data is subject to an entry check which is performed in normal editing.

Note the following to enter a comment:

- Control-in code ")" cannot be registered by itself.
- Comments entered after the key is pressed must not begin with a number, space, or address O.
- If an abbreviation for a macro is entered, the abbreviation is converted into a macro word and registered (see Section 9.7).
- Address O and subsequent numbers, or a space can be entered but are omitted when registered.

10.2 **AUTOMATIC INSERTION OF SEQUENCE NUMBERS**


Sequence numbers can be automatically inserted in each block when a program is created using the MDI keys in the EDIT mode. Set the increment for sequence numbers in parameter 3216.

Procedure for automatic insertion of sequence numbers

Procedure

- Set 1 for SEQUENCE NO. (see III–11.4.3).
- Enter the **EDIT** mode.
- Press | PROG | to display the program screen.
- Search for or register the number of a program to be edited and move the cursor to the EOB (;) of the block after which automatic insertion of sequence numbers is started. When a program number is registered and an EOB (;) is entered with the | NSERT | key, sequence numbers are automatically inserted starting with 0. Change the initial value, if required, according to step 10, then skip to step 7.
- and enter the initial value of N. Press address key
- Press INSERT
- Enter each word of a block.
- Press EOB

9 Press NSERT. The EOB is registered in memory and sequence numbers are automatically inserted. For example, if the initial value of N is 10 and the parameter for the increment is set to 2, N12 inserted and displayed below the line where a new block is specified.



- In the example above, if N12 is not necessary in the next block, pressing the person key after N12 is displayed deletes N12.
 - To insert N100 in the next block instead of N12, enter N100 and press ALTER after N12 is displayed. N100 is registered and initial value is changed to 100.

10.3 CREATING PROGRAMS IN TEACH IN MODE (PLAYBACK) When the playback option is selected, the **TEACH IN JOG** mode and **TEACH IN HANDLE** mode are added. In these modes, a machine position along the X, Y, and Z axes obtained by manual operation is stored in memory as a program position to create a program.

The words other than X, Y, and Z, which include O, N, G, R, F, C, M, S, T, P, Q, and EOB, can be stored in memory in the same way as in **EDIT** mode.

Procedure for Creating Programs in TEACH IN Mode

Procedure

The procedure described below can be used to store a machine position along the X, Y, and Z axes.


- 1 Select the **TEACH IN JOG** mode or **TEACH IN HANDLE** mode.
- 2 Move the tool to the desired position with jog or handle.
- 3 Press PROG key to display the program screen. Search for or register the number of a program to be edited and move the cursor to the position where the machine position along each axis is to be registered (inserted).
- 4 Key in address X.
- **5** Press the key. Then a machine position along the X axis is stored in memory.

(Example) X10.521 Absolute positon (for mm input) X10521 Data stored in memory

6 Similarly, key in Y, then press the wey. Then a machine position along the Y axis is stored in memory. Further, key in Z, then press the wey. Then a machine position along the Z axis is stored in memory.

All coordinates stored using this method are absolute coordinates.

Examples



1	Set the setting data SEQUENCE NO. to 1 (on). (The incremental value
	parameter (No. 3216) is assumed to be "1".)

2.	Select the	TEACH IN	HANDI	F mode
4	DOICEL LITE	ILACIIII	IIAIIDE	

- 3 Make positioning at position P0 by the manual pulse generator.
- 4 Select the program screen.
- 5 Enter program number O1234 as follows:



This operation registers program number O1234 in memory. Next, press the following keys:



An EOB (;) is entered after program number O1234. Because no number is specified after N, sequence numbers are automatically inserted for N0 and the first block (N1) is registered in memory.

6 Enter the P0 machine position for data of the first block as follows:




This operation registers G92X10000Y0Z10000; in memory. The automatic sequence number insertion function registers N2 of the second block in memory.

- 7 Position the tool at P1 with the manual pulse generator.
- **8** Enter the P1 machine position for data of the second block as follows:



This operation registers G00G90X3025Z23723; in memory. The automatic sequence number insertion function registers N3 of the third block in memory.


- **9** Position the tool at P2 with the manual pulse generator.
- 10 Enter the P2 machine position for data of the third block as follows:



This operation registers G01Z –325F300; in memory.

The automatic sequence number insertion function registers N4 of the fourth block in memory.

11 Register M02; in memory as follows:



N5 indicating the fifth block is stored in memory using the automatic sequence number insertion function. Press the DELETE key to delete it.

This completes the registration of the sample program.

Explanations

 Checking contents of the memory The contents of memory can be checked in the **TEACH IN** mode by using the same procedure as in **EDIT** mode.

```
PROGRAM
                                   O1234 N00004
   (RELATIVE)
                             (ABSOLUTE)
   Χ
       -6.975
                             Χ
                                  3.025
                             Υ
   Υ
       23.723
                                 23.723
      -10.325
                                 -0.325
   O1234:
   N1 G92 X10000 Y0 Z10000 ;
   N2 G00 G90 X3025 Y23723;
   N3 G01 Z-325 F300 ;
   N4 M02 ;
   %
 THND
                                    14:17:27
                                     (OPRT)
                           )(
PRGRM
            LIB
```

 Registering a position with compensation When a value is keyed in after keying in address X, Y, or Z

then the key is pressed, the value keyed in for a machine position is added for registration. This operation is useful to correct a machine position by key—in operation.

 Registering commands other than position commands Commands to be entered before and after a machine position must be entered before and after the machine position is registered, by using the same operation as program editing in **EDIT** mode.

11

SETTING AND DISPLAYING DATA

General

To operate a CNC machine tool, various data must be set on the MDI panel for the CNC. The operator can monitor the state of operation with data displayed during operation.

This chapter describes how to display and set data for each function.

Explanations

·Screen transition chart



MDI function keys (Shaded keys () are described in this chapter.)


bed


The screen transition for when each function key on the MDI panel is pressed is shown below. The subsections referenced for each screen are also shown. See the appropriate subsection for details of each screen and the setting procedure on the screen. See other chapters for screens not described in this chapter.


See Chapter 7 for the screen that appears when function key pressed. See Chapter 12 for the screen that appears when function key is pressed. See Chapter 13 for the screen that appears when function key help is pressed. In general, function key is prepared by the machine tool builder and used for macros. Refer to the manual issued by the machine tool builder for the screen that appears when function key is pressed.


Data protection key


The machine may have a data protection key to protect part programs, tool compensation values, setting data, and custom macro variables. Refer to the manual issued by the machine tool builder for where the data protection key is located and how to use it.











• Setting screens

The table below lists the data set on each screen.

Table.11. Setting screens and data on them

No.	Setting screen	Contents of setting	Reference item
1	Tool offset value	Tool offset value Tool length offset value Cutter compensation value	III-11.4.1
		Tool length measurement	III-11.4.2
2	Setting data(handy)	Parameter write TV check Punch code Input unit (mm/inch) I/O channel Automatic insert of Sequence No. Conversion of tape format (F15)	III-11.4.3
		Sequence number comparison and stop	III–11.4.4
3	Setting data (mirror image)	Mirror image	III–11.4.3
4	Setting data (timer)	Parts required	III-11.4.5
5	Macro variables	Custom macro common variables (#100 to #149) or (#100 to #199) (#500 to #531) or (#500 to #599)	III-11.4.8
6	Parameter	Parameter	III-11.5.1
7	Pitch error	Pitch error compensation data	III-11.5.2
8	software operator's panel	Mode selection Jog feed axis selection Jog rapid traverse Axis selection for Manual pulse generator Multiplication for manual pulse generator Jog feedrate Feedrate override Rapid traverse override Optional block skip Single block Machine lock Dry run Protect key Feed hold	III-11.4.10
9	Tool life data (Tool life management)	Life count	III–11.4.11
10	Tool life data (Extended tool life man- agement)	Life count type (cycle or minute) Life value Life counter Tool number H code D code New tool group New tool number Skipping tool Clearing tool	III-11.4.12
11	Work coordinate system setting	Work origin offset value	III-11.4.6

11.1 SCREENS DISPLAYED BY FUNCTION KEY POS

Press function key Pos to display the current position of the tool.

The following three screens are used to display the current position of the tool:

- ·Position display screen for the work coordinate system.
- ·Position display screen for the relative coordinate system.
- ·Overall position display screen.

The above screens can also display the feedrate, run time, and the number of parts. In addition, a floating reference position can be set on these screens.

Function key Pos can also be used to display the load on the servo motor and spindle motor and the rotation speed of the spindle motor (operating monitor display).


Function key Pos can also be used to display the screen for displaying the distance moved by handle interruption. See III–4.8 for details on this screen.

11.1.1 Position Display in the Work Coordinate System

Displays the current position of the tool in the workpiece coordinate system. The current position changes as the tool moves. The least input increment is used as the unit for numeric values. The title at the top of the screen indicates that absolute coordinates are used.

Display procedure for the current position screen in the workpiece coordinate system

- 1 Press function key Pos
- 2 Press soft key [ABS].
- Display with one–path control



Display including compensation values


Bits 6 and 7 of parameter 3104 (DAL, DAC) can be used to select whether the displayed values include tool length offset and cutter compensation.

11.1.2 Position Display in the Relative Coordinate System

Displays the current position of the tool in a relative coordinate system based on the coordinates set by the operator. The current position changes as the tool moves. The increment system is used as the unit for numeric values. The title at the top of the screen indicates that relative coordinates are used.

Display procedure for the current position screen with the relative coordinate system


- 1 Press function key Pos
- 2 Press soft key [REL].



See Explanations for the procedure for setting the coordinates.

Procedure to set the axis coordinate to a specified value


Procedure



- 1 Enter an axis address (such as X or Y) on the screen for the relative coordinates. The indication for the specified axis blinks and the soft keys change as shown on the left.
- To reset the coordinate to 0, press soft key **[ORGIN]**. The relative coordinate for the blinking axis is reset to 0.
 - To preset the coordinate to a specified value, enter the value and press soft key [PRESET]. The relative coordinate for the blinking axis is set to the entered value.

Procedure to reset all axes

Procedure



1 Press soft key [(OPRT)].

- 2 Press soft key [ORIGIN].
- 3 Press soft key [ALLEXE].
 The relative coordinates for all axes are reset to 0.
- Display including compensation values

Bits 4 and 5 of parameter 3104 (DRL, DRC) can be used to select whether the displayed values include tool length offset and cutter compensation.

Presetting by setting a coordinate system

Bit 3 of parameter 3104 (PPD) is used to specify whether the displayed positions in the relative coordinate system are preset to the same values as in the workpiece coordinate system when a coordinate system is set by a G92 command or when the manual reference position return is made.

11.1.3 Overall Position Display

Displays the following positions on a screen: Current positions of the tool in the workpiece coordinate system, relative coordinate system, and machine coordinate system, and the remaining distance. The relative coordinates can also be set on this screen. See III–11.1.2 for the procedure.

Procedure for displaying overall position display screen

Procedure

- 1 Press function key Pos
- 2 Press soft key [ALL].

ACTUAL POSITION	O1000 N00010
/ CTO/ LT GOTTION	
(RELATIVE)	(ABSOLUTE)
X 246.912	X 123.456
Y 913.780	Y 456.890
Z 1578.246	Z 789.123
	(5,05,1,105,50,00)
(MACHINE)	(DISTANCE TO GO)
X 0.000	X 0.000
Y 0.000	Y 0.000
Z 0.000	Z 0.000
	PART COUNT 5
RUN TIME 0H15M	CYCLE TIME 0H 0M38S
ACT.F 3000 MM/M	S 0 T0000
MEM **** ***	09:06:35
	L [HNDL] [OPRT]
[ABS] [REL] [AL	E [[[OFKI]

Explanations

Coordinate display

The current positions of the tool in the following coordinate systems are displayed at the same time:

- Current position in the relative coordinate system (relative coordinate)
- Current position in the work coordinate system (absolute coordinate)
- Current position in the machine coordinate system (machine coordinate)
- Distance to go (distance to go)

The distance remaining is displayed in the MEMORY or MDI mode. The distance the tool is yet to be moved in the current block is displayed.

The least command increment is used as the unit for values displayed in the machine coordinate system. However, the least input increment can be used by setting bit 0 (MCN) of parameter 3104.

Only the coordinates for the first to fifth axes are displayed initially whenever there are six or more controlled axes. Pressing the **[ALL]** soft key displays the coordinates for the sixth and subsequent axes.

- Distance to go
- Machine coordinate system
- Displaing the sixth and subsequent axes

 Displaying the fifth and subsequent axes Relative coordinates cannot be displayed together with absolute coordinates whenever there are five or more controlled axes. Pressing the **[ALL]** soft key toggles the display between absolute and relative coordinates.

Resetting the relative coordinates

The total position display screen also supports the resetting of the relative coordintes to 0 or presetting of them to specified values. See the procedure for resetting the relative coordintes described in Subsection III–11.1.2


11.1.4 Presetting the Workpiece Coordinate System

A workpiece coordinate system shifted by an operation such as manual intervention can be preset using MDI operations to a pre—shift workpiece coordinate system. The latter coordinate system is displaced from the machine zero point by a workpiece zero point offset value.

A command (G92.1) can be programmed to preset a workpiece coordinate system. (See II–7.2.4 in the section for programming.)

Procedure for Presetting the Workpiece Coordinate System

Procedure



- 1 Press function key Pos
- 2 Press soft key [(OPRT)].
- 3 When [WRK-CD] is not displayed, press the continuous menu key □.
- 4 Press soft key [WRK-CD].
- **5** Press soft key **[ALLAXS]** to preset all axes.
- 6 To preset a particular axis in step 5, enter the axis name (X, Y, ...) and O, then press soft key [AXS-CD].

Explanations

Operation mode

Presetting relative coordinates

This function can be executed when the reset state or automatic operation stop state is entered, regardless of the operation mode.

As with absolute coordinates, bit 3 (PPD) of parameter No. 3104 is used to specify whether to preset relative coordinates (RELATIVE).


11.1.5 Actual Feedrate Display

The actual feedrate on the machine (per minute) can be displayed on a current position display screen or program check screen by setting bit 0 (DPF) of parameter 3105. On the 9.5"/10.4" LCD, the actual feedrate is always displayed.

Display procedure for the actual feedrate on the current position display screen

Procedure

1 Press function key Pos to display a current position display screen.



Actual feedrate is displayed after ACT.F.

Explanations

The actual feedrate is displayed in units of millimeter/min or inch/min (depending on the specified least input increment) under the display of the current position.

Actual feedrate value

The actual rate is calculated by the following expression:

$$Fact = \sqrt{\sum_{i=1}^{n} (fi)^2}$$

where

n: Number of axes

fi : Cutting feed rate in the tangential direction of each axis or rapid traverse rate

Fact: Actual feedrate displayed

The display unit: mm/min (metric input).

inch/min (Inch input, Two digits below the decimal point are displayed.)

The feedrate along the PMC axis can be omitted by setting bit 1 (PCF) of parameter 3105.

 Actual feedrate display of feed per revolution In the case of feed per revolution and thread cutting, the actual feedrate displayed is the feed per minute rather than feed per revolution.

 Actual feedrate display of rotary axis In the case of movement of rotary axis, the speed is displayed in units of deg/min but is displayed on the screen in units of input system at that time. For example, when the rotary axis moves at 50 deg/min, the following is displayed: 0.50 INCH/M

 Actual feedrate display on the other screen The program check screen also displays the actual feedrate.


11.1.6 Display of Run Time and Parts Count

The run time, cycle time, and the number of machined parts are displayed on the current position display screens.

Procedure for displaying run time and parts count on the current position display screen

Procedure

1 Press function key Pos to display a current position display screen.



The number of machined parts (PART COUNT), run time (RUN TIME), and cycle time (CYCLE TIME) are displayed under the current position.

Explanations

PART COUNT

Indicates the number of machined parts. The number is incremented each time M02, M30, or an M code specified by parameter 6710 is executed.

RUN TIME

Indicates the total run time during automatic operation, excluding the stop and feed hold time.

CYCLE TIME

Indicates the run time of one automatic operation, excluding the stop and feed hold time. This is automatically preset to 0 when a cycle start is performed at reset state. It is preset to 0 even when power is removed.

 Display on the other screen

Details of the run time and the number of machined parts are displayed on the setting screen. See III–11.4.5.

Parameter setting

The number of machined parts and run time cannot be set on current position display screens. They can be set by parameters No. 6711, 6751, and 6752 or on the setting screen.

Incrementing the number of machined parts

Bit 0 (PCM) of parameter 6700 is used to specify whether the number of machined parts is incremented each time M02, M30, or an M code specified by parameter 6710 is executed, or only each time an M code specified by parameter 6710 is executed.


11.1.7 Operating Monitor Display

The reading on the load meter can be displayed for each servo axis and the serial spindle by setting bit 5 (OPM) of parameter 3111 to 1. The reading on the speedometer can also be displayed for the serial spindle.

Procedure for displaying the operating monitor

Procedure

- 1 Press function key Pos to display a current position display screen.
- 2 Press the continuous–menu key [>].
- **3** Press soft key [MONI].



Explanations

Display of the servo axes

The reading on the load meter can be displayed for up to eight servo axes by setting parameters 3151 to 3158.

When all these parameters are set to 0, data is displayed only to the 3rd axis.

Display of the spindle axes

When serial spindles are used, the reading on the load meter and speedometer can be displayed only for the main serial spindle.

Unit of graph

The bar graph for the load meter shows load up to 200% (only a value is displayed for load exceeding 200%). The bar graph for the speedometer shows the ratio of the current spindle speed to the maximum spindle speed (100%).

Load meter

The reading on the load meter depends on servo parameter 2086 and spindle parameter 4127.

Speedometer

Although the speedometer normally indicates the speed of the spindle motor, it can also be used to indicate the speed of the spindle by setting bit 6 (OPS) of parameter 3111 to 1.

The spindle speed to be displayed during operation monitoring is calculated from the speed of the spindle motor (see the formula below). The spindle speed can therefore be displayed, during operation monitoring, even when no position coder is used. To display the correct spindle speed, however, the maximum spindle speed for each gear (spindle speed at each gear ratio when the spindle motor rotates at the maximum speed) must be set in parameters No. 3741 to 3744.

The input of the clutch and gear signals for the first serial spindle is used to determine the gear which is currently selected. Control the input of the CTH1A and CTH2A signals according to the gear selection, by referring to the table below.

(Formula for calculating the spindle speed to be displayed)

The following table lists the correspondence between clutch and gear selection signals CTH1A and CTH2A, used to determine the gear being used, and parameters:

CTH1A	CTH2A	Parameter	Serial spindle spec
0	0	=No.3741 (Maximum spindle speed with gear 1)	HIGH
0	1	=No.3742 (Maximum spindle speed with gear 2)	MEDIUM HIGH
1	0	=No.3743 (Maximum spindle speed with gear 3)	MEDIUM LOW
1	1	=No.3744 (Maximum spindle speed with gear 4)	LOW

The speed of the spindle motor and spindle can be displayed, during operation monitoring, only for the first serial spindle and the spindle switching axis for the first serial spindle. It cannot be displayed for the second spindle.

Color of graph

If the value of a load meter exceeds 100%, the bar graph turns purple.

11.2 SCREENS DISPLAYED BY FUNCTION KEY PROG (IN MEMORY MODE OR MDI MODE)

This section describes the screens displayed by pressing function key in MEMORY or MDI mode. The first four of the following screens display the execution state for the program currently being executed in MEMORY or MDI mode and the last screen displays the command values for MDI operation in the MDI mode:

- 1. Program contents display screen
- 2. Current block display screen
- 3. Next block display screen
- 4. Program check screen
- 5. Program screen for MDI operation

Function key PROG can also be pressed in MEMORY mode to display the program restart screen and scheduling screen.

See III–4.5 for the program restart screen.

See III–4.6 for the scheduling screen.

11.2.1 Program Contents Display

Displays the program currently being executed in MEMORY or MDI mode.

Procedure for displaying the program contents

- 1 Press function key Prog to display the program screen.
- 2 Press chapter selection soft key [PRGRM].
 The cursor is positioned at the block currently being executed.

```
PROGRAM
                              O2000 N00130
 O2000:
 N100 G92 X0 Y0 Z70.;
 N110 G91 G00 Y-70.;
 N120 Z-70.
 N130 G42 G39 I-17.5;
 N140 G41 G03 X-17.5 Y17.5 R17.5;
 N150 G01 X-25.
 N160 G02 X27.5 Y27.5 R27.5;
 N170 G01 X20.;
 N180 G02 X45. Y45. R45.;
                                   S 0 T0000
MEM STRT ***
                        16:05:59
[PRGRM] [CHECK] [CURRNT] [NEXT] [(OPRT)]
```

Explanations

• 12 soft keys display unit

The contents of the program are displayed on the right half of the screen or on the entire screen (switched each time soft key **[PRGRM]** is pressed).

```
O0006 N00000
PROGRAM
O0003;
                               N015 G99G82X550.0Y-450.0
N001 G92X0Y0Z0;
N002 G90 G00 Z250.0 T11 M6;
                                      Z-130.0R-97.0P300F70;
                               N016 G98Y-650.0;
N003 G43 Z0 H11;
                               N017 G99X1050.0;
     S30 M3
N004
                               N018 G98Y-450.0:
                               N019 G00X0Y0M5;
N005 G99 G81X400.0 R Y-350.0
      Z-153.0R-97.0 F120;
                               N020 G49Z250.0T31M6:
N006
                               N021
                                     G43Z0H31:
N007
     G98Y-750.0;
                               N022 S10M3;
N008 G99X1200.0;
                               N023 G85G99X800.0Y-350.0
N009
     Y-550.0;
                                      Z-153.0R47.0F50;
N010 G98Y-350.0;
                               N024 G91Y-200.0K2;
     G00X0Y0M5;
N011
                               N025 G28X0Y0M5;
N012 G497250 0T15M6
                                N026
                                     G49Z0;
N013 G43Z0H15;
N014 S20M3;
                                                07:12:55
                                     O SRH SRH↑ SRH↓ REWIND
```


11.2.2 Current Block Display Screen

Displays the block currently being executed and modal data in the MEMORY or MDI mode.

Procedure for displaying the current block display screen

Procedure


- 1 Press function key Prog.
- 2 Press chapter selection soft key [CURRNT]. The block currently being executed and modal data are displayed. The screen displays up to 22 modal G codes and up to 11 G codes specified in the current block.



Explanations

• 12 soft keys display unit

The current block display screen is not provided for 12 soft keys display unit. Press soft key **[PRGRM]** to display the contents of the program on the right half of the screen. The block currently being executed is indicated by the cursor. Modal data is displayed on the left half of the screen. The screen displays up to 18 modal G codes.



11.2.3 Next Block Display Screen

Displays the block currently being executed and the block to be executed next in the MEMORY or MDI mode.

Procedure for displaying the next block display screen

Procedure

- 1 Press function key Prog
- 2 Press chapter selection soft key [NEXT].

The block currently being executed and the block to be executed next are displayed.

The screen displays up to 11 G codes specified in the current block and up to 11 G codes specified in the next block.

```
PROGRAM O2000 N00130

(CURRNT) (NEXT)

G01 X 17.500 G39 I -17.500

G17 F 2000 G42

G41 H 2

G80

>_
MEM STRT ***

S 0 T0000
```

[PRGRM][CHECK][CURRNT][NEXT][(OPRT)]

11.2.4 Program Check Screen

Displays the program currently being executed, current position of the tool, and modal data in the MEMORY mode.

Procedure for displaying the program check screen

Procedure

- 1 Press function key PROG
- 2 Press chapter selection soft key [CHECK]. The program currently being executed, current position of the tool, and modal data are displayed.

```
PROGRAM
                             O2000 N00130
  O0010;
  G92 G90 X100. Y200. Z50.;
  G00 X0 Y0 Z0;
  G01 Z250. F1000;
  (ABSOLUTE)(DIST TO GO) G00 G94
   G80
     0.000 X 0.000 G17 G21 G98
     0.000 Y 0.000 G90 G40 G50
  Z 0.000 Z 0.000 G22 G49 G67
                         В
                         M
                    D
    F
              S
                                   S 0 T0000
MEM STRT
                  16:05:59
[ PRGRM ][ CHECK ][ CURRNT ][ NEXT ][ (OPRT) ]
```

Explanations

Program display

The screen displays up to four blocks of the current program, starting from the block currently being executed. The block currently being executed is displayed in reverse video. During DNC operation, however, only three blocks can be displayed.

Current position display

The position in the workpiece coordinate system or relative coordinate system and the remaining distance are displayed. The absolute positions and relative positions are switched by soft keys [ABS] and [REL].

When there are six or more controlled axes, pressing the **[ABS]** soft key toggles the display between the absolute coordinates for the first to fifth axes and those for the sixth to eighth axes. Pressing the **[REL]** soft key toggles the relative coordinate display in the same way.

Modal G codes

Up to 12 modal G codes are displayed.

 Display during automatic operation

During automatic operation, the actual speed, SACT, and repeat count are displayed. The key input prompt (>_) is displayed otherwise.


T codes

Then bit 2 (PCT) of parameter No. 3108 is set to 1, the T codes specified with the PMC (HD.T/NX.T) are displayed instead of those specified in the program. Refer to the FANUC PMC Programming Manual (B–61863E) for details of HD.T/NX.T.

• 12 soft keys display unit

The program check screen is not provided for 12 soft keys display unit. Press soft key **[PRGRM]** to display the contents of the program on the right half of the screen. The block currently being executed is indicated by the cursor. The current position of the tool and modal data are displayed on the left half of the screen.

Up to 18 modal G codes are displayed.




11.2.5 Program Screen for MDI Operation

Displays the program input from the MDI and modal data in the MDI mode.

Procedure for displaying the program screen for MDI operation

Procedure

- 1 Press function key Prog
- 2 Press chapter selection soft key [MDI].
 The program input from the MDI and modal data are displayed.



Explanations

MDI operation

See III–4.2 for MDI operation.

Modal information

The modal data is displayed when bit 7 (MDL) of parameter 3107 is set to 1. Up to 16 modal G codes are displayed. However, the contents of the program are displayed on the right half of the screen and the modal data is displayed on the left half of the screen, regardless of this parameter.

 Displaying during automatic operation During automatic operation, the actual speed, SACT, and repeat count are displayed. The key input prompt (>_) is displayed otherwise.

11.3 SCREENS DISPLAYED BY FUNCTION KEY PROG (IN THE EDIT MODE)

This section describes the screens displayed by pressing function key in the EDIT mode. Function key in the EDIT mode can display the program editing screen and the program list screen (displays memory used and a list of programs). Pressing function key programming in the EDIT mode can also display the conversational graphics programming screen and the floppy file directory screen. See III–9 and 10 for the program editing screen and conversational graphics programming screen. See III–8 for the floppy file directory screen.

11.3.1 Displaying Memory Used and a List of Programs

Displays the number of registered programs, memory used, and a list of registered programs.

Procedure for displaying memory used and a list of programs

Procedure

- 1 Select the **EDIT** mode.
- 2 Press function key Prog
- 3 Press chapter selection soft key [DIR].

PROGRAM DIRECTORY O0001 N00010 MEMORY (CHAR.) PROGRAM (NUM.) USED: 60 3321 FREE: O0010 O0001 O0003 O0002 O0555 O0999 O0062 O0004 O0005 O1111 O0969 O6666 O0021 O1234 O0588 O0020 O0040 S 0 T0000 MDI **** *** 16:05:59 [PRGRM] [DIR] [] [C.A.P.] [(OPRT)]

Explanations

Details of memory used

PROGRAM NO. USED

PROGRAM NO. USED: The number of the programs registered

(including the subprograms)

FREE : The number of programs which can be

registered additionally.

MEMORY AREA USED

MEMORY AREA USED: The capacity of the program memory in which

data is registered (indicated by the number of

characters).

**FREE : The capacity of the program memory which

can be used additionally (indicated by the

number of characters).

Program library list

Program Nos. registered are indicated.

Also, the program name can be displayed in the program table by setting parameter NAM (No. 3107#0) to 1.

PROGRAM DIRECTORY O0001 N00010 PROGRAM (NUM.) MEMORY (CHAR.) USED: 60 3321 FREE: 2 429 O0001 (MACRO-GCODE.MAIN) O0002 (MACRO-GCODE.SUB1) O0010 (TEST-PROGRAM.ARTHMETIC NO.1) O0020 (TEST-PROGRAM.F10-MACRO) O0040 (TEST-PROGRAM.OFFSET) O0050 O0100 (INCH/MM CONVERT CHECK NO.1) O0200 (MACRO-MCODE.MAIN) EDIT **** ***] [(OPRT)] [PRGRM] [**DIR**] [] [

Program name

Always enter a program name between the control out and control in codes immediately after the program number.

Up to 31 characters can be used for naming a program within the parentheses. If 31 characters are exceeded, the exceeded characters are not displayed.

Only program number is displayed for the program without any program name.

Software series

Software series of the system is displayed.

It is used for maintenance; user is not required this information.

 Order in which programs are displayed in the program library list Programs are displayed in the same order that they are registered in the program library list. However, if bit 4 (SOR) of parameter 3107 is set to 1, programs are displayed in the order of program number starting from the smallest one.

Order in which programs are registered

When no program has been deleted from the list, each program is registered at the end of the list.

If some programs in the list were deleted, then a new program is registered, the new program is inserted in the empty location in the list created by the deleted programs.

Example) When bit 4 (SOR) of parameter 3107 is 0

- 1. After clearing all programs, register programs O0001, O0002, O0003, O0004, and O0005 in this order. The program library list displays the programs in the following order: O0001, O0002, O0003, O0004, O0005
- 2. Delete O0002 and O0004. The program library list displays the programs in the following order: O0001, O0003, O0005
- 3. Register O0009. The program library list displays the programs in the following order: O0001, O0009, O0003, O0005

11.3.2 Displaying a Program List for a Specified Group

In addition to the normal listing of the numbers and names of CNC programs stored in memory, programs can be listed in units of groups, according to the product to be machined, for example.


To assign CNC programs to the same group, assign names to those programs, beginning each name with the same character string.

By searching through the program names for a specified character string, the program numbers and names of all the programs having names including that string are listed.


Procedure for Displaying a Program List for a Specified Group


Procedure

- 1 Enter EDIT or background editing mode.
- 2 Press the Prog function key.
- 3 Press the PROG function key or **[DIR]** soft key to display the program list.



- 4 Press the **[(OPRT)]** operation soft key.
- 5 Press the **[GROUP]** operation soft key.
- **6** Press the **[NAME]** operation soft key.
- 7 Enter the character string corresponding to the group for which a search is to be made, using the MDI keys. No restrictions are imposed on the length of a program name. Note, however, that search is made based on only the first 32 characters.







8 Pressing the **[EXEC]** operation soft key displays the group—unit program list screen, listing all those programs whose name includes the specified character string.

[Group-unit program list screen displayed when a search is made for "GEAR-1000*"]

When the program list consists of two or more pages, the pages can be changed by using a page key.

Explanations

* and ?

In the above example, the asterisk (*) must not be omitted. The asterisk indicates an arbitrary character string (wild card specification).

"GEAR-1000*" indicates that the first nine characters of the target program names must be "GEAR-1000," followed by an arbitrary character string. If only "GEAR-1000" is entered, a search is made only for those CNC programs having the nine-character name "GEAR-1000."

A question mark (?) can be used to specify a single arbitrary character. For example, entering "????-1000" enables a search to be made for programs having names which start with four arbitrary characters, followed by "-1000".

[Example of using wild cards]

(Entered character string)		(Group for which the search will be made)
(a)	··** [*]	CNC programs having any name
(b)	"*ABC"	CNC programs having names which end with "ABC"
(c)	"ABC*"	CNC programs having names which start with "ABC"
(d)	"*ABC*"	CNC programs having names which include "ABC"
(e)	"?A?C"	CNC programs having four-character names, the second and fourth characters of which are A and C, respectively
(f)	"??A?C"	CNC programs having five-character names, the third and fifth characters of which are A and C, respectively
(g)	"123*456"	CNC programs having names which start with "123" and which end with "456"

If no program is located as a result of a search for an entered character

string, warning message "DATA NOT FOUND" is displayed on the

A group—unit program list, generated by a search, is held until the power

- When the specified character string cannot be found
- Holding the group for which a search is made
- Group for which previous search was made

After changing the screen from the group—unit program list to another screen pressing the **IPR—GRP1** operation soft key (displayed in step 6)

is turned off or until another search is performed.

program list screen.

screen, pressing the **[PR-GRP]** operation soft key (displayed in step 6) redisplays the group—unit program list screen, on which the program names for the previously searched group are listed. Using this soft key eliminates the need to enter the relevant character string again to redisplay the search results after changing the screen.

Examples

Assume that the main programs and subprograms for machining gear part number 1000 all have names which include character string "GEAR–1000." The numbers and names of those programs can be listed by searching through the names of all CNC programs for character string "GEAR–1000." This function facilitates the management of the CNC programs stored in large–capacity memory.

11.4 SCREENS DISPLAYED BY FUNCTION KEY OFFSET OFFSE

Press function key sering to display or set tool compensation values and other data.

This section describes how to display or set the following data:

- 1. Tool offset value
- 2. Settings
- 3. Run time and part count
- 4. Workpiece origin offset value
- 5. Custom macro common variables
- 6. Pattern menu and pattern data
- 7. Software operator's panel
- 8. Tool life management data

This section also describes measurement of tool length and the sequence number comparison and stop function.

The pattern menu, pattern data, software operator's panel, and tool life management data depend on the specifications of the machine tool builder. See the manual issued by the machine tool builder for details.

11.4.1 Setting and Displaying the Tool Offset Value

Tool offset values, tool length offset values, and cutter compensation values are specified by D codes or H codes in a program. Compensation values corresponding to D codes or H codes are displayed or set on the screen.

Procedure for setting and displaying the tool offset value


Procedure

1 Press function key $\left[\begin{array}{c} OFFSET \\ SETTING \end{array}\right]$.


For the two-path control, select the tool post for which tool compensation values are to be displayed with the tool post selection switch.

2 Press chapter selection soft key [OFFSET] or press several times until the tool compensation screen is displayed.

The screen varies according to the type of tool offset memory.



Tool offset memory A



Tool offset memory C

- 3 Move the cursor to the compensation value to be set or changed using page keys and cursor keys, or enter the compensation number for the compensation value to be set or changed and press soft key [NO.SRH].
- 4 To set a compensation value, enter a value and press soft key [INPUT]. To change the compensation value, enter a value to add to the current value (a negative value to reduce the current value) and press soft key [+INPUT]. Or, enter a new value and press soft key [INPUT].

Explanations

Decimal point input

A decimal point can be used when entering a compensation value.

Other setting method

An external input/output device can be used to input or output a tool offset value. See III–8. A tool length offset value can be set by measuring the tool length as described in the next subsection.

Tool offset memory

There are tool offset memories A, B, and C, which are classified as follows:

Tool offset memory A

D codes and H codes are treated the same. Tool geometry compensation and tool wear compensation are treated the same.

Tool offset memory B

D codes and H codes are treated the same. Tool geometry compensation and tool wear compensation are treated differently.


Tool offset memory C

D codes and H codes are treated differently. Tool geometry compensation and tool wear compensation are treated differently.


 Disabling entry of compensation values The entry of compensation values may be disabled by setting bit 0 (WOF) and bit 1 (GOF) of parameter 3290 (not applied to tool offset memory A). And then, the input of tool compensation values from the MDI can be inhibited for a specified range of offset numbers. The first offset number for which the input of a value is inhibited is set in parameter No. 3294. The number of offset numbers, starting from the specified first number, for which the input of a value is inhibited is set in parameter No. 3295. Consecutive input values are set as follows:

- 1) When values are input for offset numbers, starting from one for which input is not inhibited to one for which input is inhibited, a warning is issued and values are set only for those offset numbers for which input is not inhibited.
- 2) When values are input for offset numbers, starting from one for which input is inhibited to one for which input is not inhibited, a warning is issued and no values are set.

• 12 soft keys display unit



Tool offset memory A



Tool offset memory C

11.4.2 Tool Length Measurement


The length of the tool can be measured and registered as the tool length offset value by moving the reference tool and the tool to be measured until they touch the specified position on the machine.

The tool length can be measured along the X-, Y-, or Z-axis.

Procedure for tool length measurement

Procedure


- 1 Use manual operation to move the reference tool until it touches the specified position on the machine (or workpiece.)
- 2 Press function key Pos several times until the current position display screen with relative coordinates is displayed.



- **3** Reset the relative coordinate for the Z-axis to 0 (see III-11.1.2 for details).
- 4 Press function key several times until the tool compensation screen is displayed.
- 5 Use manual operation to move the tool to be measured until it touches the same specified position. The difference between the length of the reference tool and the tool to be measured is displayed in the relative coordinates on the screen.
- 6 Move the cursor to the compensation number for the target tool (the cursor can be moved in the same way as for setting tool compensation values).
- 7 Press the address key Z.
 If either X or Y key is depressed instead of Z key, the X or Y axis relative coordinate value is input as an tool length compensation value.



8 Press the soft key **[INP.C.]**. The Z axis relative coordinate value is input and displayed as an tool length offset value.



11.4.3 Displaying and Entering Setting Data

Data such as the TV check flag and punch code is set on the setting data screen. On this screen, the operator can also enable/disable parameter writing, enable/disable the automatic insertion of sequence numbers in program editing, and perform settings for the sequence number comparison and stop function.

See III–10.2 for automatic insertion of sequence numbers.

See III–11.4.4 for the sequence number comparison and stop function. This subsection describes how to set data.

Procedure for setting the setting data

Procedure

- 1 Select the MDI mode.
- 2 Press function key OFFSET SETTING.
- 3 Press soft key **[SETING]** to display the setting data screen. This screen consists of several pages.

Press page key or until the desired screen is displayed.

An example of the setting data screen is shown below.

```
SETTING (HANDY)
                                O0001 N00000
 PARAMETER WRITE = 1 (0:DISABLE 1:ENABLE)
 TV CHECK
                 = 0 (0:OFF 1:ON)
 PUNCH CODE
                 = 1 (0:EIA 1:ISO)
                = 0 (0:MM 1:INCH)
 INPUT UNIT
 I/O CHANNEL
                 = 0 (0-3:CHANNEL NO.)
 SEQUENCE NO.
                 = 0 (0:OFF 1:ON)
 TAPE FORMAT
                 = 0 (0:NO CNV 1:F15)
 SEQUENCE STOP =
                          0 (PROGRAM NO.)
 SEQUENCE STOP =
                          0 (SEQUENCE NO.)
MDI **** ***
                             16:05:59
[OFFSET][SETING][WORK][
                                  ] [(OPRT)]
```

```
SETTING (HANDY)

MIRROR IMAGE

MIRROR IMAGE
```

Move the cursor to the item to be changed by pressing cursor keys

↑, , , or .

5 Enter a new value and press soft key [INPUT].

Contents of settings

• **PARAMETER WRITE** Setting whether parameter writing is enabled or disabled.

0 : Disabled1 : Enabled

• TV CHECK Setting to perform TV check.

0 : No TV check1 : Perform TV check

• **PUNCH CODE** Setting code when data is output through reader puncher interface.

0: EIA code output1: ISO code output

• **INPUT UNIT** Setting a program input unit, inch or metric system

0 : Metric1 : Inch

• **I/O CHANNEL** Using channel of reader/puncher interface.

0: Channel 01: Channel 12: Channel 23: Channel 3

SEQUENCE STOP

Setting of whether to perform automatic insertion of the sequence number or not at program edit in the EDIT mode.

0: Does not perform automatic sequence number insertion.

 $1: \ Perform\ automatic\ sequence\ number\ insertion.$

• **TAPE FORMAT** Setting the F15 tape format conversion.

0: Tape format is not converted.1: Tape format is converted.

See II. PROGRAMMING for the F15 tape format.

• **SEQUENCE STOP** Setting the sequence number with which the operation stops for the

sequence number comparison and stop function and the number of the

program to which the sequence number belongs

• MIRROR IMAGE Setting of mirror image ON/OFF for each axes.

0 : Mirror image off1 : Mirror image on

• Others

Page key or can also be pressed to display the SETTING

(TIMER) screen. See III-11.4.5 for this screen.

11.4.4 Sequence Number Comparison and Stop

If a block containing a specified sequence number appears in the program being executed, operation enters single block mode after the block is executed.

Procedure for sequence number comparison and stop

Procedure

- 1 Select the MDI mode.
- 2 Press function key OFFSET SETTING
- 3 Press chapter selection soft key [SETING].
- 4 Press page key or several times until the following screen is displayed.

```
SETTING (HANDY)
                                 O0001 N00000
 PARAMETER WRITE = 1 (0:DISABLE 1:ENABLE)
 TV CHECK
                  = 0 (0:OFF 1:ON)
 PUNCH CODE
                = 1 (0:EIA 1:ISO)
 INPUT UNIT
                = 0 (0:MM 1:INCH)
                = 0 (0-3:CHANNEL NO.)
 I/O CHANNEL
 SEQUENCE NO. = 0 (0:OFF 1:ON) 
TAPE FORMAT = 0 (0:NO CNV 1:F10/11)
 SEQUENCE STOP =
                           0 (PROGRAM NO.)
                          11 (SEQUENCE NO.)
 SEQUENCE STOP =
MDI **** ***
                            16:05:59
[OFFSET][SETING] [ WORK ] [
                                   ] [(OPRT)]
```

- 5 Enter in (PROGRAM NO.) for SEQUENCE STOP the number (1 to 9999) of the program containing the sequence number with which operation stops.
- **6** Enter in (SEQUENCE NO.) for SEQUENCE STOP (with five or less digits) the sequence number with which operation is stopped.
- 7 When automatic operation is executed, operation enters single block mode at the block containing the sequence number which has been set.

Explanations

 Sequence number after the program is executed After the specified sequence number is found during the execution of the program, the sequence number set for sequence number compensation and stop is decremented by one. When the power is turned on, the setting of the sequence number is 0.

Exceptional blocks

If the predetermined sequence number is found in a block in which all commands are those to be processed within the CNC control unit, the execution does not stop at that block.

Example

N1 #1=1;

N2 IF [#1 EQ 1] GOTO 08;

N3 GOTO 09; N4 M98 P1000; N5 M99;

In the example shown above, if the predetermined sequence number is found, the execution of the program does not stop.

Stop in the canned cycle

If the predetermined sequence number is found in a block which has a canned-cycle command, the execution of the program stops after the return operation is completed.

 When the same sequence number is found several times in the program If the predetermined sequence number appears twice or more in a program, the execution of the program stops after the block in which the predetermined sequence number is found for the first time is executed.

 Block to be repeated a specified number of times If the predetermined sequence number is found in a block which is to be executed repeatedly, the execution of the program stops after the block is executed specified times.

11.4.5 Displaying and Setting Run Time,Parts Count, and Time

Various run times, the total number of machined parts, number of parts required, and number of machined parts can be displayed. This data can be set by parameters or on this screen (except for the total number of machined parts and the time during which the power is on, which can be set only by parameters).

This screen can also display the clock time. The time can be set on the screen.

Procedure for Displaying and Setting Run Time, Parts Count and Time

Procedure

- 1 Select the MDI mode.
- 2 Press function key OFFSET SETTING
- 3 Press chapter selection soft key [SETING].
- 4 Press page key or several times until the following screen is displayed.

```
SETTING (TIMER)
                                      O0001 N00000
     PARTS TOTAL
     PARTS REQUIRED =
     PARTS COUNT =
     POWER ON
                             = 4H 31M
     OPERATING TIME
                         OH OM
     CUTTING TIME
                         0H 37M
     FREE PURPOSE
                            OH OM
                                     08
     CYCLE TIME
                            OH OM
          DATE
                      1997/07/05
          TIME=
                      11:32:52
MDI **** ***
[OFFSET] [ SETING] [ WORK ] [
                                        ] [ (OPRT) ]
```

- 5 To set the number of parts required, move the cursor to PARTS REQUIRED and enter the number of parts to be machined.
- To set the clock, move the cursor to DATE or TIME, enter a new date or time, then press soft key [INPUT].

Display items

PARTS TOTAL

This value is incremented by one when M02, M30, or an M code specified by parameter 6710 is executed. This value cannot be set on this screen. Set the value in parameter 6712.

PARTS REQUIRED

It is used for setting the number of machined parts required. When the "0" is set to it, there is no limitation to the number of parts. Also, its setting can be made by the parameter (NO. 6713).

PARTS COUNT

This value is incremented by one when M02, M30, or an M code specified by parameter 6710 is executed. The value can also be set by parameter 6711. In general, this value is reset when it reaches the number of parts required. Refer to the manual issued by the machine tool builder for details.

POWER ON

Displays the total time which the power is on. This value cannot be set on this screen but can be preset in parameter 6750.

• OPERATING TIME

Indicates the total run time during automatic operation, excluding the stop and feed hold time.

This value can be preset in parameter 6751 or 6752.

CUTTING TIME

Displays the total time taken by cutting that involves cutting feed such as linear interpolation (G01) and circular interpolation (G02 or G03). This value can be preset in parameter 6753 or 6754.

• FREE PURPOSE

This value can be used, for example, as the total time during which coolant flows. Refer to the manual issued by the machine tool builder for details.

CYCLE TIME

Indicates the run time of one automatic operation, excluding the stop and feed hold time. This is automatically preset to 0 when a cycle start is performed at reset state. It is preset to 0 even when power is removed.

DATA and TIME

Displays the current date and time. The date and time can be set on this screen.

Limitations

Usage

When the command of M02 or M30 is executed, the total number of machined parts and the number of machined parts are incremented by one. Therefore, create the program so that M02 or M30 is executed every time the processing of one part is completed. Furthermore, if an M code set to the parameter (NO. 6710) is executed, counting is made in the similar manner. Also, it is possible to disable counting even if M02 or M30 is executed (parameter PCM (No. 6700#0) is set to 1). For details, see the manual issued by machine tool builders.

Restrictions

Run time and part count settings

Negative value cannot be set. Also, the setting of "M" and "S" of run time is valid from 0 to 59.

Negative value may not be set to the total number of machined parts.

Time settings

Neither negative value nor the value exceeding the value in the following table can be set.

Item	Maximum value	Item	Maximum value
Year	2085	Hour	23
Month	12	Minute	59
Day	31	Second	59


11.4.6 Displaying and Setting the Workpiece Origin Offset Value

Displays the workpiece origin offset for each workpiece coordinate system (G54 to G59, G54.1 P1 to G54.1 P48 and G54.1 P1 to G54.1 P300) and external workpiece origin offset. The workpiece origin offset and external workpiece origin offset can be set on this screen.

Procedure for Displaying and Setting the Workpiece Origin Offset Value

Procedure

- 1 Press function key OFFSET SETTING
- 2 Press chapter selection soft key [WORK].
 The workpiece coordinate system setting screen is displayed.



- The screen for displaying the workpiece origin offset values consists of two or more pages. Display a desired page in either of the following two ways:
 - Press the page up or page down key.
 - Enter the workpiece coordinate system number (0 : external workpiece origin offset, 1 to 6: workpiece coordinate systems G54 to G59, P1 to P48 : workpiece coordinate systems G54.1 P1 to G54.1 P48, P1 to P300 : workpiece coordinate systems G54.1 P1 to G54.1 P300) and press operation selection soft key [NO.SRH].
- 4 Turn off the data protection key to enable writing.
- 5 Move the cursor to the workpiece origin offset to be changed.
- 6 Enter a desired value by pressing numeric keys, then press soft key [INPUT]. The entered value is specified in the the workpiece origin offset value. Or, by entering a desired value with numeric keys and pressing soft key [+INPUT], the entered value can be added to the previous offset value.
- 7 Repeat 5 and 6 to change other offset values.
- **8** Turn on the data protection key to disable writing.


11.4.7 Direct Input of Measured Workpiece Origin Offsets

This function is used to compensate for the difference between the programmed workpiece coordinate system and the actual workpiece coordinate system. The measured offset for the origin of the workpiece coordinate system can be input on the screen such that the command values match the actual dimensions.

Selecting the new coordinate system matches the programmed coordinate system with the actual coordinate system.

Procedure for Direct Inputting of Measured Workpiece Origin Offsets

Procedure



- 1 When the workpiece is shaped as shown above, position the reference tool manually until it touches surface A of the workpiece.
- 2 Retract the tool without changing the Y coordinate.
- 3 Measure distance α between surface A and the programmed origin of the workpiece coordinate system as shown above.
- 4 Press function key OFFSET SETTING

5 To display the workpiece origin offset setting screen, press the chapter selection soft key **[WORK]**.

WORK COORDINATES (G54)	O1234 N56789	
NO. DATA	NO.	DATA
00 X 0.000	02 X	0.000
(EXT) Y 0.000	(G55) Y	0.000
Z 0.000	Z	0.000
01 X 0.000	03 X	0.000
(G54) Y 0.000	(G56) Y	0.000
Z 0.000	Z	0.000
> Z100. MDI **** *** *** [NO.SRH] [MEASUR] [_	S 0 T0000 05:59 JT][INPUT]

- 6 Position the cursor to the workpiece origin offset value to be set.
- 7 Press the address key for the axis along which the offset is to be set (Y-axis in this example).
- 8 Enter the measured value (α) then press the **[MEASUR]** soft key.
- **9** Move the reference tool manually until it touches surface B of the workpiece.
- 10 Retract the tool without changing the X coordinate.
- 11 Measure distance β then enter the distance at X on the screen in the same way as in steps 7 and 8.

Limitations

Consecutive input

 During program execution Offsets for two or more axes cannot be input at the same time.


This function cannot be used while a program is being executed.

11.4.8 Displaying and Setting Custom Macro Common Variables


Displays common variables (#100 to #149 or #100 to #199, and #500 to #531 or #500 to #999) on the screen. When the absolute value for a common variable exceeds 99999999, ******* is displayed. The values for variables can be set on this screen. Relative coordinates can also be set to valiables.

Procedure for displaying and setting custom macro common variables


Procedure



- 1 Press function key OFFSET SETTING
- 2 Press the continuous menu key \triangleright , then press chapter selection soft key [MACRO]. The following screen is displayed:



- 3 Move the cursor to the variable number to set using either of the following methods:
 - Enter the variable number and press soft key [NO.SRH].
 - Move the cursor to the variable number to set by pressing page keys




- 4 Enter data with numeric keys and press soft key [INPUT].
- 5 To set a relative coordinate in a variable, press address key $\begin{bmatrix} X \end{bmatrix}$, $\begin{bmatrix} Y \end{bmatrix}$, or $\begin{bmatrix} Z \end{bmatrix}$, then press soft key **[INP.C.]**.
- 6 To set a blank in a variable, just press soft key [INPUT]. The value field for the variable becomes blank.

11.4.9 Displaying Pattern Data and Pattern Menu

This subsection uses an example to describe how to display or set machining menus (pattern menus) created by the machine tool builder. Refer to the manual issued by the machine tool builder for the actual pattern menus and pattern data. See II. PROGRAMMING for the pattern data entry function.

Procedure for displaying the pattern data and the pattern menu


Procedure



1 Press function key offset setting

2 Press the continuous menu key \triangleright , then press chapter selection soft key [MENU].

The following screen (pattern menu screen) is displayed:



3 Enter a pattern number and press soft key [SELECT].

In this example, press 5, then press [SELECT].

The following screen (pattern data screen) is displayed:

```
VAR.: BOLT HOLE
                                  O0001 N00000
 NO.
        NAME
                        DATA
                                 COMMENT
 500
        TOOL
                        0.000
                                 *BOLT HOLE
 501
        STANDARD X
                        0.000
        STANDARD Y
                                 CIRCLE*
 502
                        0.000
                                 SET PATTERN
 503
        RADIUS
                        0.000
        S. ANGL
                        0.000
                                 DATA TO VAR.
 505
        HOLES NO
                        0.000
                                 NO.500-505.
                        0.000
 506
                        0.000
ACTUAL POSITION (RELATIVE)
                                 0.000
       0.000
  Ζ
MDI **** ***
                              16:05:59
[OFFSET] [SETING] [
                         ] [
                                 ] [ (OPRT) ]
```

4 Enter necessary pattern data and press [NPUT].

5 After entering all necessary data, enter the **MEMORY** mode and press the cycle start button to start machining.

Explanations

 Explanation of the pattern menu screen

HOLE PATTERN: Menu title

An optional character string can be displayed within 12 characters.

BOLE HOLE: Pattern name

An optional character string can be displayed within 10 characters.

The machine tool builder should program character strings of menu title and pattern name by custom macro, and load them into the program memory.

Explanation of the pattern data screen

BOLT HOLE: Pattern data title

An optional character string can be displayed within 12 characters.

TOOL: Variable name

An optional character string can be displayed within 10 characters.

BOLT HOLE CIRCLE: Comment statement

An optional character string comment can be displayed up to 12 characters/line by 8 lines.

The machine tool builder should program the character strings of variable name and comment statement by custom macro, and load them into the program memory.


11.4.10 Displaying and Setting the Software Operator's Panel

With this function, functions of the switches on the machine operator's panel can be controlled from the CRT/MDI panel.

Jog feed can be performed using numeric keys.


Procedure for displaying and setting the software operator's panel


Procedure



- 1 Press function key OFFSET SETTING
- 2 Press the continuous menu key , then press chapter selection soft key [OPR].
- 3 The screen consists of several pages.

Press page key or until the desired screen is displayed.






4 Move the cursor to the desired switch by pressing cursor key

or

.

- 5 Push the cursor move key ← or → to match the mark to an arbitrary position and set the desired condition.
- 6 Press one of the following arrow keys to perform jog feed. Press the 5 key together with an arrow key to perform jog rapid traverse.



Explanations

Valid operations

The valid operations on the software operator's panel are shown below. Whether to use the MDI panel or machine operator's panel for each group of operations can be selected by parameter 7200.

Group1: Mode selection

Group2: Selection of jog feed axis, jog rapid traverse

Group3: Selection of manual pulse generator feed axis, selection of

manual pulse magnification x1, x10, x100

Group4: Jog federate, federate override, rapid traverse override Group5: Optional block skip, single block, machine lock, dry run

Group6: Protect key Group7: Feed hold

The groups for which the machine operator's panel is selected by parameter 7200 are not displayed on the software operator's panel.

When the screen indicates other than the software operator's panel screen and diagnostic screen, jog feed is not conducted even if the arrow key is pushed.

The feed axis and direction corresponding to the arrow keys can be set with parameters (Nos. 7210 to 7217).

Eight optionally definable switches are added as an extended function of the software operator's panel. The name of these switches can be set by parameters (Nos. 7220 to 7283) as character strings of max. 8 characters. For the meanings of these switches, refer to the manual issued by machine tool builder.

Display

Screens on which jog feed is valid

Jog feed and arrow keys

 General purpose switches

11.4.11 Displaying and Setting Tool Life Management Data

Tool life data can be displayed to inform the operator of the current state of tool life management. Groups which require tool changes are also displayed. The tool life counter for each group can be preset to an arbitrary value. Tool data (execution data) can be reset or cleared. To register or modify tool life management data, a program must be created and executed. See Explanations in this section for details.


When bit 6 (EXT) of parameter 6801 is 1, extended tool life management applies. See III–11.4.12.

Procedure for display and setting the tool life management data

Procedure

- 1 Press function key OFFSET SETTING
- 2 Press the continuous menu key \(\subseteq \) to display chapter selection soft key **[TOOLLF]**.
- 3 Press softkey [TOOLLF].
- 4 One page displays data on two groups. Pressing page key

 or successively displays data on the following groups. Up
 to four group Nos., for which the Tool Change signal is being issued, are displayed at the bottom of each page. An arrow shown in the figure is displayed for five or more groups, if exists.



To display the page containing the data for a group, enter the group number and press soft key [NO.SRH].


The cursor can be moved to an arbitrary group by pressing cursor key



- 6 To change the value in the life counter for a group, move the cursor to the group, enter a new value (four digits), and press [INPUT]. The life counter for the group indicated by the cursor is preset to the entered value. Other data for the group is not changed.
- 7 To reset the tool data, move the cursor on the group to reset, then press the **[(OPRT)]**, **[CLEAR]**, and **[EXEC]** soft keys in this order. All execution data for the group indicated by the cursor is cleared together with the marks (@, #, or *).

Explanations

Display contents



- The first line is the title line.
- In the second line the group number of the current command is displayed.

When there is no group number of the current command, 0 is displayed.

• In lines 3 to 7 the tool life data of the group is displayed.

The third line displays group number, life and the count used.

The life count is chosen by parameter LTM (No. 6800#2) as either minutes(or hours) or number of times used.

In lines 4 to 5, tool numbers are displayed. In this case, the tool is selected in the order, $0034 \rightarrow 0078 \rightarrow 0012 \rightarrow 056 \rightarrow 0090$...

The meaning of each mark before the tool numbers is:

- * : Shows the life has finished.
- #: Shows that the skip command has been accepted.
- @ : Shows that the tool is currently being used.

The life counter counts for tool with @.

- "*" is displayed when the next command is issued by the group to which it belongs.
- Lines 8 to 12 are next group life data to the group displayed in lines 3 to 7.
- In the thirteenth line the group number when the tool change signal is being emitted is displayed. The group number display appears in ascending order. When it cannot be completely displayed, "——>" is displayed.

11.4.12

Displaying and Setting Extended Tool Life Management


The extended tool life management function provides more detailed data display and more data editing functions than the ordinary tool life management function.

Moreover, if the tool life is specified in units of time, the time which has been set can be increased or reduced (life count override).

When bit 6 (EXT) of parameter 6801 is set to 0, the ordinary tool life management function applies. See III-11.4.11.

Procedure for displaying and Setting extended tool life management

Procedure




- Press function key OFFSET SETTING
- 2 Press the continuous menu key \(\) to display chapter selection soft key [TOOLLF].
- 3 Press soft key [TOOLLF] to display the tool life management data

On this screen, place the cursor on a group of items to be edited.

- 4 Press soft key [(OPRT)].
- Press soft key [EDIT].

The extended tool life management data editing screen for the group indicated by the cursor is the displayed.



Tool life management data can be edited as follows:

- 6 Select the MDI mode.
- Stop, pause, or reset the CNC by the feed hold, single block stop, or reset operation (tool life management data cannot be edited while data is set by a program.).

The following editing can be performed. See each step for details:

- Setting the life count type, life value, current life count, and tool data (T, H, or D code): 7–1
- Adding a tool group: 7–2
- Adding a tool number (T code): 7–3

Deleting a tool group: 7–4
Deleting tool data (T, H, or D code): 7–5
Skipping a tool: 7–6
Clearing the life count (resetting the life): 7–7

7–1 Setting the life count type, life value, current life count, and tool data (T, H, or D code)

- (1) Position the cursor on the data item to be changed.
- (2) Enter a desired value.
- (3) Press the softkey [INPUT].

7-2 Adding a tool group

- (1) In step 3, select a group for which no data is set and display the editing screen.
- (2) Enter tool numbers.
- (3) Press soft key [INSERT].
- · In this case, the type of the life counter is determined by the setting of LTM (No. 6800#2), and 0 is set in both the life expectancy and life counter.
- · 0 is set in both the H code and D code.
- · The cursor remains on the tool number until the T code is specified.

7-3 Adding a tool number

- (1) Move the cursor to the tool data (T, H, or D code) after which a new number is to be added.
- (2) Enter the tool number.
- (3) Press soft key [INSERT].

Example), Inserting tool No. 1500 between No. 1 and No. 2.

	NO.	STATE	T-CODE	H-CODE	D-CODE
ı	01	*	0034	11	5
ı	02	#	0078	0	33

Move the cursor to 5 in D–CODE column and press soft key **[INSERT]**.

NO.	STATE	T-CODE	H-CODE	D-CODE
01	*	0034	11	5
02		1500	0	0
03	#	0078	0	33

7–4 Deleting a tool group

- (1) In step 3, position the cusor on a group to be deleted and display the editing screen.
- (2) Press soft key [DELETE].
- (3) Press soft key [GROUP].
- (4) Press soft key **[EXEC]**.

7–5 Deleting tool data (T, H, or D code)

- (1) Position the cursor on the data item (T, H, or D code) to be deleted.
- (2) Press soft key [DELETE].
- (3) Press soft key [**<CRSR>**].
- · The line containing the cursor is deleted.
- When a tool with mark @ (being used) is deleted, mark @ shifts to the tool whose life has expired most recently or which has been skipped.
 In this case, marks * and # are displayed in reverse video. #

7–6 Skipping a tool

- (1) Position the cursor on the data item (T, H, or D code) for the tool to be skipped.
- (2) Press soft key [STATE].
- (3) Press soft key [SKIP].

7–7 Clearing the life count (resetting the life)

- (1) Position the cursor on the data item (T, H, or D code) of the tool to be cleared.
- (2) Press soft key [STATE].
- (3) Press soft key [CLEAR].
- **8** To complete the edit operation, press soft key **[END]**. The tool life management screen is displayed again.

Explanations

Displays

```
LIFE DATA EDIT
                  GROUP: 001 O0010 N00001
         : 1 (1:C 2:M)
 TYPE
                          NEXT GROUP: ***
                          USE GROUP: ***
 LIFE
          9800
 COUNT : 6501
                          SELECTED GROUP: 001
  NO. STATE
               T-CODE
                           H-CODE
                                       D-CODE
  01
                 0034
                             011
                                         005
  02
         #
                 0078
                             000
                                         033
  03
         @
                 0012
                             004
                                         018
  04
                 0056
                             000
                                         000
  05
                 0090
                             000
                                         000
  06
                 0076
                             023
                                         012
MDI **** ***
              16:05:59
[INSERT] [DELETE] [STATE] [END] [INPUT]
```

NEXT GROUP:

Number of the tool group whose life is to be calculated by the next M06 command

USE GROUP:

Number of the tool group whose life is being calculated

SELECTED GROUP:

Number of the tool group whose life is being calculated or was calculated last

TYPE: 1: Life count is represented in units of cycles. **TYPE: 2**: Life count is represented in units of minutes.

LIFE: Life expectancy COUNT: Life counter STATE: State of the tool

Tool state	In use	Not in use
Available	@	_(Space)
Skip	#	#
Skipped	w / 🗱 (Note)	*

NOTE

When bit 3 (EMD) of parameter 6801 is set to 0, @ is displayed until the next tool is selected.

T-CODE : Tool number H-CODE : H code D-CODE : D code

Tool life management screen

When the extended tool life management function is provided, the following items are added to the tool life management screen:

- NEXT: Tool group to be used next
- USE: Tool group in use
- Life counter type for each tool group (C: Cycles, M: Minutes)

```
TOOL LIFE DATA
                                   O0001 N00001
NEXT
                           SELECTED GROUP: 001
            USE
GROUP
            001: C
                      LIFE 9800
                                  COUNT 6501
                           @0012
   *0034
               #0078
                                         *0056
    0090
               *0076
GROUP
            002: C
                      LIFE 9800
                                  COUNT 1001
   *0011
               #0022
                           *0201
                                       *0144
   *0155
               #0066
                           0176
                                        0188
    0019
               0234
                           0007
                                        0112
    0156
               0090
                           0016
                                        0232
TO BE CHANGED:
                      006
                           012 013 014
                   S 0 T0000
 MDI **** ***
                16:05:59
 [NO.SRH][
                 ] [CLEAR] [ EDIT ] [INPUT]
```

• Life count override

The tool life count can be overridden provided that the life counter is indicated in units of minutes and LFV (bit 2 of parameter 6801) is 1. Override values can be specified using the override switch on the operator's panel within the range from 0 to 99.9. If 0 is specified, tool life is not counted. If the count of actual cutting time is less than 4 seconds, the override value is invalid.

Example

When cutting is performed for 10 minutes with an override of 0.1, the tool life counter counts one minute.

 Display of the mark indicating that the life of a tool has expired The symbol * for indicating that the life of a tool has expired can be displayed either when the machine starts using the next tool or when the life of the tool actually expires. Either of these methods can be selected using EMD (bit 3 of parameter 6801).

Influence of changes in data

- Modification of the life expectancy or life counter does not affect the tool states or tool change signal.
- When the type of the life counter is changed, be sure to change the life expectancy and life count as well.

11.5 SCREENS DISPLAYED BY FUNCTION KEY SYSTEM

When the CNC and machine are connected, parameters must be set to determine the specifications and functions of the machine in order to fully utilize the characteristics of the servo motor or other parts.

This chapter describes how to set parameters on the MDI panel. Parameters can also be set with external input/output devices such as the Handy File (see III–8).

In addition, pitch error compensation data used for improving the precision in positioning with the ball screw on the machine can be set or displayed by the operations under function key system.

See III–7 for the diagnostic screens displayed by pressing function key $$\screen$$.

11.5.1 Displaying and Setting Parameters


When the CNC and machine are connected, parameters are set to determine the specifications and functions of the machine in order to fully utilize the characteristics of the servo motor. The setting of parameters depends on the machine. Refer to the parameter list prepared by the machine tool builder.

Normally, the user need not change parameter setting.

Procedure for displaying and setting parameters

Procedure

- 1 Set 1 for **PARAMETER WRITE** to enable writing. See the procedure for enabling/disabling parameter writing described below.
- 2 Press function key system
- **3** Press chapter selection soft key **[PARAM]** to display the parameter screen.



- 4 Move the cursor to the parameter number to be set or displayed in either of the following ways:
 - Enter the parameter number and press soft key [NO.SRH].
 - Move the cursor to the parameter number using the page keys,
 and and and and cursor keys,
 , , , and , and .
- 5 To set the parameter, enter a new value with numeric keys and press soft key [INPUT]. The parameter is set to the entered value and the value is displayed.
- **6** Set 0 for **PARAMETER WRITE** to disable writing.

Procedure for enabling/displaying parameter writing

- 1 Select the **MDI** mode or enter state emergency stop.
- 2 Press function key OFFSET SETTING
- 3 Press soft key [**SETING**] to display the setting screen.

```
SETTING (HANDY)
                                  O0001 N00000
 PARAMETER WRITE = 1 (0:DISABLE 1:ENABLE)
                        (0:OFF 1:ON)
 TV CHECK
                  = 0
 PUNCH CODE
                   = 1 (0:EIA 1:ISO)
 INPUT UNIT
                   = 0 (0:MM 1:INCH)
                  = 0 (0-3:CHANNEL NO.)
  I/O CHANNEL
 SEQUENCE NO.
                   = 0 (0:OFF 1:ON)
                  = 0 (0:NO CNV 1:F10/11)
  TAPE FORMAT
  SEQUENCE STOP
                        0 (PROGRAM NO.)
                  =
  SEQUENCE STOP
                        11(SEQUENCE NO.)
                                   S 0 T0000
MDI **** ***
[OFFSET] [SETING] [WORK] [
                                   ] [ (OPRT) ]
```

- 4 Move the cursor to **PARAMETER WRITE** using cursor keys.
- 5 Press soft key **[(OPRT)]**, then press **[1: ON]** to enable parameter writing.
 - At this time, the CNC enters the P/S alarm state (No. 100).
- 6 After setting parameters, return to the setting screen. Move the cursor to PARAMETER WRITE and press soft key [(OPRT)], then press [0: OFF].
- 7 Depress the RESET key to release the alarm condition. If P/S alarm No. 000 has occurred, however, turn off the power supply and then turn it on, otherwise the P/S alarm is not released.

Explanations

- Setting parameters with external input/output devices
- Parameters that require turning off the power
- Parameter list
- Setting data

See III–8 for setting parameters with external input/output devices such as the Handy File.

Some parameters are not effective until the power is turned off and on again after they are set. Setting such parameters causes P/S alarm 000. In this case, turn off the power, then turn it on again.

Refer to the FANUC Series 21*i*/210*i*—A Parameter Manual (B–63090EN) for the parameter list.

Some parameters can be set on the setting screen if the parameter list indicates "Setting entry is acceptable". Setting 1 for **PARAMETER WRITE** is not necessary when three parameters are set on the setting screen.

11.5.2 Displaying and Setting Pitch Error Compensation Data

If pitch error compensation data is specified, pitch errors of each axis can be compensated in detection unit per axis.

Pitch error compensation data is set for each compensation point at the intervals specified for each axis. The origin of compensation is the reference position to which the tool is returned.


The pitch error compensation data is set according to the characteristics of the machine connected to the NC. The content of this data varies according to the machine model. If it is changed, the machine accuracy is reduced.

In principle, the end user must not alter this data.

Pitch error compensation data can be set with external devices such as the Handy File (see III–8). Compensation data can also be written directly with the MDI panel.

The following parameters must be set for pitch error compensation. Set the pitch error compensation value for each pitch error compensation point number set by these parameters.

In the following example, 33 is set for the pitch error compensation point at the reference position.



- Number of the pitch error compensation point at the reference position (for each axis): Parameter 3620
- Number of the pitch error compensation point having the smallest value (for each axis): Parameter 3621
- Number of the pitch error compensation point having the largest value (for each axis): Parameter 3622
- Pitch error compensation magnification (for each axis): Parameter 3623
- Interval of the pitch error compensation points (for each axis) : Parameter 3624


Procedure for displaying and setting the pitch error compensation data

Procedure


- 1 Set the following parameters:
 - Number of the pitch error compensation point at the reference position (for each axis): Parameter 3620
 - Number of the pitch error compensation point having the smallest value (for each axis): Parameter 3621
 - Number of the pitch error compensation point having the largest value (for each axis): Parameter 3622
 - Pitch error compensation magnification (for each axis): Parameter 3623
 - Interval of the pitch error compensation points (for each axis): Parameter 3624
- 2 Press function key SYSTEM



The following screen is displayed:



- 4 Move the cursor to the compensation point number to be set in either of the following ways:
 - Enter the compensation point number and press the **[NO.SRH**] soft key.
 - Move the cursor to the compensation point number using the page keys,
 and
 and cursor keys,
 ,
 ,
 ,
 ,
 ,
 ,
 and
- 5 Enter a value with numeric keys and press the [INPUT] soft key.



11.6 DISPLAYING THE PROGRAM NUMBER, SEQUENCE NUMBER, AND STATUS, AND WARNING MESSAGES FOR DATA SETTING OR INPUT/OUTPUT OPERATION

The program number, sequence number, and current CNC status are always displayed on the screen except when the power is turned on, a system alarm occurs, or the PMC screen is displayed.

If data setting or the input/output operation is incorrect, the CNC does not accept the operation and displays a warning message.

This section describes the display of the program number, sequence number, and status, and warning messages displayed for incorrect data setting or input/output operation.

11.6.1 Displaying the Program Number and Sequence Number

The program number and sequence number are displayed at the top right on the screen as shown below.

```
PROGRAM
                                   O2000 N00130
                                                    Sequence
 O2000:
                                                    No.
 N100 G92 X0 Y0 Z70.;
                                                    Program
 N110 G91 G00 Y-70.;
                                                    No.
 N120 Z-70.;
 N130 G42 G39 I-17.5
 N140 G41 G03 X-17.5 Y17.5 R17.5;
 N150 G01 X-25.;
 N160 G02 X27.5 Y27.5 R27.5
 N170 G01 X20.;
 N180 G02 X45. Y45. R45.;
EDIT **** ***
                 16:05:59
[PRGRM] [CHECK] [CURRNT] [NEXT] [(OPRT)]
```

The program number and sequence number displayed depend on the screen and are given below:

On the program screen in the EDIT mode on Background edit screen: The program No. being edited and the sequence number just prior to the cursor are indicated.

Other than above screens:

The program No. and the sequence No. executed last are indicated.

Immediately after program number search or sequence number search:

Immediately after the program No. search and sequence No. search, the program No. and the sequence No. searched are indicated.


11.6.2

Displaying the Status and Warning for Data Setting or Input/Output Operation

The current mode, automatic operation state, alarm state, and program editing state are displayed on the next to last line on the screen allowing the operator to readily understand the operation condition of the system. If data setting or the input/output operation is incorrect, the CNC does not accept the operation and a warning message is displayed on the next to last line of the screen. This prevents invalid data setting and input/output errors.

Explanations

Description of each display



NOTE

Actually, (10) is displayed at the position where (8) is now displayed.

(1) Current mode

MDI: Manual data input, MDI operation

MEM : Automatic operation (memory operation)

RMT : Automatic operation (DNC operation, or such like)

EDIT : Memory editing HND : Manual handle feed

JOG: Jog feed

TJOG: TEACH IN JOG
THND: TEACH IN HANDLE
INC: Manual incremental feed

REF: Manual reference position return

(2) Automatic operation status

**** : Reset (When the power is turned on or the state in which program execution has terminated and automatic operation has

terminated.)

STOP: Automatic operation stop (The state in which one block has

been executed and automatic operation is stopped.)

D: Feed hold (The state in which execution of one block has

HOLD: Feed hold (The state in which execution of one block has been interrupted and automatic operation is stopped.)

STRT : Automatic operation start—up (The state in which the system operates automatically)

(3) Axis moving status/dwell status

MTN: Indicates that the axis is moving.

DWL : Indicates the dwell state.

*** : Indicates a state other than the above.

(4) State in which an auxiliary function is being executed

FIN : Indicates the state in which an auxiliary function is being

executed. (Waiting for the complete signal from the PMC)

*** : Indicates a state other than the above.

(5) Emergency stop or reset status EMG—: : Indicates emergency stop.(Blinks in reversed display.)RESET—: Indicates that the reset signal is being received.

(6) Alarm status

ALM: Indicates that an alarm is issued. (Blinks in reversed display.)

BAT: Indicates that the battery is low. (Blinks in reversed display.)

Space: Indicates a state other than the above.

(7) Current time

hh:mm:ss - Hours, minutes, and seconds

(8) Program editing status

INPUT : Indicates that data is being input.

OUTPUT : Indicates that data is being output.

SRCH : Indicates that a search is being performed.

EDIT : Indicates that another editing operation is being performed

(insertion, modification, etc.)

LSK : Indicates that labels are skipped when data is input.
RSTR : Indicates that the program is being restarted

Space : Indicates that no editing operation is being performed.

(9) Warning for data setting or input/output operation

When invalid data is entered (wrong format, value out of range, etc.), when input is disabled (wrong mode, write disabled, etc.), or when input/output operation is incorrect (wrong mode, etc.), a warning message is displayed. In this case, the CNC does not accept the setting or input/output operation (retry the operation according to the message). The following are examples of warning messages:

Example 1)

When a parameter is entered

> 1
EDIT WRONG MODE

(Display sof tkeys)

Example 2)

When a parameter is entered

> 999999999 MDI TOO MANY DIGITS (Display soft keys)

Example 3)

When a parameter is output to an external input/output device

> _ MEM WRONG MODE (Display soft keys)

11.7 SCREENS DISPLAYED BY FUNCTION KEY MESSAGE

By pressing the function key [MESSAGE], data such as alarms, alarm history data, and external messages can be displayed.

For information relating to alarm display, see Section III.7.1. For information relating to alarm history display, see Section III.7.2.


For information relating to external message display, see the relevant manual supplied by the machine tool builder.

11.7.1 External Operator Message History Display

External operator messages can be preserved as history data.

Preserved history data can be displayed on the external operator message history screen.

Procedure for external operator message history display



NOTE

Up to 255 characters can be specified for an external operator message. By setting MS1 and MS0 (bits 7 and 6 of parameter No. 3113), however, the number of characters that can be preserved as external operator message history data can be restricted, and the number of history data items selected.

Explanations

 Updating external operator message history data When an external operator message number is specified, updating of the external operator message history data is started; this updating is continued until a new external operator message number is specified or deletion of the external operator message history data is specified.

Clearing external operator message history data

To clear external operator message history data, press the **[CLEAR]** soft key. This clears all external operator message history data. (Set MSGCR (bit 0 of parameter No. 3113) to 1.)

Note that when MS1 and MS0 (bits 7 and 6 of parameter No. 3113), used to specify the number of external operator message history data items to be displayed, are changed, all existing external operator message history data is cleared.

Limitations

Two-path control

When two-path control is exercised, the external operator messages for system 1 are displayed. (The external operator messages for system 2 are not displayed.)

Option

Before this function can be used, the external data input function or optional external message function must be selected.

11.8 CLEARING THE SCREEN

Displaying the same characters in the same positions on the screen causes a LCD to degrade relatively quickly. To help prevent this, the screen can be cleared by pressing specific keys. It is also possible to specify the automatic clearing of the screen if no keys are pressed during a period specified with a parameter.

11.8.1 Erase Screen Display

Holding down the CAN key and pressing an arbitrary function key clears the screen.

Procedure for erase screen display

Procedure

ullet Clearing the screen Hold down the lacktriangle key and press an arbitrary function key (such as lacktriangle and lacktriangle).

• **Restoring the screen** Press an arbitrary function key.

11.8.2 Automatic Erase Screen Display

The CNC screen is automatically cleared if no keys are pressed during the period (in minutes) specified with a parameter. The screen is restored by pressing any key.

Procedure for automatic erase screen display

Clearing the screen

The CNC screen is cleared once the period (minutes) specified with parameter No. 3123 has elapsed, provided the following conditions are satisfied:

Conditions for clearing the CNC screen

- Parameter No. 3123 is set to other than 0.
- None of the following keys have been pressed: MDI keys Soft keys External input keys
- No alarm has been issued.

Restoring the screen

The cleared CNC screen is restored once at least one of the following conditions is satisfied:

Conditions for restoring the CNC screen

- Any of the following keys has been pressed: MDI keys Soft keys Externally input keys
- An alarm has been issued.

Some machines feature a special key for restoring the screen. For an explanation of the location and use of this key, refer to the corresponding manual, supplied by the machine tool builder.

Explanations

Clearing the screen
 using CAN + function key

If parameter No. 3123 is set to 0, clearing of the screen using the AN key and a function key (III–11.8.1) is disabled.

Specified period

The period specified with parameter No. 3123 is valid only for tool post 1.

Alarm for another path

The screen is not cleared if an alarm is issued for tool post 1 or 2 or the loader before the specified period elapses.

CAUTION

Pressing any key while the screen is being cleared restores the screen. In such a case, however, the function assigned to the pressed key is initiated. Do not press the DELET, or ALTER key to restore the screen, therefore.

12

GRAPHICS FUNCTION

Two graphic functions are available. One is a graphic display function, and the other is a dynamic graphic display function.

The graphic display function can draw the tool path specified by a program being executed on a screen. The graphic display function also allows enlargement and reduction of the display.

The dynamic graphic display function can draw a tool path and machining profile.

In tool path drawing, automatic scaling and solid drawing are possible. In machining profile drawing, the status of machining in progress can be drawn through simulation. Blank figures can also be drawn.

The background drawing function enables drawing to be performed by one program while machining is performed by another program.

This chapter mainly explains drawing procedures and drawing parameters for the following:

- 1. Drawing the tool path specified by a program being executed, with the graphic display function
- 2. Drawing the tool path with the dynamic graphic display function

12.1 GRAPHICS DISPLAY

It is possible to draw the programmed tool path on the screen, which makes it possible to check the progress of machining, while observing the path on the screen.

In addition, it is also possible to enlarge/reduce the screen.

Before drawing, graphic parameters must be set.


When the dynamic graphics function is used, the graphics function described in this section cannot be used. See Section 12.2 for the dynamic graphics function.

Graphics display procedure

Procedure


1 Press function key GRAPH . Press CUSTOM for a small MDI unit.

The graphic parameter screen shown below appears. (If this screen does not appear, press soft key [PARAM].)



- 2 Move the cursor with the cursor keys to a parameter to set.
- 3 Enter data, then press the NPUT key.
- 4 Repeat steps 2 and 3 until all required parameters are specified.
- 5 Press soft key [GRAPH].

6 Automatic operation is started and machine movement is drawn on the screen.



Explanation

 RANGE (Actual graphic range) The size of the graphic screen will be as follows:




Fig.12.1 (a) Graphic range

As shown in Fig.12.1 (a), the maximum graphics range is an area of approx. 144 mm (width) $\times 90 \text{ mm}$ (height) for 7.2''/8.4'' LCD and approx. 240 mm (width) $\times 150 \text{ mm}$ (height) for 9.5''/10.4'' LCD.

Setting the graphics range

To draw a section of the program within the actual graphics range, set the graphics range using one of the following two methods:

- 1. Set the center coordinates of the range and the magnification.
- 2 . Set the maximum and minimum coordinates for the range in the program.

Whether 1 or 2 is used depends on which parameters are set last. A graphics range which has been set is retained when the power is turned off.

 Setting the center coordinate of the graphics range and graphics magnification Set the center of the graphic range to the center of the screen. If the drawing range in the program can be contained in the above actual graphics range, set the magnification to 1 (actual value set is 100).

When the drawing range is larger than the maximum graphics range or much smaller than the maximum graphics range, the graphics magnification should be changed. The graphics magnification is 0.01 to 100.00 times, which is usually determined as follows;

Graphics magnification=Graphics magnification (**H**), or graphics magnifications (**V**), whichever is smaller

Graphics magnification $\mathbf{H} = \alpha/(\text{length on program to horizontal direction axis})$

Graphics magnification $V=\beta/(length\ on\ program\ to\ vertical\ direction\ axis)$

α:144mm(for 7.2"/8.4" LCD)

β:90mm

α:240mm(for 9.5"/10.4" LCD)

β:150mm




Fig.12.1 (b) Applying graphics magnification (Example of enlargement)

2. Setting the maximum and minimum coordinates for the drawing range in the program

When the actual tool path is not near the center of the screen, method 1 will cause the tool path to be drawn out of the geaphics range if graphics magnification is not set properly.

To avoid such cases, the following six graphic parameters are prepared;

Graphic range (Max.) X

Graphic range (Max.) Y

Graphic range (Max.) Z

Graphic range (Min.) X

Graphic range (Min.) Y

Graphic range (Min.) Z

With the above parameters, the center of screen (Gcx, Gcy, Gcz) is determined by the CNC as follows;

Gex = (X (MAX.) + X (MIN.))/2

Gcy = (Y (MAX.) + Y (MIN.))/2

Gcz = (Z (MAX.) + Z (MIN.)) / 2

The unit of the value will be 0.001 mm or 0.0001 inch depending on the input unit.

Graphics magnification is applied automatically. When the graphics range is specified, the center coordinates and magnification do not need to be calculated.

 Work coordinate system and graphics The graphic origin and graphic center point will not be changed even if the workpiece coordinate origin is changed.

In other words, the workpiece coordinate origin is always consistent with the graphic origin.





Fig.12.1 (c) Workpiece coordinate origin and graphics origin

• Graphics parameter

· AXES

Specify the plane to use for drawing. The user can choose from the following six coordinate systems.

With two-path control, a different drawing coordinate system can be selected for each tool post.



The rotating angle (horizontal, vertical) for isometric display of 5) and 6) is fixed at 45°in both cases.

Fig12.1 (d) Coordinate system

RANGE (Max., Min.)

Set the graphic range displayed on the screen by specifying maximum and minimum values along each axis.

X=Maximum value X=Minimum value

Y=Maximum value Y=Minimum value

Z=Maximum value Z=Minimum value

Valid range: 0 to \pm 9999999

NOTE

- 1 The units are 0.001 mm or 0.0001 inch. Note that the maximum value must be greater than the minimum value for each axis.
- 2 When setting the graphics range with the graphics parameters for the maximum and minimum values, do not set the parameters for the magnification and screen center coordinates afterwards. Only the parameters set last are effective.

· SCALE

Set the graphic magnification

The setting range is 0 to 10000 (unit:0.01 time).

GRAPHIC CENTER

<=

Y=

Z=_

Set the coordinate value on the workpiece coordinate system at graphic center.

NOTE

- 1 When MAX. and MIN. of RANGE are set, the values will be set automatically once drawing is executed
- 2 When setting the graphics range with the graphics parameters for the magnification and screen center coordinates, do not set the parameters for the maximum and minimum values afterward. Only the parameters set last are effective.

· PROGRAM STOP

N=

Set the sequence No. of the end block when necessary to partially display.

This value is automatically cancelled and set to -1 once drawing is executed.

· AUTO ERASE

- 1: Erase the previous drawing automatically when the automatic operation is started under reset condition.
- 2: Not erase automatically.

Executing drawing only

Since the graphic drawing is done when coordinate value is renewed during automatic operation, etc., it is necessary to start the program by automatic operation. To execute drawing without moving the machine, therefore, enter the machine lock state.

Deleting the previous drawing

When the AUTO operation is started under reset condition, the program is executed after deleting the previous drawing automatically (Automatic deleting=1). It is possible not to delete the previous drawing by graphic parameter (Automatic deleting=0).

Drawing a part of a program

When necessary to display a part of a program, search the starting block to be drawn by the sequence No. search, and set the sequence No. of the end block to the PROGRAM STOP N= of the graphic parameter before starting the program under cycle operation mode.

Drawing using dashed lines and solid lines

The tool path is shown with a dashed line (----) for rapid traverse and with a solid line (----) for cutting feed.

Limitations

Feedrate

In case the feed rate is considerably high, drawing may not be executed correctly, decrease the speed by dry—run, etc. to execute drawing.

• Two-path lathe control

For the two-path lathe control, two paths can not be displayed at the same time.

12.2 DYNAMIC GRAPHIC DISPLAY

There are the following two functions in Dynamic Graphics.

Path graphic	This is used to draw the path of tool center commanded by the part program.
Solid graphic	This is used to draw the workpiece figure machined by tool movement commanded by the part program.

The path graphic function is used to precisely check the part program for drawing the tool path with a line. The solid graphic function is used to draw the workpiece figure to be machined with a program. Thus, it is easy to recognize roughly the part program. These two functions can be used freely by switching them.

12.2.1 Path Drawing

The path graphic feature calls a program from memory and draws the tool path specified by the program. This feature provides the following functions.

1. Drawing plane

The user can choose the drawing plane from four types of plane views, two types of isometric projection views, and biplane view.

2. Drawing rotation

When an isometric projection view is used, the drawing can be rotated horizontally and vertically.

Drawing enlargement and reduction A drawing can be enlarged or reduced by specifying a magnification from 0.01 to 100 with respect to the actual size. In addition, a drawing can be automatically enlarged or reduced by setting maximum and minimum values.

4. Partial drawing

A range of the program can be drawn by specifying a starting sequence number and ending sequence number.

Programmed path and tool path drawing The user can specify whether to apply tool length offset and cutter compensation to drawing. This way, either the actual programmed path or the tool path can be drawn.

6. Color

When a tool path is drawn on a screen, the colors used can be chosen from seven colors including white. The color of the tool path can be changed according to the T code.

7. Automatic scaling

The CNC automatically determines the maximum and minimum drawing coordinates for each program. This means that drawing can be performed with a magnification automatically determined according to these maximum and minimum values.

Partial enlargement drawing

Except for biplane views the user can enlarge all types of drawings by a factor of up to 100 while looking at the drawing that has been made.

Indicating the current tool position with a mark The current tool position can be displayed on the screen.

Indicating the coordinates of the current position

The current position can also be indicated using coordinates.

 Displaying coordinate axes and actual size dimensions lines Coordinate axes and actual size dimension lines are displayed together with the drawing so that actual size can be referenced.

The first six functions above (1. to 6.) are available by setting the graphic parameters. The seventh to ninth functions (7. to 9.) are mainly executed using soft keys after drawing has been setup. The tenth function (10.) is enabled by setting a parameter. The eleventh function (11.) can be used at any time.

Path drawing procedure

Procedure

1 To draw a tool path, necessary data must be set beforehand.

So press the function button GRAPH some times (GUSTOM GRAPH) for the small MDI). The "PATH GRAPHIC (PARAMETER)" is displayed.


```
PATH GRAPHIC (PARAMETER-1)
                                    O0000 N00002
AXES
           P=
(XY=0, YZ=1, ZY=2, XZ=3, XYZ=4, ZXY=5, 2P=6)
ANGLE
 ROTATION
                          0
 TILTING
                A=
                          0
SCALE
                        0.00
                K=
CENTER OR MAX./MIN.
  X=130.000
                               Z = 50.000
                Y=
                     110.000
   I = 0.000
                    -10.000
                               K = 0.000
                .l=
START SEQ. NO.
                N=
                          0
END SEQ. NO.
                N=
NO.
     A=
MDI
                               14:25:07
                        SCALE
```

```
PATH GRAPHIC (PARAMETER-2) O0000 N00001
TOOL. COMP
COLOR (0123456)
              P=
                     0
PATH
TOOL
              Q=
                     0
AUTO CHANGE
              R=
MDI
                            14:25:51
            EXEC
                 SCALE
                                POS
```

- 2 There are two screens for setting drawing parameters. Press the page key according to the setting items for selecting screens.
- 3 Set the cursor to an item to be set by cursor keys.
- 4 Input numerics by numeric keys.
- 5 Press the INPUT key.

The input numerics are set by these operations and the cursor automatically moves to the next setting items. The set data is held even after the power is turned off.


- 6 Set the operation mode to the memory mode, press function key PROG, and call the part program which should be drawn.
- 7 Press function key GRAPH (CUSTOM GRAPH) for a small MDI) several times to redisplay the PATH GRAPHIC (PARAMETER) screen, then press soft key [EXEC] to display the PATH GRAPHIC (EXECUTION) screen.



- 8 Press soft key **[(OPRT)]**, then press soft key **[AUTO]** or **[START]**. Pressing **[AUTO]** enables automatic scaling. See item 7 in introduction of path drawing and the description of soft key **[AUTO]** in Explanations for details. Drawing is now started. During drawing, the message "DRAWING" blinks at the lower–right corner of the CRT screen.
- 9 Press soft key [STOP] to pause drawing. The indication of "STOP" blinks at the lower right corner on the CRT screen. Press soft key [START] to start drawing. In addition, press soft key [REWIND] to redraw from the top of program before pressing soft key [START].
- 10 Execute the last of part program (M02/M30) to end drawing. This will cause, blinking of the "DRAWING" light to turn off. The tool path view drawn can be retained until the power is turned off unless a new tool path view is drawn.

Partial enlargement

11 For partial drawing enlargement, display the PATH GRAPHIC (SCALE) screen by pressing the soft key [ZOOM] on the PATH GRAPHIC (PARAMETER) screen of step 1 above. The tool path is displayed. Next, press soft key [(OPRT)].



- Perform positioning of marks displayed at the center of the screen to the center of the part enlarged using soft keys $[\leftarrow]$, $[\downarrow]$, and $[\uparrow]$.
- 13 Set the relative magnification rate for the tool path view which is being drawn using the address keys "P" and "M". When you press address key P or M, the following results:


Address key	Function
Р	The relative magnification rate increases by 0.1.
M	The relative magnification rate decreases by 0.1.

The relative magnification rate is continuously changed by keeping the address keys depressed. It is possible to magnify up to 100 times in reference to the actual dimensions.

Press the soft key **[EXEC]** after setting the relative magnification rate. Then, the screen automatically changes to "TOOL PATH (EXECUTION)" and the drawing of set partial enlargement view starts. The set partial enlargement status is valid until soft key **[AUTO]** or **[ERASE]** is pressed.

Mark display

15 To display a mark at the current tool position, display the PATH GRAPHIC (POSITION) screen by pressing soft key [POS] on the PATH GRAPHIC (PARAMETER) screen of step 1 above. This mark blinks at the current tool center position on the tool path.



Explanations

AXES

The relationship between the setting value and drawing screen is as shown below:

Setting value	Drawing screen
0	Plane view (XY)
1	Plane view (YZ)
2	Plane view (ZY)
3	Plane view (XZ)
4	Isometric projection (XYZ)
5	Isometric projection (ZXY)
6	Biplane view (XY,XZ)

• Plane view (XY,YZ,ZY,XZ)

The following coordinate systems are selected.




Fig. 12.2.1 (a) Coordinate systems for the plane view

Isometric projection (XYZ,ZXY)

Projector view by isometric can be drawn.




Fig.12.2.1(b) Coordinate systems for the isometric projection

Biplane view




Fig.12.2.1 (c) Coordinate systems for the biplane view

Biplanes (XY and XZ) can be drawn simultaneously. The maximum and minimum coordinate values must be set to draw the biplane view. The maximum and minimum coordinate values can also be set by performing automatic scaling

The direction of the coordinate axis is set when the isometric projection is the setting of the drawing screen. The direction is set by horizontal and vertical rotation angles. The unit is expressed in degrees.

The horizontal rotation angle is set in the range of -180° to $+180^{\circ}$ in reference to the vertical axis. Set a positive value for clockwise rotation of the coordinate axis. Thus, the direction of projection (visual arrow)



ROTATION




Fig.12.2.1 (d) Rotating

becomes counterclockwise.

TILTING

The tilting angle of the vertical axis is set in the range of -90° to $+90^{\circ}$ in reference to the horizontal axis crossing the vertical axis at a right angle. When a positive value is set, the vertical axis slants to the other side of the graphic screen. Thus, the projection direction (arrow direction) becomes the horizontal direction.




Fig.12.2.1 (e) Tilting

SCALE

• CENTER OR MAX./MIN.

Set the magnification rate of drawing from 0.01 to 100.00. When 1.0 is set, drawing is carried out in actual dimensions. When 0 is set, the drawing magnification rate is automatically set based on the setting of maximum and minimum coordinate values of drawing.

When a graphics (drawing) magnification of 0 is set, maximum coordinates on the X-axis, Y-axis, and Z-axis in the workpiece coordinate system must be set in addresses X, Y, and Z, and minimum coordinates must be set in addresses I, J, and K, to specify the graphics (drawing) range. For biplane view drawing, maximum and minimum coordinates for drawing must be specified.

When a drawing magnification other than 0 is set, the X, Y, and Z coordinates of the drawing center in the workpiece coordinate system must be set in addresses X, Y, and Z. Addresses I, J, and K are not used. The table below summarizes the setting requirements described above.

Setting the drawing	Setting										
magnification rate	Address X/Y/Z	Address I/J/K									
Other than 0	Drawing center coordinate value of X, Y, and Z axes	Ignored									
0 or biplane view drawing	Drawing maximum coordinate value of X, Y, and Z axes	Drawing minimum coordinate value of X, Y, and Z axes									

 START SEQ. NO. and END SEQ. NO. Set the start and end sequence numbers of drawing in five digits each. The part program for drawing is executed from the head and only the part enclosed by the start sequence and end sequence numbers is drawn. When 0 is commanded as the start sequence number, drawing is performed from the head of the program. In addition, when 0 is commanded as the end sequence number, drawing is performed up to the end of program. The sequence number is referred to regardless of either main program or subprogram.

• TOOL COMP.

COLOR

It is possible to set whether the tool path is drawn by making the tool length offset or cutter compensation valid or invalid.

Setting value	Tool length offset or cutter compensation
0	Perform drawing by making tool compensation valid (An actual tool path is drawn.)
1	Perform drawing by making tool compensation invalid (A programmed path is drawn.)

Always set 0 before drawing when indicating the mark of the current tool position.

Specify the color of the tool path. In the case of monochrome it is not required to set it. The relationship between the setting value and color is as shown below:

Setting value	Color					
0	White					
1	Red					
2	Green					
3	Yellow					
4	Blue					
5	Purple					
6	Light blue					

- · **PATH** Specify the color of the tool path.
- **TOOL** Specify the color of the current position mark of the tool.
- **AUTO CHANGE** Set if for changing the color of the tool path automatically according to the T –code command.

Setting value	Function
0	The color of the tool path is not changed.
1	The color of the tool path is changed automatically.

When 1 is set, the setting value of the color designation of PATH is incremented by 1 every time the T code is commanded. At the same time, the color of the tool path changes. If the setting value exceeds 6, it returns to 0.

Soft key functions on the "PATH GRAPHIC [EXECUTION]"screen

Software key	Function								
[AUTO]	Automatic scaling is performed. Obtain the maximum and minimum coordinates of the part program before performing drawing, specify them for the maximum and minimum values of drawing parameters, and set the drawing magnification rate to 0 before starting drawing. Thus, the tool path view is properly laid out on the screen.								
[START]	Drawing starts. When the [START] is pressed while the drawing is not in STOP, the part program starts from the top of the part program. Press the [START] while the drawing is in stop to allow drawing to be carried out continuously.								
[STOP]	Stop drawing. (Single block stop)								
[REWIND]	Press this key to start drawing from the top of part program. Searches for the beginning of a part program.								
[ERASE]	Erase the tool path view which has been drawn.								

Graphic program

No part program which has not been registered in memory can be drawn. Also, it is necessary that the M02 or M30 should be commanded at the end of the part program.

Mark for the tool current position

The period of mark blinking is short when the tool is moving and becomes longer when the tool stops.

The mark indicating the current position of tool is displayed on the XY plane view when the biplane drawing is performed.

Position mark

Parameter 6501 (CSR, bit 5) is used to specify whether to use or x as the mark for indicating the current tool position and the center of a partially enlarged drawing.

Display of the coordinate value

Parameter 6500 (DPO, bit 5) is used to specify whether to display the coordinates of the current position on the tool path drawing screen.

 Changing the coordinate system If a program specifies a coordinate system change, parameter 6501 (ORG, bit 0) is used to specify whether to draw without changing the coordinate system or to draw by regarding the current drawing position as the current position in the new coordinate system.

Restrictions

• Graphic condition

If machine operation is not allowed, no drawing can be carried out. No drawing can be made during machine operation. The setting data and switches required for drawing are as shown below:

Setting data and switch	Status
Tool offset amount	Set it properly when performing drawing while the tool offset amount becomes valid.
Single block	Off
Optional block skip	Set it properly.
Feed hold	Off

Partial enlargement

The partial enlargement can be carried out on the plane view and isometric projection view. No partial enlargement can be made in the drawing of the biplane view.

• Tool current position

In dynamic graphics display, drawing cannot be executed while the machine is operating even though this is possible in ordinary graphics display (see III–12.1). However, after drawing is executed, the operator can see how the tool moves along the tool path by operating the machine while displaying the mark for the current position of the tool.

It is necessary that the setting data and switches related to the machine operation should be the same status between drawing operation and machining operation for properly displaying the current position of tool on the drawn tool path.

13

HELP FUNCTION

The help function displays on the screen detailed information about alarms issued in the CNC and about CNC operations. The following information is displayed.

 Detailed information of alarms When the CNC is operated incorrectly or an erroneous machining program is executed, the CNC enters the alarm state. The help screen displays detailed information about the alarm that has been issued and how to reset it. The detailed information is displayed only for a limited number of P/S alarms. These alarms are often misunderstood and are rather difficult to understand.

Operation method

If you are not sure about a CNC operation, refer to the help screen for information about each operation.

Parameter table

When setting or referring to a system parameter, if you are not sure of the number of the parameter, the help screen displays a list of parameter Nos. for each function.

Help Function Procedure

Procedure

1 Press the HELP key on the MDI panel. HELP (INITIAL MENU) screen is displayed.




Fig.13(a) HELP (INITIAL MENU) screen

The user cannot switch the screen display from the PMC screen or CUSTOM screen to the help screen. The user can return to the normal CNC screen by pressing the HELP key or another function key.

ALARM DETAIL screen

2 Press soft key [1 ALAM] on the HELP (INITIAL MENU) screen to display detailed information about an alarm currently being raised.




Fig.13(b) ALARM DETAIL screen when alarm P/S 027 is issued

Note that only details of the alarm identified at the top of the screen are displayed on the screen.

If the alarms are all reset while the help screen is displayed, the alarm displayed on the ALARM DETAIL screen is deleted, indicating that no alarm is issued.




Fig.13(c) ALARM DETAIL screen when no alarm is issued

3 To get details on another alarm number, first enter the alarm number, then press soft key **[SELECT]**. This operation is useful for investigating alarms not currently being raised.

```
>100 S 0 T00000
MEM **** *** *** 10:12:25
[ ] [ ] [ ] [ SELECT]
```

Fig.13(d) How to select each ALARM DETAILS

The following is the screen when P/S alarm 100 is selected as example.




Fig.13(e) ALARM DETAIL screen when P/S 100 is selected

OPERATION METHOD screen

4 To determine an operating procedure for the CNC, press the soft key [2 OPR] key on the HELP (INITIAL MENU) screen. The OPERATION METHOD menu screen is then displayed.

```
HELP (OPERATION METHOD) O1234 N00001
 1. PROGRAM EDIT
 2. SEARCH
 3. RESET
 4. DATA INPUT WITH MDI
 5. DATA INPUT WITH TAPE
 6. OUTPUT
 7. INPUT WITH FANUC CASSETTE
 8. OUTPUT WITH FANUC CASSETTE
 9. MEMORY CLEAR
                                   S
                                        0 T0000
                             00:00:00
            2 OPR 3 PARA
  1 ALAM
                                         (OPRT)
```

Fig.13(f) OPERATION METHOD menu screen

To select an operating procedure, enter an item No. from the keyboard then press the **[SELECT]** key.

```
>1 S 0 T0000
MEM **** *** *** 10:12:25
[ ] [ ] [ ] [ SELECT]
```

Fig.13(g) How to select each OPERATION METHOD screen

When "1. PROGRAM EDIT" is selected, for example, the screen in Figure 13 (h) is displayed.

On each OPERATION METHOD screen, it is possible to change the displayed page by pressing the PAGE key. The current page No. is shown at the upper right corner on the screen.




Fig.13(h) Selected OPERATION METHOD screen

5 To return to the OPERATION METHOD menu screen, press the RETURN MENU key to display "[2 OPR]" again, and then press the [2 OPR] key again.

To directly select another OPERATION METHOD screen on the screen shown in Figure 13 (h), enter an item No. from the keyboard and press the **[SELECT]** key.




Fig.13(i) How to select another OPERATION METHOD screen

6 If you are not sure of the No. of a system parameter to be set, or to refer to a system parameter, press the [3 PARA] key on the HELP (INITIAL MENU) screen. A list of parameter Nos. for each function is displayed. (See Figure 13 (j).)

It is possible to change the displayed page on the parameter screen.



PARAMETER TABLE screen

The current page No. is shown at the upper right corner on the screen.


HELP (PARAMETER TABLE)	01234 N00001 1/4	
* SETTEING * READER/PUNCHER INTERFACE * AXIS CONTROL	(No. 0000~) (No. 0100~)	
/SETTING UNIT * COORDINATE SYSTEM * STROKE LIMIT * FEED RATE * ACCEL/DECELERATION CTRL * SERVORELATED	(No. 1000~) (No. 1200~) (No. 1300~) (No. 1400~) (No. 1600~) (No. 1800~)	
* DI/DO >_ MEM **** *** *** 10:12:25	(No. 3000~) S 0 T0000	
[1 ALM] [2 OPR] [3 PARA] [] [1

Fig. 13(j) PARAMETER TABLE screen

7 To exit from the help screen, press the HELP key or another function key.

Explanation

 Configuration of the Help Screen



IV. MAINTENANCE



METHOD OF REPLACING BATTERY

This chapter describes how to replace the CNC backup battery and absolute pulse coder battery. This chapter consists of the following sections:

- 1.1 REPLACING THE ALKALINE DRY CELLS (SIZE D)
- 1.2 USE OF ALKALINE DRY CELLS (SIZE D)
- 1.3 BATTERY FOR SEPARATE ABSOLUTE PULSE CODERS

Battery for memory backup

Part programs, offset data, and system parameters are stored in CMOS memory in the control unit. The power to the CMOS memory is backed up by a lithium battery mounted on the front panel of the control unit. Therefore, the above data is not lost even if the main battery fails. The backup battery is installed in the control unit prior to being shipped from the factory. This battery can provide backup for the memory contents for about a year.

When the battery voltage falls, alarm message "BAT" blinks on the LCD display and the battery alarm signal is output to the PMC. When this alarm is displayed, replace the battery as soon as possible. In general, the battery can be replaced within one or two weeks of the alarm first being issued. This, however, depends on the system configuration.

If the battery voltage subsequently drops further, backup of memory can no longer be provided. Turning on the power to the control unit in this state causes system alarm 910 (SRAM parity alarm) to be issued because the contents of memory are lost. Replace the battery, clear the entire memory, then reenter the data.

Replace the memory backup battery while the control unit is turned off. The following two kinds of batteries can be used.


- Lithium battery, incorporated into the CNC control unit.
- Two alkaline dry cells (size D) in an external battery case.

NOTE

A lithium battery is installed as standard at the factory.

Replacing the lithium battery

- 1 Obtain a new lithium battery (ordering drawing number: A02B-0200-K102).
- 2 Turn the Series 21*i*/210*i* on for about 30 seconds.
- 3 Turn the Series 21i/210i off.
- 4 Remove the old battery from the top of the CNC control unit. First, disconnect the battery cable then remove the battery from its case. The battery case of a control unit with no option slots is located at the top right end of the unit. That of a control unit with 2 slots or 4 slots is located in the central area of the top of the unit (between fans).



5 Insert a new battery and reconnect the cable.

NOTE

Complete steps 3 to 5 within 30 minutes (within five minutes for the Series 21*i*/210*i* with PC functions).

If the battery is left disconnected for any longer, the contents of memory will be lost.

If for some reason, it may prove impossible to complete the battery replacement within 30 minutes, save the entire contents of the CMOS memory to a memory card in advance. The data can thus be easily restored if the contents of memory are lost.

For an explanation of the operating procedure, refer to the maintenance manual.

WARNING

Using other than the recommended battery may result in the battery exploding.

Replace the battery only with the specified type (A02B-0200-K102).

Dispose of used batteries as follows:


- (1) Small quantities (less than 10)
 Discharge the batteries and dispose of them as ordinary unburnable waste.
- (2) Large quantities Please consult FANUC.

1.1 REPLACING THE ALKALINE DRY CELLS (SIZE D)

- 1 Obtain two new alkaline dry cells (size D).
- 2 Turn the Series 21*i*/210*i* on.
- 3 Remove the battery case cover.
- 4 Replace the batteries, paying careful attention to their orientation.
- 5 Replace the battery case cover.

NOTE


When replacing the dry cells while the power is off, use the same procedure as that for lithium battery replacement, described above.



1.2 USE OF ALKALINE DRY CELLS (SIZE D)

Connection

Power from external batteries is supplied through the same connector as that to which the lithium battery is connected. The lithium battery, provided as standard, can be replaced with external batteries in a battery case (A02B–0236–C281) according to the battery replacement procedures described above.



NOTE

Install the battery case (A02B–0236–C281: 14–m cable) in a location where the batteries can be replaced even when the control unit power is on.

The battery cable connector is attached to the control unit by means of a simple lock system. To prevent the connector from being disconnected due to the weight or tension of the cable, secure the cable within 50 cm of the connector.

1.3 BATTERY FOR SEPARATE ABSOLUTE PULSE CODERS

One battery unit can maintain the current position data held in an absolute pulse coder for about one year.

When the battery voltage falls, APC alarms 306 to 308 are displayed on the screen. When APC alarm 307 is displayed, replace the battery as soon as possible. In general, the battery should be replaced within one or two weeks of the alarm first appearing. This, however, depends on the number of pulse coders being used.

If the battery voltage drops any further, the current positions for the pulse coders will be lost. Turning on the power to the control unit in this state results in APC alarm 300 (reference position return request alarm) being issued. Return the tool to the reference position after replacing the battery. See Subsection 7.9.2 for details of connecting the battery to separate absolute pulse coders. The battery for the built—in absolute pulse coder is installed in the servo amplifier. For an explanation of the replacement procedure, refer to the FANUC CONTROL MOTOR AMPLIFIER α Series Maintenance Manual.

APPENDIX



TAPE CODE LIST

ISO code											ı	ΞIΑ	CC	ode						Meaning		
Character	8	7	6	5	4		3	2	1	Character	8	7	6	5	4		3	2	1		Without CUSTOM MACRO B	With CUSTOM MACRO B
0			0	0		0				0			0			0				Number 0		
1	0		0	\bigcirc		0			0	1						0			\circ	Number 1		
2	0		0	\bigcirc		0		0		2						0		0		Number 2		
3			0	\bigcirc		0		0	0	3				0		0		0	\circ	Number 3		
4	0		0	0		0	0			4						0	0			Number 4		
5			0	0		0	0		0	5				0		0	0		0	Number 5		
6			0	0		0	0	0		6				0		0	0	0		Number 6		
7	0		0	0		0	0	0	0	7						0	0	0	0	Number 7		
8	0		0	0	0	0				8					0	0				Number 8		
9			0	0	0	0			0	9				0	0	0			0	Number 9		
А		0				0	Г		0	а		0	0	Г		0	Γ		0	Address A		
В		0				0		0		b		0	0			0		0		Address B		
С	0	0				0		0	0	С		0	0	0		0		0	0	Address C		
D		0				0	0			d		0	0			0	0			Address D		
Е	0	0				0	0		0	е		0	0	0		0	0		0	Address E		
F	0	0				0	0	0		f		0	0	0		0	0	0		Address F		
G		0			Г	0	0	0	0	g		0	0	Г		0		0	0	Address G		
Н		0			0	0	Г			h		0	0	Г	0	0	T	Т		Address H		
I	0	0			0	0	Г		0	i		0	0	0	0	0			0	Address I		
J	0	0			0	0	Г	0		j		0		0		0		0	0	Address J		
K		0			0	0	T	0	0	k		0		0		0	T	0		Address K		
L	0	0			0	0	0			I		0	Г			0	T	0	0	Address L		
М		0			0	0	0		0	m		0	Г	0		0				Address M		
N		0			0	0	0	0		n		0	Г	Т		0			0	Address N		
0	0	0			0	0	0	0	0	0		0	T	Γ		0	0	0		Address O		
Р	Ė	0		0	Ť	0	Ť	Ť	Ė	р		0	Г	0		0	Ō	0	0			
Q	0			0	T	0	T		0	q	Т	0	Т	0	0	0	Ť	Ť	Ť	Address Q		
R	0	0		0	T	0	T	0	Ė	r	Г	0	T	Ť	0	0	t		0	Address R		
S	ŕ	0	\vdash	0	\vdash	0	\vdash	0	0	s		É	0	0	ŕ	0	T	0	Ĺ	Address S		
T	0	Ō		0	T	0	0	Ť	Ė	t			0	Ť		0	t	Ō	0	Address T		
U	É	0	\vdash	0	T	0	0		0	u			0	0		0			Ĺ	Address U		
V		0		0	T	0	0	0	Ĺ	V		T	0	Ť		0	0		0	Address V		
W	0	0		0	T	0	0	0	0	W			0	\vdash		0	0	0	Ĺ	Address W		
X	0	0	\vdash	0		0	Ť	Ĺ	Ĺ	х			0	0		0	0	0	0	Address X		
Y	Ť	0		0	Ó	0	\vdash		0	у			0	0	0	0	Ť	Ť	Ť	Address Y		
Z	\vdash		\vdash	$\overline{\bigcirc}$	<u></u>	0	T	0	Ť	Z		\vdash	0	Ť	$\overline{\bigcirc}$	0	\vdash	T	\bigcirc	Address Z		

		E	IA	CO	de						Meaning											
Character	8	7	6	5	4		3	2	1	Character	8	7	6	5	4		3	2	1		Without CUSTOM MACRO B	With CUSTOM MACRO B
DEL	0	0	0	0	0	0	0	0	0	Del		0	0	0	0	0	0	0	0		×	×
NUL						0	Γ			Blank						0					×	×
BS	\bigcirc				0	0				BS			0		0	0		0			×	×
HT					0	0			0	Tab			\circ	0	0	0	0	0			×	×
LF or NL					0	0		0		CR or EOB	0					0						
CR	\circ				0	0	0		\circ												×	×
SP	\bigcirc		0			0				SP				0		0						
%	\bigcirc		0			0	0		\bigcirc	ER					\bigcirc	0		0	\bigcirc			
(0		0	0				(2-4-5)				0	0	0		0				
)	\bigcirc		0		0	0			\bigcirc	(2-4-7)		0			0	0		\bigcirc				
+			0		0	0		0	0	+		0	0	0		0					Δ	
_			0		0	0	0		0	_		0				0						
:			0	0	0	0		0														
/	0		0		0	0	0	0	0	/			0	0		0			0			
			0		0	0	0	0				0	0		0	0		0	0			
#	0		0			0		0	0	Parameter (No. 6012)												
\$			0			0	0														Δ	0
&	0		0			0	0	0		&					0	0	0	0			Δ	0
\triangle			0			0	0	0	0												Δ	0
*	0		0		0	0		0		Parameter (No. 6010)											Δ	
,	0		0		0	0	0			,			0	0	0	0		0	0			
;	0		0	0	0	0		0	0												Δ	Δ
<			0	0	0	0	0		Ш												Δ	Δ
=	0		0	0	0	0			0	Parameter (No. 6011)											Δ	
>	0		0	0	0	0	0	0													Δ	Δ
?			0	0	0	0	0	\bigcirc	0												Δ	0
@	0	0				0															Δ	0
"			0					0													Δ	Δ
[0	0		0	0	0		0	0	Parameter (No. 6013)											Δ	
]	0	0		0	0	0	0		0	Parameter (No. 6014)											Δ	

NOTE

1 The symbols used in the remark column have the following meanings.

(Space): The character will be registered in memory and has a specific meaning.

It it is used incorrectly in a statement other than a comment, an alarm occurs.

The character will not be registered in memory and will be ignored.

 Δ : The character will be registered in memory, but will be ignored during program

execution.

: The character will be registered in memory. If it is used in a statement other than

a comment, an alarm occurs.

: If it is used in a statement other than a comment, the character will not be registered in memory. If it is used in a comment, it will be registered in memory.

2 Codes not in this table are ignored if their parity is correct.

3 Codes with incorrect parity cause the TH alarm. But they are ignored without generating the TH alarm when they are in the comment section.

4 A character with all eight holes punched is ignored and does not generate TH alarm in EIA code.



LIST OF FUNCTIONS AND TAPE FORMAT

Some functions cannot be added as options depending on the model. In the tables below, $\ ^{\text{IP}}$ _:presents a combination of arbitrary axis addresses using X,Y,Z,A,B and C (such as X_Y_Z_A_).

x = 1st basic axis (X usually)

y = 2nd basic axis (Y usually)

z = 3rd basic axis (Z usually)

Functions	Illustration	Tape format
Positioning (G00)	Start point	G00 IP_;
Linear interpolation (G01)	Start point	G01 IP_F_;
Circular interpolation (G02, G03)	Start point R J G02 (x, y) (x, y) G03 Start point J	$G17 \left\{ \begin{matrix} G02 \\ G03 \end{matrix} \right\} X_{-}Y_{-} \left\{ \begin{matrix} R_{-} \\ I_{-}J_{-} \end{matrix} \right\} F_{-};$ $G18 \left\{ \begin{matrix} G02 \\ G03 \end{matrix} \right\} X_{-}Z_{-} \left\{ \begin{matrix} R_{-} \\ I_{-}K_{-} \end{matrix} \right\} F_{-};$ $G19 \left\{ \begin{matrix} G02 \\ G03 \end{matrix} \right\} Y_{-}Z_{-} \left\{ \begin{matrix} R_{-} \\ J_{-}K_{-} \end{matrix} \right\} F_{-};$
Helical interpolation (G02, G03)	Start (xyz) Start point (x, y) (In case of X–Y plane)	$G17 \begin{cases} G02 \\ G03 \end{cases} X_{-}Y_{-} \begin{Bmatrix} R_{-} \\ I_{-}J_{-} \end{Bmatrix} \alpha_{-}F_{-};$ $G18 \begin{cases} G02 \\ G03 \end{cases} X_{-}Z_{-} \begin{Bmatrix} R_{-} \\ I_{-}K_{-} \end{Bmatrix} \alpha_{-}F_{-};$ $G19 \begin{cases} G02 \\ G03 \end{cases} Y_{-}Z_{-} \begin{Bmatrix} R_{-} \\ J_{-}K_{-} \end{Bmatrix} \alpha_{-}F_{-};$ $\alpha \colon \text{ Any axis other than circular interpolation axes.}$

Functions	Illustration	Tape format
Dwell (G04)		$G04\left\{\begin{matrix}X_{-}\\P_{-}\end{matrix}\right\}\;;$
Look-ahead control (G08)		G08 P1: Look-ahead control mode on G08 P0: Look-ahead control mode off
Exact stop (G09)	Velocity	$G09 \left\{ egin{array}{c} G01 \\ G02 \\ G03 \end{array} ight\} \ \mathbb{P}_{-};$
Change of offset value by program (G10)		G10 L11 P_R_; G10 L1 P_R_;
Polar coordinate (G15, G16)	Yp Local coordinate Yp Xp (x y) Work coordinate system	G17 G16 Xp_ Yp; G18 G16 Zp_ Xp; G19 G16 Yp_ Zp; G15; Cancel
Plane section (G17, G18, G19)		G17; G18; G19;
Inch/millimeter conversion (G20, G21)		G20; Inch input G21; Millimeter input
Stored stroke check (G22, G23)	(XYZ)	G22 X_Y_Z_I_J_K_; G23 Cancel;
Reference position return check (G27)	Start point	G27 ℙ_;
Reference position return (G28) 2nd, reference position return (G30)	Intermediate position IP 2nd reference position (G30) Start point	G28 IP_; G30 IP_;
Return from reference position to start point (G29)	Reference position IP Intermediate position	G29 IP_;

Functions	Illustration	Tape format
Skip function (G31)	Start point Skip signal	G31 P_F_;
Thread cutting (G33)	F	G33
Cutter compensation C (G40 – G42)	G40 G42	$ \left\{ \begin{array}{l} \text{G17} \\ \text{G18} \\ \text{G19} \end{array} \right\} \left\{ \begin{array}{l} \text{G41} \\ \text{G42} \end{array} \right\} \ \text{D}_{-}; $ D : Tool offset G40 : Cancel
Tool length offset A (G43, G44, G49)	Offset	$ \left\{ \begin{array}{l} \text{G43} \\ \text{G44} \end{array} \right\} \ Z \ \text{H}; $ $ \left\{ \begin{array}{l} \text{G43} \\ \text{G44} \end{array} \right\} \ \text{H}; $ $ \text{H}: \text{Tool offset} \\ \text{G49}: \text{Cancel} $
Tool length offset B (G43, G44, G49)		$ \begin{cases} G17 \\ G18 \\ G19 \end{cases} \begin{cases} G43 \\ G44 \end{cases} \begin{cases} Z_{-} \\ Y_{-} \\ X_{-} \end{cases} H_{-}; $ $ \begin{cases} G17 \\ G18 \\ G19 \end{cases} \begin{cases} G43 \\ G44 \end{cases} H_{-}; $ $ H: Tool offset \\ G49: Cancel $
Tool length offset C (G43, G44, G49)		$ \begin{cases} G43 \\ G44 \end{cases} \alpha H; $ $\alpha : An \ optional \ address \ of \ one \ axis \\ H : Tool \ offset \ number \\ G49 : Cancel $
Tool offset (G45 – G48)	G 45 Increase G 46 Increase G 47 Increase G 48 Increase G 48 Increase G 48 Increase IP Decrease increase G decrease Compensation value	G45 G46 G47 G48 D: Tool offset number

Functions	Illustration	Tape format
Scaling (G50, G51)	P ₄ P ₃ P ₃ P ₁ P ₂ P ₁ P ₂ P ₂	G51 IP_ P_; P : Scaling magnification G50 ; Cancel
Programmable mirror image (G50.1, G51.1)	Mirror	G51.1 ℙ _ ; G50.1 ; Cancel
Setting of local coordinate system (G52)	Local coordinate system IP Work coordinate system	G52 ℙ_ ;
Command in machine coordinate system (G53)		G53 ℙ_ ;
Selection of work coordinate system (G54 – G59)	Work zero point offset Work coordinate system Machine coordinate system	{ G54
Single direction positioning (G60)	₽	G60 IP_;
Cutting mode/Exact stop mode, Tapping mode, Automatic corner override	G64 t	G64_; Cutting mode G61_; Exact stop mode G63_; Tapping mode G62_; Automatic corner override
Custom macro (G65, G66, G67)	G65 P_L _ ; Macro O_ ; M99 ;	One-shot call G65 P_ L_ <argument assignment="">; P: Program No. L: Number of repeatition Modal call G66 P_L_ <argument assignment="" cancel="" g67;="">;</argument></argument>

Functions	Illustration	Tape format
Coordinate system rotation (G68, G69)	Y α (x y) X (In case of X–Y plane)	$G68 \begin{cases} G17 \ X_{-} \ Y_{-} \\ G18 \ Z_{-} \ X_{-} \\ G19 \ Y_{-} \ Z_{-} \end{cases} R \ \underline{\alpha} \ ;$ $G69 \ ; \ Cancel$
Canned cycles (G73, G74, G80 – G89)	Refer to II.13. FUNCTIONS TO SIMPLIFY PROGRAMMING	G80; Cancel G73 G74 G76 G81 : G89 X_Y_Z_P_Q_R_F_K_;
Absolute/incremental programming (G90/G91)		G90_; Absolute command G91_; Incremental command G90_G91_; Combined use
Change of workpiece coordinate system (G92)		G92 ℙ_ ;
Workpiece coordinate system preset (G92.1)		G92.1 IP 0;
Feed per minute, Feed per revolution (G94, G95)	mm/min inch/min mm/rev inch/rev	G98 F_ ; G99 F_ ;
Constant surface speed control (G96, G97)		G96 S_ ; G97 S_ ;
Initial point return / R point return (G98, G99)	G98 Initial level G99 R level Z point	G98_; G99_;



RANGE OF COMMAND VALUE

Linear axis

 In case of millimeter input, feed screw is millimeter

	Increment system	
	IS-B	IS-C
Least input increment	0.001 mm	0.0001 mm
Least command increment	0.001 mm	0.0001 mm
Max. programmable dimension	±99999.999 mm	±9999.9999 mm
Max. rapid traverse Note	240000 mm/min	100000 mm/min
Feedrate range Note	1 to 240000 mm/min	1 to 100000 mm/min
Incremental feed	0.001, 0.01, 0.1, 1 mm/step	0.0001, 0.001, 0.01, 0.1 mm/step
Tool compensation	0 to ±999.999 mm	0 to ±999.9999 mm
Dwell time	0 to 99999.999 sec	0 to 99999.999 sec

• In case of inch input, feed screw is millimeter

	Increment system	
	IS-B	IS-C
Least input increment	0.0001 inch	0.00001 inch
Least command increment	0.001 mm	0.0001 mm
Max. programmable dimension	±9999.9999 inch	±393.70078 inch
Max. rapid traverse Note	240000 mm/min	100000 mm/min
Feedrate range Note	0.01 to 9600 inch/min	0.01 to 4000 inch/min
Incremental feed	0.0001, 0.001, 0.01, 0.1 inch/step	0.00001, 0.0001, 0.001, 0.01 inch/step
Tool compensation	0 to ±99.9999 inch	0 to ±99.9999 inch
Dwell time	0 to 99999.999 sec	0 to 9999.9999 sec

• In case of inch input, feed screw is inch

	Increment system	
	IS-B	IS-C
Least input increment	0.0001 inch	0.00001 inch
Least command increment	0.0001 inch	0.00001 inch
Max. programmable dimension	±9999.9999 inch	±9999.9999 inch
Max. rapid traverse Note	9600 inch/min	4000 inch/min
Feedrate range Note	0.01 to 9600 inch/min	0.01 to 4000 inch/min
Incremental feed	0.0001, 0.001, 0.01, 0.1 inch/step	0.00001, 0.0001, 0.001, 0.01 inch/step
Tool compensation	0 to ±99.9999 inch	0 to ±99.9999 inch
Dwell time	0 to 99999.999 sec	0 to 9999.9999 sec

• In case of millimeter input, feed screw is inch

	Increment system	
	IS-B	IS-C
Least input increment	0.001 mm	0.0001 mm
Least command increment	0.0001 inch	0.00001 inch
Max. programmable dimension	±99999.999 mm	±9999.9999 mm
Max. rapid traverse Note	9600 inch/min	4000 inch/min
Feedrate range Note	1 to 240000 mm/min	1 to 100000 mm/min
Incremental feed	0.001, 0.01, 0.1, 1 mm/step	0.0001, 0.001, 0.01, 0.1 mm/step
Tool compensation	0 to ±999.999 mm	0 to ±999.9999 mm
Dwell time	0 to 99999.999 sec	0 to 9999.9999 sec

Rotation axis

	Increment system	
	IS-B	IS-C
Least input increment	0.001 deg	0.0001 deg
Least command increment	0.001 deg	0.0001 deg
Max. programmable dimension	±99999.999 deg	±9999.9999 deg
Max. rapid traverse Note	240000 deg/min	100000 deg/min
Feedrate range Note	1 to 240000 deg/min	1 to 100000 deg/min
Incremental feed	0.001, 0.01, 0.1, 1 deg/step	0.0001, 0.001, 0.01, 0.1 deg/step

NOTE

The feedrate range shown above are limitations depending on CNC interpolation capacity. As a whole system, limitations depending on servo system must also be considered.



NOMOGRAPHS

D.1 INCORRECT THREADED LENGTH

The leads of a thread are generally incorrect in δ_1 and δ_2 , as shown in Fig. D.1 (a), due to automatic acceleration and deceleration.

Thus distance allowances must be made to the extent of δ_1 and δ_2 in the program.




Fig.D.1(a) Incorrect thread position

Explanations

• How to determine δ_2

 $\delta_2 = T_1 V \text{ (mm)} \dots (1)$ $V = \frac{1}{60} RL$ $T_1 : \text{Time constant of servo system (sec)}$ V : Cutting speed (mm/sec) $\text{Time constant } T_1 \text{ (sec) of }$

R: Spindle speed (mm)
L: Thread feed (mm)

Time constant T_1 (sec) of the servo system: Usually 0.033 s.

• How to determine δ_1

$$\delta_1 = \{t - T_1 + T_1 \exp(-\frac{t}{T_1})\}V \qquad ... \qquad (2)$$

$$a = \exp(-\frac{t}{T_1}) \qquad ... \qquad (3)$$

$$T_1 \qquad : \text{ Time constant of servo system (sec)} \text{ Time constant } T_1 \text{ (sec) of the servo system: Usually } 0.033 \text{ s.}$$

The lead at the beginning of thread cutting is shorter than the specified lead L, and the allowable lead error is ΔL . Then as follows.

$$a = \frac{\Delta L}{L}$$

When the value of $H\alpha I$ is determined, the time lapse until the thread accuracy is attained. The time HtI is substituted in (2) to determine δ_1 : Constants V and T_1 are determined in the same way as for δ_2 . Since the calculation of δ_1 is rather complex, a nomography is provided on the following pages.

How to use nomograph

First specify the class and the lead of a thread. The thread accuracy, α , will be obtained at (1), and depending on the time constant of cutting feed acceleration/ deceleration, the δ_1 value when V=10mm/ s will be obtained at (2). Then, depending on the speed of thread cutting, δ_1 for speed other than 10mm/ s can be obtained at (3).




Fig.D.1(b) Nomograph

NOTE

The equations for δ_1 , and δ_2 are for when the acceleration/deceleration time constant for cutting feed is 0.

D.2 SIMPLE CALCULATION OF INCORRECT THREAD LENGTH




Fig. D.2 (a) Incorrect threaded portion

Explanations

• How to determine δ_2

$$\delta_2 = \frac{LR}{1800^*} \text{ (mm)}$$

R: Spindle speed (rpm) L: Thread lead (mm)

* When time constant T of the servo system is 0.033 s.

• How to determine δ_1

$$\delta_1 = \frac{LR}{1800 *} (-1 - lna)$$

$$= \delta_2 (-1 - lna)$$
 (mm)

R: Spindle speed (rpm) L: Thread lead (mm)

* When time constant T of the servo system is 0.033 s.

Following a is a permited value of thread.

а	-1-Ina
0.005	4.298
0.01	3.605
0.015	3.200
0.02	2.912

Examples

R=350rpm

L=1mm

a=0.01 ther

$$\delta_2 = \frac{350 \times 1}{1800} = 0.194$$
 (mm)

$$\delta_{\rm 1}=\delta_{\rm 2}\times 3.605=0.701~\rm (mm)$$

• Reference




Fig D.2 (b) Nomograph for obtaining approach distance δ_{1}

D.3 TOOL PATH AT CORNER

When servo system delay (by exponential acceleration/deceleration at cutting or caused by the positioning system when a servo motor is used) is accompanied by cornering, a slight deviation is produced between the tool path (tool center path) and the programmed path as shown in Fig. D.3 (a).

Time constant T_1 of the exponential acceleration/deceleration is fixed to 0.




Fig. D.3 (a) Slight deviation between the tool path and the programmed path

This tool path is determined by the following parameters:

- Feedrate (V_1, V_2)
- Corner angle (θ)
- Exponential acceleration / deceleration time constant (T_1) at cutting $(T_1=0)$
- Presence or absence of buffer register.

The above parameters are used to theoretically analyze the tool path and above tool path is drawn with the parameter which is set as an example. When actually programming, the above items must be considered and programming must be performed carefully so that the shape of the workpiece is within the desired precision.

In other words, when the shape of the workpiece is not within the theoretical precision, the commands of the next block must not be read until the specified feedrate becomes zero. The dwell function is then used to stop the machine for the appropriate period.

Analysis

The tool path shown in Fig. D.3 (b) is analyzed based on the following conditions:

Feedrate is constant at both blocks before and after cornering.

The controller has a buffer register. (The error differs with the reading speed of the tape reader, number of characters of the next block, etc.)




Fig. D.3(b) Example of tool path

Description of conditions and symbols

 $\begin{array}{lll} V_{X1} = V\cos\phi_1 \\ \\ V_{Y1} = V\sin\phi_1 \\ \\ V_{X2} = V\cos\phi_2 \\ \\ V_{Y2} = V\sin\phi_2 \\ \\ \\ V : & \text{Feedrate at both blocks before and after cornering} \\ V_{X1} : & X\text{-axis component of feedrate of preceding block} \\ V_{Y1} : & Y\text{-axis component of feedrate of preceding block} \\ V_{X2} : & X\text{-axis component of feedrate of following block} \\ V_{Y2} : & Y\text{-axis component of feedrate of following block} \\ \theta : & \text{Corner angle} \\ \phi_1 : & \text{Angle formed by specified path direction of preceding block} \\ & \text{and } X\text{-axis} \\ \end{array}$

Initial value calculation




Fig. D.3(c) Initial value

The initial value when cornering begins, that is, the X and Y coordinates at the end of command distribution by the controller, is determined by the feedrate and the positioning system time constant of the servo motor.

$$X_0 = V_{X1}(T_1 + T_2)$$
$$Y_0 = V_{Y1}(T_1 + T_2)$$

 T_1 :Exponential acceleration / deceleration time constant. (T=0) T_2 :Time constant of positioning system (Inverse of position loop gain)

Analysis of corner tool path

The equations below represent the feedrate for the corner section in X-axis direction and Y-axis direction.

$$V_{X}(t) = (V_{X2} - V_{X1})[1 - \frac{V_{X1}}{T_{1} - T_{2}} \{ T_{1} \exp(-\frac{t}{T_{1}}) - T_{2} \exp(-\frac{t}{T_{2}}) \} + V_{X1}]$$

$$= V_{X2}[1 - \frac{V_{X1}}{T_{1} - T_{2}} \{ T_{1} \exp(-\frac{t}{T_{1}}) - T_{2} \exp(-\frac{t}{T_{2}}) \}]$$

$$V_{Y}(t) = \frac{V_{Y1} - V_{Y2}}{T_{1} - T_{2}} \{ T_{1} \exp(-\frac{t}{T_{1}}) - T_{2} \exp(-\frac{t}{T_{2}}) \} + V_{Y2}$$

Therefore, the coordinates of the tool path at time *t* are calculated from the following equations:

$$X(t) = \int_{0}^{t} V_{X}(t)dt - X_{0}$$

$$= \frac{V_{X2} - V_{X1}}{T_{1} - T_{2}} \{T_{1}^{2} \exp(-\frac{t}{T_{1}}) - T_{2}^{2} \exp(-\frac{t}{T_{2}})\} - V_{X2}(T_{1} + T_{2} - t)$$


$$Y(t) = \int_{0}^{t} V_{Y}(t)dt - Y_{0}$$

$$= \frac{V_{Y2} - V_{Y1}}{T_{1} - T_{2}} \{T_{1}^{2} \exp(-\frac{t}{T_{1}}) - T_{2}^{2} \exp(-\frac{t}{T_{2}})\} - V_{Y2}(T_{1} + T_{2} - t)$$

D.4 RADIUS DIRECTION ERROR AT CIRCLE CUTTING

When a servo motor is used, the positioning system causes an error between input commands and output results. Since the tool advances along the specified segment, an error is not produced in linear interpolation. In circular interpolation, however, radial errors may be produced, sepecially for circular cutting at high speeds.

This error can be obtained as follows:



$$\Delta r = \frac{1}{2} (T_1^2 + T_2^2) \frac{V^2}{r}$$
 (1)

⊿r : Maximum radius error (mm)

v : Feedrate (mm/s) r : Circle radius (mm)

T₁: Exponential acceleration/deceleration time constant (sec) at cutting

(T=0)

T₂: Time constant of positoning system (sec).

(Inverse of positon loop gain)

In the case of bell–shaped acceleration/deceleration and linear acceleration/deceleration after cutting feed interpolation, an approximation of this radius error can be obtained with the following expression:

$$\Delta r = (\frac{1}{24}T_1^2 + \frac{1}{2}T_2^2)\frac{V^2}{r}$$

Thus, the radius error in the case of bell–shaped acceleration/deceleration and linear acceleration/deceleration after interpolation is smaller than in case of exponential acceleration/deceleration by a factor of 12, excluding any error caused by a servo loop time constant.

Since the machining radius r (mm) and allowable error Δr (mm) of the workpiece is given in actual machining, the allowable limit feedrate v (mm/sec) is determined by equation (1).

Since the acceleration/deceleration time constant at cutting which is set by this equipment varies with the machine tool, refer to the manual issued by the machine tool builder.



STATUS WHEN TURNING POWER ON, WHEN CLEAR AND WHEN RESET

Parameter CLR (No. 3402#6) is used to select whether resetting the CNC places it in the cleared state or in the reset state (0: reset state/1: cleared state).

The symbols in the tables below mean the following:

:The status is not changed or the movement is continued.

×:The status is cancelled or the movement is interrupted.

	Item	When turning power on	Cleared	Reset
Setting data	Offset value	0	0	0
uaia	Data set by the MDI setting operation	0	0	0
	Parameter	0	0	0
Various data	Programs in memory	0	0	0
uaia	Contents in the buffer storage	×	×	○ : MDI mode × : Other mode
	Display of sequence number	0	O (Note 1)	○ (Note 1)
	One shot G code	×	×	×
	Modal G code	Initial G codes. (The G20 and G21 codes return to the same state they were in when the power was last turned off.)	Initial G codes. (G20/G21 are not changed.)	0
	F	Zero	Zero	0
	S, T, M	×	0	0
	K (Number of repeats)	×	×	×
Work cod	ordinate value	Zero	0	0

	Item	When turning power on	Cleared	Reset
Action in	Movement	×	×	×
opera-	Dwell	×	×	×
tion	Issuance of M, S and T codes	×	×	×
	Tool length compensation	×	Depending on parameter LVK(No.5003#6)	○ : MDI mode Other modes depend on parameter LVK(No.5003#6).
	Cutter compensation	×	×	○ : MDI mode × : Other modes
	Storing called subprogram number	×	× (Note 2)	○ : MDI mode × : Other modes (Note 2)
Output signals AL		Extinguish if there is no cause for the alarm	Extinguish if there is no cause for the alarm	Extinguish if there is no cause for the alarm
	Reference position return completion LED	×	○ (× : Emergency stop)	(x: Emergency stop)
	S, T and B codes	×	0	0
	M code	×	×	×
	M, S and T strobe signals	×	×	×
	Spindle revolution signal (S analog signal)	×	0	0
	CNC ready signal MA	ON	0	0
	Servo ready signal ON (When other than servo servo alarm)		ON (When other than servo alarm)	ON (When other than servo alarm)
	Cycle start LED (STL)	×	×	×
	Feed hold LED (SPL)	×	×	×

NOTE

- 1 When heading is performed, the main program number is displayed.
- 2 When a reset is performed during execution of a subprogram, control returns the head of main program.

Execution cannot be started from the middle of the subprogram.



CHARACTER-TO-CODES CORRESPONDENCE TABLE

Char- acter	Code	Comment	Char- acter	Code	Comment
А	065		6	054	
В	066		7	055	
С	067		8	056	
D	068		9	057	
Е	069			032	Space
F	070		!	033	Exclamation mark
G	071		"	034	Quotation mark
Н	072		#	035	Hash sign
I	073		\$	036	Dollar sign
J	074		%	037	Percent
K	075		&	038	Ampersand
L	076		,	039	Apostrophe
М	077		(040	Left parenthesis
N	078)	041	Right parenthesis
0	079		*	042	Asterisk
Р	080		+	043	Plus sign
Q	081		,	044	Comma
R	082		_	045	Minus sign
S	083			046	Period
Т	084		/	047	Slash
U	085		:	058	Colon
V	086		;	059	Semicolon
W	087		<	060	Left angle bracket
Х	088		=	061	Equal sign
Y	089		>	062	Right angle bracket
Z	090		?	063	Question mark
0	048		@	064	HAtl mark
1	049		[091	Left square bracket
2	050		^	092	
3	051]	094	Right square bracket
4	052			095	Underscore
5	053				



1) Program errors (P/S alarm)

Number	Message	Contents
000	PLEASE TURN OFF POWER	A parameter which requires the power off was input, turn off power.
001	TH PARITY ALARM	TH alarm (A character with incorrect parity was input). Correct the tape.
002	TV PARITY ALARM	TV alarm (The number of characters in a block is odd). This alarm will be generated only when the TV check is effective.
003	TOO MANY DIGITS	Data exceeding the maximum allowable number of digits was input. (Refer to the item of max. programmable dimensions.)
004	ADDRESS NOT FOUND	A numeral or the sign "-" was input without an address at the beginning of a block. Modify the program.
005	NO DATA AFTER ADDRESS	The address was not followed by the appropriate data but was followed by another address or EOB code. Modify the program.
006	ILLEGAL USE OF NEGATIVE SIGN	Sign " ." input error (Sign " – " was input after an address with which it cannot be used. Or two or more " – " signs were input.) Modify the program.
007	ILLEGAL USE OF DECIMAL POINT	Decimal point "-" input error (A decimal point was input after an address with which it can not be used. Or two decimal points were input.) Modify the program.
009	ILLEGAL ADDRESS INPUT	Unusable character was input in significant area. Modify the program.
010	IMPROPER G-CODE	An unusable G code or G code corresponding to the function not provided is specified. Modify the program.
011	NO FEEDRATE COMMANDED	Feedrate was not commanded to a cutting feed or the feedrate was in- adequate. Modify the program.
014	CAN NOT COMMAND G95	A synchronous feed is specified without the option for threading / synchronous feed.
015	TOO MANY AXES COMMANDED	The number of the commanded axes exceeded that of simultaneously controlled axes.
020	OVER TOLERANCE OF RADIUS	In circular interpolation (G02 or G03), difference of the distance between the start point and the center of an arc and that between the end point and the center of the arc exceeded the value specified in parameter No. 3410.
021	ILLEGAL PLANE AXIS COMMANDED	An axis not included in the selected plane (by using G17, G18, G19) was commanded in circular interpolation. Modify the program.
022	NO CIRCULAR RADIUS	When circular interpolation is specified, neither R (specifying an arc radius), nor I, J, and K (specifying the distance from a start point to the center) is specified.
025	CANNOT COMMAND F0 IN G02/G03	F0 (fast feed) was instructed by F1 –digit column feed in circular interpolation. Modify the program.
027	NO AXES COMMANDED IN G43/G44	No axis is specified in G43 and G44 blocks for the tool length offset type C. Offset is not canceled but another axis is offset for the tool length offset type C. Modify the program.
028	ILLEGAL PLANE SELECT	In the plane selection command, two or more axes in the same direction are commanded. Modify the program.

Number	Message	Contents
029	ILLEGAL OFFSET VALUE	The offset values specified by H code is too large. Modify the program.
030	ILLEGAL OFFSET NUMBER	The offset number specified by D/H code for tool length offset or cutter compensation is too large. Modify the program.
031	ILLEGAL P COMMAND IN G10	In setting an offset amount by G10, the offset number following address P was excessive or it was not specified. Modify the program.
032	ILLEGAL OFFSET VALUE IN G10	In setting an offset amount by G10 or in writing an offset amount by system variables, the offset amount was excessive.
033	NO SOLUTION AT CRC	A point of intersection cannot be determined for cutter compensation C. Modify the program.
034	NO CIRC ALLOWED IN ST-UP /EXT BLK	The start up or cancel was going to be performed in the G02 or G03 mode in cutter compensation C. Modify the program.
035	CAN NOT COMMANDED G39	G39 is commanded in cutter compensation B cancel mode or on the plane other than offset plane. Modify the program.
036	CAN NOT COMMANDED G31	Skip cutting (G31) was specified in cutter compensation mode. Modify the program.
037	CAN NOT CHANGE PLANE IN CRC	G40 is commanded on the plane other than offset plane in cutter compensation B. The plane selected by using G17, G18 or G19 is changed in cutter compensation C mode. Modify the program.
038	INTERFERENCE IN CIRCULAR BLOCK	Overcutting will occur in cutter compensation C because the arc start point or end point coincides with the arc center. Modify the program.
041	INTERFERENCE IN CRC	Overcutting will occur in cutter compensation C. Two or more blocks are consecutively specified in which functions such as the auxiliary function and dwell functions are performed without movement in the cutter compensation mode. Modify the program.
042	G45/G48 NOT ALLOWED IN CRC	Tool offset (G45 to G48) is commanded in cutter compensation. Modify the program.
043	ILLEGAL T-CODE COMMAND	In a system using the DRILL-MATE with an ATC, a T code was not specified together with the M06 code in a block. Alternatively, the Tcode was out of range.
044	G27–G30 NOT ALLOWED IN FIXED CYC	One of G27 to G30 is commanded in canned cycle mode. Modify the program.
046	ILLEGAL REFERENCE RETURN COMMAND	Other than P2, P3 and P4 are commanded for 2nd, 3rd and 4th reference position return command.
050	CHF/CNR NOT ALLOWED IN THRD BLK	Chamfering or corner R is commanded in the thread cutting block. Modify the program.
051	MISSING MOVE AFTER CHF/CNR	Improper movement or the move distance was specified in the block next to the chamfering or corner R block. Modify the program.
052	CODE IS NOT G01 AFTER CHF/ CNR	The block next to the chamfering or corner R block is not G01,G02,or G03. Modify the program.
053	TOO MANY ADDRESS COM- MANDS	For systems without the arbitary angle chamfering or corner R cutting, a comma was specified. For systems with this feature, a comma was followed by something other than R or C Correct the program.
055	MISSING MOVE VALUE IN CHF/ CNR	In the arbitrary angle chamfering or corner R block, the move distance is less than chamfer or corner R amount.
058	END POINT NOT FOUND	In a arbitrary angle chamfering or corner R cutting block, a specified axis is not in the selected plane. Correct the program.

Number	Message	Contents
059	PROGRAM NUMBER NOT FOUND	In an external program number search, a specified program number was not found. Otherwise, a program specified for searching is being edited in background processing. Check the program number and external signal. Or discontinue the background eiting.
060	SEQUENCE NUMBER NOT FOUND	Commanded sequence number was not found in the sequence number search. Check the sequence number.
070	NO PROGRAM SPACE IN MEMORY	The memory area is insufficient. Delete any unnecessary programs, then retry.
071	DATA NOT FOUND	The address to be searched was not found. Or the program with specified program number was not found in program number search. Check the data.
072	TOO MANY PROGRAMS	The number of programs to be stored exceeded 63 (basic), 125 (option), 200 (option), or 400 (option). Delete unnecessary programs and execute program registeration again.
073	PROGRAM NUMBER ALREADY IN USE	The commanded program number has already been used. Change the program number or delete unnecessary programs and execute program registeration again.
074	ILLEGAL PROGRAM NUMBER	The program number is other than 1 to 9999. Modify the program number.
075	PROTECT	An attempt was made to register a program whose number was protected.
076	ADDRESS P NOT DEFINED	Address P (program number) was not commanded in the block which includes an M98, G65, or G66 command. Modify the program.
077	SUB PROGRAM NESTING ERROR	The subprogram was called in five folds. Modify the program.
078	NUMBER NOT FOUND	A program number or a sequence number which was specified by address P in the block which includes an M98, M99, M65 or G66 was not found. The sequence number specified by a GOTO statement was not found. Otherwise, a called program is being edited in background processing. Correct the program, or discontinue the background editing.
079	PROGRAM VERIFY ERROR	In memory or program collation,a program in memory does not agree with that read from an external I/O device. Check both the programs in memory and those from the external device.
080	G37 ARRIVAL SIGNAL NOT AS- SERTED	In the automatic tool length measurement function (G37), the measurement position reach signal (XAE, YAE, or ZAE) is not turned on within an area specified in parameter 6254 (value ϵ). This is due to a setting or operator error.
081	OFFSET NUMBER NOT FOUND IN G37	Tool length automatic measurement (G37) was specified without a H code. (Automatic tool length measurement function) Modify the program.
082	H-CODE NOT ALLOWED IN G37	H code and automatic tool compensation (G37) were specified in the same block. (Automatic tool length measurement function) Modify the program.
083	ILLEGAL AXIS COMMAND IN G37	In automatic tool length measurement, an invalid axis was specified or the command is incremental. Modify the program.
085	COMMUNICATION ERROR	When entering data in the memory by using Reader / Puncher interface, an overrun, parity or framing error was generated. The number of bits of input data or setting of baud rate or specification No. of I/O unit is incorrect.
086	DR SIGNAL OFF	When entering data in the memory by using Reader / Puncher interface, the ready signal (DR) of reader / puncher was off. Power supply of I/O unit is off or cable is not connected or a P.C.B. is defective.
087	BUFFER OVERFLOW	When entering data in the memory by using Reader / Puncher interface, though the read terminate command is specified, input is not interrupted after 10 characters read. I/O unit or P.C.B. is defective.

Number	Message	Contents
090	REFERENCE RETURN INCOM- PLETE	The reference position return cannot be performed normally because the reference position return start point is too close to the reference position or the speed is too slow. Separate the start point far enough from the reference position, or specify a sufficiently fast speed for reference position return.
091	REFERENCE RETURN INCOM- PLETE	In the automatic operation halt state, manual reference position return cannot be performed.
092	AXES NOT ON THE REFERENCE POINT	The commanded axis by G27 (Reference position return check) did not return to the reference position.
094	P TYPE NOT ALLOWED (COORD CHG)	P type cannot be specified when the program is restarted. (After the automatic operation was interrupted, the coordinate system setting operation was performed.) Perform the correct operation according to th operator's manual.
095	P TYPE NOT ALLOWED (EXT OFS CHG)	P type cannot be specified when the program is restarted. (After the automatic operation was interrupted, the external workpiece offset amount changed.)
096	P TYPE NOT ALLOWED (WRK OFS CHG)	P type cannot be specified when the program is restarted. (After the automatic operation was interrupted, the workpiece offset amount changed.)
097	P TYPE NOT ALLOWED (AUTO EXEC)	P type cannot be directed when the program is restarted. (After power ON, after emergency stop or P/S alarm 94 to 97 were reset, no automatic operation is performed.) Perform automatic operation.
098	G28 FOUND IN SEQUENCE RETURN	A command of the program restart was specified without the reference position return operation after power ON or emergency stop, and G28 was found during search. Perform the reference position return.
099	MDI EXEC NOT ALLOWED AFT. SEARCH	After completion of search in program restart, a move command is given with MDI.
100	PARAMETER WRITE ENABLE	On the PARAMETER(SETTING) screen, PWE(parameter writing enabled) is set to 1. Set it to 0, then reset the system.
101	PLEASE CLEAR MEMORY	The power turned off while rewriting the memory by program edit operation. If this alarm has occurred, press <reset> while pressing <prog>, and only the program being edited will be deleted. Register the deleted program.</prog></reset>
109	FORMAT ERROR IN G08	A value other than 0 or 1 was specified after P in the G08 code, or no value was specified.
110	DATA OVERFLOW	The absolute value of fixed decimal point display data exceeds the allowable range. Modify the program.
111	CALCULATED DATA OVERFLOW	The result of calculation is out of the allowable range (-10^{47} to -10^{-29} , 0, and 10^{-29} to 10^{47}).
112	DIVIDED BY ZERO	Division by zero was specified. (including tan 90°)
113	IMPROPER COMMAND	A function which cannot be used in custom macro is commanded. Modify the program.
114	FORMAT ERROR IN MACRO	There is an error in other formats than <formula>. Modify the program.</formula>
115	ILLEGAL VARIABLE NUMBER	A value not defined as a variable number is designated in the custom macro. Modify the program.
116	WRITE PROTECTED VARIABLE	The left side of substitution statement is a variable whose substitution is inhibited. Modify the program.
118	PARENTHESIS NESTING ERROR	The nesting of bracket exceeds the upper limit (quintuple). Modify the program.
119	ILLEGAL ARGUMENT	The SQRT argument is negative, BCD argument is negative, or other values than 0 to 9 are present on each line of BIN argument. Modify the program.

Number	Message	Contents
122	QUADRUPLICATE MACRO MODAL-CALL	A total of four macro calls and macro modal calls are nested. Correct the program.
123	CAN NOT USE MACRO COMMAND IN DNC	Macro control command is used during DNC operation. Modify the program.
124	MISSING END STATEMENT	DO – END does not correspond to 1 : 1. Modify the program.
125	FORMAT ERROR IN MACRO	<formula> format is erroneous. Modify the program.</formula>
126	ILLEGAL LOOP NUMBER	In DOn, $1 \le n \le 3$ is not established. Modify the program.
127	NC, MACRO STATEMENT IN SAME BLOCK	NC and custom macro commands coexist. Modify the program.
128	ILLEGAL MACRO SEQUENCE NUMBER	The sequence number specified in the branch command was not 0 to 9999. Or, it cannot be searched. Modify the program.
129	ILLEGAL ARGUMENT ADDRESS	An address which is not allowed in <argument designation=""> is used. Modify the program.</argument>
130	ILLEGAL AXIS OPERATION	An axis control command was given by PMC to an axis controlled by CNC. Or an axis control command was given by CNC to an axis controlled by PMC. Modify the program.
131	TOO MANY EXTERNAL ALARM MESSAGES	Five or more alarms have generated in external alarm message. Consult the PMC ladder diagram to find the cause.
132	ALARM NUMBER NOT FOUND	No alarm No. concerned exists in external alarm message clear. Check the PMC ladder diagram.
133	ILLEGAL DATA IN EXT. ALARM MSG	Small section data is erroneous in external alarm message or external operator message. Check the PMC ladder diagram.
135	ILLEGAL ANGLE COMMAND	The index table indexing positioning angle was instructed in other than an integral multiple of the value of the minimum angle. Modify the program.
136	ILLEGAL AXIS COMMAND	In index table indexing, another control axis was instructed together with the B axis. Modify the program.
138	SUPERIMPOSED DATA OVERFLOW	In PMC-based axis control, the increment for pulse distribution on the CNC and PMC side are too large when the superimposed control extended function is used.
139	CAN NOT CHANGE PMC CONTROL AXIS	An axis is selected in commanding by PMC axis control. Modify the program.
141	CAN NOT COMMAND G51 IN CRC	G51 (Scaling ON) is commanded in the tool offset mode. Modify the program.
142	ILLEGAL SCALE RATE	Scaling magnification is commanded in other than 1 – 999999. Correct the scaling magnification setting (G51 Pp or parameter 5411 or 5421).
143	SCALED MOTION DATA OVER- FLOW	The scaling results, move distance, coordinate value and circular radius exceed the maximum command value. Correct the program or scaling mangification.
144	ILLEGAL PLANE SELECTED	The coordinate rotation plane and arc or cutter compensation C plane must be the same. Modify the program.
148	ILLEGAL SETTING DATA	Automatic corner override deceleration rate is out of the settable range of judgement angle. Modify the parameters (No.1710 to No.1714)
149	FORMAT ERROR IN G10L3	A code other than Q1,Q2,P1 or P2 was specified as the life count type in the extended tool life management.
150	ILLEGAL TOOL GROUP NUMBER	Tool Group No. exceeds the maximum allowable value. Modify the program.
151	TOOL GROUP NUMBER NOT FOUND	The tool group commanded in the machining program is not set. Modify the value of program or parameter.

Number	Message	Contents
152	NO SPACE FOR TOOL ENTRY	The number of tools within one group exceeds the maximum value registerable. Modify the number of tools.
153	T-CODE NOT FOUND	In the registration of tool life data, a T code was not specified in a block where it is required. Alternatively, only M06 was specified in a block for tool change type D. Correct the program.
154	NOT USING TOOL IN LIFE GROUP	When the group is not commanded, H99 or D99 was commanded. Correct the program.
155	ILLEGAL T-CODE IN M06	In the machining program, M06 and T code in the same block do not correspond to the group in use. Correct the program.
156	P/L COMMAND NOT FOUND	P and L commands are missing at the head of program in which the tool group is set. Correct the program.
157	TOO MANY TOOL GROUPS	The number of tool groups to be set exceeds the maximum allowable value. See parameter GS1, GS2 (No. 6800 bit 0 and 1). Modify the program.
158	ILLEGAL TOOL LIFE DATA	The tool life to be set is too excessive. Modify the setting value.
159	TOOL DATA SETTING INCOM- PLETE	During executing a life data setting program, power was turned off. Set again.
175	ILLEGAL G107 COMMAND	Conditions when performing cylindrical interpolation start or cancel not correct. To change the mode to the cylindrical interpolation mode, specify the command in a format of "G07.1 rotation—axis name radius of cylinder."
176	IMPROPER G-CODE IN G107	Any of the following G codes which cannot be specified in the cylindrical interpolation mode was specified.
		1) G codes for positioning, such as G28,, G73, G74, G76, G81 – G89, including the codes specifying the rapid traverse cycle
		2) G codes for setting a coordinate system: G52,G92,
		3) G code for selecting coordinate system: G53 G54–G59
		Modify the program.
177	CHECK SUM ERROR (G05 MODE)	Check sum error Modify the program.
178	G05 COMMANDED IN G41/G42 MODE	G05 was commanded in the G41/G42 mode. Correct the program.
179	PARAM. (PRM NO. 7510) SETTING ERROR	The number of controlled axes set by the parameter 7510 exceeds the maximum number. Modify the parameter setting value.
180	COMMUNICATION ERROR (REMOTE BUF)	Remote buffer connection alarm has generated. Confirm the number of cables, parameters and I/O device.
190	ILLEGAL AXIS SELECT	In the constant surface speed control, the axis specification is wrong. (See parameter No. 3770.) The specified axis command (P) contains an illegal value. Correct the program.
194	SPINDLE COMMAND IN SYN- CHRO-MODE	A contour control mode, spindle positioning (Cs–axis control) mode, or rigid tapping mode was specified during the serial spindle synchronous control mode. Correct the program so that the serial spindle synchronous control mode is released in advance.
197	C-AXIS COMMANDED IN SPINDLE MODE	The program specified a movement along the Cs–axis when the signal CON(DGN=G027#7) was off. Correct the program, or consult the PMC ladder diagram to find the reason the signal is not turned on.
199	MACRO WORD UNDEFINED	Undefined macro word was used. Modify the custom macro.
200	ILLEGAL S CODE COMMAND	In the rigid tap, an S value is out of the range or is not specified. The maximum value for S which can be specified in rigid tapping is set in parameter (No.5241 to 5243). Change the setting in the parameter or modify the program.

Number	Message	Contents
201	FEEDRATE NOT FOUND IN RIGID TAP	In the rigid tapping, no F value is specified. Correct the program.
202	POSITION LSI OVERFLOW	In the rigid tapping, spindle distribution value is too large.
203	PROGRAM MISS AT RIGID TAPPING	In the rigid tapping, position for a rigid M code (M29) or an S command is incorrect. Modify the program.
204	ILLEGAL AXIS OPERATION	In the rigid tapping, an axis movement is specified between the rigid M code (M29) block and G84 (G74) block. Modify the program.
205	RIGID MODE DI SIGNAL OFF	Rigid tapping signal (DGNG 061#1) is not 1 when G84 (G74) is executed though the rigid M code (M29) is specified. Consult the PMC ladder diagram to find the reason the DI signal is not turned on. Modify the program.
206	CAN NOT CHANGE PLANE (RIGID TAP)	Plane changeover was instructed in the rigid mode. Correct the program.
207	RIGID DATA MISMATCH	The specified distance was too short or too long in rigid tapping.
210	CAN NOT COMAND M198/M99	1) M198 and M99 are executed in the schedule operation. Or M198 is executed in the DNC operation.
		2) In a multiple repetitive pocketing canned cycle, an interrupt macro was specified, and M99 was executed.
212	ILLEGAL PLANE SELECT	The arbitrary angle chamfering or a corner R is commanded or the plane including an additional axis. Correct the program.
213	ILLEGAL COMMAND IN SYN- CHRO-MODE	Any of the following alarms occurred in the operation with the simple synchronization control.
		The program issued the move command to the slave axis.
		2) The program issued the manual continuous feed/manual handle feed/incremental feed command to the slave axis.
		3) The program issued the automatic reference position return command without executing the manual reference position return after the power was turned on.
		4) The difference between the position error amount of the master and slave axes exceeded the value specified in parameter No. 8313.
214	ILLEGAL COMMAND IN SYN- CHRO-MODE	Coordinate system is set or tool compensation of the shift type is executed in the synchronous control. Correct the program.
224	RETURN TO REFERENCE POINT	Reference position return has not been performed before the automatic operation starts. Perform reference position return only when parameter ZRN $_{\rm X}$ (No.1005#0) is 0.
231	ILLEGAL FORMAT IN G10 OR L50	 Any of the following errors occurred in the specified format at the programmable—parameter input. 1) Address N or R was not entered. 2) A number not specified for a parameter was entered. 3) The axis number was too large. 4) An axis number was not specified in the axis—type parameter. 5) An axis number was specified in the parameter which is not an axis type. 6) An attempt was made to reset bit 4 of parameter 3202 (NE9) or change parameter 3210 (PSSWD) when they are protected by a password. Correct the program.
232	TOO MANY HELICAL AXIS COM- MANDS	Three or more axes (in the normal direction control mode two or more axes) were specified as helical axes in the helical interpolation mode.
233	DEVICE BUSY	When an attempt was made to use a unit such as that connected via the RS–232–C interface, other users were using it.
239	BP/S ALARM	While punching was being performed with the function for controlling external I/O units ,background editing was performed.
240	BP/S ALARM	Background editing was performed during MDI operation.

Number	Message	Contents
253	G05 IS NOT AVAIRABLE	Binary–input operation with a high–speed remote buffer (G05) or high–speed cycle machining (G05) has been specified in look–ahead control mode (G08P1). Before attempting to specify these commands, first specify G08P0; to cancel look–ahead control mode.
5010	END OF RECORD	The end of record (%) was specified.
5020	PARAMETER OF RESTART ERROR	The parameter for specifying program restart is not set correctly.
5046	ILLEGAL PARAMETER (ST.COMP)	An illegal parameter has been specified for straightness compensation. Possible reasons are as follows:
		1 There is no axis corresponding to the axis number specified in the move axis or compensation axis parameter.
		2 More than 128 pitch error compensation points are not sequentially numbered.
		3 The straightness compensation points are not sequentially numbered.
		4 A specified straightness compensation point is outside the range between the pitch error compensation points having the maximum positive and negative coordinates.
		5 The compensation value specified for each compensation point is too large or too small.
5073	NO DECIMAL POINT	A decimal point is not specified for a command for which a decimal point must be specified.
5074	ADDRESS DUPLICATION ERROR	The same address appears more than once in a block. Alternatively, a block contains two or more G codes belonging to the same group.
5134	FSSB: OPEN READY TIME OUT	The FSSB did not become ready to open during initialization.
5135	FSSB: ERROR MODE	The FSSB entered an error mode.
5136	FSSB: NUMBER OF AMPS IS SMALL	The number of amplifiers recognized by the FSSB is insufficient, compared with the number of controlled axes.
5137	FSSB: CONFIGURATION ERROR	The FSSB detected a configuration error.
5138	FSSB: AXIS SETTING NOT COM PLETE	Axis setting has not been performed in automatic setting mode. Perform axis setting using the FSSB setting screen.
5197	FSSB: OPEN TIME OUT	The FSSB did not open when the CNC had allowed the FSSB to open.
5198	FSSB: ID DATA NOT READ	The initial ID information for the amplifier cannot be read because of a failure in the temporary assignment.

2) Background edit alarm

Number	Message	Contents
???	BP/S alarm	BP/S alarm occurs in the same number as the P/S alarm that occurs in ordinary program edit. (P/S alarm No. 070, 071, 072, 073, 074, 085 to 087) Modify the program.
140	BP/S alarm	It was attempted to select or delete in the background a program being selected in the foreground. (Note) Use background editing correctly.

NOTE

Alarm in background edit is displayed in the key input line of the background edit screen instead of the ordinary alarm screen and is resettable by any of the MDI key operation.

3) Absolute pulse coder (APC) alarm

Number	Message	Contents
300	nth-axis origin return	Manual reference position return is required for the nth–axis (n=1 - 4).
301	APC alarm: nth–axis communication	nth–axis (n=1 – 4) APC communication error. Failure in data transmission Possible causes include a faulty APC, cable, or servo interface module.
302	APC alarm: nth-axis over time	nth–axis (n=1 – 4) APC overtime error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo interface module.
303	APC alarm: nth-axis framing	nth–axis (n=1 – 4) APC framing error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo interface module.
304	APC alarm: nth-axis parity	nth—axis (n=1 – 4) APC parity error. Failure in data transmission. Possible causes include a faulty APC, cable, or servo interface module.
305	APC alarm: nth-axis pulse error	nth–axis (n=1 – 4) APC pulse error alarm. APC alarm.APC or cable may be faulty.
306	APC alarm: nth–axis battery voltage 0	nth–axis (n=1 – 4) APC battery voltage has decreased to a low level so that the data cannot be held. APC alarm. Battery or cable may be faulty.
307	APC alarm: nth-axis battery low 1	nth–axis (n=1 – 4) axis APC battery voltage reaches a level where the battery must be renewed. APC alarm. Replace the battery.
308	APC alarm: nth-axis battery low 2	nth–axis (n=1 – 4) APC battery voltage has reached a level where the battery must be renewed (including when power is OFF). APC alarm .Replace battery.
309	APC ALARM : n AXIS ZRN IMPOSSIBL	An attempt was made to perform reference position return without rotating the motor through one or more turns. Rotate the motor through one or more turns, turn off the power then on again, then perform reference position return.

4) Serial pulse coder (SPC) alarms

When either of the following alarms is issued, a possible cause is a faulty serial pulse coder or cable.

Number		Message	Contents
360	n AXIS:	ABNORMAL CHECKSUM (INT)	A checksum error occurred in the built–in pulse coder.
361	n AXIS:	ABNORMAL PHASE DATA (INT)	A phase data error occurred in the built-in pulse coder.
362	n AXIS:	ABNORMAL REV. DATA (INT)	A rotation speed count error occurred in the built-in pulse coder.
363	n AXIS:	ABNORMAL CLOCK (INT)	A clock error occurred in the built–in pulse coder.
364	n AXIS:	SOFT PHASE ALARM (INT)	The digital servo software detected invalid data in the built—in pulse coder.
365	n AXIS:	BROKEN LED (INT)	An LED error occurred in the built–in pulse coder.
366	n AXIS:	PULSE MISS (INT)	A pulse error occurred in the built in pulse coder.
367	n AXIS:	COUNT MISS (INT)	A count error occurred in the built–in pulse coder.
368	n AXIS:	SERIAL DATA ERROR (INT)	Communication data from the built–in pulse coder cannot be received.
369	n AXIS:	DATA TRANS. ERROR (INT)	A CRC or stop bit error occurred in the communication data being received from the built–in pulse coder.
380	n AXIS:	BROKEN LED (EXT)	The separate detector is erroneous.
381	n AXIS:	ABNORMAL PHASE (EXT LIN)	A phase data error occurred in the separate linear scale.
382	n AXIS:	COUNT MISS (EXT)	A pulse error occurred in the separate detector.
383	n AXIS:	PULSE MISS (EXT)	A count error occurred in the separate detector.
384	n AXIS:	SOFT PHASE ALARM (EXT)	The digital servo software detected invalid data in the separate detector.
385	n AXIS:	SERIAL DATA ERROR (EXT)	Communication data from the separate detector cannot be received.
386	n AXIS:	DATA TRANS. ERROR (EXT)	A CRC or stop bit error occurred in the communication data being received from the separate detector.

The details of serial pulse coder alarm No.350

The details of serial pulse coder alarm No. 350 (pulse coder alarm) are displayed in the diagnosis display (No. 202) as shown below.

	#7	#6	#5		0		#1	0
202		CSA	BLA	PHA	RCA	BZA	CKA	SPH

CSA: The serial pulse coder is defective. Replace it.

BLA: The battery voltage is low. Replace the batteries. This alarm has nothing to do with alarm No. 350 (serial pulse coder alarm).

SPH: The serial pulse coder or feedback cable is defective. Replace the serial pulse coder or cable.

RCA: The serial pulse coder is defective. Replace it.

BZA: The pulse coder was supplied with power for the first time.

Make sure that the batteries are connected.

Turn the power off, then turn it on again and perform a reference position return. This alarm has nothing to do with alarm No. 350 (serial pulse coder alarm).

CKA: The serial pulse coder is defective. Replace it.

PHA: The serial pulse coder or feedback cable is defective. replace the serial pulse coder or cable.

 The details of serial pulse coder alarm No.351 The details of serial pulse coder alarm No. 351 (communication alarm) are displayed in the diagnosis display (No. 203) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
203	DTE	CRC	STB	PRM				

DTE: The serial pulse coder encountered a communication error.

The pulse coder, feedbak cable, or feedback receiver circuit is defective. Replace the pulse coder, feedback cable, or NC-axis board

CRC: The serial pulse coder encountered a communication error. The pulse coder, feedback cable, or feedback receiver circuit is defective. Replace the pulse coder, feedback cable, or NC-axis board.

STB: the serial pulse coder encountered a communication error. The pulse coder, feedback cable, or feedback receiver circuit is defective.

Replace the pulse coder, feedback cable, or NC-axis board.

PRM: An invalid parameter was found. Alarm No. 417 (invalid servo parameter) is also issued.

5) Servo alarms

Number	Message	Contents
401	SERVO ALARM: n-TH AXIS VRDY OFF	The n-th axis (axis 1-4) servo amplifier READY signal (DRDY) went off.
404	SERVO ALARM: n-TH AXIS VRDY ON	Even though the n-th axis (axis 1-4) READY signal (MCON) went off, the servo amplifier READY signal (DRDY) is still on. Or, when the power was turned on, DRDY went on even though MCON was off. Check that the servo interface module and servo amp are connected.
405	SERVO ALARM: (ZERO POINT RETURN FAULT)	Position control system fault. Due to an NC or servo system fault in the reference position return, there is the possibility that reference position return could not be executed correctly. Try again from the manual reference position return.
407	SERVO ALARM: EXCESS ERROR	The difference in synchronous axis position deviation exceeded the set value.
409	TORQUEALM': EXCESS ERROR	An abnormal load on the servo motor was detected. Alternatively, an abnormal load on the spindle motor was detected in Cs mode.
410	SERVO ALARM: n-TH AXIS - EX- CESS ERROR	The position deviation value when the n–th axis (axis 1–4) stops is larger than the set value. Note) Limit value must be set to parameter No.1829 for each axis.
411	SERVO ALARM: n-TH AXIS - EX- CESS ERROR	The position deviation value when the n-th axis (axis 1-4) moves is larger than the set value. Note) Limit value must be set to parameter No.1828 for each axis.
413	SERVO ALARM: n-th AXIS - LSI OVERFLOW	The contents of the error register for the n–th axis (axis 1–4) are beyond the range of -2^{31} to 2^{31} . This error usually occurs as the result of an improperly set parameters.
415	SERVO ALARM: n-TH AXIS - EX- CESS SHIFT	A speed higher than 511875 units/s was attempted to be set in the n-th axis (axis 1-4). This error occurs as the result of improperly set CMR.

Number	Message	Contents
417	SERVO ALARM: n-TH AXIS - PA- RAMETER INCORRECT	This alarm occurs when the n-th axis (axis 1-4) is in one of the conditions listed below. (Digital servo system alarm)
		1) The value set in Parameter No. 2020 (motor form) is out of the specified limit.
		2) A proper value (111 or –111) is not set in parameter No.2022 (motor revolution direction).
		3) Illegal data (a value below 0, etc.) was set in parameter No. 2023 (number of speed feedback pulses per motor revolution).
		4) Illegal data (a value below 0, etc.) was set in parameter No. 2024 (number of position feedback pulses per motor revolution).
		5) Parameters No. 2084 and No. 2085 (flexible field gear rate) have not been set.
		6) A value outside the limit of {1 to the number of control axes} or a non- continuous value (Parameter 1023 (servo axis number) contains a value out of the range from 1 to the number of axes, or an isolated value (for example, 4 not preeded by 3).was set in parameter No. 1023 (servo axisnumber).
420	SYNC TORQUE': EXCESS ERROR	When simple synchronous control is applied, the torque command dif- ference between the master and slave axes exceeded the value set in parameter No. 2031.
421	EXCESS ER(D)': EXCESS ERROR	While the dual position feedback function is being applied, an excessive difference was detected between a semi-closed loop error and closed loop error. Check the dual position conversion factor set in parameter Nos. 2078 and 2079.
442	n AXIS : CNV. CHARGE FAULT/INV.	PSM: The spare discharge circuit of the DC link is abnormal.
	DB	2) PSMR: The spare discharge circuit of the DC link is abnormal.
		3) α series SVU: The dynamic brake circuit is abnormal.
443	n AXIS : CNV. COOLING FAN FAIL- URE	1) PSM: The internal stirring fan failed.
		2) PSMR: The internal stirring fan failed.
444	n AXIS : INV. COOLING FAN FAIL-	3) β series SVU: The internal stirring fan failed.
444	URE	SVM: The internal stirring fan failed.
445	n AXIS : SOFT DISCONNECT ALARM	The digital servo software detected a broken wire in the pulse coder.
446	n AXIS : HARD DISCONNECT ALARM	A broken wire in the built–in pulse coder was detected by hardware.
447	n AXIS : HARD DISCONNECT (EXT)	A broken wire in the separate detector was detected by hardware.
448	n AXIS : UNMATCHED FEEDBACK ALARM	The sign of feedback data from the built–in pulse coder differs from that of feedback data from the separate detector.
449	n AXIS : INV. IPM ALARM	SVM: IPM (intelligent power module) detected an alarm.
		2) α series SVU: IPM (intelligent power module) detected an alarm.
460	n AXIS : FSSB DISCONNECT	FSSB communication was disconnected suddenly. The possible causes are as follows:
		The FSSB communication cable was disconnected or broken.
		2) The power to the amplifier was turned off suddenly.
		A low–voltage alarm was issued by the amplifier.
461	n AXIS : ILLEGAL AMP INTERFACE	The axes of the 2–axis amplifier were assigned to the fast type interface.
462	n AXIS : SEND CNC DATA FAILED	Because of an FSSB communication error, a slave could not receive correct data.

Number	Message	Contents
463	n AXIS : SEND SLAVE DATA FAILED	Because of an FSSB communication error, the servo system could not receive correct data.
464	n AXIS : WRITE ID DATA FAILED	An attempt was made to write maintenance information on the amplifier maintenance screen, but it failed.
465	n AXIS : READ ID DATA FAILED	At power–up, amplifier initial ID information could not be read.
466	n AXIS : MOTOR/AMP COMBINA- TION	The maximum current rating for the amplifier does not match that for the motor.
467	n AXIS : ILLEGAL SETTING OF AXIS	The servo function for the following has not been enabled when an axis occupying a single DSP (corresponding to two ordinary axes) is specified on the axis setting screen.
		1. Learning control (bit 5 of parameter No. 2008 = 1)
		2. High-speed current loop (bit 0 of parameter No. 2004 = 1)
		3. High-speed interface axis (bit 4 of parameter No. 2005 = 1)

Details of servo alarm No.414

The details of servo alarm No. 414 are displayed in the diagnosis display (No. 200 and No.204) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
200	OVL	LV	OVC	HCA	HVA	DCA	FBA	OFA

OVL: An overload alarm is being generated.

(This bit causes servo alarm No. 400. The details are indicated in diagnostic data No.201).

LV: A low voltage alarm is being generated in servo amp. Check LED.

OVC: A overcurrent alarm is being generated inside of digital servo.

HCA: An abnormal current alarm is being generated in servo amp. Check LED.

HVA: An overvoltage alarm is being generated in servo amp. Check LED.

DCA: A regenerative discharge circuit alarm is being generated in servo amp.

Check LED.

FBA: A disconnection alarm is being generated.

(This bit causes servo alarm No.416.The details are indicated in diagnostic data No. 201)

OFA: An overflow alarm is being generated inside of digital servo.

	#7	#6	#5	#4	#3	#2	#1	#0
201	ALD			EXP				

When OVL equal 1 in diagnostic data No.200 (servo alarm No. 400 is being generated):

ALD 0 : Motor overheating 1 : Amplifier overheating

When FBAL equal 1 in diagnostic data No.200 (servo alarm No. 416 is being generated):

ALD	EXP	Alarm details
1	0	Built-in pulse coder disconnection (hardware)
1	1	Separately installed pulse coder disconnection (hardware)
0	0	Pulse coder is not connected due to software.

	#7	#6	#5	#4	#3	#2	#1	#0
204		OFS	MCC	LDA	PMS			

OFS: A current conversion error has occured in the digital servo. **MCC**: A magnetic contactor contact in the servo amplifier has

welded.

LDA: The LED indicates that serial pulse coder C is defective

PMS: A feedback pulse error has occured because the feedback cable

is defective.

6) Over travel alarms

Number	Message	Contents
500	OVER TRAVEL : +n	Exceeded the n-th axis + side stored stroke limit I. (Parameter No.1320 or 1326 Notes)
501	OVER TRAVEL : -n	Exceeded the n-th axis – side stored stroke limit I. (Parameter No.1321 or 1327 Notes)
502	OVER TRAVEL : +n	Exceeded the n-th axis + side stored stroke limit II. (Parameter No.1322)
503	OVER TRAVEL : -n	Exceeded the n-th axis – side stored stroke limit II. (Parameter No.1323)
506	OVER TRAVEL : +n	Exceeded the n-th axis + side hardware OT.
507	OVER TRAVEL : -n	Exceeded the n-th axis - side hardware OT.

NOTE

Parameters 1326 and 1327 are effective when EXLM (stroke limit switch signal) is on.

7) Overheat alarms

Number	Message	Contents
700	OVERHEAT: CONTROL UNIT	Control unit overheat Check that the fan motor operates normally, and clean the air filter.
701	OVERHEAT: FAN MOTOR	The fan motor on the top of the cabinet for the contorl unit is overheated. Check the operation of the fan motor and replace the motor if necessary.

8) Rigid tapping alarm

Number	Message	Contents		
740	RIGID TAP ALARM : EXCESS ERROR	During rigid tapping, the position deviation of the spindle in the stop state exceeded the setting.		
741	RIGID TAP ALARM : EXCESS ERROR	During rigid tapping, the position deviation of the spindle in the sto state exceeded the setting.		
742	RIGID TAP ALARM : LSI OVER FLOW	During rigid tapping, an LSI overflow occurred on the spindle side.		

9) Spindle alarms

Number	Message	Contents
749	S-SPINDLE LSI ERROR	A communication error occurred for the serial spindle. The cause may be the disconnection of an cable or the interruption of the power to the spindle amplifier.
		(Note) Unlike spindle alarm No. 750, this alarm occurs when a serial communication alarm is detected after the spindle amplifier is normally activated.
750	SPINDLE SERIAL LINK START FAULT	This alarm is generated when the spindle control unit is not ready for starting correctly when the power is turned on in the system with the serial spindle. The four reasons can be considered as follows:
		An improperly connected cable, or the spindle control unit's power is OFF.
		2) When the NC power was turned on under alarm conditions other than SU–01 or AL–24 which are shown on the LED display of the spindle control unit. In this case, turn the spindle amplifier power off once and perform startup again.
		3) Other reasons (improper combination of hardware) This alarm does not occur after the system including the spindle control unit is activated.
		4) The second spindle (when SP2, bit 4 of parameter No. 3701, is 1) is in one of the above conditions 1) to 3).
		See diagnostic display No. 409 for details.
751	FIRST SPINDLE ALARM DETECTION (AL-XX)	This alarm indicates in the NC that an alarm is generated in the spindle unit of the system with the serial spindle. The alarm is displayed in form AL–XX (XX is a number). Refer to (11) Alarms displayed on spindle servo unit .The alarm number XX is the number indicated on the spindle amplifier. The CNC holds this number and displays on the screen.
752	FIRST SPINDLE MODE CHANGE FAULT	This alarm is generated if the system does not properly terminate a mode change. The modes include the Cs contouring, spindle positioning, rigid tapping, and spindle control modes. The alarm is activated if the spindle control unit does not respond correctly to the mode change command issued by the NC.
754	SPINDLE-1 ABNORMAL TORQUE ALM	An abnormal load on the first spindle motor was detected.

Number	Message	Contents		
761	SECOND SPINDLE ALARM DETECTION (AL-XX)	Refer to spindle alarm No. 751. (For 2nd axis)		
762 SECOND SPINDLE MODE CHANGE FAULT		Refer to spindle alarm No. 752.(For 2nd axis)		
764	SPINDLE-2 ABNORMAL TORQUE ALM	Same as for alarm No. 754 (for the second spindle)		

The details of spindle alarm No.750

The details of spindle alarm No. 750 are displayed in the diagnosis display (No. 409) as shown below.

	#7	#6	#5	#4	#3	#2	#1	#0
409					SPE	S2E	S1E	SHE

- **SPE 0**: In the spindle serial control, the serial spindle parameters fulfill the spindle unit startup conditions.
 - 1: In the spindle serial control, the serial spindle parameters do not fulfill the spindle unit startup conditions.
- ${f S2E}$ 0: The second spindle is normal during the spindle serial control startup.
 - 1: The second spindle was detected to have a fault during the spindle serial control startup.
- ${f S1E}$ 0: The first spindle is normal during the spindle serial control startup.
 - 1: The first spindle was detected to have a fault during the spindle axis serial control startup.
- **SHE 0**: The serial communications module in the CNC is normal.
 - 1: The serial communications module in the CNC was detected to have a fault.

10) System alarms

(These alarms cannot be reset with reset key.)

Number	Message	Contents
900	ROM PARITY	ROM parity error (CNC/OMM/Servo) Rewrite the flash ROM with the indicated ROM number.
910	SRAM PARITY : (BYTE 0)	RAM parity error in the tape memory SRAM module. Clear the memory or replace the module. After this operation, reset all data including the parameters.
911	SRAM PARITY: (BYTE 1)	RAM parity error in the tape memory SRAM module. Clear the memory or replace the module/mother board. After this operation, reset all data including the parameters.
912	DRAM PARITY: (BYTE 0)	RAM parity error in the DRAM module. Replace the DRAM module.
913	DRAM PARITY : (BYTE 1)	
914	DRAM PARITY : (BYTE 2)	
915	DRAM PARITY : (BYTE 3)	
916	DRAM PARITY : (BYTE 4)	
917	DRAM PARITY : (BYTE 5)	
918	DRAM PARITY : (BYTE 6)	
919	DRAM PARITY : (BYTE 7)	
920	SERVO ALARM (1 to 4 AXIS)	Servo alarm (1st to 4th axis). A watchdog alarm or a RAM parity error in the servo module occurred. Replace the servo control module on the main CPU board.
926	FSSB ALARM	FSSB alarm. Replace the servo control module on the main CPU board.
930	CPU INTERRUPUT	CPU error (abnormal interrupt) The main CPU board is faulty.
950	PMC SYSTEM ALARM	Fault occurred in the PMC. The PMC control module on the main CPU board or option board may be faulty.
951	PMC-RC WATCH DOG ALARM	Fault occurred in the PMC–RC (watchdog alarm). Option board may be faulty.
972	NMI OCCURRED IN OTHER MOD- ULE	NMI occurred in a board other than the main CPU board.
973	NON MASK INTERRUPT	NMI occurred for an unknown reason.
974	F-BUS ERROR	BUS error of FANUC BUS. The main CPU board or option boards may be faulty.
975	BUS ERROR (MAIN)	Main CPU board bus error. The main CPU board may be faulty.
976	L-BUS ERROR	BUS error of Local Bus. The main CPU board may be faulty.

11) Alarms Displayed on spindle Servo Unit

No.	Message	Alarm No.	Meaning	Description	Remedy
		"A" display	Program ROM abnormality (not installed)	Detects that control program is not started (due to program ROM not installed, etc.)	Install normal program ROM
7n01	SPN_n_: MOTOR OVERHEAT	AL-01	Motor overheat	Detects motor speed exceeding specified speed excessively.	Check load status. Cool motor then reset alarm.
7n02	SPN_n_: EX SPEED ER- ROR	AL-02	Excessive speed deviation	Detects motor speed exceeding specified speed excessively.	Check load status. Reset alarm.
7n03	SPN_n_ : FUSE ON DC LINK BLOWN	AL-03	DC link section fuse blown	Detects that fuse F4 in DC link section is blown (models 30S and 40S).	Check power transistors, and so forth. Replace fuse.
7n04	SPN_n_: INPUT FUSE/ POWER FAULT	AL-04	Input fuse blown. Input power open phase.	Detects blown fuse (F1 to F3), open phase or momentary failure of power (models 30S and 40S).	Replace fuse. Check open phase and power supply regenerative circuit operation.
7n05	SPN_n_: POWER SUP- PLY FUSE BLOWN	AL-05	Control power supply fuse blown	Detects that control power supply fuse AF2 or AF3 is blown (models 30S and 40S).	Check for control power supply short circuit . Replace fuse.
7n07	SPN_n_: OVERSPEED	AL-07	Excessive speed	Detects that motor rotation has exceeded 115% of its rated speed.	Reset alarm.
7n08	SPN_n_: HIGH VOLT IN- PUT POWER	AL-08	High input voltage	Detects that switch is flipped to 200 VAC when input voltage is 230 VAC or higher (models 30S and 40S).	Flip switch to 230 VAC.
7n09	SPN_n_: OVERHEAT MAIN CIRCUIT	AL-09	Excessive load on main circuit section	Detects abnormal temperature rise of power transistor radiator.	Cool radiator then reset alarm.
7n10	SPN_n_: LOW VOLT IN- PUT POWER	AL-10	Low input voltage	Detects drop in input power supply voltage.	Remove cause, then reset alarm.
7n11	SPN_n_: OVERVOLT POW CIRCUIT	AL-11	Overvoltage in DC link section	Detects abnormally high direct current power supply voltage in power circuit section.	Remove cause, then reset alarm.
7n12	SPN_n_ : OVERCUR- RENT POW CIRCUIT	AL-12	Overcurrent in DC link section	Detects flow of abnormally large current in direct current section of power cirtcuit	Remove cause, then reset alarm.
7n13	SPN_n_ : DATA MEMORY FAULT CPU	AL-13	CPU internal data memory abnormality	Detects abnormality in CPU internal data memory. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n15	SPN_n_: SP SWITCH CONTROL ALARM	AL-15	Spindle switch/output switch alarm	Detects incorrect switch sequence in spindle switch/out- put switch operation.	Check sequence.

No.	Message	Alarm No.	Meaning	Description	Remedy
7n16	SPN_n_: RAM FAULT	AL-16	RAM ab- normality	Detects abnormality in RAM for external data. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n18	SPN_n_: SUMCHECK ERROR PGM DATA	AL-18	Program ROM sum check er- ror	Detects program ROM data error. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n19	SPN_n_: EX OFFSET CURRENT U	AL-19	Excessive U phase current detection cir- cuit offset	Detects excessive U phase current detection ciucuit offset. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n20	SPN_n_: EX OFFSET CURRENT V	AL-20	Excessive V phase current detection cir- cuit offset	Detects excessive V phase current detection circuit offset. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n24	SPN_n_: SERIAL TRANSFER ERROR	AL-24	Serial transfer data error	Detects serial transfer data er- ror (such as NC power supply turned off, etc.)	Remove cause, then reset alarm.
7n25	SPN_n_: SERIAL TRANSFER STOP	AL-25	Serial data transfer stopped	Detects that serial data transfer has stopped.	Remove cause, then reset alarm.
7n26	SPN_n_: DISCONNECT C-VELO DE- TECT	AL-26	Disconnection of speed detection sig- nal for Cs con- touring control	Detects abnormality in position coder signal (such as unconnected cable and parameter setting error).	Remove cause, then reset alarm.
7n27	SPN_n_: DISCONNECT POS-CODER	AL-27	Position coder signal disconnection	Detects abnormality in position coder signal (such as unconnected cable and adjustment error).	Remove cause, then reset alarm.
7n28	SPN_n_: DISCONNECT C-POS DE- TECT	AL-28	Disconnection of position detection sig- nal for Cs con- touring control	Detects abnormality in position detection signal for Cs contouring control (such as unconnected cable and adjustment error).	Remove cause, then reset alarm.
7n29	SPN_n_: SHORTTIME OVERLOAD	AL-29	Short-time overload	Detects that overload has been continuously applied for some period of time (such as restraining motor shaft in positioning).	Remove cause, then reset alarm.
7n30	SPN_n_ : OVERCUR- RENT POW CIRCUIT	AL-30	Input circuit overcurrent	Detects overcurrent flowing in input circuit.	Remove cause, then reset alarm.
7n31	SPN_n_: MOTOR LOCK OR V-SIG LOS	AL-31	Speed detection signal disconnection motor restraint alarm or motor is clamped.	Detects that motor cannot rotate at specified speed or it is detected that the motor is clamped. (but rotates at very slow speed or has stopped). (This includes checking of speed detection signal cable.)	Remove cause, then reset alarm.

No.	Message	Alarm No.	Meaning	Description	Remedy
7n32	SPN_n_: RAM FAULT SERIAL LSI	AL-32	Abnormality in RAM inside the LSI used for serial data transfer. This check is made only when power is turned on.	Detects abnormality in RAM inside the LSI used for serial data transfer. This check is made only when power is turned on.	Remove cause, then reset alarm.
7n33	SPN_n_: SHORTAGE POWER CHARGE	AL-33	Insufficient DC link section charging	Detects insufficient charging of direct current power supply voltage in power circuit section when magnetic contactor in amplifier is turned on (such as open phase and defectifve charging resistor).	Remove cause, then reset alarm.
7n34	SPN_n_: PARAMETER SETTING ER- ROR	AL-34	Parameter data setting beyond allow- able range of values	Detects parameter data set beyond allowable range of values.	Set correct data.
7n35	SPN_n_: EX SETTING GEAR RATIO	AL-35	Excessive gear ratio data setting	Detects gear ratio data set beyond allowable range of values.	Set correct data.
7n36	SPN_n_: OVERFLOW ERROR COUNTER	AL-36	Error counter overflow	Detects error counter overflow.	Correct cause, then reset alarm.
7n37	SPN_n_: SPEED DE- TECT PAR. ERROR	AL-37	Speed detector parameter setting error	Detects incorrect setting of parameter for number of speed detection pulses.	Set correct data.
7n39	SPN_n_ : 1-ROT Cs SIGNAL ER- ROR	AL-39	Alarm for indicating failure in detecting 1—rotation signal for Cs contouring control	Detects 1–rotaion signal detection failure in Cs contouring contorl.	Make 1–rotaion signal adjustment. Check cable shield status.
7n40	SPN_n_: NO 1-ROT Cs SIGNAL DE- TECT	AL-40	Alarm for indicating 1–rotation signal for Cs contouring control not detected	Detects that 1-rotation signal has not occurred in Cs contouring control.	Make 1-rotaion signal adjustment.
7n41	SPN_n_: 1-ROT POS- CODER ER- ROR	AL-41	Alarm for indicating failure in detecting position coder 1–rotaion signal.	Detects failure in detecting position coder 1-rotation signal.	Make signal adjustment for signal conversion circuit. Check cable shield status.

No.	Message	Alarm No.	Meaning	Description	Remedy
7n42	SPN_n_: NO 1-ROT. POS-CODER DETECT	AL-42	Alarm for indicating position coder 1–rotation signal not detected	Detects that position coder 1-rotation signal has not issued.	Make 1–rotation signal adjustment for signal conversion circuit.
7n43	SPN_n_: DISCON. PC FOR DIF. SP. MOD.	AL-43	Alarm for indi- cating discon- nection of position coder signal for dif- ferential speed mode	Detects that main spindle position coder signal used for differential speed mode is not connected yet (or is disconnected).	Check that main spindle position coder signal is connected to connector CN12.
7n44	SPN_n_: CONTROL CIRCUIT(AD) ERROR	AL-44			
7n46	SPN_n_: SCREW 1-ROT POS- COD. ALARM	AL-46	Alarm for indicating failure in detecting position coder 1–rotation signal in thread cutting operation.	Detects failure in detecting position coder 1-rotation signasl in thread cutting operation.	Make 1–rotation signal adjustment for signal conversion circuit. Check cable shield status.
7n47	SPN_n_: POS-CODER SIGNAL AB- NORMAL	AL-47	Position coder signal ab-normality	Detects incorrect position coder signal count operation.	Make signal adjustment for signal conversion circuit. Check cable shield status.
7n49	SPN_n_: HIGH CONV. DIF. SPEED	AL-49	The converted differential speed is too high.	Detects that speed of other spindle converted to speed of local spindle has exceeded allowable limit in differential mode.	Calculate differential speed by multiplying speed of other spindle by gear ratio. Check if calculated value is not greater than maximum speed of motor.
7n50	SPN_n_: SPNDL CON- TROL OVER- SPEED	AL-50	Excessive speed com- mand calcula- tion value in spindle syn- chronization control	Detects that speed command calculation value exceeded allowable range in spindle synchronization control.	Calculate motor speed by multiplying specified spindle speed by gear ratio. Check if calculated value is not greater than maximum speed of motor.
7n51	SPN_n_: LOW VOLT DC LINK	AL-51	Undervoltage at DC link sec- tion	Detects that DC power supply voltage of power circuit has dropped (due to momentary power failure or loose contact of magnetic contactor).	Remove cause, then reset alarm.
7n52	SPN_n_: ITP SIGNAL ABNORMAL I	AL-52	ITP signal ab- normality I	Detects abnormality in synchronization signal (ITP signal) used in software.	Replace servo amp. PCB.
7n53	SPN_n_: ITP SIGNAL ABNORMAL II	AL-53	ITP signal ab- normality II	Detects abnormality in synchronization signal (ITP signal) used in hardware.	Replace servo amp. PCB.

No.	Message	Alarm No.	Meaning	Description	Remedy
7n56	SPN_n_: INNER COOL- ING FAN STOP	AL-56	The cooling fan in the unit stopped.	The cooling fan in the control circuit section stopped.	Check the turning state of the cooling fan. Replace the cooling fan.
7n57	SPN_n_: EX DECEL- ERATION POWER	AL-57	Deceleration power is too high.	Abnormal current flowed through the regenerative resistor.	Check the selection of the regenerative resistor. Alternatively, check whether the cooling fan motor is rotating.
7n58	SPN_n_: OVERLOAD IN PSM	AL-58	Overload on the PSM main circuit	The temperature of the radiator of the main circuit has increased abnormally. (Cooling fan failure, dirt in the cooling fan, overload operation, etc.)	Eliminate the cause, then reset the alarm.
7n59	SPN_n_ : COOLING FAN STOP IN PSM	AL-59	The PSM cooling fan stopped.	The cooling fan of the control circuit section stopped.	Check the turning state of the cooling fan. Replace the cooling fan.



OPERATION OF PORTABLE TAPE READER

Portable tape reader is the device which inputs the NC program and the data on the paper tape to CNC.

Names and descriptions of each section




Table 1 Description of Each Section

No.	Name	Descriptions		
1	Light Sources	An LED (Light emitting diode) is mounted for each channel and for the feed hole (9 diodes in total). A built–in Stop Shoe functions to decelerate the tape. The light source is attracted to the optical reader by a magnet so that the tape will be held in the correct position. This unit can be opened upward, by turning the tape reader control switch to the RELEASE position (this turns off the magnet).		
2	Optical Reader	Reads data punched on the tape, through a glass window. Dust or scratches on the glass window can result in reading errors. Keep this window clean.		
3	Capstan Roller	Controls the feeding of tape as specified by the control unit.		
4	Tape Reader Control Switch	A 3-position switch used to control the Tape Reader. RELEASE The tape is allowed to be free, or used to open the lightsource. When loading or unloading the tape, select this position. AUTO The tape is set to fixed position by the Stop Shoe. The feed and stop of the tape is controlled by the CNC. To input data from tape, the Light Source must be closed and this position must be selected. MANUAL The tape can be fed in the forward reading direction. if another position is selected, the tape feed is stopped.		
5	Tape Box	A Tape Box is located below the Tape Reader. A belt used to draw out a paper tape is located inside the box. The paper tape can easily be pulled out using this belt. The tape box accomodates 15 meters of tape.		
6	Handle	Used to carry the tape reader.		

No.	Name	Descriptions			
7	Winder	Used to advance or rewind the tape.			
8	Metal A	Fastener (usually kept open) Push Paper tape Paper tape			
		When removing the rolled tape, reduce the internal diameter by pushing the fastener.			
9	Cover lock	Be sure to use the lock for fastening the cover before carrying the tape reader.			
10	Lowering lock lever	When the tape reader is raised, the latch mechanism is activated to fix the tape reader. Thus, the tape reader is not lowered. The latch is locked with the lowering lock lever. The latch is therefore not unlocked even when the tape reader is raised with the handle. When the latch is locked, the lever is horizontal. To store the tape reader in the box, push the lever to release the lock, then raise the tape reader with the handle to unlock the latch.			
		When the latch is unlocked, the tape reader can be stored in the box.			
		When storing the tape reader, secure it with the cover lock.			
11	Cable storage	Used to store rolled power and signal cables. The cable length is 1.5 m.			
12	Photoamplifier	For the tape reader			
13	Reader/punch interface adapter	200 VAC input and 5 VDC output power and reader/punch interface adapter PCB			

Procedure for Operating the Portable Tape Reader


Preparations

- 1 Unlock the cover locks 9. Raise the tape reader with the handle 6 until it clicks, then lower the tape reader. The tape reader then appears and is secured. Check that the lowering lock levers 10 are horizontal.
- 2 Take out the signal and power cables from the cable storage 11 and connect the signal cable with the CNC reader/punch interface port and the power cable with the power supply.

Setting the tape

3 Turn the control switch to the RELEASE position.

4 Lift the Light Source Unit, and insert an NC tape between the gap. The tape must be positioned as shown in the figure, when viewed looking downward.



- 5 Pull the tape until the top of the tape goes past the Capstan roller.
- **6** Check that the NC tape is correctly positioned by the Tape Guide.
- 7 Lower the Light Source.
- **8** Turn the switch to the AUTO position.
- **9** Suspend the top and rear—end of the tape in the Tape Box.

Removing the tape

- **10** Turn the switch to the RELEASE position.
- 11 Lift the Light Source and remove the tape.
- 12 Lower the Light Source


Storage

- 13 Store the cables in the cable storage 11.
- 14 Push the lowering lock lever 10 at both sides down.
- 15 Raise the tape reader with the handle 6 to unlock the latch, then gently lower it.
- 16 Lock the cover lock 9 and carry the tape reader with the handle 6.

CAUTION

1 SETTING OF A TAPE

When the NC tape is loaded, the Label Skip function activates to read but skip data until first End of Block code (CR in EIA code or LF in ISO code) is read. When loading an NC tape, the location within the tape, from which data reading should be started must properly be selected and the NC tape should be set as shown in the figure below.



CAUTION

2 DISCONNECTION AND CONNECTION OF A PORTABLE TAPE READER CONNECTION CABLE

Don't disconnect or connect CNC tape reader connection cable (signal cable) without turning off the CNC power supply, otherwise the PCB of the tape reader and master PCB of CNC controller may be broken. Turn off the CNC power supply before disconnecting or connecting the connection cable, accordingly.

B-63094EN/01 Index

≪A≫

Absolute and incremental programming (G90, G91), 90

Actual feedrate display, 604

Adding workpiece coordinate systems (G54.1 or G54), 84

Alarm and self-diagnosis functions, 481

Alarm display, 380, 482

Alarm history display, 484

Alarm list, 716

Altering a word, 560

Arithmetic and logic operation, 296

Automatic corner override, 65

Automatic erase screen display, 661

Automatic insertion of sequence numbers, 585

Automatic operation, 371, 434

Automatic override for inner corners (G62), 65

Automatic tool length measurement (G37), 193

Auxiliary function, 112

Auxiliary function (M function), 113

Axis control functions, 360

Axis name, 29

≪B≫

Background editing, 580

Battery for separate absolute pulse coders, 690

Boring cycle, 154

Boring cycle (G86), 156

Boring cycle (G88), 160

Boring cycle (G89), 162

Boring cycle back boring cycle (G87), 158

Branch and repetition, 302

≪ **C**≫

Canned cycle, 132

Canned cycle cancel, 164

Canned cycle cancel (G80), 176

Changing workpiece coordinate system, 79

Character-to-codes correspondence table, 715

Characters and codes to be used for the pattern data input function 347

Check by running the machine, 373

Checking by self-diagnostic screen, 485

Circular interpolation (G02, G03), 43

Clearing the screen, 660

CNC Control Unit with 7.2"/8.4" LCD, 385

CNC Control Unit with 9.5"/10.4" LCD, 385

Command for machine operations-miscellaneous function, 22

Compensation function, 184

Conditional branch (IF statement), 303

Constant surface speed control (G96, G97), 98

Controlled axes, 28, 29

Coordinate system, 75

Coordinate system on part drawing and coordinate system specified by CNC – Coordinate system, 16

specified by CNC – Coordinate system, 16

Coordinate system rotation (G68, G69), 270

Coordinate value and dimension, 89

Copying ann entire program, 571

Copying part of a program, 572

Corner Circular Interpolation (G39), 261

Creating programs, 583

Creating programs in teach in mode (Playback), 587

Creating programs using the MDI panel, 584

Current block display screen, 611

Current position display, 380

Custom macro, 283

Cutting feed, 60

Cutting feedrate control, 63

Cutting mode (G64), 64

Cutting speed-spindle speed function, 20

Cylindrical interpolation (G07.1), 48

≪D≫

Data input/output, 382, 488

Data input/output on the all IO screen, 516

Data input/output using a memory card, 542

Decimal point programming, 95

Deleting a block, 562

Deleting a word, 561

Deleting all programs, 568

Deleting blocks, 562

Deleting files, 513

Deleting more than one program by specifying a range, 569

Deleting multiple blocks, 563

Deleting one program, 568

Deleting programs, 568

Details of cutter compensation C, 208

Details of functions, 330

Direct input of measured workpiece origin offsets, 635

Display, 379

Display of run time and parts count, 606

Displaying a program list for a specified group, 619

Displaying and entering setting data, 628

Displaying and setting custom macro common variables, 637

Displaying and setting data, 376

Displaying and setting extended tool life management, 645

Displaying and setting parameters, 651

Displaying and setting pitch error compensation data, 653

Displaying and setting run time, parts count, and time, 632

INDEX B-63094EN/01

Displaying and setting the software operator's panel, 640

Displaying and setting the workpiece origin offset value, 634

Displaying and setting tool life management data, 642

Displaying directory of floppy cassette, 507

Displaying memory used and a list of programs, 616

Displaying pattern data and pattern menu, 638

Displaying the directory, 508

Displaying the pattern menu, 339

Displaying the program number and sequence number, 655

Displaying the program number, sequence number, and status, and warning messages for data setting or input/output operation, 655

Displaying the status and warning for data setting or input/output operation, 656

DNC operation, 442

Drilling cycle counter boring cycle, 144

Drilling cycle, spot drilling (G81), 142

Dry run, 471

Dwell (G04), 69

Dynamic graphic display, 669

≪**E**≫

Editing a part program, 375

Editing of custom macros, 579

Editing programs, 554

Emergency stop, 475

Erase screen display, 660

Exact stop (G09, G61), 64

Extended part program editing function, 570

External I/O devices, 413

External motion function (G81), 180

External operator message history display, 658

External output commands, 324



FANUC FA card, 416

FANUC floppy cassette, 415

FANUC handy file, 415

FANUC PPR, 416

Feed functions, 56

Feed-feed function, 14

Feedrate clamping by arc radius, 353

Feedrate override, 469

File deletion, 493

File search, 491

Files, 489

Fine boring cycle (G76), 140

Function keys, 393

Function keys and soft keys, 392

Functions to simplify programming, 131



G53, G28, G30, G30.1 and G29 commands in cutter compensation C mode, 242

General flow of operation of CNC machine tool, 5

General screen operations, 392

Graphic display, 381

Graphics display, 663

Graphics function, 662



Heading a program, 558

Helical interpolation (G02, G03), 47

Help function, 678

High speed cutting functions, 352

High speed skip signal (G31), 55

High-speed peck drilling cycle (G73), 136

High-speed remote buffer, 356

High-speed remote buffer A (G05), 356

High-speed remote buffer B (G05), 359

How to indicate command dimensions for moving the tool – absolute, incremental commands, 19

How to use nomograph, 706

How to view the position display change without running the machine, 374



Inch/metric conversion (G20,G21), 94

Incorrect threaded length, 705

Increment system, 30

Incremental feed, 426

Index table indexing function, 181

Input command from MDI, 241

Inputting a program, 494

Inputting and outputting floppy files, 528

Inputting and outputting offset data, 525

Inputting and outputting parameters, 523

Inputting and outputting parameters and pitch error compensation data, 501

Inputting and outputting programs, 518

Inputting custom macro common variables, 505

Inputting offset data, 499

Inputting parameters, 501

Inputting pitch error compensation data, 503

Inputting/outputting custom macro common variables, 505

Inserting a word, 559

Inserting, altering and deleting a word, 555

B-63094EN/01 INDEX

Interference check, 233

Internal circular cutting feedrate change, 68

Interpolation functions, 36

Interruption type custom macro, 328



Jog feed, 424



Key input a input buffer, 410

≪L>

Left-handed rigid tapping cycle (G74), 171

Left-handed tapping cycle (G74), 138

Linear interpolation, 41

List of function and tape format, 696

Local coordinate system, 86

Look-ahead control (G08), 354

≪M≫

Machine coordinate system, 76

Machine lock and auxiliary function lock, 467

Macro call, 307

Macro call using an M code, 315

Macro call using G code, 314

Macro statements and NC statements, 301

Manual absolute on and off, 429

Manual handle feed, 427

Manual handle interruption, 459

Manual intervention and return, 464

Manual operation, 368, 421

Manual reference position return, 422

Maximum stroke, 30

MDI operation, 438

Memory card input/output, 533

Memory operation, 435

Memory operation using FS10/11 tape format, 351

Merging a program, 574

Method of replacing battery, 685

Mirror image, 462

Modal call (G66), 312

Moving part of a program, 573

Multiple M commands in a single block, 114



Next block display screen, 612

Nomographs, 704

Normal direction control (G40.1, G41.1, G42.1 or G150, G151, G152), 276

Note on reading this manual, 7



Offset data input and output, 499

Operating motor display, 607

Operation of portable tape reader, 738

Operational devices, 383

Optional angle chamfering and corner rounding, 177

Outputting a program, 497

Outputting a program list for a specified group, 515

Outputting custom macro common variable, 506

Outputting custom macro common variables, 527

Outputting offset data, 500

Outputting parameters, 502

Outputting pitch error compensation data, 504

Outputting programs, 512

Overall position display, 601

Overcutting by cutter compensation, 238

Overtravel, 476

Overview of cutter compensation C (G40 – G42), 202



Part drawing and tool movement, 15

Parts count display, run time display, 381

Password function, 581

Path drawing, 669

Pattern data display, 343

Pattern data input function, 338

Peck drilling cycle (G83), 146

Peek rigid tapping cycle (G84 or G74), 174

Plane selection, 88

Polar coordinate command (G15, G16), 91

Portable tape reader, 417

Position display in the relative coordinate system, 599

Position display in the work coordinate system, 598

Positioning (G00), 37

Power disconnection, 420

Power on/off, 418

Preparatory function (G function), 31

Presetting the workpiece coordinate system, 603

Processing macro statements, 320

Program check screen, 613

Program components other than program sections, 118

INDEX

B-63094EN/01

Program configuration, 23, 116

Program contents display, 610

Program display, 379

Program input/output, 494

Program number search, 565

Program restart, 445

Program screen for MDI operation, 615

Program section configuration, 121

Programmable mirror image (G50.1, G51.1), 281

Programmable parameter entry (G10), 349

≪**R**≫

Radius direction error at circle cutting, 712

Range of command value, 701

Rapid traverse, 59

Rapid traverse override, 470

Reading files, 511

Reference position, 70

Reference position (machine-specific position), 15

Reference position return, 71

Register, change and delete of tool life management data, 105

Registering custom macro programs, 322

Repetition (while statement), 304

Replacement of words and addresses, 577

Replacing the alkaline dry cells (Size D), 688

Rigid tapping, 167

Rigid tapping (G84), 168

Rotary axis roll-over, 364

≪**S**≫

Safety functions, 474

Scaling (G50, G51), 265

Scheduling function, 452

MDI mode), 609

616

Screen displayed at power-on, 419

Screens displayed by function key

Screens displayed by function key

ey offset setting, 622

Screens displayed by function key

POS, 597

Screens displayed by function key PROG

PROG (in the edit mode),

(In memory mode or

Screens displayed by function key

, 658

Screens displayed by function key

Selecting a workpiece coordinate system, 78

Selection of tool used for various machining-tool function, 21

Separate-type small MDI unit, 386

Separate-type standard MDI unit (Horizontal type), 387

Separate-type standard MDI unit (Vertical type), 388

Separate-type standard MDI unit (Vertical type) (for 210i), 389

Sequence number comparison and stop, 630

Sequence number search, 566

Setting a workpiece, 77

Setting and display units, 384

Setting and displaying data, 590

Setting and displaying the tool offset value, 623

Setting input/output-related parameters, 517

Simple calculation of incorrect thread length, 707

Simple call (G65), 308

Simple synchronous control, 361

Single block, 472

Single direction positioning (G60), 39

Skip function (G31), 53

Soft key configuration, 412

Soft keys, 394

Specification method, 329

Specifying the spindle speed value directly (S5–digit command), 97

Specifying the spindle speed with a code, 97

Spindle speed function (S function), 96

Status when turning power on, when clear and when reset, 713

Stroke check, 477

Subprogram (M98, M99), 127

Subprogram call function (M198), 457

Subprogram call using an M code, 316

Subprogram calls using a T code, 317

Supplementary explanation for copying, moving and merging, 575

System variables, 288



Tape code list, 693

Tapping cycle, 152

Tapping mode (G63), 64

Test operation, 466

Testing a program, 373

The second auxiliary functions (B codes), 115

Thread cutting (G33), 51

Tool compensation values, number of compensation values, and entering values from the program (G10), 263

Tool figure and tool motion by program, 26

Tool function (T function), 101

Tool length measurement, 626

Tool length offset (G43,G44,G49), 185

Tool life, 111

B-63094EN/01 INDEX

Tool life management, 104

Tool life management command in a machining program, 108

Tool life management function, 103

Tool movement along workpiece pars figure-interpolation, 12

Tool movement by programming – automatic operation, 370

Tool movement in offset mode, 213

Tool movement in offset mode cancel, 227

Tool movement in start-up, 209

Tool movement range-stroke, 27

Tool offset (G45-G48), 197

Tool path at corner, 709

Tool selection function, 102

Turning on the power, 418



Unconditional branch (GOTO statement), 302 Use of alkaline dry cells (Size D), 689



Variables, 284



Warning messages, 411

Word search, 556

Workpiece coordinate system, 77

Revision Record

FANUC Series 21i/210i-MA OPERATOR'S MANUAL (B-63094EN)

			Contents
			Date
			Edition
			Contents
		Apr., '97	Date
		01	Edition

- No part of this manual may be reproduced in any form.
- · All specifications and designs are subject to change without notice.